

IGNITION SYSTEMS

CONTENTS

	page		page
2.2L TBI, 2.5L TBI, TURBO I AND 3.0L IGNITION SYSTEMS—DIAGNOSTIC PROCEDURES	11	IGNITION SWITCH	48
2.2L TBI, 2.5L TBI, TURBO I AND 3.0L IGNITION SYSTEMS—SERVICE PROCEDURES	14	SPECIFICATIONS	50
2.2L TBI, 2.5L TBI, TURBO I AND 3.0L IGNITION SYSTEMS—SYSTEM OPERATION	1	TURBO III, 3.3L AND 3.8L IGNITION SYSTEM —DIAGNOSTIC PROCEDURES	37
		TURBO III, 3.3L AND 3.8L IGNITION SYSTEM —SYSTEM OPERATION	26
		TURBO III, 3.3L AND 3.8L IGNITION SYSTEMS—SERVICE PROCEDURES	41

GENERAL INFORMATION

Throughout this group, references are made to particular vehicles by letter designation. A chart explaining the designations appears in the Introduction Section of this manual.

2.2L TBI, 2.5L TBI, TURBO I AND 3.0L IGNITION SYSTEMS— SYSTEM OPERATION

INDEX

	page		page
Auto Shutdown (ASD) Relay and Fuel Pump Relay	9	Distributor Pick-Up—3.0L Engine	7
Coolant Temperature Sensor	7	Engine Controller	6
Detonation Sensor (Knock Sensor)—Turbo I Engine	8	General Information	1
Distributor (Hall Effect) Pick-Up—Engine Controller Input	6	Ignition Coil	9
Distributor Cap	1	Manifold Absolute Pressure (MAP) Sensor	8
		Rotor	2
		Spark Plug Cables	2
		Spark Plugs	3

GENERAL INFORMATION

This section describes the ignition systems of the 2.2L TBI, 2.5L TBI, Turbo I and 3.0L engines.


The Fuel Injection sections of Group 14 explain On Board Diagnostics.

Group 0, Lubrication and Maintenance, contains general maintenance information for ignition related items. The Owner's Manual also contains maintenance information.

DISTRIBUTOR CAP

Remove the distributor cap and inspect the inside for flashover, cracking of carbon button, lack of spring tension on carbon button, cracking of cap, and burned, worn terminals (Fig. 1). Also check for broken distributor cap towers. If any of these conditions are present the distributor cap and/or cables should be replaced.

When replacing the distributor cap, transfer cables from the original cap to the new cap one at a time.



918D-24

Fig. 1 Distributor Cap Inspection

Ensure each cable is installed into the corresponding tower of the new cap. Fully seat the wires into the towers. If necessary, refer to the appropriate engine

firing order diagram (Fig. 2 or Fig. 3).

Light scaling of the terminals can be cleaned with a sharp knife. If the terminals are heavily scaled, replace the distributor cap.

A cap that is greasy, dirty or has a powder-like substance on the inside should be cleaned with a solution of warm water and a mild detergent. Scrub the cap with a soft brush. Thoroughly rinse the cap and dry it with a clean soft cloth.




Fig. 2 Engine Firing Order—2.2L TBI, 2.5L TBI, Turbo I and Turbo III Engines




Fig. 3 Engine Firing Order—3.0L Engine


ROTOR

Replace the rotor if it is cracked, the tip is excessively burned or heavily scaled (Fig. 4). If the spring terminal does not have adequate tension, replace the rotor.

SPARK PLUG CABLES

Spark Plug cables are sometimes referred to as secondary ignition wires. They transfer electrical current from the distributor to individual spark plugs at each cylinder. 2.2L TBI, 2.5L TBI, Turbo I, Turbo III and 3.0L engines use resistance type cables. The cables suppress radio frequency emissions from the ignition system.

Check the spark plug cable connections for good contact at the coil and distributor cap towers and at the spark plugs. Terminals should be fully seated.



J908D-48

Fig. 4 Rotor Inspection—Typical

The nipples and spark plug covers should be in good condition. Nipples should fit tightly on the coil and distributor cap towers and spark plug cover should fit tight around spark plug insulators. Loose cable connections can cause ignition malfunctions by permitting water to enter the towers, corroding, and increasing resistance. **To maintain proper sealing at the terminal connections, the connections should not be broken unless testing indicates high resistance, an open circuit or other damage.**

CAUTION: Do not pull spark plug cables from distributor cap of four cylinder engines. The cables must be released from inside the distributor cap (Fig. 5).




Fig. 5 Spark Plug Cable Removal/Installation—2.2L and 2.5L TBI Engines

Clean high tension cables with a cloth moistened with a non-flammable solvent and wipe dry. Check for brittle or cracked insulation.

When testing secondary cables for punctures and cracks with an oscilloscope follow the equipment manufacturers instructions.

If an oscilloscope is not available, secondary cables can be tested as follows:

CAUTION: Do not leave any one spark plug cable disconnected any longer than necessary during testing. Excessive heat could damage the catalytic converter. Total test time must not exceed ten minutes.

(a) With the engine not running, connect one end of a test probe to a good ground. Use a probe made of insulated wire with insulated alligator clips on each end.

(b) With engine running, move test probe along entire length of all cables (approximately 0 to 1/8 inch gap). If punctures or cracks are present there will be a noticeable spark jump from the faulty area to the probe. Check the coil cable the same way. Replace cracked, leaking or faulty cables.

When replacing cables, install the new high tension cable and nipple assembly over cap or coil tower. When entering the terminal into the tower, push lightly, then pinch the large diameter of nipple to release air trapped between the nipple and tower. Continue pushing on the cable and nipple until cables are properly seated in the cap towers. A snap should be heard as terminal goes into place.

Use the same procedure to install cable in coil tower. Wipe the spark plug insulator clean before reinstalling cable and cover.

Use the following procedure when removing the high tension cable from the spark plug. First, remove the cable from the retaining bracket. Then grasp the terminal as close as possible to the spark plug. Rotate the cover and pull the cable straight back. **Pulling on the cable itself will damage the conductor and terminal connection. Do not use pliers and do not pull the cable at an angle. Doing so will damage the insulation, cable terminal or the spark plug insulator. Wipe spark plug insulator clean before reinstalling cable and cover.**

Resistance type cable is identified by the words **Electronic Suppression** printed on the cable jacket.

Use an ohmmeter to check resistance type cable for open circuits, loose terminals or high resistance as follows:

(a) Remove cable from spark plug.

(b) Lift distributor cap from distributor with cables intact. **Do not remove cables from cap.** The cables must be removed from the spark plugs.

(c) Connect the ohmmeter between spark plug end terminal and the corresponding electrode inside the cap, make sure ohmmeter probes are in good contact. Resistance should be within tolerance shown in the cable resistance chart. If resistance is not within tolerance, remove cable at cap tower and check the cable. If resistance is still not within tolerance, replace cable assembly. Test all spark plug cables in same manner.

CABLE RESISTANCE CHART

MINIMUM	MAXIMUM
250 Ohms Per Inch	1000 Ohms Per Inch
3000 Ohms Per Foot	12,000 Ohms Per Foot

J908D-43

To test coil to distributor cap high tension cable, remove distributor cap with the cable intact. **Do not remove cable from the cap.** Connect the ohmmeter between center contact in the cap and remove the cable at coil tower and check cable resistance. If resistance is not within tolerance, replace the cable.

SPARK PLUGS

Resistor spark plugs are used in all engines and have resistance values of 6,000 to 20,000 ohms when checked with at least a 1000 volt tester.

Remove the spark plugs and examine them for burned electrodes and fouled, cracked or broken porcelain insulators. Keep plugs arranged in the order in which they were removed from the engine. An isolated plug displaying an abnormal condition indicates that a problem exists in the corresponding cylinder. Replace spark plugs at the intervals recommended in Group O.


Undamaged low mileage spark plugs can be cleaned and reused. Refer to the Spark Plug Condition section of this group. After cleaning, file the center electrode flat with a small point file or jewelers file. Adjust the gap between the electrodes (Fig. 6) to the dimensions specified in the chart at the end of this section.

Always tighten spark plugs to the specified torque. Over tightening can cause distortion and change spark plug gap. Tighten 2.5L and 3.0L engine spark plugs to 28 N•m (20 ft. lbs.) torque.

SPARK PLUG CONDITION

NORMAL OPERATING CONDITIONS


The few deposits present will be probably light tan or slightly gray in color with most grades of commercial gasoline (Fig. 7). There will not be evidence of electrode burning. Gap growth will not average more than approximately 0.025 mm (.001 in) per 1600 km (1000 miles) of operation. Spark plugs that have nor-



J908D-10

Fig. 6 Setting Spark Plug Electrode Gap—Typical

mal wear can usually be cleaned, have the electrodes filed and regapped, and then reinstalled.



J908D-15

Fig. 7 Normal Operation and Cold (Carbon) Fouling

Some fuel refiners in several areas of the United States have introduced a manganese additive (MMT) for unleaded fuel. During combustion, fuel with MMT coats the entire tip of the spark plug with a rust color deposit. The rust color deposits could be misdiagnosed as being caused by coolant in the combustion chamber. MMT deposits do not affect spark plug performance.

COLD FOULING (CARBON FOULING)

Cold fouling is sometimes referred to as carbon fouling. The deposits that cause cold fouling are basically carbon (Fig. 7). A dry, black deposit on one or two plugs in a set may be caused by sticking valves or

defective spark plug cables. Cold (carbon) fouling of the entire set may be caused by a clogged air cleaner.


Cold fouling is normal after short operating periods. The spark plugs do not reach a high enough operating temperature during short operating periods.

WET FOULING

A spark plug that is coated with excessive wet fuel or oil is wet fouled. In older engines, wet fouling can be caused by worn rings or excessive cylinder wear. **Break-in fouling of new engines may occur before normal oil control is achieved. In new or recently overhauled engines, wet fouled spark plugs can be usually be cleaned and reinstalled.**

OIL OR ASH ENCRUSTED

If one or more plugs are oil or oil ash encrusted, engine oil is entering the combustion chambers (Fig. 8). Evaluate the engine to determine the cause.



PR1673

Fig. 8 Oil or Ash Encrusted


HIGH SPEED MISS

When replacing spark plugs because of a high speed miss condition; **wide open throttle operation should be avoided for approximately 80 km (50 miles) after installation of new plugs.** This will allow deposit shifting in the combustion chamber to take place gradually and avoid plug destroying splash fouling shortly after the plug change.

ELECTRODE GAP BRIDGING

Loose deposits in the combustion chamber can cause electrode gap bridging. The deposits accumulate on the spark plugs during continuous stop-and-go driving. When the engine is suddenly

subjected to a high torque load, the deposits partially liquefy and bridge the gap between the electrodes (Fig. 9). This short circuits the electrodes. Spark plugs with electrode gap bridging can be cleaned using standard procedures.




J908D-11

Fig. 9 Electrode Gap Bridging

SCAVENGER DEPOSITS

Fuel scavenger deposits may be either white or yellow (Fig. 10). They may appear to be harmful, but are a normal condition caused by chemical additives in certain fuels. These additives are designed to change the chemical nature of deposits and decrease spark plug misfire tendencies. Accumulation on the ground electrode and shell area may be heavy but the deposits are easily removed. Spark plugs with scavenger deposits can be considered normal in condition and be cleaned using standard procedures.




J908D-12

Fig. 10 Scavenger Deposits

CHIPPED ELECTRODE INSULATOR

A chipped electrode insulator usually results from bending the center electrode while adjusting the spark plug electrode gap. Under certain conditions, severe detonation also can separate the insulator

from the center electrode (Fig. 11). Replace spark plugs with chipped electrode insulators.




J908D-13

Fig. 11 Chipped Electrode Insulator

PREIGNITION DAMAGE

Excessive combustion chamber temperature can cause preignition damage. The center electrode dissolves first and the ground electrode dissolves somewhat later (Fig. 12). Insulators appear relatively deposit free. Determine if the spark plug has the correct heat range rating for the engine, if ignition timing is over advanced or if other operating conditions are causing engine overheating. The heat range rating refers to the operating temperature of a particular type spark plug. Spark plugs are designed to operate within specific temperature ranges depending upon the thickness and length of the center electrode and porcelain insulator.



J908D-14

Fig. 12 Preignition Damage

SPARK PLUG OVERHEATING

Overheating is indicated by a white or gray center electrode insulator that also appears blistered (Fig. 13). The increase in electrode gap will be considerably in excess of 0.001 in per 1000 miles of operation. This suggests that a plug with a cooler heat range

rating should be used. Over advanced ignition timing, detonation and cooling system malfunctions also can cause spark plug overheating.

BLISTERED
WHITE OR
GRAY
COLORED
INSULATOR



J908D-16

Fig. 13 Spark Plug Overheating

SPARK PLUG SERVICE

When replacing the spark plug and coil cables, route the cables correctly and secure them in the appropriate retainers. Failure to route the cables properly can cause the radio to reproduce ignition noise, cross ignition of the spark plugs or short circuit the cables to ground.

SPARK PLUG REMOVAL

Always remove the spark plug cable by grasping at the spark plug boot turning, the boot 1/2 turn and pulling straight back in a steady motion.

(1) Prior to removing the spark plug spray compressed air around the spark plug hole and the area around the spark plug.

(2) Remove the spark plug using a quality socket with a rubber or foam insert.

(3) Inspect the spark plug condition. Refer to Spark Plug Condition in this section.

SPARK PLUG GAP ADJUSTMENT

(1) Check the spark plug gap with a gap gauge. If the gap is not correct, adjust it by bending the ground electrode (Fig. 6).

SPARK PLUG INSTALLATION

(1) To avoid cross threading, start the spark plug into the cylinder head by hand.

(2) Tighten spark plugs to 28 N•m (20 ft. lbs.) torque.

(3) Install spark plug cables over spark plugs.

ENGINE CONTROLLER


The ignition system is regulated by the Single board Engine Controller II (SBEC II), **referred to in this manual as the Engine Controller (Fig. 14).** The controller supplies battery voltage to the ignition

coil through the Auto Shutdown (ASD) Relay. The controller also controls the ground circuit for the ignition coil. By switching the ground path for the coil on and off, the engine controller adjusts ignition timing to meet changing engine operating conditions.

During the crank-start period the controller advances ignition timing a set amount. During engine operation, the amount of spark advance provided by the engine controller is determined by these input factors:

- coolant temperature
- detonation sensor (Turbo I only)
- engine RPM
- available manifold vacuum

The engine controller also regulates the fuel injection system. Refer to the Fuel Injection sections of Group 14.



918D-48

Fig. 14 Engine Controller

DISTRIBUTOR (HALL EFFECT) PICK-UP—ENGINE CONTROLLER INPUT

The engine speed is supplied to the engine controller by the distributor pick-up. The distributor pick-up is a Hall Effect device (Fig. 15 or Fig. 16).

A shutter (sometimes referred to as an interrupter) is attached to the distributor shaft. The shutter contains four blades, one per engine cylinder. A switch plate is mounted to the distributor housing above the shutter. The switch plate contains the distributor pick-up (a Hall Effect device and magnet) through which the shutter blades rotate. As the shutter blades pass through the pick-up, they interrupt the magnetic field. The Hall effect device in the pick-up senses the change in the magnetic field and switches on and off (which creates pulses), generating the input signal to the engine controller. The engine controller calculates engine speed through the number of pulses generated.

On Turbo I engines, one of the shutter blades has a window cut into it. The controller determines injector synchronization from the window. Also, the controller uses the input for detonation control.




Fig. 15 Hall Effect Distributor—2.2L and 2.5L TBI Engines

DISTRIBUTOR PICK-UP—3.0L ENGINE

The distributor pick-up provides two inputs to the engine controller. From one input the engine controller determines RPM (engine speed). From the other input it derives crankshaft position. The engine controller regulates injector synchronization and adjusts ignition timing and engine speed based on these inputs.

The distributor pick-up contains two signal generators. The pick-up unit consists of 2 light emitting diodes (LED), 2 photo diodes, and a separate timing disk. The timing disk contains two sets of slots. Each set of slots rotates between a light emitting diode and a photo diode (Fig. 17). The inner set contains 6 large slots, one for each cylinder. The outer set contains several smaller slots.

The outer set of slots on the rotating disk represents 2 degrees of crankshaft rotation. Up to 1200 engine RPM, the controller uses the input from the outer set of slots to increase ignition timing accuracy.

The outer set of slots contains a 10 degree flat spot. This area is not slotted (Fig. 17). The flat spot tells




Fig. 17 Distributor Pick-up—3.0L Engine

the engine controller that the next piston at TDC will be number 6. Each piston's position is referenced by one of the six inner slots (Fig. 18).

As each slot on the timing disk passes between the diodes, they interrupt the beam from the light emitting diode. This creates an alternating voltage in each photo diode which is converted into on-off pulses. The pulses are the input to the engine controller.

During cranking, the engine controller cannot determine which cylinder will be at TDC until the 10 degree flat spot on the outer set of slots rotates through the optical unit. Once the flat spot is detected, the controller knows piston number 6 will be the next piston at TDC.

Since the disk rotates at half crankshaft speed, it may take up to 2 engine revolutions during cranking before the engine controller determines the position of piston number 6. For this reason the engine controller energizes all six injectors at the same time until it senses the position of piston number 6.

COOLANT TEMPERATURE SENSOR

On 2.2L TBI, 2.5L TBI and Turbo I engines, the coolant temperature sensor is installed behind the thermostat housing and ignition coil in the hot box (Fig. 19). On 3.0L engines the sensor is located next to the thermostat housing (Fig. 20). The sensor provides an input voltage to the engine controller. The sensor is a variable resistance (thermistor) with a range of -40°F to 265°F. As coolant temperature varies, the sensors resistance changes, resulting in a different input voltage to the engine controller.

The engine controller contains different spark advance schedules for cold and warm engine operation. The schedules reduce engine emissions and improve driveability. Because spark advance changes at dif-




Fig. 16 Hall Effect Distributor—Turbo I Engines




Fig. 18 Inner and Outer Slots of Rotating Disk—3.0L Engine

ferent engine operating temperatures during warm-up, all spark advance testing should be done with the engine fully warmed.

The controller demands slightly richer air-fuel mixtures and higher idle speeds until the engine reaches normal operating temperature.

The coolant sensor input is also used for radiator fan control.




Fig. 19 Coolant Temperature Sensor—2.2L TBI, 2.5L TBI and Turbo I Engines

DETONATION SENSOR (KNOCK SENSOR)—TURBO I ENGINE

Turbo I engines use a detonation sensor. The sensor generates a signal when spark knock occurs in the combustion chambers. The sensor is mounted on the intake manifold (Fig. 21). The sensor provides infor-




Fig. 20 Coolant Temperature Sensor—3.0L Engines

mation used by the engine controller to modify spark advance and boost schedules in order to eliminate detonation.




Fig. 21 Detonation Sensor

MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR

The MAP sensor reacts to absolute pressure in the intake manifold and provides an input voltage to the engine controller. As engine load changes, manifold pressure varies. The changes in engine load causes the MAP sensors output voltage to change. The change in MAP sensor output voltage results in a different input voltage to the engine controller.

The input voltage level supplies the engine controller with information relating to ambient barometric pressure during engine start-up (cranking) and engine load while its operating. The engine controller uses this input along with inputs from other sensors to adjust air-fuel mixture.

On 2.2L TBI, 2.5L TBI and Turbo I engines, the MAP sensor is mounted to the dash panel (Fig. 22 or Fig. 23). On 3.0L engines, the sensor is mounted to a bracket across from the distributor (Fig. 24). The

sensor is connected to the throttle body or intake manifold with a vacuum hose and to the engine controller electrically.




Fig. 22 MAP Sensor—2.2L and 2.5L TBI Engines




Fig. 23 MAP Sensor—Turbo I Engines




Fig. 24 MAP Sensor—3.0L Engine

AUTO SHUTDOWN (ASD) RELAY AND FUEL PUMP RELAY

The engine controller operates the auto shutdown (ASD) relay and fuel pump relay through one ground path. The controller operates the relays by switching the ground path on and off. Both relays turn on and off at the same time.

The ASD relay connects battery voltage to the fuel injector and ignition coil. The fuel pump relay connects battery voltage to the fuel pump and oxygen sensor heating element.

The engine controller turns the ground path off when the ignition switch is in the Off position. Both relays are off. When the ignition switch is in the On or Crank position, the engine controller monitors the distributor pick-up signal. From the pick-up signal, the controller determines engine speed and ignition timing (coil dwell). If the engine controller does not receive a distributor signal when the ignition switch is in the Run position, it will de-energize both relays. When the relays are de-energized, battery voltage is not supplied to the fuel injector, ignition coil, fuel pump and oxygen sensor heating element.

On AC, AG, AJ and AY models, the ASD relay and fuel pump relay are located in the power distribution center (Fig. 25, 26, 27, or 28).

On AA and AP models, the ASD relay and fuel pump relay are mounted on the drivers side fender well, next to the strut tower (Fig. 29).




Fig. 25 Power Distribution Center (PDC) (AC Body)

IGNITION COIL

The 2.2L TBI, 2.5L TBI, Turbo I and 3.0L engines use an epoxy type coil. The coils are not oil filled. The windings are embedded in a heat and vibration resistant epoxy compound.

The engine controller operates the ignition coil through the auto shutdown (ASD) relay. When the relay is energized by the engine controller, battery voltage is connected to the ignition coil positive terminal. The engine controller will de-energize the ASD relay if it does not receive an input from the




Fig. 26 Relay Identification (AC Body)




Fig. 27 Power Distribution Center (PDC) (AG and AJ Body)




Fig. 28 Relay Identification (AG and AJ Body)

distributor pick-up. Refer to Auto Shutdown (ASD) Relay and Fuel Pump Relay in this section.




Fig. 29 Relay Identification (AA and AP Bodies)

On 2.2L TBI, 2.5L TBI and Turbo I engines, the ignition coil is mounted to the thermostat housing (Fig. 30). On 3.0L engines the coil is mounted on the rear of the intake manifold next to the air cleaner (Fig. 31).




Fig. 30 Ignition Coil—2.2L TBI, 2.5L TBI and Turbo I Engines




Fig. 31 Ignition Coil—3.0L Engine

2.2L TBI, 2.5L TBI, TURBO I AND 3.0L IGNITION SYSTEMS— DIAGNOSTIC PROCEDURES

INDEX

	page		page
Coolant Temperature Sensor Test	13	Manifold Absolute Pressure (MAP) Sensor Test ...	13
Detonation (Knock) Sensor	13	Poor Performance Test	13
Failure to Start Test—2.5L Tbi and 3.0L Engines ..	12	Spark Plugs	11
General Information	11	Testing for Spark at Coil	12
Ignition Coil	11		

GENERAL INFORMATION

For additional information, refer to On Board Diagnostics in the Fuel Injection General Diagnosis sections of Group 14. Also, refer to the DRB II tester and appropriate Powertrain Diagnostic Procedures Manual.

SPARK PLUGS

Faulty or fouled spark plugs may perform well at idle speed, but frequently fail at higher engine speeds. Faulty plugs can be identified in a number of

ways: poor fuel economy, power loss, decrease in engine speed, hard starting and, in general, poor engine performance.

Spark plugs also malfunction because of carbon fouling, excessive electrode air gap, or a broken insulator. Refer to the General Information Section of this group for spark plug diagnosis.

IGNITION COIL

The ignition coil is designed to operate without an external ballast resistor.

COIL RESISTANCE

COIL (MANUFACTURER)	PRIMARY RESISTANCE 21–27°C (70–80°F)	SECONDARY RESISTANCE 21–27°C (70–80°F)
Diamond	0.97 - 1.18 Ohms	11,300 - 15,300 Ohms
Toyodenso	0.95 - 1.20 Ohms	11,300 - 13,300 Ohms

Inspect the coil for arcing. Test the coil according to coil tester manufacturer's instructions. Test coil primary and secondary resistance. Replace any coil that does not meet specifications. Refer to the Coil Resistance chart.

If the ignition coil is replaced due to a burned tower, carbon tracking, arcing at the tower, or damage to the terminal or boot on the coil end of the secondary cable, the cable must be replaced. Arcing at the tower will carbonize the nipple which, if it is connected to a new coil, will cause the coil to fail.

If a secondary cable shows any signs of damage, the cable should be replaced with a new cable and new terminal. Carbon tracking on the old cable can cause arcing and the failure of a new coil.

TESTING FOR SPARK AT COIL

WARNING: APPLY PARKING BRAKE AND/OR BLOCK THE WHEELS BEFORE PERFORMING ANY TEST WITH THE ENGINE RUNNING.

CAUTION: Spark plug cables may be damaged if this test is performed with more than 1/4 inch clearance between the cable and engine ground.

Remove the coil secondary cable from the distributor cap. Hold the end of cable about 6 mm (1/4-inch) away from a good engine ground (Fig. 1). Crank the engine and inspect for spark at the coil secondary cable.




Fig. 1 Checking for Spark

There must be a constant spark at the coil secondary cable. If the spark is constant, have a helper continue to crank engine and, while slowly moving coil secondary cable away from ground, look for arcing at the coil tower. If arcing occurs at the tower, replace the coil. If spark is not constant or there is no spark, proceed to the failure to start test.

If a constant spark is present and no arcing occurs at the coil tower, the ignition system is producing the

necessary high secondary voltage. However, make sure that the spark plugs are firing. Inspect the distributor rotor, cap, spark plug cables, and spark plugs. If they are in proper working order, the ignition system is not the reason why the engine will not start. Inspect the fuel system and engine for proper operation.

FAILURE TO START TEST—2.5L TBI AND 3.0L ENGINES

Before proceeding with this test make sure Testing For Spark At Coil has been performed. Failure to do this may lead to unnecessary diagnostic time and wrong test results.

WARNING: BE SURE TO APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING ANY TEST WITH THE ENGINE RUNNING.

(1) Battery voltage must be at least 12.4 volts to perform test.

(2) Crank the engine for 5 seconds while monitoring the voltage at the coil positive (+) terminal (Fig. 2 or Fig. 3). If the voltage remains near zero during the entire period of cranking, refer to Group 14 for On-Board Diagnostic checks. Also, refer to the DRB II tester and the appropriate Powertrain Diagnostic Procedures manual. These checks will help diagnose problems with the engine controller and auto shut-down relay.




Fig. 2 Coil Terminals—2.2L TBI, 2.5L TBI and Turbo I Engines

(3) If voltage is at near-battery voltage and drops to zero after 1-2 seconds of cranking, refer to On-Board Diagnostic in Group 14. Also, refer to the DRB II tester and the appropriate Powertrain Diagnostic Procedures manual. These tests will help check the distributor reference pickup circuit to the engine controller.

(4) If voltage remains at near battery voltage during the entire 5 seconds, **with the key off**, remove




Fig. 3 Coil Terminals—3.0L Engine

the engine controller 60-way connector. Check the 60-way connector for any terminals that are pushed out or loose.

(5) Remove the connector to coil (+) and connect a jumper wire between battery (+) and coil (+).

(6) Using the special jumper (Fig. 4), momentarily ground terminal #19 of the 60-way connector (Fig. 5). A spark should be generated when the ground is removed.




Fig. 4 Special Jumper to Ground Coil Negative




Fig. 5 60-Way Electrical Connector, Engine Controller

(7) If spark is generated, replace the engine controller.

(8) If no spark is seen, use the special jumper to ground the coil (-) terminal directly.

(9) If spark is produced, inspect wiring harness for an open condition.

(10) If no spark is produced, replace the ignition coil.

POOR PERFORMANCE TEST

To prevent unnecessary diagnostic time and possible incorrect results, the Testing For Spark At Coil procedure should be performed before this test.

WARNING: APPLY PARKING BRAKE AND/OR BLOCK THE WHEELS BEFORE PERFORMING ANY ENGINE RUNNING TESTS.

Check and adjust basic timing (refer to the specification section of this group and see service procedures).

COOLANT TEMPERATURE SENSOR TEST

(1) With key off, disconnect wire connector from coolant temperature sensor (Fig. 6).

(2) Connect one lead of ohmmeter to one terminal of coolant temperature sensor.

(3) Connect the other lead of ohmmeter to remaining terminal of coolant temperature sensor. The ohmmeter should read as follows;

- Engine/Sensor at normal operating temperature around 200°F should read approximately 700 to 1,000 ohms.
- Engine/Sensor at room temperature around 70°F, ohmmeter should read approximately 7,000 to 13,000 ohms.

Refer to On Board Diagnostics in the General Diagnosis section of Group 14. Also, refer to the DRB II tester and the appropriate Powertrain Diagnostic Procedures manual for additional test procedures.




Fig. 6 Coolant Temperature Sensor Test

MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR TEST

Refer to the DRB II tester and appropriate Powertrain Diagnostic Procedures manual for further test procedures.

DETONATION (KNOCK) SENSOR

Refer to the DRB II tester and appropriate Powertrain Diagnostic Procedures manual for test procedures.

2.2L TBI, 2.5L TBI, TURBO I AND 3.0L IGNITION SYSTEMS— SERVICE PROCEDURES

INDEX

	page		page
Coolant Temperature Sensor	14	Ignition Coil—2.2L TBI, 2.5L TBI and Turbo I Engines	15
Distributor Pick-Up—2.2L TBI, 2.5L TBI and Turbo I Engines	20	Ignition Coil—3.0L Engines	15
Distributor Service—3.0L Engine	21	Ignition Timing Procedure—2.2L TBI, 2.5L TBI, Turbo I, and 3.0L Engines	18
Distributor—2.2L TBI, 2.5L TBI and Turbo I Engines	19	Manifold Absolute Pressure (MAP) Sensor Service—2.5L TBI and 3.0L Engines	24
Engine Controller	14	Spark Plug Service	15
Idle RPM Test—2.5L and 3.0L Engines	16		

ENGINE CONTROLLER

The engine controller is located next to the battery (Fig. 1).




Fig. 1 Engine Controller

REMOVAL

- (1) Remove air cleaner duct or air cleaner assembly.
- (2) Remove battery.
- (3) Remove engine controller mounting screws.
- (4) Remove 60-way wiring connector from the engine controller.
- (5) Remove controller.

INSTALLATION

- (1) Connect 60-Way electrical connector to Engine Controller (Fig. 1).
- (2) Install engine controller. Tighten mounting screws.
- (3) Install battery.
- (4) Install air cleaner duct or air cleaner assembly.

COOLANT TEMPERATURE SENSOR

On 2.2L TBI, 2.5L TBI and Turbo I engines, the coolant temperature sensor is located behind the ignition coil (Fig. 2). On 3.0L engines the sensor is located

next to the thermostat housing (Fig. 3).

REMOVAL

- (1) Drain cooling system until coolant level is below coolant sensor. Refer to Group 7, Cooling System.
- (2) Disconnect electrical connector from sensor.
- (3) Remove sensor from engine.

INSTALLATION

- (1) Install coolant sensor. Tighten 2.2L TBI, 2.5L TBI or Turbo I engine coolant sensor to 28 N•m (20 ft. lbs.) torque. Tighten the 3.0L engine coolant sensor to 7 N•m (60 in. lbs.) torque.
- (2) Connect electrical connector to sensor.
- (3) Fill cooling system. Refer to Group 7, Cooling System.




Fig. 2 Coolant Temperature Sensor—2.2 TBI, 2.5L TBI and Turbo I Engines




Fig. 3 Coolant Temperature Sensor—3.0L Engine
IGNITION COIL—2.2L TBI, 2.5L TBI AND TURBO I ENGINES

The ignition coil mounts to the thermostat housing (Fig. 4).




Fig. 4 Ignition Coil—2.2L TBI, 2.5L TBI and Turbo I Engines

REMOVAL

- (1) Disconnect the coil to distributor ignition cable (Fig. 4).
- (2) Disconnect the wiring harness connector from the coil.

- (3) Remove ignition coil mounting screws.

INSTALLATION

- (1) Install ignition coil onto the bracket. Tighten the screws to 9.5 N•m (85 in. lbs.) torque.
- (2) Connect the wiring harness connector.
- (3) Connect the coil to distributor ignition cable.

IGNITION COIL—3.0L ENGINES

The ignition coil is located at the back of the intake manifold (Fig. 5).




Fig. 5 Ignition Coil—3.0L Engine

REMOVAL

- (1) Remove air cleaner assembly.
- (2) Disconnect ignition cable from coil.
- (3) Disconnect wiring harness connector from coil.
- (4) Remove coil mounting screws.

INSTALLATION

- (1) Loosely install ignition coil on intake manifold. Tighten the intake manifold fastener to 13 N•m (115 in. lbs.) torque. Tighten ignition coil bracket fasteners to 10 N•m (96 in. lbs.) torque.
- (2) Connect the wiring harness connector.
- (3) Connect the coil to distributor ignition cable.
- (4) Install the air cleaner assembly. Tighten the air cleaner fasteners to 25 N•m (225 in. lbs.) torque.

SPARK PLUG SERVICE

When replacing the spark plug and coil cables, route the cables correctly and secure them in the appropriate retainers. Incorrectly routed cables can cause the radio to reproduce ignition noise. It can also cause cross ignition of the spark plugs or short circuit the cables to ground.

SPARK PLUG REMOVAL

Always remove cables by grasping at boot, rotating the boot 1/2 turn, and pulling straight back in a steady motion.


(1) Prior to removing the spark plug spray compressed air around the spark plug hole and the area around the spark plug.

(2) Remove the spark plug using a quality socket with a rubber or foam insert.

(3) Inspect the spark plug condition. Refer to Spark Plug Condition in this section.

SPARK PLUG GAP ADJUSTMENT

Check the spark plug gap with a gap gauge. If the gap is not correct, adjust it by bending the ground electrode (Fig. 6).



J908D-10

Fig. 6 Setting Spark Plug Gap—Typical

SPARK PLUG INSTALLATION

(1) Start the spark plug into the cylinder head by hand to avoid cross threading.

(2) Tighten spark plugs to 28 N•m (20 ft. lbs.) torque.

(3) Install spark plug cables over spark plugs.

IDLE RPM TEST—2.5L AND 3.0L ENGINES

WARNING: APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING IDLE CHECK OR ADJUSTMENT, OR ANY TESTS WITH A RUNNING ENGINE.

Engine idle set rpm should be **tested and recorded when the vehicle is first brought into shop for testing**. This will assist in diagnosing complaints of engine stalling, creeping and hard shifting on vehicles equipped with automatic transmissions.

Proceed to the Throttle Body Minimum Airflow procedures.

THROTTLE BODY MINIMUM AIR FLOW CHECK PROCEDURE—2.2L TBI AND 2.5L TBI ENGINES

(1) Connect Diagnostic Readout Box II (DRBII).

(2) Remove air cleaner assembly. Plug the heated air door vacuum hose.

(3) Warm engine in Park or Neutral until the cooling fan has cycled on and off at least once.


(4) Hook-up timing check device and tachometer.

(5) Disconnect the coolant temperature sensor and set basic timing to $12^\circ\text{BTDC} \pm 2^\circ\text{BTDC}$.

(6) Shut off engine. Reconnect coolant temperature sensor.

(7) Disconnect the PCV valve hose from the intake manifold nipple.

(8) Attach Air Metering Fitting #6457 (Fig. 7) to the intake manifold PCV nipple.



9114-68

Fig. 7 Air Metering Fitting

(9) Restart the engine, allow engine to idle for at least one minute.

(10) Using the DRBII, Access Min Airflow Idle Spd in the sensor read test mode.

(11) The following will then occur:

- AIS motor will fully close.
- Idle spark advance will become fixed.
- Idle fuel will be provided at a set value.
- Engine RPM will be displayed on Diagnostic Readout Box II (DRBII).

(12) Check idle RPM with tachometer. If idle RPM is within the specifications listed below, then the throttle body min. air flow is set correctly.

IDLE SPECIFICATIONS

Odometer Reading	Engine	Idle RPM
Below 1000 Miles	2.2L	700 - 1300 RPM
	2.5L	650 - 1250 RPM
Above 1000 Miles	2.2L	1100 - 1300 RPM
	2.5L	1050 - 1250 RPM

9114-37

If idle RPM is not within specification replace throttle body.

- (13) Shut off engine.
- (14) Remove Special Tool number 6457 from intake manifold PCV nipple. Reinstall the PCV valve hose.
- (15) Remove DRBII.
- (16) Reinstall air cleaner assembly. Reinstall heated air door vacuum hose.
- (17) Disconnect timing check device and tachometer.

THROTTLE BODY MINIMUM AIR FLOW CHECK PROCEDURE—TURBO I ENGINES

- (1) Warm engine in Park or neutral until the cooling fan has cycled on and off at least once.
- (2) Hook-up timing check device and Tachometer.
- (3) Disconnect the coolant temperature sensor and set basic timing to 12° BTDC $\pm 2^{\circ}$ BTDC.
- (4) Shut off engine. Connect harness connector to coolant temperature sensor.
- (5) Disconnect the PCV valve hose from the nipple on the intake manifold.
- (6) Attach Air Metering Fitting #6457 (0.125 in. orifice) to the intake manifold PCV nipple (Fig. 7).
- (7) Disconnect 3/16 inch manifold vacuum purge line from the top of the throttle body. Cap the 3/16 inch throttle body nipple.
- (8) Connect Diagnostic Readout Box II (DRB II).
- (9) Restart engine. Allow engine to idle for at least one minute.
- (10) Using the DRB II, access Min. Airflow Idle Spd. The following will then occur:
 - AIS motor will fully close.
 - Idle spark advance will become fixed.
 - Engine RPM will be displayed on Diagnostic Readout Box II (DRB II).
- (11) Check idle RPM with tachometer, if idle RPM is within the below specification then the throttle body minimum airflow is set correctly.

IDLE SPECIFICATIONS

Odometer Reading	Idle RPM
Below 1000 miles	650-1400 RPM
Above 1000 miles	700-1400 RPM

9214-100

If the idle RPM is not within specification, replace the throttle body.

- (12) Shut off engine.

(13) Remove Air Metering Fitting #6457 from the intake manifold PCV nipple. Reinstall the PCV valve hose.

- (14) Remove DRB II.
- (15) Disconnect timing check device and tachometer.
- (16) Reconnect purge line to throttle body.

THROTTLE BODY MINIMUM AIR FLOW CHECK PROCEDURE—3.0L ENGINE

- (1) Warm engine in Park or Neutral until the cooling fan has cycled on and off at least once.
- (2) Ensure that all accessories are off.
- (3) Hook-up the timing check device and tachometer.
- (4) Disconnect the coolant temperature sensor and set basic timing to 12° BTDC $\pm 2^{\circ}$ BTDC.
- (5) Shut off engine. Reconnect coolant temperature sensor wire.
- (6) Disconnect the PCV valve hose from the PCV valve (Fig. 8).
- (7) Plug the PCV valve nipple.




Fig. 8 PCV Valve—3.0L Engine

(8) Disconnect the idle purge hose from the engine vacuum harness tee (Fig. 9).

(9) Install Air Metering Fitting #6457 (0.125 inch orifice) in the intake manifold mounted idle purge hose (Fig. 7).

(10) Connect Diagnostic Readout Box II (DRB II).

(11) Restart the engine, allow engine to idle for at least one minute.

(12) Using the DRBII, access Min. Airflow Idle Speed.

(13) The following will then occur:

- AIS motor will fully close.
- Idle spark advance will become fixed.
- Engine RPM will be displayed on Diagnostic Readout Box II (DRB II)

(14) Check idle RPM with tachometer, if idle RPM is within the below specification then the throttle body min. air flow is set correctly.




Fig. 9 Idle Purge Hose—3.0L
IDLE SPECIFICATIONS

Odometer Reading	Idle RPM
Below 1000 Miles	625-950 RPM
Above 1000 Miles	750-950 RPM

9114-69

(15) If idle RPM is not within specifications, shut off the engine and clean the throttle body as follows:

- (a) Remove the throttle body from engine.

WARNING: CLEAN THROTTLE BODY IN A WELL VENTILATED AREA. WEAR RUBBER OR BUTYL GLOVES, DO NOT LET MOPAR PARTS CLEANER COME IN CONTACT WITH EYES OR SKIN. AVOID INGESTING THE CLEANER. WASH THOROUGHLY AFTER USING CLEANER.

(b) While holding the throttle open, spray the entire throttle body bore and the manifold side of the throttle plate with Mopar Parts Cleaner. **Only use Mopar Parts Cleaner to clean the throttle body.**

(c) Using a soft scuff pad, clean the top and bottom of throttle body bore and the edges and manifold side of the throttle blade. **The edges of the throttle blade and portions of the throttle bore that are closest to the throttle blade when is closed, must be free of deposits.**

- (d) Use compressed air to dry the throttle body.
- (e) Inspect throttle body for foreign material.
- (f) Install throttle body on manifold.

(g) Repeat steps 1 through 14. If the minimum air flow is still not within specifications, the problem is not caused by the throttle body.

(16) Shut off engine.

(17) Remove Air Metering Fitting #6457 from the intake manifold idle purge hose. Reconnect the hose to the engine vacuum harness tee.

(18) Remove the plug from the PCV valve. Reconnect the PCV valve hose to the PCV valve.

(19) Disconnect the DRB II.

IGNITION TIMING PROCEDURE—2.2L TBI, 2.5L TBI, TURBO I, AND 3.0L ENGINES

WARNING: APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING SETTING IGNITION TIMING OR PERFORMING ANY TEST ON AN OPERATING ENGINE.

Proper ignition timing is required to obtain optimum engine performance. The distributor must be correctly indexed to provide correct initial ignition timing.

(1) Set the gearshift selector in park or neutral and apply the parking brake. All lights and accessories must be off.

(2) If using a magnetic timing light, insert the pickup probe into the open receptacle next to the timing scale window. If a magnetic timing unit is not available, use a conventional timing light connected to the number one cylinder spark plug cable.

Do not puncture cables, boots or nipples with test probes. Always use proper adapters. Puncturing the spark plug cables with a probe will damage the cables. The probe can separate the conductor and cause high resistance. In addition breaking the rubber insulation may permit secondary current to arc to ground.

(3) Turn selector switch to the appropriate cylinder position.

(4) Start engine and run until operating temperature is obtained.

(5) With the engine at normal operating temperature, connect the DRB II to the diagnostic connector. Access the State Display screen. Refer to the appropriate Powertrain Diagnostics Procedures Manual. **If not using the DRB II tester, disconnect the coolant temperature sensor electrical connector.** The electric radiator fan will operate and the Check Engine light will turn on after disconnecting the coolant sensor or starting the DRB II procedure.

(6) Aim Timing Light at timing scale (Fig. 10 or Fig. 11) or read magnetic timing unit. If flash occurs when timing mark is before specified degree mark, timing is advanced. To adjust, turn distributor housing in direction of rotor rotation.

If flash occurs when timing mark is after specified degree mark, timing is retarded. To adjust, turn dis-




Fig. 10 Timing Scale—2.2L TBI, 2.5L TBI and Turbo I Engines




Fig. 11 Timing Scale—3.0L Engine

tributor housing against direction of rotor rotation. Refer to Vehicle Emission Control Information label for correct timing specification. If timing is within $\pm 2^\circ$ of value specified on the label, proceed to step (8). If outside specified tolerance, proceed to next step.

(7) Loosen distributor hold-down arm screw enough to rotate the distributor housing (Fig. 12 or Fig. 13). Turn distributor housing to adjust timing. Tighten the hold-down arm screw and recheck timing.

(8) Turn the engine off. Remove timing light or magnetic timing unit and tachometer. If the coolant temperature sensor was disconnected, connect the sensor and **erase fault codes using the Erase Fault Code Mode on the DRBII.**

DISTRIBUTOR—2.2L TBI, 2.5L TBI and TURBO I ENGINES

REMOVAL

(1) Disconnect distributor pick-up connector from wiring harness connector (Fig. 14).




Fig. 12 Distributor Holddown—2.5L Engine




Fig. 13 Distributor Holddown—3.0L Engine




Fig. 14 Distributor Pickup Connector—2.5L Engine

- (2) Remove splash shield retaining screws (Fig. 15).
- (3) Remove splash shield (Fig. 15).




Fig. 15 Splash Shield—2.5L Engine

(4) Loosen distributor cap retaining screws (Fig. 16).




Fig. 16 Distributor Cap Retaining Screws—2.5L Engine

- (5) Lift cap off of distributor (Fig. 17).
- (6) Rotate engine crankshaft until the distributor rotor is pointing toward the cylinder block. Use this as reference when reinstalling distributor.
- (7) Remove distributor hold-down screw.
- (8) Carefully lift the distributor from the engine.

INSTALLATION

- (1) Position distributor in engine. Make certain that the O-ring is properly seated on distributor. If O-ring is cracked or nicked, replace it with new one.
- (2) Carefully engage distributor drive with auxiliary shaft drive. When distributor is installed properly, rotor will be pointing toward cylinder block. **If engine has been cranked while distributor is**




Fig. 17 Distributor Cap—2.5L Engine

removed, establish proper relationship between the distributor shaft and Number 1 piston position as follows:

- (a) Rotate the crankshaft until number one piston is at top of compression stroke. Pointer on clutch housing should be in line with the **O(TDC)** mark on flywheel.
- (b) Rotate rotor to a position just ahead of the number one distributor cap terminal.
- (c) Lower the distributor into the opening, engaging distributor drive with drive on auxiliary shaft. With distributor fully seated on engine, rotor should be under the cap number 1 tower.
- (3) Install the distributor cap. Ensure all high tension wires snap firmly in the cap towers.
- (4) Install hold-down arm screw and finger tighten.
- (5) Install splash shield.
- (6) Connect distributor pick-up connector lead wire at wiring harness connector.
- (7) Set ignition timing to specification. Refer to Ignition Timing.

DISTRIBUTOR PICK-UP—2.2L TBI, 2.5L TBI AND TURBO I ENGINES

REMOVAL

- (1) Remove splash shield and cap. Refer to Distributor Removal.
- (2) Remove rotor from shaft (Fig. 18).
- (3) Remove **Hall effect pick-up assembly** (Fig. 19).

INSTALLATION

- (1) Place pick-up assembly into distributor housing (Fig. 19).




Fig. 18 Ignition Rotor—2.2L TBI, 2.5L TBI and Turbo I Engines




Fig. 19 Hall Effect Pickup Assembly—2.2L TBI, 2.5L TBI and Turbo I Engines

The distributor pick-up wires may be damaged if not properly reinstalled.

- (2) Install rotor (Fig. 18).
- (3) Install cap and splash shield. Refer to Distributor Installation.

DISTRIBUTOR SERVICE—3.0L ENGINE

REMOVAL

- (1) Disconnect distributor connector from wiring harness connector (Fig. 20).




Fig. 20 Distributor Electrical Connector—3.0L Engine

- (2) Loosen distributor cap retaining screws.
- (3) Lift cap off distributor (Fig. 21).
- (4) Rotate engine crankshaft until the distributor rotor points the intake manifold plenum. Scribe a mark on the plenum in line with the rotor. The scribe line indicates where to position the rotor when reinstalling the distributor.




Fig. 21 Distributor Cap—3.0L Engine

- (5) Remove distributor hold down nut (Fig. 22).
- (6) Carefully lift the distributor from the engine.

INSTALLATION

- (1) Position distributor in engine. Make certain that the O-ring is properly seated on distributor. If O-ring is cracked or nicked replace with new one.
- (2) Carefully engage distributor drive with gear on camshaft. When the distributor is installed properly,




Fig. 22 Distributor Hold-Down—3.0L Engine

the rotor will be in line with previously scribe line on air intake plenum. **If engine was cranked while distributor was removed, establish proper relationship between the distributor shaft and Number 1 piston position as follows:**

- (a) Rotate the crankshaft until number one piston is at top of compression stroke.
- (b) Rotate rotor to number one rotor terminal (Fig. 23).

(c) Lower the distributor into the opening, engaging distributor drive with drive on camshaft. With distributor fully seated on engine, rotor should be under the number 1 terminal (Fig. 23).




Fig. 23 Distributor Cap Terminal Routing, View from Top of Cap—3.0L Engine

- (3) Install distributor cap. Ensure sure all high tension wires are firmly in the cap towers.
- (4) Install hold-down nut and finger tighten.
- (5) Connect distributor electrical connector to wiring harness connector (Fig. 20).
- (6) Set ignition timing to specification. Refer to Ignition Timing in this section.

DISASSEMBLY

- (1) Remove distributor cap mounting screws (Fig. 21).
- (2) Remove distributor cap and inspect for flash-over, cracked carbon button, cracked cap, or burned terminals. If any of these conditions exist, replace cap.
- (3) Remove rotor screw (Fig. 24). Inspect rotor for cracks or burned electrode. If any of these conditions exist, replace rotor.




Fig. 24 Rotor Screw

- (4) Remove protective cover from distributor housing (Fig. 25).




Fig. 25 Protective Cover

- (5) Remove lead wire clamp screw and remove lead wire (Fig. 26).
- (6) Remove disk assembly screw (Fig. 27).
- (7) Remove disk spacers and disk (Fig. 28). Disk and spacers are keyed. Check disk for warpage, cracks or damaged slots (Fig. 29).




Fig. 26 Lead Wire Clamp




Fig. 27 Disk Assembly Screw




Fig. 28 Disk and Spacers Installed

(8) Remove bushing and photo optic sensing unit fasteners. Remove unit from distributor housing (Fig. 30).

(9) Remove bearing retainer screws (Fig. 31).




Fig. 29 Disk and Spacers




Fig. 30 Photo Optic Sensing Unit Assembly and Bushing




Fig. 31 Bearing Retainer Screws

(10) Make reassembly alignment marks on gear and shaft (Figs. 32 and 33).

(11) With a pin punch drive out distributor drive gear roll pin (Fig. 34).




Fig. 32 Marking Drive Gear and Shaft




Fig. 34 Drive Gear Roll Pin




Fig. 33 Marks on Drive Gear and Shaft




Fig. 35 Drive Gear

- (12) Remove distributor drive gear (Fig. 35).
- (13) Remove distributor shaft and bearing assembly (Fig. 36).
- (14) To reassemble, reverse preceding procedure. Refer to Fig. 37.

MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR SERVICE—2.5L TBI AND 3.0L ENGINES

- (1) Remove vacuum hose and remove mounting screws from sensor (Fig. 38, 39 and 40).
- (2) Remove wiring harness and remove sensor.
- (3) Reverse the above procedure for installation. Check that vacuum hose is attached to vacuum source.




Fig. 36 Distributor Shaft




Fig. 37 Distributor—3.0L Engine




Fig. 38 Manifold Absolute Pressure (MAP) Sensor—2.2L and 2.5L TBI Engines




Fig. 39 Manifold Absolute Pressure (MAP) Sensor—Turbo I Engines




Fig. 40 Manifold Absolute Pressure (MAP) Sensor—3.0L Engine

TURBO III, 3.L AND 3.8L IGNITION SYSTEM—SYSTEM OPERATION

INDEX

	page		page
Auto Shutdown (ASD) Relay and Fuel Pump Relay	35	Engine Controller	26
Camshaft Reference Sensor	30	General Information	26
Coolant Temperature Sensor	34	Ignition Coil	33
Crankshaft Timing Sensor	32	Manifold Absolute Pressure (MAP) Sensor	34
Detonation Sensor (Knock Sensor)—Turbo III Engine	34	Spark Plug Cables	28
		Spark Plugs	28

GENERAL INFORMATION

This section describes the ignition systems for Turbo III, 3.3L and 3.8L engines.

The Fuel Injection sections of Group 14 describe On Board Diagnostics.

Group 0, Lubrication and Maintenance, contains general maintenance information for ignition related items. The Owner's Manual also contains maintenance information.

Turbo III, 3.3L and 3.8L engines uses a fixed ignition timing system. Basic ignition timing is not adjustable. All spark advance is determined by the engine controller.

The ignition system does not use a distributor. The system is referred to as the Direct Ignition System. The system's three main components are the coil pack, crankshaft timing sensor, and camshaft reference sensor. The crankshaft and camshaft sensors are hall effect devices.

The camshaft and crankshaft sensors generate pulses that are the inputs sent to the engine controller. The engine controller interprets crankshaft and camshaft positions from these sensors. The engine

controller uses crankshaft position reference to determine ignition timing. The controller determines injector sequence from the camshaft position reference.

The camshaft sensor senses when a slot in the camshaft gear passes beneath it (Fig. 1 or Fig. 2). The crankshaft sensor senses when a window in the drive plate passes under it (Fig. 3 or Fig. 4). When a slot or window is sensed, the input voltage from the sensor to the engine controller switches from low (less than .3 volts) to high (5 volts). As the slot or window passes, the input voltage is switched back to low (less than .3 volts).

FIRING ORDER

The firing order of the Turbo I engine direct ignition system is 1-3-4-2 (Fig. 5). The firing order of the 3.3L and 3.8L engines direct ignition system is 1-2-3-4-5-6 (Fig. 6).

ENGINE CONTROLLER

The ignition system is regulated by the Single board Engine Controller II (SBEC II), **referred to in this manual as the Engine Controller (Fig. 7).** The controller supplies battery voltage to the igni-




Fig. 1 Camshaft Sprocket—Turbo III Engine




Fig. 2 Camshaft Sprocket—3.3L and 3.8L Engines

tion coil through the Auto Shutdown (ASD) Relay. The controller also controls ground circuit for the ignition coil. By switching the ground path for the coil on and off, the engine controller adjusts ignition timing to meet changing engine operating conditions.

During the crank-start period the controller advances ignition timing a set amount. During engine operation, the amount of spark advance provided by the engine controller is determined by these input factors:

- coolant temperature
- detonation sensor (Turbo III)




Fig. 3 Driveplate—Turbo III Engine




Fig. 4 Driveplate—3.3L and 3.8L Engines





Fig. 5 Spark Plug Wire Routing—Turbo III Engine


- engine RPM
- available manifold vacuum

The engine controller also regulates the fuel injection system. Refer to the Fuel Injection sections of Group 14.



918D-2

Fig. 6 Spark Plug Wire Routing—3.3L and 3.8L Engines



918D-48

Fig. 7 Single Board Engine Controller

SPARK PLUG CABLES

Spark Plug cables are sometimes referred to as secondary ignition wires. The wires transfer electrical current from the distributor to individual spark plugs at each cylinder. The spark plug cables are of nonmetallic construction and have a built in resistance. The cables provide suppression of radio frequency emissions from the ignition system.

Check the spark plug cable connections for good contact at the coil and distributor cap towers and at the spark plugs. Terminals should be fully seated. The nipples and spark plug covers should be in good


condition. Nipples should fit tightly on the coil and distributor cap towers and spark plug cover should fit tight around spark plug insulators. Loose cable connections can cause ignition malfunctions by permitting water to enter the towers, corroding, and increasing resistance.

SPARK PLUGS

The Turbo III, 3.3L and 3.8L engines use resistor spark plugs. They have resistance values of 6,000 to 20,000 ohms when checked with at least a 1000 volt tester.

Remove the spark plugs and examine them for burned electrodes and fouled, cracked or broken porcelain insulators. Keep plugs arranged in the order in which they were removed from the engine. An isolated plug displaying an abnormal condition indicates that a problem exists in the corresponding cylinder. Replace spark plugs at the intervals recommended in Group O.

Spark plugs that have low mileage may be cleaned and reused if not otherwise defective. Refer to the Spark Plug Condition section of this group. After cleaning, file the center electrode flat with a small point file or jewelers file. Adjust the gap between the electrodes (Fig. 8) to the dimensions specified in the chart at the end of this section.



J908D-10


Fig. 8 Setting Spark Plug Electrode Gap—Typical

Always tighten spark plugs to the specified torque. Over tightening can cause distortion and change spark plug gap. Tighten Turbo III, 3.3L and 3.8L spark plugs to 28 N•m (20 ft. lbs.) torque.

SPARK PLUG CONDITION

NORMAL OPERATING CONDITIONS

The few deposits present will be probably light tan or slightly gray in color with most grades of commercial gasoline (Fig. 9). There will not be evidence of electrode burning. Gap growth will not average more than approximately 0.025 mm (.001 in) per 1600 km (1000 miles) of operation. Spark plugs that have normal wear can usually be cleaned, have the electrodes filed and regapped, and then reinstalled.



J908D-15

Fig. 9 Normal Operation and Cold (Carbon) Fouling

Some fuel refiners in several areas of the United States have introduced a manganese additive (MMT) for unleaded fuel. During combustion, fuel with MMT may coat the entire tip of the spark plug with a rust colored deposit. The rust color deposits can be misdiagnosed as being caused by coolant in the combustion chamber. Spark plug performance is not affected by MMT deposits.

COLD FOULING (CARBON FOULING)

Cold fouling is sometimes referred to as carbon fouling because the deposits that cause cold fouling are basically carbon (Fig. 9). A dry, black deposit on one or two plugs in a set may be caused by sticking valves or defective spark plug cables. Cold (carbon) fouling of the entire set may be caused by a clogged air cleaner.


Cold fouling is normal after short operating periods. The spark plugs do not reach a high enough operating temperature during short operating periods.

WET FOULING

A spark plug that is coated with excessive wet fuel or oil is wet fouled. In older engines, wet fouling can be caused by worn rings or excessive cylinder wear. **Break-in fouling of new engines may occur before normal oil control is achieved. In new or recently overhauled engines, wet fouled spark plugs can be usually be cleaned and reinstalled.**

OIL OR ASH ENCRUSTED

If one or more plugs are oil or oil ash encrusted, engine oil is entering the combustion chambers (Fig. 10). Evaluate the engine to determine the cause.



PR1673

Fig. 10 Oil or Ash Encrusted

HIGH SPEED MISS


When replacing spark plugs because of a high speed miss condition; **wide open throttle operation should be avoided for approximately 80 km (50 miles) after installation of new plugs.** This will allow deposit shifting in the combustion chamber to take place gradually and avoid plug destroying splash fouling shortly after the plug change.

ELECTRODE GAP BRIDGING

Loose deposits in the combustion chamber can cause electrode gap bridging. The deposits accumulate on the spark plugs during continuous stop-and-go driving. When the engine is suddenly subjected to a high torque load, the deposits partially liquefy and bridge the gap between the electrodes (Fig. 11). This short circuits the electrodes. Spark plugs with electrode gap bridging can be cleaned using standard procedures.

SCAVENGER DEPOSITS


Fuel scavenger deposits may be either white or yellow (Fig. 12). They may appear to be harmful, but are a normal condition caused by chemical additives in certain fuels. These additives are designed to change the chemical nature of deposits and decrease spark plug misfire tendencies. Accumulation on the ground electrode and shell area may be heavy but the deposits are easily removed. Spark plugs with scavenger deposits can be considered normal in con-



J908D-11

Fig. 11 Electrode Gap Bridging

dition and be cleaned using standard procedures.



J908D-12


Fig. 12 Scavenger Deposits

CHIPPED ELECTRODE INSULATOR

A chipped electrode insulator usually results from bending the center electrode while adjusting the spark plug electrode gap. Under certain conditions, severe detonation also can separate the insulator from the center electrode (Fig. 13). Spark plugs with chipped electrode insulators must be replaced.

PREIGNITION DAMAGE


Excessive combustion chamber temperature can cause preignition damage. First, the center electrode dissolves and the ground electrode dissolves somewhat later (Fig. 14). Insulators appear relatively deposit free. Determine if the spark plug has the correct heat range rating for the engine, if ignition timing is over advanced or if other operating conditions are causing engine overheating. The heat range rating refers to the operating temperature of a particular type spark plug. Spark plugs are designed to operate



J908D-13

Fig. 13 Chipped Electrode Insulator

within specific temperature ranges depending upon the thickness and length of the center electrode and porcelain insulator.



J908D-14

Fig. 14 Preignition Damage

SPARK PLUG OVERHEATING

Overheating is indicated by a white or gray center electrode insulator that also appears blistered (Fig. 15). The increase in electrode gap will be considerably in excess of 0.001 in per 1000 miles of operation. This suggests that a plug with a cooler heat range rating should be used. Over advanced ignition timing, detonation and cooling system malfunctions also can cause spark plug overheating.

CAMSHAFT REFERENCE SENSOR

The camshaft sensor provides fuel injection synchronization and cylinder identification information (Fig. 16 or Fig. 17). The sensor generates pulses that are the input sent to the engine controller. The engine controller interprets the camshaft sensor input (along with the crankshaft sensor input) to determine crankshaft position. The engine controller uses crankshaft position reference to determine injector sequence and ignition timing.


BLISTERED
WHITE OR
GRAY
COLORED
INSULATOR



J908D-16


Fig. 15 Spark Plug Overheating

PAPER
SPACER



918D-36

Fig. 16 Camshaft Reference Sensor—Turbo III Engine




908D-2

Fig. 17 Camshaft Reference Sensor—3.3L and 3.8L Engines

The camshaft sensor determines when a slot in the camshaft gear passes beneath it (Fig. 18 or Fig. 19). When a slot is sensed, the input voltage from the sensor to the engine controller switches from low (less than 0.3 volts) to high (5 volts). As the slot or window passes, the input voltage is switched back to low (less than 0.3 volts).

SLOTS




CAMSHAFT SPROCKET

918D-10

Fig. 18 Camshaft Gear—Turbo III Engine

CAMSHAFT SPROCKET



SLOTS

918D-3

Fig. 19 Camshaft Gear—3.3L and 3.8L Engines

The camshaft sensor is mounted to the top of the timing case cover (Fig. 20 or Fig. 21). The bottom of the sensor is positioned above the camshaft sprocket. **The distance between the bottom of sensor and the camshaft sprocket is critical to the operation of the system. When servicing the camshaft sensor, refer to the Turbo III, 3.3L and 3.8L Ignition System—Service Procedures section in this Group.**




Fig. 20 Camshaft Reference Sensor Location—Turbo III Engines




Fig. 21 Camshaft Reference Sensor Location—3.3L and 3.8L Engines

CRANKSHAFT TIMING SENSOR

The crankshaft sensor senses slots cut into the transmission driveplate extension (Fig. 22 or Fig. 23). On Turbo III, there are a 2 sets of slots. Each set contains 4 slots, for a total of 8 slots (Fig. 24). On 3.3L and 3.8L engines, there are a 3 sets of slots. Each set contains 4 slots, for a total of 12 slots (Fig. 25).

Basic timing is set by the position of the last slot in each group. Once the engine controller senses the last slot, it determines crankshaft position (which piston will next be at TDC) from the camshaft sensor input. It may take the controller up to two thirds of an engine revolution to determine crankshaft position.

The engine controller uses the camshaft reference sensor to determine injector sequence. The controller determines ignition timing from the crankshaft timing sensor. Once crankshaft position has been determined, the engine controller begins energizing the injectors in sequence.




Fig. 22 Crankshaft Timing Sensor—Turbo III Engine




Fig. 23 Crankshaft Timing Sensor—3.3L and 3.8L Engines




Fig. 24 Timing Slots in Transmission Driveplate—Turbo III Engine

On Turbo III engines, the crankshaft timing sensor is located in the transmission housing, below the throttle body (Fig. 26). On 3.3L and 3.8L engines, the crankshaft timing sensor is located in the transmission housing, above the vehicle distance sensor (Fig. 27).




Fig. 25 Timing Slots in Transmission Driveplate—3.3L and 3.8L Engines

The bottom of the sensor is positioned next to the drive plate. **The distance between the bottom of sensor and the drive plate is critical to the operation of the system. When servicing the crankshaft sensor, refer to the 3.3L Ignition System—Service Procedures section in this Group.**




Fig. 26 Crankshaft Sensor Location—Turbo III Engines

IGNITION COIL

WARNING: THE DIRECT IGNITION SYSTEM GENERATES APPROXIMATELY 40,000 VOLTS. PERSONAL INJURY COULD RESULT FROM CONTACT WITH THIS SYSTEM.

The 3.3L and 3.8L coil assembly consists of 3 coils molded together (Fig. 28). The assembly is mounted on the intake manifold. The Turbo II coil assembly consists of 2 coils molded together (Fig. 29). The assembly is mounted at the front of the engine. For all engines, the number of each coil appears on the




Fig. 27 Crankshaft Sensor Location—3.3L and 3.8L Engines

front of the coil pack.




Fig. 28 Coil Pack—Turbo III Engine




Fig. 29 Coil Pack—3.3L and 3.8L Engines

High tension leads route to each cylinder from the coil. The coil fires two spark plugs every power stroke. One plug is the cylinder under compression, the other cylinder fires on the exhaust stroke. The engine controller determines which of the coils to charge and fire at the correct time.

On 3.3L and 3.8L engines, coil one fires cylinders 1 and 4, coil two fires cylinders 2 and 5, coil three fires cylinders three and six.

The coil's low primary resistance allows the engine controller to fully charge the coil for each firing.

COOLANT TEMPERATURE SENSOR

On Turbo III engines, the coolant temperature sensor is installed into the thermostat housing (Fig. 30). On 3.3L and 3.8L engines, the coolant temperature sensor is located next to the thermostat housing (Fig. 31).




Fig. 30 Coolant Temperature Sensor—Turbo III Engines




Fig. 31 Coolant Temperature Sensor—3.3L and 3.8L Engines

The coolant temperature sensor provides an input voltage to the engine controller. The sensor is a vari-

able resistance (thermistor) with a range of -40°C to 130°C (-40°F to 265°F). As coolant temperature varies, the sensor's resistance changes, resulting in a different input voltage to the engine controller.

The engine controller contains different spark advance schedules for cold and warm engine operation. The schedules reduce engine emission and improve driveability.

The engine controller demands slightly richer air-fuel mixtures and higher idle speeds until the engine reaches normal operating temperature.

The coolant sensor input is also used for cooling fan control.

DETONATION SENSOR (KNOCK SENSOR)—TURBO III ENGINE

Turbo III engines use a detonation sensor. The sensor generates a signal when spark knock occurs in the combustion chambers. The sensor is mounted on the intake manifold behind the PCV breather (Fig. 32). The sensor provides information used by the engine controller to modify spark advance and boost schedules in order to eliminate detonation.




Fig. 32 Detonation Sensor—Turbo III Engine

MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR

The MAP sensor reacts to absolute pressure in the intake manifold and provides an input voltage to the engine controller. As engine load changes, manifold pressure varies. The changes in engine load cause the MAP output voltage to change. The change in MAP sensor output voltage results in a different input voltage to the engine controller.

The input voltage level supplies the engine controller with information relating to ambient barometric pressure during engine start-up (cranking) and engine load while its operating. The engine controller uses this input along with inputs from other sensors to adjust air-fuel mixture.

On Turbo III engines, the MAP sensor is mounted to the front right fender (Fig. 33). On 3.3L and 3.8L engines, the MAP sensor (Fig. 34) is mounted to the

side of the intake manifold, below the positive crankcase ventilation (PCV) valve. The sensor is connected to the engine controller electrically.




Fig. 33 MAP Sensor—Turbo III Engine




Fig. 34 Map Sensor—3.3L and 3.8L Engines

AUTO SHUTDOWN (ASD) RELAY AND FUEL PUMP RELAY

The engine controller operates the auto shutdown (ASD) relay and fuel pump relay through one ground path. The controller operates the relays by switching the ground path on and off. Both relays turn on and off at the same time.

The ASD relay connects battery voltage to the fuel injector and ignition coil. The fuel pump relay connects battery voltage to the fuel pump and oxygen sensor heating element.

The engine controller turns the ground path off when the ignition switch is in the Off position. Both relays are off. When the ignition switch is in the On

or Crank position, the engine controller monitors the camshaft and crankshaft signals. From these inputs, the controller determines engine speed and ignition timing (coil dwell). If the engine controller does not receive a distributor signal when the ignition switch is in the Run position, it will de-energize both relays. When the relays are de-energized, battery voltage is not supplied to the fuel injector, ignition coil, fuel pump and oxygen sensor heating element.

On AC, AG, AJ and AY models, the ASD relay and fuel pump relay are located in the power distribution center (Fig. 35, 36, 37, or 38).

On AA and AP models, the ASD relay and fuel pump relay are mounted on the drivers side fender well, next to the strut tower (Fig. 39).




Fig. 35 Power Distribution Center (PDC) (AC Body)




Fig. 36 Relay Identification (AC Body)




Fig. 37 Power Distribution Center (PDC) (AG Body)




Fig. 38 Relay Identification (AG Body)




Fig. 39 Relay Identification (AA and AP Bodies)

TURBO III, 3.3L AND 3.8L IGNITION SYSTEM—DIAGNOSTIC PROCEDURES

INDEX

	page		page
Check Coil Test—3.3L and 3.8L Engines	38	Failure to Start Test—Turbo III Engine	37
Check Coil Test—Turbo III Engine	37	Manifold Absolute Pressure (MAP) Sensor Test	40
Coolant Temperature Sensor Test	40	Testing for Spark at Coil—3.3L and 3.8L Engines	38
Crankshaft Sensor and Camshaft Sensor Tests	40	Testing for Spark at Coil—Turbo III Engine	37
Failure to Start Test	39		

TESTING FOR SPARK AT COIL—TURBO III ENGINE

WARNING: THE DIRECT IGNITION SYSTEM GENERATES APPROXIMATELY 40,000 VOLTS. PERSONAL INJURY COULD RESULT FROM CONTACT WITH THIS SYSTEM.

The coil pack contains 2 independent coils. Each coil must be checked individually.

CAUTION: Spark plug wire damage may occur if the spark plug is moved more than 1/4 inch away from the engine ground.

Remove the cable from number 1 spark plug. Insert a clean spark plug into the spark plug boot, and ground plug to the engine (Fig. 1).




Fig. 1 Testing For Spark

CAUTION: Spark plug wire damage may occur if the spark plug is moved more than 1/4 inch away from the engine ground.

Crank the engine and look for spark across the electrodes of the spark plug. Repeat the above test for the remaining cylinders. If there is no spark during the cylinder tests, proceed to the failure to start test.

If one or more cylinders have irregular, weak, or no spark, proceed to Check Coil Test.

CHECK COIL TEST—TURBO III ENGINE

Cylinders 1 & 4, and 2 & 3 are grouped together.

(1) Remove the ignition cables and measure the resistance of the cables. Resistance must be between 3,000 to 12,000 ohms per foot of cable. Replace any cable not within tolerance.

(2) Disconnect the electrical connector from the coil pack (Fig. 2).




Fig. 2 Ignition Coil Electrical Connection—Turbo III Engine

(3) Measure the primary resistance of each coil. At the coil, connect an ohmmeter between the B+ pin and the pin corresponding to the cylinders in question (Fig. 3). Resistance on the primary side of each coil should be 0.5-0.7 ohm. Replace the coil if resistance is not within tolerance.

(4) Remove ignition cables from the secondary towers of the coil. Measure the secondary resistance of the coil between the towers of each individual coil (Fig. 4). Secondary resistance should be 11,600 to 15,800 ohms. Replace the coil if resistance is not within tolerance.

FAILURE TO START TEST—TURBO III ENGINE

(1) Determine that sufficient battery voltage (12.4 volts nominal) is present for the cranking and ignition systems.




Fig. 3 Ignition Coil Terminal Identification




Fig. 4 Checking Ignition Coil Secondary Resistance—Turbo III Engines

(2) Connect a voltmeter to the wiring harness coil connector at the B+ pin (Fig. 5).




Fig. 5 Wiring Harness Coil Connector—Turbo III Engine

(3) Crank the engine for 5 seconds while monitoring the voltage at the B+ connector terminal. If the voltage remains near zero during the entire period of cranking, check the auto shutdown relay and engine controller. Refer to DRB II tester and the appropriate Powertrain Diagnostic Procedures manual. Refer to Group 14 for description of On Board Diagnostics.

(4) If voltage is at near-battery voltage, and drops to zero after 1-2 seconds of cranking, check the camshaft sensor and crankshaft sensor and their circuits. Refer to the DRB II tester and the appropriate Power-

train Diagnostic Procedure manual. Refer to Group 14 for a description of On-Board Diagnostics.

(5) If voltage remains at near-battery voltage during the entire 5 seconds, turn the key off, remove the engine controller 60-way connector. Check the 60-way for any terminals loose from the connector (push-out).

TESTING FOR SPARK AT COIL—3.3L AND 3.8L ENGINES

WARNING: THE ENGINE DIRECT IGNITION SYSTEM GENERATES APPROXIMATELY 40,000 VOLTS. PERSONAL INJURY COULD RESULT FROM CONTACT WITH THIS SYSTEM.

The coil pack contains 3 independent coils. Each coil must be checked individually.

CAUTION: Spark plug wire damage may occur if the spark plug is moved more than 1/4 inch away from the engine ground.

Remove the cable from number 2 spark plug. Insert a clean spark plug into the spark plug boot, and ground plug to the engine (Fig. 1).

Crank the engine and look for spark across the electrodes of the spark plug. Repeat the above test for the five remaining cylinders. If there is no spark during all cylinder tests, proceed to the failure to start test.

If one or more tests indicate irregular, weak, or no spark, proceed to Check Coil Test.

WARNING: THE DIRECT IGNITION SYSTEM GENERATES APPROXIMATELY 40,000 VOLTS. PERSONAL INJURY COULD RESULT FROM CONTACT WITH THIS SYSTEM.

CHECK COIL TEST—3.3L AND 3.8L ENGINES

Coils one fires cylinders 1 and 4, coil two fires cylinders 2 and 5, coil three fires cylinders three and six.

Each coil tower is labeled with the number of the corresponding cylinder.

(1) Remove the ignition cables and measure the resistance of the cables. Resistance must be between 3,000 to 12,000 ohms per foot of cable. Replace any cable not within tolerance.

(2) Disconnect the electrical connector from the coil pack (Fig. 6).

(3) Measure the primary resistance of each coil. At the coil, connect an ohmmeter between the B+ pin and the pin corresponding to the cylinders in question (Fig. 7). Resistance on the primary side of each coil should be 0.5 - 0.7 ohm. Replace the coil if resistance is not within tolerance.




Fig. 6 Ignition Coil Electrical Connection




Fig. 7 Ignition Coil Terminal Identification

(4) Remove ignition cables from the secondary towers of the coil. Measure the secondary resistance of the coil between the towers of each individual coil (Fig. 8). Refer to the Coil Specifications Chart in the Specifications section of this group. Replace the coil if resistance is not within tolerance.




Fig. 8 Checking Ignition Coil Secondary Resistance
FAILURE TO START TEST

This no-start test checks the camshaft sensor and crankshaft sensor.

The engine controller supplies 9 volts to the camshaft sensor and crankshaft sensor through one circuit. If the 9-volt supply circuit shorts to ground, neither sensor will produce a signal (output voltage to the engine controller).

When the ignition key is turned and **left in the On position**, the engine controller automatically energizes the auto shutdown (ASD) relay. However, the controller de-energizes the relay within one second because it has not received a crankshaft signal indicating engine rotation.

During cranking, the ASD relay will not energize until the engine controller receives a crankshaft signal. Secondly, the ASD relay remains energized only if the controller senses a camshaft sensor signal immediately after detecting the crankshaft sensor signal.

(1) Check battery voltage. Voltage should approximately 12.66 volts or higher to perform failure to start test.

(2) Disconnect the harness connector from the coil pack (Fig. 2).

(3) Connect a test light to the B+ (battery voltage) terminal of the coil electrical connector and ground. The wire for the B+ terminal is dark green with a black tracer.

(4) Turn the ignition key to the **ON position**. The test light should flash On and then Off. **Do not turn the Key to off position, leave it in the On position.**

(a) If the test light flashes momentarily, the engine controller grounded the auto shutdown (ASD) relay. Proceed to step 5.

(b) If the test light did not flash, the ASD relay did not energize. The cause is either the relay or one of the relay circuits. Use the DRB II to test the ASD relay and circuits. Refer to the appropriate Powertrain Diagnostics Procedure Manual. Refer to the wiring diagrams section for circuit information.

(5) Crank the engine. If the key was placed in the off position after step 4, place the key in the On position before cranking. Wait for the test light to flash once, then crank the engine.

(a) If the test light momentarily flashes during cranking, the engine controller is not receiving a camshaft sensor signal. Use the DRB II to test the camshaft sensor and sensor circuits. Refer to the appropriate Powertrain Diagnostics Procedure Manual. Refer to the wiring diagrams section for circuit information.

(b) If the test light did not flash during cranking, unplug the camshaft sensor connector. Turn the ignition key to the off position. Turn the key to the On position, wait for the test light to momentarily flash once, then crank the engine. If the test light momentarily flashes, the camshaft sensor is shorted and must be replaced. If the light did not

flash, the cause of the no-start is in either the crankshaft sensor/camshaft sensor 9-volt supply circuit, or the crankshaft sensor 5-volt output or ground circuits. Use the DRB II to test the crankshaft sensor and the sensor circuits. Refer to the appropriate Powertrain Diagnostics Procedure Manual. Refer to the wiring diagrams section for circuit information.

COOLANT TEMPERATURE SENSOR TEST


(1) With key off, disconnect wire connector from coolant temperature sensor (Fig. 9).

(2) Connect one lead of ohmmeter to one terminal of coolant temperature sensor.

(3) Connect the other lead of ohmmeter to remaining terminal of coolant temperature sensor. The ohmmeter should read as follows;

- Engine/Sensor hot at normal operating temperature around 200°F should read approximately 700 to 1,000 ohms.
- Engine/Sensor at room temperature around 70°F, ohmmeter should read approximately 7,000 to 13,000 ohms.

To test the coolant temperature sensor circuits, refer to the DRB II tester and the appropriate Powertrain Diagnostic Service manual.



RR8DG20

Fig. 9 Coolant Temperature Sensor Test

MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR TEST

Refer to the appropriate Powertrain Diagnostic Procedure manual.

CRANKSHAFT SENSOR AND CAMSHAFT SENSOR TESTS

Refer to the appropriate Powertrain Diagnostic Procedure manual.

TURBO III, 3.3L AND 3.8L IGNITION SYSTEMS—SERVICE PROCEDURES

INDEX

	page		page
Camshaft Sensor Service—Turbo III Engine	46	Idle RPM Test	43
Camshaft Sensor—3.3L and 3.8L Engines	46	Ignition Coil Service—Turbo III Engine	47
Coolant Temperature Sensor—3.3L and 3.8L Engines	41	Ignition Coil—3.3L and 3.8L Engine	47
Coolant Temperature Sensor—Turbo III	41	Manifold Absolute Pressure (MAP) Sensor—3.3L and 3.8L Engines	47
Crankshaft Sensor—3.3L and 3.8L Engines	45	Manifold Absolute Pressure (MAP) Sensor—Turbo III Engine	47
Crankshaft Sensor—Turbo III Engine	45	Spark Plug Cable Service	42
Detonation (Knock) Sensor—Turbo III Engines	42	Spark Plug Service	43
Engine Controller	41		

ENGINE CONTROLLER

REMOVAL

- (1) Remove air cleaner duct or air cleaner assembly.
- (2) Remove battery.
- (3) Remove engine controller mounting screws (Fig. 1).
- (4) Remove 60-way connector from engine controller. Remove controller.




Fig. 1 Removing the Engine Controller

INSTALLATION

- (1) Connect 60-Way connector to engine controller (Fig. 1).
- (2) Install Engine Controller on inside left front fender. Install and tighten mounting screws.
- (3) Install the battery.
- (4) Install air cleaner duct or air cleaner assembly.

COOLANT TEMPERATURE SENSOR—TURBO III

The coolant sensor threads into the thermostat housing (Fig. 2).

REMOVAL

- (1) Drain cooling system until coolant level is below thermostat housing. Refer to Group 7, Cooling System.
- (2) Remove air cleaner fresh air duct.
- (3) Disconnect electrical connector from coolant sensor.
- (4) Remove sensor from thermostat housing (Fig. 2).




Fig. 2 Coolant Temperature Sensor—Turbo III

INSTALLATION

- (1) Install sensor. Tighten to 7 N•m (60 in. lbs.) torque.
- (2) Connect electrical connector to coolant sensor
- (3) Fill cooling system. Refer to Group 7, Cooling System.
- (4) Install fresh air duct.

COOLANT TEMPERATURE SENSOR—3.3L AND 3.8L ENGINES

The coolant temperature sensor is located below the ignition coil (Fig. 3).




Fig. 3 Coolant Temperature Sensor

REMOVAL

- (1) Drain cooling system until coolant level is below coolant sensor. Refer to Group 7, Cooling System.
- (2) Remove electrical connector from coil (Fig. 4).




Fig. 4 Ignition Coil Removal

- (3) Remove coil mounting screws.
- (4) Rotate coil away from coolant temperature sensor.
- (5) Disconnect electrical connector from coolant temperature sensor.
- (6) Remove sensor from engine.

INSTALLATION

- (1) Tighten the coolant sensor to 7 N•m (60 in. lbs.) torque.
- (2) Connect electrical connector to sensor.
- (3) Fill cooling system. Refer to Group 7, Cooling System.

- (4) Install coil. Tighten coil mounting screws to 12 N•m (105 in. lbs.) torque.

- (5) Connect electrical connector to coil.

DETONATION (KNOCK) SENSOR—TURBO III ENGINES

The detonation sensor is located on the intake manifold, behind the PCV breather (Fig. 5).




Fig. 5 Detonation Sensor—Turbo III Engine

REMOVAL

- (1) Remove PCV breather.
- (2) Remove harness connector from the detonation sensor.
- (3) Remove detonation sensor.

INSTALLATION

- (1) Install detonation sensor. Tighten sensor to 9 N•m (7 ft. lbs) torque.
- (2) Connect harness connector to detonation sensor.
- (3) Install PCV breather.

SPARK PLUG CABLE SERVICE

Clean high tension cables with a cloth moistened with a non-flammable solvent. Wipe the cables dry. Check for brittle or cracked insulation.

When testing cables for punctures and cracks with an oscilloscope, follow the instructions of the equipment manufacturers.

CAUTION: Do not leave any one spark plug cable disconnected any longer than necessary during test or possible heat damage to catalytic converter will occur. Total test time must not exceed ten minutes.

If an oscilloscope is not available, cables can be tested as follows:

- (1) With the engine not running, connect one end of a test probe to a good ground. Use a probe made of insulated wire and insulated alligator clips on each end.

WARNING: THE ENGINE DIRECT IGNITION SYSTEM GENERATES APPROXIMATELY 40,000 VOLTS. PERSONAL INJURY COULD RESULT FROM CONTACT WITH THIS SYSTEM.

(2) With engine running, move test probe along entire length of all cables (approximately 0 to 1/8 inch gap). If punctures or cracks are present there will be a noticeable spark jump from the faulty area to the probe. Cracked, leaking or faulty cables should be replaced.

Use the following procedure when removing the high tension cable from the spark plug. First, remove the cable from the retaining bracket. Then grasp the terminal as close as possible to the spark plug. Rotate the cover (boot) slightly and pull straight back. **Do not use pliers and do not pull the cable at an angle.** Doing so will damage the insulation, cable terminal or the spark plug insulator. **Wipe spark plug insulator clean before reinstalling cable and cover.**

Resistance cables are identified by the words **Electronic Suppression**.

Use an ohmmeter to check cables for opens, loose terminals or high resistance.

- Remove cable from spark plug.
- Remove cable from the coil tower.
- Connect the ohmmeter between spark plug end terminal and the coil end terminal. Resistance should be within tolerance shown in the cable resistance chart. If resistance is not within tolerance, replace cable assembly. Test all spark plug cables in same manner.

CABLE RESISTANCE CHART

MINIMUM	MAXIMUM
250 Ohms Per Inch	1000 Ohms Per Inch
3000 Ohms Per Foot	12,000 Ohms Per Foot

J908D-43

SPARK PLUG SERVICE

When replacing the spark plug cables, route the cables correctly and secure them in the appropriate retainers. Incorrectly routed cables can cause the radio to reproduce ignition noise. It can also cause cross ignition of the spark plugs or short circuit the cables to ground.

SPARK PLUG REMOVAL

Always remove cables by grasping at boot, rotating the boot 1/2 turn, and pulling straight back in a steady motion.


(1) Prior to removing the spark plug spray compressed air around the spark plug hole and the area around the spark plug.

(2) Remove the spark plug using a quality socket with a rubber or foam insert.

(3) Inspect the spark plug condition. Refer to Spark Plug Condition in this section.

SPARK PLUG GAP ADJUSTMENT

Check the spark plug gap with a gap gauge. If the gap is not correct, adjust it by bending the ground electrode (Fig. 6).



J908D-10

Fig. 6 Setting Spark Plug Gap—Typical

SPARK PLUG INSTALLATION

- To avoid cross threading, start the spark plug into the cylinder head by hand.
- Tighten spark plugs to 28 N•m (20 ft. lbs.) torque.
- Install spark plug cables over spark plugs.

IDLE RPM TEST


WARNING: BE SURE TO APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING ANY ENGINE RUNNING TESTS.

Engine idle set rpm should be **tested and recorded as it is when the vehicle is first brought into shop for testing**. This will assist in diagnosing complaints of engine stalling, creeping and hard shifting on vehicles equipped with automatic transmissions.

Proceed to the Throttle Body Minimum Airflow procedures.

THROTTLE BODY MINIMUM AIR FLOW CHECK PROCEDURE—TURBO III

- (1) Warm engine in neutral until the cooling fan has cycled on and off at least once.
- (2) Shut off engine.
- (3) Hook-up Tachometer.
- (4) Disconnect the PCV valve hose from the nipple on the intake manifold.
- (5) Attach air metering fitting, special tool #6457 (0.125 inch orifice), to the intake manifold PCV nipple (Fig. 7).



9114-68

Fig. 7 Air Metering Fitting #6457

- (6) Disconnect 3/16 inch manifold vacuum purge line from the top of the throttle body. Cap the 3/16 inch throttle body nipple.
- (7) Connect Diagnostic Readout Box II (DRB II).
- (8) Restart engine. Allow engine to idle for at least one minute.
- (9) Using the DRB II, access Min. Airflow Idle Spd. The following will then occur:
 - AIS motor will fully close.
 - Idle spark advance will become fixed.
 - Engine RPM will be displayed on Diagnostic Readout Box II (DRB II).
- (10) Check idle RPM with tachometer, if idle RPM is within the below specification then the throttle body minimum airflow is set correctly.

IDLE SPECIFICATIONS

Odometer Reading	Idle RPM
Below 1000 Miles	600-1150 RPM
Above 1000 Miles	650-1150 RPM

9214-102

If the idle RPM is not within specification, replace the throttle body.

- (11) Shut off engine.

- (12) Remove air metering fitting 6457 from the intake manifold PCV nipple. Connect the PCV hose to the nipple.

- (13) Remove DRB II.

- (14) Disconnect tachometer.

- (15) Reconnect purge line to throttle body.

THROTTLE BODY MINIMUM AIR FLOW CHECK PROCEDURE—3.3L AND 3.8L ENGINES

- (1) Warm engine in Park or Neutral until the cooling fan has cycled on and off at least once.
- (2) Ensure that all accessories are off.
- (3) Shut off engine.
- (4) Disconnect the PCV valve hose from the intake manifold nipple.
- (5) Attach Air Metering Fitting #6457 (0.125 in. orifice) to the intake manifold PCV nipple (Fig. 7).
- (6) Disconnect the 3/16 inch idle purge line from the throttle body nipple. Cap the 3/16 inch nipple.
- (7) Connect Diagnostic Readout Box II (DRB II).
- (8) Restart the engine. Allow engine to idle for at least one minute.
- (9) Using the DRBII, access Min. Airflow Idle Spd.
- (10) The following will then occur:
 - AIS motor will fully close.
 - Idle spark advance will become fixed.
 - Engine RPM will be displayed on DRB II.
- (11) If idle RPM is within the range shown in the Idle Specification chart, throttle body minimum airflow is set correctly.

IDLE SPECIFICATIONS

Odometer Reading	Idle RPM
Below 1000 Miles	650-950 RPM
Above 1000 Miles	700-950 RPM

9114-73

- (12) If idle RPM is not within specifications, shut off the engine and clean the throttle body as follows:

- (a) Remove the throttle body from engine.

WARNING: CLEAN THROTTLE BODY IN A WELL VENTILATED AREA. WEAR RUBBER OR BUTYL GLOVES, DO NOT LET MOPAR PARTS CLEANER COME IN CONTACT WITH EYES OR SKIN. AVOID INGESTING THE CLEANER. WASH THOROUGHLY AFTER USING CLEANER.

- (b) While holding the throttle open, spray the entire throttle body bore and the manifold side of the

throttle plate with Mopar Parts Cleaner. **Only use Mopar Parts Cleaner to clean the throttle body.**

(c) Using a soft scuff pad, clean the top and bottom of throttle body bore and the edges and manifold side of the throttle blade. **The edges of the throttle blade and portions of the throttle bore that are closest to the throttle blade when is closed, must be free of deposits.**

(d) Use compressed air to dry the throttle body.

(e) Inspect throttle body for foreign material.

(f) Install throttle body on manifold.

(g) Repeat steps 1 through 14. If the minimum air flow is still not within specifications, the problem is not caused by the throttle body.

(13) Shut off engine.

(14) Remove Air Metering Fitting #6457 from the intake manifold PCV nipple. Reinstall the PCV valve hose.

(15) Uncap the throttle body idle purge nipple and connect the idle purge line.

(16) Remove DRB II.

IGNITION TIMING PROCEDURE

Ignition timing cannot be changed or set on Turbo III, 3.3L or 3.8L engines. For diagnostic information, refer to the DRB II tester and the appropriate Powertrain Diagnostics Procedures manual.

CRANKSHAFT SENSOR—TURBO III ENGINE

REMOVAL

- (1) Remove throttle body.
- (2) Remove inter-cooler to turbo-charger air hose.
- (3) Disconnect crank timing sensor pick-up lead at wiring harness connector (Fig. 8).




Fig. 8 Crankshaft Sensor Service—Turbo III Engine

- (4) Remove crank timing sensor retaining bolt.
- (5) Pull crank timing sensor straight up out of the transaxle housing.

INSTALLATION

(1) Install sensor in transaxle. Push sensor down until contact is made with the transaxle housing. Hold the sensor in this position. Install and tighten retaining bolt to 16 N•m (145 in. lbs.) torque.

(2) Connect electrical connector to sensor.

CRANKSHAFT SENSOR—3.3L AND 3.8L ENGINES

REMOVAL

(1) Disconnect crankshaft timing sensor electrical connector from the wiring harness connector (Fig. 9).




Fig. 9 Crankshaft Timing Sensor—3.3L and 3.8L Engines

- (2) Remove crankshaft timing sensor retaining bolt.
- (3) Pull crankshaft timing sensor straight up out of the transaxle housing.

INSTALLATION

If installing the original sensor, clean off the old spacer on the sensor face. A NEW SPACER must be attached to the sensor face before installation. If the sensor is being replaced, confirm that the paper spacer is attached to the face of the new sensor (Fig. 10).




Fig. 10 Crankshaft Sensor and Spacer

- (1) Install sensor in transaxle and push sensor down until contact is made with the drive plate.

While holding the sensor in this position, install and tighten the retaining bolt to 12 N•m (105 in. lbs.) torque.

(2) Connect crankshaft timing sensor electrical connector to the wiring harness connector.

CAMSHAFT SENSOR SERVICE—TURBO III ENGINE

REMOVAL

(1) Disconnect cam reference sensor lead at wiring harness connector (Fig. 11).




Fig. 11 Camshaft Sensor Location—Turbo III Engines

(2) Remove camshaft timing sensor retaining bolt and remove sensor.

INSTALLATION

If installing the original sensor, clean off the old spacer on the sensor face. A NEW SPACER must be attached to the face before installation. If the sensor is being replaced, confirm that the paper spacer is attached to the face (Fig. 12).




Fig. 12 Camshaft Sensor—Turbo III Engine

(1) Install sensor in the cylinder head and push sensor down until contact is made with the camshaft gear. While holding the sensor in this position, install and tighten the retaining bolt 16 N•m (145 in. lbs.) torque.

(2) Connect electrical connector to the camshaft sensor.

CAMSHAFT SENSOR—3.3L AND 3.8L ENGINES

REMOVAL

(1) Disconnect camshaft reference sensor electrical connector from the wiring harness connector (Fig. 13).




Fig. 13 Camshaft Sensor Location—3.3L and 3.8L Engine

(2) Loosen camshaft timing sensor retaining bolt enough to allow slot in sensor to slide past the bolt.

(3) Pull sensor up out of the chain case cover. **Do not pull on the sensor lead.** There is an O-ring on the sensor case. The O-ring may make removal difficult. A light tap to top of sensor prior to removal may reduce force needed for removal.

INSTALLATION

If installing the original sensor, clean off the old spacer on the sensor face. A NEW SPACER must be attached to the face before installation. Inspect O-ring for damage, replace if necessary. If the sensor is being replaced, confirm that the paper spacer is attached to the face and O-ring is positioned in groove of the new sensor (Fig. 14).

(1) Apply a couple drops of clean engine oil to the O-ring prior to installation. Install sensor in the chain case cover and push sensor down until contact is made with the cam timing gear. While holding the sensor in this position, install and tighten the retaining bolt 12 N•m (105 in. lbs.) torque.

(2) Connect camshaft reference sensor electrical connector to harness connector. Position connector away from the accessory belt.




Fig. 14 Camshaft Sensor—3.3L and 3.8L Engines

IGNITION COIL SERVICE—TURBO III ENGINE

- (1) Remove spark plug cables from coil (Fig. 15).




Fig. 15 Ignition Coil Service—Turbo III

- (2) Remove electrical connector from coil pack.
- (3) Remove ignition coil fasteners.
- (4) Reverse the above procedure for installation. Tighten fasteners to 12 N•m (105 in. lbs.) torque.

IGNITION COIL—3.3L AND 3.8L ENGINE

- (1) Remove spark plug cables from coil (Fig. 16).
 - (2) Remove ignition coil electrical connector.
 - (3) Remove ignition coil mounting screws.
 - (4) Remove ignition coil.
- Reverse the above procedure for installation. Tighten mounting screws to 12 N•m (105 in. lbs.) torque.

MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—TURBO III ENGINE

The map sensor mounts to the right front fender (Fig. 17).

- (1) Remove vacuum hose from MAP sensor.
- (2) Remove MAP sensor mounting screws.
- (3) Remove electrical connector from sensor.
- (4) Reverse procedure for installation.




Fig. 16 Ignition Coil Removal and Installation




Fig. 17 MAP Sensor—Turbo III Engine

MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—3.3L AND 3.8L ENGINES

The alignment of the MAP sensor is critical to the sensors performance. The top of the sensor is marked This Side Up (Fig. 18).

- (1) Disconnect electrical connector from MAP sensor.
- (2) Remove sensor by unscrewing from the intake manifold (Fig. 18).
- (3) Reverse the above procedure for installation.




Fig. 18 Manifold Absolute Pressure Sensor

IGNITION SWITCH

IGNITION SWITCH AND KEY CYLINDER SERVICE

The ignition switch is located on the steering column. The Key In Switch is located in the ignition switch module. For diagnosis of the Key In Switch, refer to Section 8M.

IGNITION SWITCH DESIGNATIONS



IGNITION SWITCH CONNECTOR LOOKING INTO SWITCH

WIRE CAVITY	WIRE COLOR	APPLICATION
1	YELLOW	STARTER RELAY
2	DARK BLUE	IGNITION RUN/START
3	GRAY/BLACK	BRAKE WARNING LAMP
4	PINK/BLACK	IGNITION SWITCH BATTERY FEED
5	BLACK/ORANGE	RUN ACCESSORY
6	BLACK/WHITE	ACCESSORY
7	RED	IGNITION SWITCH BATTERY FEED

928D-10

REMOVAL

If the vehicle has a floor mounted gear shifter, place the selector in the Park position.

- (1) Disconnect negative cable from battery.
- (2) If the vehicle has a tilt column, remove the tilt lever by turning it counterclockwise.
- (3) Remove upper and lower covers from steering column.
- (4) Remove ignition switch mounting screws. Use tamper proof torx bit Snap-on TTXR15A2, TTXR20A2 or equivalent to remove the screws (Fig. 1).




Fig. 1 Ignition Switch Screw Removal

- (5) Gently pull switch away from the column. Release connector locks on the 7 terminal wiring connector, then remove the connector from the ignition switch.
- (6) Release connector lock on the 4 terminal connector, then remove the connector from the ignition switch.
- (7) To remove the key cylinder from the ignition switch:
 - (a) Insert key in the ignition switch. Turn the

key to the LOCK position. Using a small screwdriver, depress the key cylinder retaining pin until it is flush with the key cylinder surface (Fig. 2).




Fig. 2 Key Cylinder Retaining Pin

(b) Rotate the key clockwise to the OFF position. The key cylinder will unseat from the ignition switch (Fig. 3). When the key cylinder is unseated, it will be approximately 1/8 inch away from the ignition switch halo light ring. **Do not attempt to remove the key cylinder at this time.**




Fig. 3 Unseated Key Cylinder

(c) With the key cylinder in the unseated position, rotate the key counterclockwise to the lock position and remove the key.

(d) Remove key cylinder from ignition switch (Fig. 4).




Fig. 4 Key Cylinder Removal

INSTALLATION

If the vehicle has a floor mounted gear shifter, place the selector in the Park position.

(1) Connect electrical connectors to the ignition switch. Make sure that the switch locking tabs are fully seated in the wiring connectors.

(2) Before attaching the ignition switch to a tilt steering column, the transmission shifter must be in the Park position. Also the park lock dowel pin and the column lock flag must be properly indexed before installing the switch (Fig. 5).




Fig. 5 Ignition Switch View From Column

(a) Place the transmission shifter in the PARK position.

(b) Place the ignition switch in the lock position. The switch is in the lock position when the column lock flag is parallel to the ignition switch terminals (Fig. 5).

(c) Position ignition switch park lock dowel pin so it will engage the steering column park lock slider linkage (Fig. 6).




Fig. 6 Ignition Switch Mounting Pad

(d) Apply a light coating of grease to the column lock flag and the park lock dowel pin.

(3) Place the ignition switch against the lock housing opening on the steering column. Ensure ignition switch park lock dowel pin enters the slot in the park lock slider linkage in the steering column.

(4) Install ignition switch mounting screws. Tighten screws to 2 N•m (17 in. lbs.) torque.

(5) Install steering column covers. Tighten screws to 2 N•m (17 in. lbs.) torque.

(6) If the vehicle is equipped with a tilt steering column, install the tilt lever.

(7) To install the ignition key in the lock cylinder:

(a) With the key cylinder and the ignition switch in the Lock position, insert the key cylinder into the ignition switch until it bottoms.

(b) Insert ignition key into lock cylinder. While gently pushing the key cylinder in toward the ignition switch, rotate the ignition key until to the end of travel.

(c) Connect negative cable to battery.


(8) Check for proper operation of the halo light, shift lock (if applicable), and column lock. Also check for proper operation of the ignition switch accessory, lock, off, run, and start positions.

SPECIFICATIONS


GENERAL INFORMATION

The following specifications are published from the latest information available at the time of publication. If anything differs from the specifications on the Vehicle Emission Control Information Label, use the specifications on the label.


SPARK PLUG WIRE ROUTING—2.2L TBI, 2.5L TBI AND TURBO I ENGINES




SPARK PLUG WIRE ROUTING—3.0L ENGINE



SPARK PLUG WIRE ROUTING—TURBO III ENGINE



SPARK PLUG WIRE ROUTING—3.3L AND 3.8L ENGINES



3.3L/3.8L ENGINE DIRECT IGNITION SYSTEM

Ignition Timing is <u>not</u> adjustable for the Direct Ignition System (DIS)	
Engine	3.3L
Engine Code	EGA
Transmission	Automatic
Firing Order	1-2-3-4-5-6

918D-50

DISTRIBUTORS

ENGINE	TRANSMISSION	ROTATION	BASIC TIMING	SPARK ADVANCE AT 2000 RPM	SHAFT SIDE PLAY	SHAFT END PLAY
2.2L	Manual and Automatic	Clockwise	12° BTDC ± 2° Manual and Automatic Trans.	16° ± 4° Automatic 21° ± 4° Manual	Not to Exceed 0.1 mm (0.004 in.)	0.03 to 0.75 mm (0.001 to 0.030 in.)
2.5L	Manual and Automatic	Clockwise	12° BTDC ± 2° Manual and Automatic Trans.	21° ± 4° Manual and Automatic Trans.	Not to Exceed 0.1 mm (0.004 in.)	0.03 to 0.75 mm (0.001 to 0.030 in.)
Turbo I	Manual and Automatic	Clockwise	12° BTDC ± 2° Manual and Automatic Trans.	30° ± 4° Automatic 25° ± 4° Manual	Not to Exceed 0.1 mm (0.004 in.)	0.03 to 0.75 mm (0.001 to 0.030 in.)
3.0L	Automatic	Clockwise	12° BTDC ± 2°	38° Automatic 34° Manual		

928D-20

IGNITION COILS

ENGINE	COIL MANUFACTURER	PRIMARY RESISTANCE AT 21°C - 27°C (70°F - 80°F)	SECONDARY RESISTANCE AT 21°C - 27°C (70°F - 80°F)
2.2L/2.5L	Diamond	0.97 to 1.18 Ohms	11,300 to 15,300 Ohms
2.2L/2.5L	Toyodenso	0.95 to 1.20 Ohms	11,300 to 13,300 Ohms
Turbo I	Diamond	0.97 to 1.18 Ohms	11,300 to 15,300 Ohms
Turbo I	Toyodenso	0.95 to 1.20 Ohms	11,300 to 13,300 Ohms
Turbo III	Diamond	0.52 to 0.63 Ohms	11,600 to 15,800 Ohms
3.0L	Diamond	0.97 to 1.18 Ohms	11,000 to 15,300 Ohms
3.3L/3.8L	Diamond	0.52 to 0.63 Ohms	11,600 to 15,800 Ohms
3.3L/3.8L	Toyodenso	0.51 to 0.61 Ohms	11,500 to 13,500 Ohms

928D-19

SPARK PLUGS

ENGINE	SPARK PLUG	GAP	THREAD SIZE
2.2L	RN12YC	0.033 to 0.038 in.	14 mm (3/4 in.) reach
2.5L	RN12YC	0.033 to 0.038 in.	14 mm (3/4 in.) reach
Turbo I	RN12YC	0.035 to 0.038 in.	14 mm (3/4 in.) reach
Turbo III	RN9YC	0.033 to 0.038 in.	14 mm (3/4 in.) reach
3.0L	RN11YC4	0.039 to 0.044 in.	14 mm (3/4 in.) reach
3.0L	BPR5ES-11	0.039 to 0.044 in.	14 mm (3/4 in.) reach
3.3L	RN16YC5	0.048 to 0.053 in.	14 mm (3/4 in.) reach
3.8L	RN16YC5	0.048 to 0.053 in.	14 mm (3/4 in.) reach

928D-18

TORQUE

DESCRIPTION	TORQUE
Camshaft sensor bolt - Turbo III	16 N•m (145 in. lbs.)
Camshaft sensor bolt - 3.3L and 3.8L	12 N•m (105 in. lbs.)
Crankshaft sensor bolt - Turbo III	16 N•m (145 in. lbs.)
Crankshaft sensor bolt - 3.3L and 3.8L	12 N•m (105 in. lbs.)
Coolant sensor - 2.2L, 2.5L and Turbo I	28 N•m (20 ft. lbs.)
Coolant sensor - 3.0L	7 N•m (60 in. lbs.)

DESCRIPTION	TORQUE
Coolant Sensor - Turbo III	7 N•m (60 in. lbs.)
Coolant Sensor - 3.3L and 3.8L	7 N•m (60 in. lbs.)
Detonation sensor - Turbo III	9 N•m (7 ft. lbs.)
Ignition coil mounting screws - 2.2L, 2.5L, Turbo I	10 N•m (85 in. lbs.)
Ignition coil mounting screws - 3.3L and 3.8L	12 N•m (105 in. lbs.)
Ignition coil bracket - 3.0L	10 N•m (96 in. lbs.)
Spark Plugs - All Engines	28 N•m (20 ft. lbs.)

928D-21