

CHRYSLER CORPORATION

ELECTRICAL—FUEL— EMISSION SYSTEMS SERVICE MANUAL

1992 FRONT WHEEL DRIVE PASSENGER VEHICLES

To order the special service tools used and illustrated, please refer to the instructions on inside back cover.



NO PART OF THIS PUBLICATION MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM, OR TRANSMITTED, IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING, OR OTHERWISE, WITHOUT THE PRIOR WRITTEN PERMISSION OF CHRYSLER CORPORATION.

Chrysler Corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

Litho in U.S.A. Copyright © 1991 Chrysler Corporation 30M0891

NEXT PAGE 

FOREWORD

The information contained in this service manual has been prepared for the professional automotive technician involved in daily repair operations. This manual does not cover theory of operation, which is addressed in service training material.

Tightening torques are provided as a specific value throughout this manual. This value represents the midpoint of the acceptable engineering torque range for a given fastener application. These torque values are intended for use in service assembly and installation procedures using the correct OEM fasteners. When replacing fasteners, always use the same type (part number) fastener as removed.

Information in this manual is divided into groups. These groups contain general information, diagnosis, testing, adjustments, removal, installation, disassembly, and assembly procedures for the components.

The Component and System Index in the back of this manual identifies the correct group for the component or system to be serviced.

To assist in locating a group title page, use the Group Tab Locator on the following page. The solid bar after the group title is aligned to a solid tab on the first page of each group. The first page of the group has a contents section that lists major topics within the group.

Chrysler Corporation reserves the right to change testing procedures, specifications, diagnosis, repair methods, or vehicle wiring at any time without prior notice or incurring obligation.

Information describing the operation and use of standard and optional equipment is included in the Owner's Manual provided with the vehicle.

FOR INFORMATION NOT CONTAINED IN THIS MANUAL, REFER TO FRONT WHEEL DRIVE PASSENGER VEHICLES ENGINE—CHASSIS—BODY OR WIRING DIAGRAMS SERVICE MANUALS.

GROUP TAB LOCATOR

Introduction	
8A Battery/Starting/Charging Systems Diagnostics	
8B Battery/Starter/Alternator Service	
8C Overhead Console	
8D Ignition Systems	
8E Instrument Panel and Guages	
8F Audio System	
8G Horns	
8H Speed Control System	
8J Turn Signal/Hazard Warning Flasher	
8K Windshield Wiper/Washer Systems	
8L Lamps	
8M Restraint Systems	
8N Rear Window Defogger	
8P Power Locks	
8Q Vehicle Theft Security System	
8R Power Seats	
8S Power Windows	
8T Power Mirrors	
8U Chime Warning/Reminder Systems	
14 Fuel Systems	
25 Emission Control Systems	
Index Component and System	

