

CHRYSLER CORPORATION

WIRING DIAGRAMS SERVICE MANUAL

1992 FRONT WHEEL DRIVE PASSENGER VEHICLES

To order the special service tools used and illustrated, please refer to the instructions on inside back cover.



NO PART OF THIS PUBLICATION MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM, OR TRANSMITTED, IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING, OR OTHERWISE, WITHOUT THE PRIOR WRITTEN PERMISSION OF CHRYSLER CORPORATION.

Chrysler Corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

Litho in U.S.A. Copyright © 1991 Chrysler Corporation 30M0891

NEXT PAGE 

FOREWORD

The information contained in this Service Manual has been prepared for the professional automotive technician involved in daily repair operations.

These diagrams contain the latest information at the time of publication and incorporate the wiring schematic for the basic vehicle and available optional equipment.

The diagrams are grouped by body type and sales division. The body codes are explained in the General Information section. (Example—AP-D, P=Shadow, Sundance). To locate a system or component refer to the black index tabs on the next page. The tab will assist you in locating the desired area of the manual.

An alphabetical index is provided at the beginning of each section to help you in locating a system or component. All diagrams are identified by SHEET NUMBER which is found in the lower right- or left-hand corner of the page.

Chrysler Corporation reserves the right to change testing procedures, specifications, diagnosis, repair methods, or vehicle wiring at any time without prior notice or incurring obligation.

Information describing the operation and use of standard and optional equipment is included in the Owner's Manual provided with the vehicle.

**FOR INFORMATION NOT CONTAINED IN THIS MANUAL, REFER TO THE FRONT WHEEL
DRIVE PASSENGER VEHICLES ENGINE—CHASSIS—BODY OR
ELECTRICAL—FUEL—EMISSIONS SERVICE MANUALS.**

NEXT PAGE ►

GROUP TAB LOCATOR

GENERAL INFORMATION

FUSE CHARTS AND RELAY BANKS

**WIRING AND COMPONENT
IDENTIFICATION**

SPLICE LOCATIONS

AA-C, D, P WIRING DIAGRAMS

AC-C, D/AY-C WIRING DIAGRAMS

AG-D, AJ-C WIRING DIAGRAMS

AP-P, D WIRING DIAGRAMS

