

COOLING SYSTEM

CONTENTS

| | page | | page |
|-----------------------------|------|--------------------------|------|
| ACCESSORY DRIVE BELTS | 25 | SERVICE PROCEDURES | 11 |
| ENGINE BLOCK HEATER | 29 | SPECIFICATIONS | 30 |
| GENERAL INFORMATION | 1 | | |

GENERAL INFORMATION

Throughout this group, references may be made to a particular vehicle by letter or number designation. A chart showing the breakdown of these designations is included in the Introduction Section at the front of this service manual.

COOLING SYSTEM


The cooling system consists of an engine cooling module, thermostat, coolant, a water pump to circulate the coolant. The engine cooling module may consist of a radiator, electric fan motor, shroud, radiator pressure cap, coolant reserve system, transmission oil cooler, hoses, clamps, air condition condenser, transmission oil lines and charge air cooler.

- When Engine is cold: Thermostat is closed, cooling system has no flow through the radiator. The coolant bypass flows through the engine only.

- When Engine is warm: Thermostat is open, cooling system has bypass flow and coolant flow through radiator.


Its primary purpose is to maintain engine temperature in a range that will provide satisfactory engine performance and emission levels under all expected driving conditions. It also provides hot water (coolant) for heater performance and cooling for automatic transmission oil. It does this by transferring heat from engine metal to coolant, moving this heated coolant to the radiator, and then transferring this heat to the ambient air.

Coolant flow circuits for 2.2L and 2.5L engine equipped vehicles are shown in (Fig 1). Turbocharged equipped engines coolant routing and plumbing are shown in (Fig 2). The 3.0L engine coolant routing is shown in (Fig 3). The 3.3L and 3.8L engine coolant routing is shown in (Fig 5).



9107-1


Fig. 1 Cooling System Operation—2.2/2.5L Engines



9107-2

Fig. 2 Turbocharger-Tube Hose Assemblies and Coolant Routing

*SEAL THREADS FULL LENGTH
TORQUE ALL CONNECTIONS
41 N·m (30 FT. LBS.)
ALL HOSE CLAMPS
2 N·m (15 IN. LBS.)



RR07B9

Fig. 3 Cooling System Operation—3.0L Engine

TURBOCHARGER COOLANT ROUTING

Engines equipped with a Turbocharger maintain a continuous engine coolant flow through the Turbocharger bearing housing water jacket. Hose and tube assemblies provide a closed loop coolant flow **from** the cylinder block water jacket to the turbocharger housing and back to the cylinder head waterbox (Fig. 2).

Excluding heated intake manifold hose routing (hose is routed from waterbox directly to heater), all other system functions are essentially the same as shown for standard engines.


During any reassembly procedures all pipe fittings in water jacket, bearing housing and waterbox require cleaning and application of thread sealant for entire length of threads. Tighten all fittings to torque specified in (Fig 2).

WATER PIPES—3.0L

The 3.0L engines use metal piping beyond the lower radiator hose to route coolant to the suction side of water pump, located in the V of the cylinder banks.


These pipes are also provided with inlet nipples for thermostat bypass and heater return coolant hos-

es, and brackets for rigid engine attachment. The pipes employ O-rings for sealing at their interconnection and to the water pump (Fig. 4).



9007-1

Fig. 4 Engine Inlet Coolant Pipes



9007-5

Fig. 5 Cooling System Operation—3.3/3.8L Engines

COOLING SYSTEM DIAGNOSIS

Establish what "driving" conditions caused this complaint. Abnormal loads on the cooling system, such as the following may be the problem:

1. Prolonged Idle, Very High Ambient Temperature, Slight Tail Wind at Idle, Slow Traffic, Traffic Jams, High Speed, Steep Grades:

Driving techniques that avoid overheating are;

(a) Idle with A/C off when temperature gauge is at end of normal range.

(b) Do not increase engine speed for more air flow and coolant flow because the electric motor fan systems are not responsive to engine RPM. The added cooling from higher coolant flow rate is more than offset by increased heat rejection (engine heat added to coolant).

2. Trailer Towing:

Consult owner's manual—Trailer Towing. Do not exceed limits.

3. Air Conditioning: Add-on or After Market:

If add-on or after market A/C is involved maximum cooling components should be installed for the model involved per manufacturer's specifications.

Further diagnostic checks should not be required.

4. Recent Service or Accident Repair:

Determine if any recent service has been performed on the vehicle that may affect the cooling system such as engine adjustment (wrong timing), loose or slipping water pump belt, brakes (possibly dragging), changed parts (possibly wrong), recored radiator or cooling system refilling (possibly under-filled or trapped air).


If investigation reveals none of the above as cause for overheating complaint refer to the following symptoms chart.

| Symptom | Action |
|---|--|
| Blinking Engine Warning Light Or High Gauge Indication—Without Coolant Loss | Normal with temporary operation with heavy load, towing a light trailer, high outdoor temperatures, and/or on a steep grade. |
| Coolant Loss | Improper refilling procedures can result in trapped air in the system. Subsequent operation of the pressure cap and coolant recovery system will deaerate the cooling system. A low coolant level will result in the Coolant Reserve Tank. Add coolant. If condition persists see System Diagnosis. |
| Fan Never Runs | Consult Electrical, Group 8. |
| Fan Always Runs | Normal with A/C compressor clutch engaged. Otherwise consult Electrical Group 8. |
| Hot Car (Not Engine) Heat Damage Hot Carpet, Seat, Trunk Hot Catalytic Converter Smoke, Burnt Odor | Check heat shielding, exhaust system, emission controls, ignition timing—fuel/air ratio, misfiring. |
| Hot Engine Crackling Sounds Hot Smell Severe Local Hot Spots | A moderate amount of sound of heating metal can be expected with any vehicle. However, a crackling sound from the thermostat housing, a hot smell and/or severe local hot spots on an engine can indicate blocked coolant passages. Inspect for plugged water passages, bad casting, core sand and plugging, a cracked block or head, or a blown head gasket. Usually accompanied with coolant loss. |
| Coolant Color | Coolant color is not necessarily an indication of adequate temperature or corrosion protection. |
| Coolant Recovery Bottle —Level Changes | Level changes are to be expected as coolant volume changes with engine temperature. If the level in the bottle is between the Maximum and Minimum marks at normal engine operating temperature, the level should return to within that range after operation at elevated temperatures. |
| —Coolant NOT Returning | Coolant will not return to the radiator if the radiator cap vent valve does not function, if an air leak destroys vacuum, or if the overflow passage is blocked or restricted. Inspect all portions of the overflow passage, pressure cap, filler neck nipple, hose, and passageways within the bottle for vacuum leak only. Coolant return failure will be evident by a low level in the radiator. Bottle level should increase during heat-up. |

COOLING SYSTEM DIAGNOSIS

CONDITION—AND CHECKS

DIAGNOSIS

Magnetic 90° Gauge Reads Low**Fig. 1—Normal Gauge Travel**

(1) Verify gauge (Fig. 1). Is temperature really low?

(1) See Electrical, Group 8, and check temperature sending unit and gauge. Repair or replace sending unit or gauge.

(2) Is code 17 set in diagnostics?

(2) Yes—Thermostat; No—Other.

(3) Does it read cold?

(3) Wiring disconnect, wrong sending unit used (sending unit for HOT Lite, not gauge).


(4) Coolant level low in cold ambient (also poor heater performance).

(4) Check radiator and CRS for level; inspect for leaks.

(5) Coolant level O.K.

(5) Check heater controls, doors; see Group 24, Heaters and Air Conditioning.

Gauge Reads High
Without Pressure Cap Blow off, without Coolant or
Steam from CRS Tank and to Ground

**Fig. 2—Gauge Reading—Hot Weather—Heavy Load**

(1) Is it really reading high?

(1) See Figure 2.

(2) If at "H" without other signs of boiling.

(2) Look for Grounded gauge, sending unit, or wire. See Group 8, Electrical.

(3) Coolant level low in Radiator and CRS.

(3) a—Fill full, remembering to Vent Air.

b—Inspect for leaks, repair.

c—Assure Pressure Cap was shut tight and that seals at top and bottom of neck are functioning properly.

(4) Coolant level low in Radiator but not in CRS.

(4) a—Fill full, remembering to vent air.

b—Inspect for leaks and repair.

c—Inspect for leaks in CRS to radiator connection.

d—Assure cap seals at top and bottom.

COOLING SYSTEM DIAGNOSIS


| CONDITION—AND CHECKS | DIAGNOSIS |
|---|--|
| (5) Check freeze point. | (5) a—Adjust to 50/50 Glycol and water. b—If no reading or below -59°C (-50°F), mixture is too rich clean system before refilling |
| (6) Assure Coolant Flow. | (6) a—Look for flow through filler neck with some coolant removed and thermostat open (6) b—Repair water pump if necessary. See Water Pump Section. |
| (7) Other possible causes. | (7) a— High speed only —Radiator or Condenser air side plugged —Radiator core tubes plugged —Add on A/C without proper radiator —Engine out of tune (specifications) —Brakes dragging —Bug screen —Trailer towing or hill climbing b— High and Low Speed —Thermostat failed partially shut particularly if ambient temperature is below 21°C (70°F) and vehicle has high mileage. —Condenser or radiator air side plugged. —Add on A/C. c— Low Speed—NOT high speed —Fan not operating. —Check Diagnostics. —Check Fan Motor by wiring to battery, when disconnected from harness. —Check, Group 8, Electrical. |
| Temperature Gauge Reads Hot with Pressure Cap Blowoff and Steam and coolant to CRS and to Ground | |
| (1) Coolant Level Low in Radiator and CRS | (1) a—Fill Cooling System Full and Vent Air. b—Inspect for Leaks—repair. c—Assure Pressure cap was shut and seals. d—If low in radiator but not in CRS, also check connection to filler neck and pressure cap sealing. |
| (2) Check Coolant Freeze point. | (2) Adjust to 50/50 Glycol and water. -37°C (-35°F .) |
| (3) Assure Coolant Flow. | (3) a—Look for flow through radiator filler neck with coolant lowered and thermostat open. b—When accompanied with "metal cracking sound"—consider core sand and/or bad head casting. |
| (4) Thermostat failed shut. | (4) Especially in cold to medium ambient temperatures. |
| (5) Head Gasket Leak. | (5) Use block leak checker. |

COOLING SYSTEM DIAGNOSIS

CONDITION—AND CHECKS


Temperature Gauge is Inconsistent

Cycles—Erratic


**Fig. 3—Normal Reaction to Fan Cycle**

(1) Is cycle normal?


(1) a—Normal Fan Cycle Due to Temperature. Rises Slowly—Drops Fast (Fig. 3).

**Fig. 4—Gauge Reaction to Thermostat**

b—Normal Thermostat Cycle (Fig. 4).

**Fig. 5—Gauge Reaction—Winter, Idle, Heater On**

c—Normal Cycle at Idle in Winter With Heater on High. (Heater Heat Transfer Exceeds Engine Heat Rejection) Drops Lower With Time. Sometimes Noticed in Winter Between Drive and Idle (Fig. 5).

**Fig. 6—Gauge Reaction—Stop After Heavy Use**

d—Hot Water Normally Builds Up at Stop After Heavy Use (Fig. 6).

(2) Is coolant level low in radiator (Low level can trap air in system which can put thermostat pellet in air and it opens late).

(2) Fill System, Vent Air and Inspect for Leaks.

COOLING SYSTEM DIAGNOSIS

| CONDITION - AND CHECKS | DIAGNOSIS |
|--|--|
| (3) Is there a head gasket leak that puts exhaust gas in system? (This acts like trapped air with same effect as 2 above.) | (3) a - Test with block leak checker and replace if necessary. b - Coolant in engine oil. c - White steam coming out of exhaust. |
| (4) Water pump impeller loose on shaft, slips sometimes. | (4) Replace. |
| (5) Air lead on suction side of water pump entraining air; see 2 above. | (5) Find leak and repair. |
| Warning Light Glows All the Time (No Gauge) | |
| (1) Check temperature sending unit. The sending unit for a light is a switch and has a screwdriver slot in the electrode that is used for calibration. The gauge sending units do NOT have a screwdriver slot. | (1) It is probably a sending unit for a gauge, NOT for a light. |
| Pressure Cap Blow-Off, With Steam to CRS and Coolant to Ground Without High Reading. Temperature Gauge Above Normal. | |
| (1) Check pressure cap relief pressure. | (1) Replace if lower than 14 psi. |
| Coolant Loss to Ground Without Pressure Cap Blow-Off | |
| (1) Leaks. | (1) a - Pressure test system while shaking hoses. b - Water pump seal. See "water pump," this Group. |
| Coolant Loss Past Pressure Cap Top Seal - Glycol Seen on Filler Neck | |
| (1) With normal gauge reading. | (1) a - Cap not on tight. b - Top seal leaking. c - Cap diaphragm "oil canned." d - Filler neck damaged. e - Rubber seal out of position. |
| (2) With high gauge reading or low gauge reading on new vehicle. | (2) a - CRS hose kinked. b - CRS tank and plastic tube plugged. c - Pressure cap rubber seal out of position. |
| Detonation or Pre-Ignition When Nothing to Cause It in Engine or Ignition | |
| (1) Check freeze point of coolant. If tester does not register reading or the reading is below -59°C, be aware that 100% glycol makes engine metal run hotter even without a hot gauge reading. | (1) a - Adjust coolant to 50/50 glycol and water -37°C. b - If 100% glycol has been found in the system, clean and flush the system before replacing with 50/50 glycol and water. |
| Hoses Observed Collapsing on Cool-Down | |
| (1) Check pressure cap vent valve. | (1) a - Must be free to move. Gasket swell can prevent valve from opening. b - Replace cap. |
| (2) Check CRS hose for kinking or plugging. | (2) Repair as required. |
| (3) Inside of cap plugged with stop leak pellet, green silica gel, or fiberglass. | (3) Clean cap. |
| Fan Runs All the Time | |
| (1) Check for relay. | (1) See Group 8, Electrical. |
| Fan Noisy | |
| (1) Check for loose fan. | (1) Repair as necessary. |
| (2) Check for fan clearance to adjacent parts. | |
| (3) Check for loose mount fasteners. | |
| (4) Check for bent fan blades. | |
| (5) Check for fan blades spinning on hub. | |
| (6) Check for air obstructions on radiator or condenser. | |

COOLING SYSTEM DIAGNOSIS

| CONDITION - AND CHECKS | DIAGNOSIS |
|--|---|
| Inadequate Air Conditioning Performance – Cooling Systems Suspected | |
| (1) Check for plugged air side of condenser and radiator – front and rear. | (1) Wash out with low-velocity water. |
| (2) Assure fan runs whenever A/C compressor clutch is engaged. | (2) Repair as necessary. |
| (3) Check for missing air seals-recirculating air path. | |
| (4) Assure correct cooling system parts. | |
| Battery Dead – Suspect Fan Current Draw as Cause | |
| (1) With a good, fully charged battery. | (1) a – Assure fan control is operating properly. b – See Charging System in Electrical, Group B. |
| Hot Smell – Suspect Cooling System | |
| (1) Was temperature gauge high? | (1) a – Yes, See "Gauge Reads High." b – No, See 2, 3, 4, and 5. |
| (2) Heat shields all in place? | (2) a – Yes, See 3, 4, and 5. b – Repair as required. |
| (3) Fan control operating properly? | (3) a – Yes, See 4 and 5. b – No, See "Fan," this Group. |
| (4) Heat exchanger air side plugged? | (4) Clean as required. |
| (5) Engine missing or running rich? | (5) Repair as required. |
| Poor Driveability – Suspect Failed Open Thermostat | |
| (1) Check diagnostics – is code 17 set? | (1) If yes, change thermostat. |
| Poor Heater Performance – Suspect Failed Open Thermostat | |
| (1) Does gauge read low? | (1) See 3a. |
| (2) Check coolant level. | (2) See 3a. |
| (3) Check diagnostics – is code 17 set? | (3) If yes, change thermostat. If no, check heater bypass valve, which should be closed except in Max A/C or Off mode; if not, see Heater and Air Conditioning, Group 24. |
| Steaming, Observe Water Vapor Through Grill or Head Gap at Standstill at Idle – In Wet Weather | |
| (1) This is normal. It is moisture, snow, or water on the outside of the radiator that evaporates when the thermostat opens to put hot water into the radiator. This usually occurs in cold weather with no fan or air flow to blow it away. | (1) Normal condition – no service required. |

SERVICE PROCEDURES

INDEX

| | page | | page |
|---|------|--------------------------|------|
| Automatic Transmission Oil Coolers | 24 | Fans | 22 |
| Coolant | 15 | Radiator Hoses | 21 |
| Coolant Recovery System (CRS) | 18 | Radiator Pressure Cap | 19 |
| Cooling System Drain, Clean, Flush and Refill | 16 | Radiators | 19 |
| Electric Fan Motor | 23 | Testing System for Leaks | 18 |
| Engine Thermostats | 14 | Water Pumps | 11 |
| Fan Shroud | 23 | | |

WATER PUMPS

A quick test to tell whether or not the pump is working is to see if the heater warms properly. A defective pump will not be able to circulate heated coolant through the long heater hose.

The water pump on all models can be replaced without discharging the air conditioning system.

WATER PUMP—2.2/2.5L ENGINE

The 2.2/2.5L engine water pump has a diecast aluminum body and housing with a stamped steel impeller. The 2.2/2.5L pump uses an O-ring gasket between body and housing. The assembly bolts directly to the block. Cylinder block to water pump sealing is provided by a rubber O-ring.




Fig. 1 Water Pump—2.2/2.5L Engines

REMOVAL

(1) Drain cooling system. Refer to Draining Cooling System in this group.

(2) If equipped with air conditioning, see Solid Mount Accessory Bracket in (Standard Service Procedures) Group 9, Engine:

(a) Remove air conditioning compressor and alternator from solid mount bracket and set aside. It is not necessary to discharge the a/c system.

(b) Remove solid mount bracket.

(3) If the vehicle is not equipped with air conditioning, remove alternator and mounting bracket.

(4) Disconnect lower radiator and heater hoses from pump.

(5) Remove water pump attaching screws to engine (Fig. 1). Turbo III has a spacer between the water pump and block on the lower screw.

DISASSEMBLY

(1) Remove three screws holding pulley to water pump.

(2) Remove nine screws holding water pump body to housing. Remove the pump body from housing (Fig. 2).

(3) Clean gasket surfaces on water pump housing and engine block.

(4) Remove and discard O-ring gaskets and clean O-ring grooves.




Fig. 2 Water Pump Components—2.2/2.5L

INSPECTION

Replace water pump body assembly if it has any of these defects:

- (1) Cracks or damage on the body.
- (2) Water leaks from the shaft seal, evident by coolant traces below the vent hole.
- (3) Loose or rough turning bearing.
- (4) Impeller rubs either the pump body or the housing.

ASSEMBLY

Body assembly and housing are serviced as separate components.

- (1) Install new O-ring gasket in body O-ring groove.
- (2) Assemble pump body to housing and tighten nine screws to 12 N•m (105 in. lbs.) (Fig. 2).
- (3) Rotate pump by hand to check for freedom of movement.
- (4) Position water pump pulley to water pump. Install three screws and tighten to 30 N•m (250 in. lbs.).
- (5) Position new O-ring in housing to block O-ring groove.




Fig. 3 Coolant Deflector—Turbo III

INSTALLATION

- (1) On Turbo III engines install the coolant deflector into the block before installing pump on engine (Fig. 3). **Install spacer between the pump and block for Turbo III only before tightening pump to specifications.** Tighten three top screws (Fig. 1) to 28 N•m (250 in. lbs.) and lower screw to 68 N•m (50 ft. lbs.).
- (2) Install bypass/heater hose and lower radiator hose.
- (3) Install alternator and air conditioning compressor bracket(s). For solid mount bracket see standard service procedures in Group 9 Engine.
- (4) Install alternator and air conditioning compressor.

(5) Refill cooling system. See **Refilling Cooling System.**

(6) Install drive belt, See Accessory Drive Belts, this Group.

WATER PUMP—3.0L ENGINE

The 3.0L pump bolts directly to the engine block, using a gasket for pump to block sealing (Fig. 4). The pump is serviced as a unit.

The water pump is driven by the timing belt. See Timing System in Group 9, Engine for component removal providing access to water pump.




Fig. 4 Water Pump—3.0L Engine




Fig. 5 Water Pump Inspection

REMOVAL

- (1) Drain cooling system. Refer to Draining Cooling System in this group.
- (2) Remove mounting bolts.
- (3) Separate pump from water inlet pipe (Figs. 4 and 5) and remove.

INSPECTION

Replace the water pump if it has any of the following defects.

- (1) Damage or cracks on the pump body.
- (2) Coolant leaks, if the shaft seal is leaking, evident by traces of coolant leaks from vent hole A in (Fig. 5).
- (3) Impeller rubs inside of pump.
- (4) Excessively loose or rough turning bearing.




Fig. 6 Water Pipe O-Ring

INSTALLATION

- (1) Clean all gasket and O-ring surfaces on pump and water pipe inlet tube.
- (2) Install new O-ring on water inlet pipe (Fig. 6). Wet the O-ring with water to facilitate assembly.

CAUTION: Keep the O-ring free of oil or grease.

(3) Install new gasket on water pump and install pump inlet opening over water pipe, press assembly to cause water pipe insertion into pump housing.

(4) Install pump to block mounting bolts and tighten to 27 N•m (20 ft. lbs.).

(5) See Timing System in Engine, Group 9 and install timing belt. Reassemble engine.

(6) Fill cooling system. See Refilling Cooling System.

WATER PUMP—3.3L AND 3.8L ENGINES

The pump has a die cast aluminum body and a stamped steel impeller. It bolts directly to the chain case cover, using an O-ring for sealing. It is driven by the back surface of the Poly-V Drive Belt.

REMOVAL

- (1) Drain Cooling System. Refer to Draining Cooling System in this group.
- (2) Remove Poly V Drive Belt.
- (3) Remove right front lower fender shield.
- (4) Remove pump pulley bolts and remove pulley.
- (5) Remove pump mounting screws (Fig. 7). Remove pump.
- (6) Remove and discard O-ring seal.




Fig. 7 Water Pump—3.3L and 3.8L Engines

- (7) Clean O-ring groove and O-ring surfaces on pump and chain case cover. Take care not to scratch or gouge sealing surface.

INSPECTION

Replace the water pump if it has any of the following defects.

- (1) Damage or cracks on the pump body.
- (2) Coolant leaks; if the seal is leaking, evident by traces of coolant leaks from vent hole.
- (3) Loose or rough turning bearing.
- (4) Impeller rubs either the pump body or chain-case cover.




Fig. 8 Water Pump Body

INSTALLATION

- (1) Install new O-ring in O-ring groove (Fig. 8).
- (2) Install pump to chain case cover. Torque screws to 12 N•m (105 in. lbs.).
- (3) Rotate pump by hand to check for freedom of movement.
- (4) Position pulley on pump. Install screws and torque to 30 N•m (250 in. lbs.).

- (5) Install drive belt. See Accessory Drive Belts this group.
- (6) Install right front lower fender shield.
- (7) Refill Cooling System. See Refilling Cooling System in this section.

ENGINE THERMOSTATS

The 2.2 and 2.5L engine thermostats are located on the front of the engine (radiator side) in the water box which is part of the cylinder head construction (Fig. 9). Turbo III thermostat is located in the water box located on the driver side of the cylinder head (Fig. 10).

These thermostats do not have an air bleed notch.

The 3.0L engine thermostat is located in a water box, formed in the timing belt end of the intake manifold. This thermostat has an air bleed valve, located in the thermostat flange (Fig. 11).

The 3.3/3.8L engine thermostat is located in a water box, formed in the drive belt side of the intake manifold (Fig. 13).

DESCRIPTION AND OPERATION

The engine cooling thermostats are wax pellet driven, reverse poppet choke type. They are designed to provide the fastest warm up possible by preventing leakage through them and to guarantee a minimum engine operating temperature of 88 to 93°C (192 to 199°F). They also automatically reach wide open so they do not restrict flow to the radiator as temperature of the coolant rises in hot weather to around 104°C (220°F). Above this temperature the coolant temperature is controlled by the radiator, fan, and ambient temperature, not the thermostat.

OPERATION AND TESTING

The thermostat is operated by a wax filled container (pellet) which is sealed so that when heated to a predetermined temperature. The wax expands enough to overcome the closing spring and water pump pressure, which forces the valve to open. Coolant leakage into the pellet will cause a thermostat to fail open. Do not attempt to free up a thermostat with a screwdriver.

The open too soon type failure mode is included in the onboard diagnosis. The check engine light will not be lit by an open too soon condition. If it has failed open, code 17 will be set. Do not change a thermostat for lack of heat by gauge or heater performance, unless code 17 is present, see diagnosis for other probable causes. Failing shut is the normal long term mode of failure, and normally, only on high mileage vehicles. The temperature gauge will indicate this. Refer to diagnosis in this section.

REMOVAL

- (1) Drain cooling system down to thermostat level or below.

- (2) Remove thermostat housing bolts and housing (Figs. 9, 10, 11 and 13).
- (3) Remove thermostat, discard gasket and clean both gasket sealing surfaces.




Fig. 9 Thermostat, Housing, and Water Box—2.2/2.5L Engine

INSTALLATION—2.2/2.5L AND TURBO III ENGINES

Place a new gasket (dipped in clean water) on water box surface, center thermostat in water box on gasket. Place housing over gasket and thermostat, making sure thermostat is in the thermostat housing. Bolt housing to water box (Figs. 9 and 10). Tighten bolts to 28 N•m (250 in. lbs.). Refill cooling system (see **Refilling System**).




Fig. 10 Thermostat, Housing, and Water Box—Turbo III
INSTALLATION—3.0L ENGINE

Center thermostat in water box pocket. Check that the flange is seated correctly in the countersunk portion of the intake manifold water box (Figs. 11 and 12). Install new gasket on water box. Install housing over gasket and thermostat and tighten bolts to 12 N•m (133 in. lbs. torque).




Fig. 11 Thermostat, Housing, and Water Box—3.0L Engine




Fig. 12 Thermostat Installed—3.0L Engine

INSTALLATION—3.3L AND 3.8L ENGINE

Place a new gasket (dipped in water) on the water box surface, center thermostat into opening in the intake manifold. Place housing over gasket and thermostat, making sure thermostat is in recess provided (Fig. 13). Bolt housing to intake manifold, tighten bolts to 28 N•m (250 in. lbs.). Refill cooling system (see **Refilling System**).

COOLANT

The cooling system is designed around the coolant. The coolant must accept heat from engine metal, in the cylinder head area near the exhaust valves. Then carry this heat to the radiator where the tube/fin assemblies of these components can give it up to the air.




Fig. 13 Thermostat, Housing and Waterbox—3.3L and 3.8L Engine

PERFORMANCE

Performance is measurable. For heat transfer pure water excels (Formula = 1 btu per minute for each degree of temperature rise for each pound of water). This formula is altered when necessary additives to control boiling, freezing, and corrosion are added as follows:

- Pure Water (1 btu) boils at 100°C (212°F) and freezes at 0°C (32°F).
- 100 Percent Glycol (.7 btu) can cause a hot engine and detonation and will raise the freeze point to 22°C (-8°F).
- 50/50 Glycol and Water (.82 btu) is the recommended combination that provides a freeze point of -37°C (-35°F). The radiator, water pump, engine water jacket, radiator pressure cap, thermostat, temperature gauge, sending unit and heater are all designed for 50/50 glycol.

Where required, a 56 percent glycol and 44 percent water mixture will provide a freeze point of -59°C (-50°F).

CAUTION: Richer mixtures cannot be measured with field equipment which can lead to problems associated with 100 percent glycol.

SELECTION AND ADDITIVES

The use of aluminum cylinder heads, intake manifolds, and water pumps requires special corrosion protection. Mopar Antifreeze, Prestone II, Peak or antifreeze containing Alugard 340-2, or their equivalent are recommended for best engine cooling without corrosion. When mixed only to a freeze point of

-37°C (-35°F) to -59°C (-50°F). If it loses color or becomes contaminated, drain, flush, and replace with fresh properly mixed solution.

SERVICE

Coolant should be changed at 52,500 miles or three years, whichever occurs first, then every two years or 30,000 miles.

ROUTINE LEVEL CHECK

Do not remove radiator cap for routine coolant level inspections.

The coolant reserve system provides a quick visual method for determining the coolant level without removing the radiator cap. Simply observe, with the engine idling and warmed up to normal operating temperature, that the level of the coolant in the reserve tank (Figs. 5 and 6) is between the minimum and maximum marks.

ADDING ADDITIONAL COOLANT

The radiator cap should not be removed. When additional coolant is needed to maintain this level, it should be added to the coolant reserve tank. Use only 50/50 concentration of ethylene glycol type antifreeze and water.

SERVICE COOLANT LEVEL

The cooling system is closed and designed to maintain coolant level to the top of the radiator.

When servicing requires a coolant level check in the radiator, the engine must be **off** and **not** under pressure. Drain several ounces of coolant from the radiator drain cock while observing the Coolant Recovery System (CRS) Tank. Coolant level in the CRS tank should drop slightly. Then remove the radiator cap. The radiator should be full to the top. If not, and the coolant level in the CRS tank is at the MIN mark there is an air leak in the CRS system. Check hose or hose connections to the CRS tank, radiator filler neck or the pressure cap seal to the radiator filler neck for leaks.

LOW COOLANT LEVEL AERATION

Low coolant level in a cross flow radiator will equalize in both tanks with engine off. With engine at running operating temperature the high pressure inlet tank runs full and the low pressure outlet tank drops. If this level drops below the top of the transmission oil cooler, air will be sucked into the water pump:

- Transmission oil will become hotter.
- High reading shown on the temperature gauge.
- Air in the coolant will also cause loss of flow through the heater.
- Exhaust gas leaks into the coolant can also cause the same problems.

DEAERATION

Air can only be removed from the system by gathering under the pressure cap. On the next heat up it will be pushed past the pressure cap into the CRS tank by thermal expansion of the coolant. It then escapes to the atmosphere in the CRS tank and is replaced with solid coolant on cool down.

COOLING SYSTEM DRAIN, CLEAN, FLUSH AND REFILL

Drain, flush, and fill the cooling system at the mileage or time intervals specified in the Maintenance Schedule in this Group. If the solution is dirty or rusty or contains a considerable amount of sediment, clean and flush with a reliable cooling system cleaner. Care should be taken in disposing of the used engine coolant from your vehicle. Check governmental regulations for disposal of used engine coolant.

DRAINING

To drain cooling system move temperature selector for heater to full heat with engine running (to provide vacuum for actuation). **Without removing radiator pressure cap and with system not under pressure**, Shut engine off and open draincock. The coolant reserve tank (Fig. 5) should empty first, then remove radiator pressure cap. (if not, see Testing Cooling System for leaks). To vent 2.2/2.5L engines remove the plug above thermostat housing (Fig. 1). For Turbo III engines remove coolant temperature sensor in the thermostat housing (Fig. 2). For 3.3L /3.8L engine remove the engine temperature sending unit (Fig. 3).




Fig. 1 Thermostat Housing Drain/Fill Plug—2.2/2.5L Engines

Removal of a plug or other component is required because the thermostat has no air vent and prevents air flow through it. This allows the coolant to drain from the engine block.




Fig. 2 Coolant Temperature Sensor—Turbo III Drain/Fill

CLEANING

Drain cooling system (see: **Draining Cooling System**) and refill with clean water (see: **Refilling Cooling System**). Run engine with radiator cap installed until upper radiator hose is hot. Stop engine and drain water from system. If water is dirty, fill, run and drain system again until water runs clear.

REVERSE FLUSHING

Reverse flushing of the cooling system is the forcing of water through the cooling system, using air pressure in a direction opposite to that of the normal flow of water. This is only necessary with dirty systems and evidence of partial plugging.




Fig. 3 Engine Temperature Sending Unit—3.3L and 3.8L Drain/Fill

RADIATOR

Drain cooling system and remove radiator hoses from engine. Install suitable flushing gun in radiator lower hose. Fill radiator with clean water and turn on air in short blasts.

CAUTION: Internal radiator pressure must not exceed 138 kPa (20 psi) as damage to radiator may result. Continue this procedure until water runs clear.

ENGINE

Drain radiator (see: **Draining Cooling System**) and remove hoses from radiator. Remove engine thermostat and reinstall thermostat housing. Install suitable flushing gun to thermostat housing hose. Turn on water, and when engine is filled, turn on air, but no higher than 138 kPa (20 psi) in short blasts. Allow engine to fill between blasts of air. Continue this procedure until water runs clean. Install thermostat using a new housing gasket. Fill cooling system (See **Refilling Cooling System**).

CHEMICAL CLEANING

One type of corrosion encountered with aluminum cylinder heads is aluminum hydroxide deposits. Corrosion products are carried to the radiator and deposited when cooled off. They appear as dark grey when wet and white when dry. This corrosion can be removed with a two part cleaner (oxalic acid and neutralizer) available in auto parts outlets. Follow manufacturers directions for use.

REFILLING

First clean system to remove old glycol, see Cooling System Cleaning.

Fill system using antifreeze described in Coolant section. Fill 50 percent of capacity with 100 percent glycol. Then complete filling system with water. The 2.2/2.5L engines require venting by removal of the plug on top of the water box (Fig. 1). Turbo III engines require venting by removing the coolant temperature sensor on top of the thermostat housing (Fig. 2). The 3.3/3.8L Engines require removal of the Engine Temperature Sending Unit on the front of the cylinder head (Fig. 3). The thermostat in these engines do not allow air flow through them. When coolant reaches the vent holes;

- Install vent plug and tighten to 20 N•m (15 ft. lbs.) for 2.2/2.5L Engines.
- Install Coolant Temperature Sensor and tighten to 27 N•m (20 ft. lbs.) for Turbo III Engine.
- Install Engine Temperature Sending Unit and tighten to 7 N•m (60 in. lbs.) for 3.3/3.8L Engines.

Continue filling system until full, this provides better heater performance. **Be careful not to spill coolant on drive belts or the alternator.**

Fill coolant reserve system to at least the MAX mark with 50/50 solution. It may be necessary to add coolant to the reserve tank to maintain coolant level between the MAX and MIN mark after three or four warm-up, cool down cycles and trapped air has been removed.

TESTING SYSTEM FOR LEAKS

With engine not running, wipe the radiator filler neck sealing seat clean. The radiator should be full.

Attach a radiator pressure tester to the radiator, as shown in (Fig. 4) and apply 104 kPa (15 psi) pressure. If the pressure drops more than 2 psi in 2 minutes inspect all points for external leaks.

All hoses, radiator and heater, should be moved while at 15 psi since some leaks occur while driving due to engine rock, etc.




Fig. 4 Pressure Testing Cooling System

If there are no external leaks after the gauge dial shows a drop in pressure, detach the tester. Start engine and run the engine to normal operating temperature in order to open the thermostat and allow the coolant to expand. Re-attach the tester. If the needle on the dial fluctuates it indicates a combustion leak, usually a head gasket leak.

WARNING: WITH TOOL IN PLACE PRESSURE BUILDS UP FAST. ANY EXCESSIVE AMOUNT OF PRESSURE BUILT UP BY CONTINUOUS ENGINE OPERATION MUST BE RELEASED TO A SAFE PRESSURE POINT. NEVER PERMIT PRESSURE TO EXCEED 138 KPA (20 PSI).

If the needle on the dial does not fluctuate, race the engine a few times. If an abnormal amount of coolant or steam is emitted from the tail pipe, it may indicate a faulty head gasket, cracked engine block or cylinder head.

There may be internal leaks which can be determined by removing the oil dip-stick. If water globules appear intermixed with the oil it will indicate a inter-

nal leak in the engine. If there is an internal leak, the engine must be disassembled for repair.

COOLANT RECOVERY SYSTEM (CRS)

This system works in conjunction with the radiator pressure cap to utilize thermal expansion and contraction of the coolant to keep the coolant free of trapped air. It provides a volume for expansion and contraction, provides a convenient and safe method for checking coolant level and adjusting level at atmospheric pressure without removing the radiator pressure cap. It also provides some reserve coolant to cover minor leaks and evaporation or boiling losses. All vehicles are equipped with this system (Figs. 5 and 6).




Fig. 5 Coolant Recovery System Typical

See Coolant Level Check Service, Deaeration and Pressure Cap sections for operation and service. Vehicles equipped with the electric monitor system use a level sensor in the CRS tank, see Group 8E Electrical for service.




Fig. 6 Coolant Recovery System—AC-AY Models

RADIATOR PRESSURE CAP

Radiators are equipped with a pressure cap which releases pressure at some point within a range of 97-124 kPa (14-18 psi) (Fig. 7).

The system will operate at higher than atmospheric pressure which raises the coolant boiling point allowing increased radiator cooling capacity.

There is also a vent valve in the center of the cap that allows a small coolant flow to the CRS tank. **If valve is stuck shut, the radiator hoses will be collapsed on cool down. Clean the vent valve (Fig. 7) to ensure proper sealing when boiling point is reached.**




Fig. 7 Radiator Pressure Cap Filler Neck

There is also a gasket in the cap to seal to the top of the filler neck so that vacuum can be maintained for drawing coolant back into the radiator from the coolant reserve system tank.

RADIATOR CAP TO FILLER NECK SEAL PRESSURE RELIEF CHECK

The pressure cap upper gasket (seal) pressure relief can be checked by removing the overflow hose at the radiator filler neck nipple (Fig. 7). Attach the Radiator Pressure Tool to the filler neck nipple and pump air into the radiator. Pressure cap upper gasket should relieve at 69-124 kPa (10-18 psi) and hold pressure at 55 kPa (8 psi) minimum.

WARNING: THE WARNING WORDS DO NOT OPEN HOT ON THE RADIATOR PRESSURE CAP IS A SAFETY PRECAUTION. WHEN HOT, PRESSURE BUILDS UP IN COOLING SYSTEM. TO PREVENT SCALDING OR INJURY, THE RADIATOR CAP SHOULD NOT BE REMOVED WHILE THE SYSTEM IS HOT AND/OR UNDER PRESSURE.

There is no need to remove the radiator cap at any time **except** for the following purposes:

- (1) Check and adjust antifreeze freeze point.
- (2) Refill system with new antifreeze.
- (3) Conducting service procedures.
- (4) Checking for vacuum leaks.

WARNING: IF VEHICLE HAS BEEN RUN RECENTLY, WAIT 15 MINUTES BEFORE REMOVING CAP. THEN

PLACE A SHOP TOWEL OVER THE CAP AND WITHOUT PUSHING DOWN ROTATE IT COUNTER-CLOCKWISE TO THE FIRST STOP. ALLOW FLUIDS TO ESCAPE THROUGH THE OVERFLOW TUBE AND WHEN THE SYSTEM STOPS PUSHING COOLANT AND STEAM INTO THE CRS TANK AND PRESSURE DROPS PUSH DOWN AND REMOVE THE CAP COMPLETELY. SQUEEZING THE RADIATOR INLET HOSE WITH A SHOP TOWEL (TO CHECK PRESSURE) BEFORE AND AFTER TURNING TO THE FIRST STOP IS RECOMMENDED.

PRESSURE TESTING RADIATOR CAPS

Dip the pressure cap in water, clean any deposits off the vent valve or its seat and apply cap to end of Radiator Pressure Tool. Working the plunger, bring the pressure to 104 kPa (15 psi) on the gauge. If the pressure cap fails to hold pressure of at least 97 kPa (14 psi) replace cap. See **CAUTION**

If the pressure cap tests properly while positioned on Radiator Pressure Tool, but will not hold pressure or vacuum when positioned on the radiator. Inspect the radiator filler neck and cap top gasket for irregularities that may prevent the cap from sealing properly.

CAUTION: Radiator Pressure Tool is very sensitive to small air leaks which will not cause cooling system problems. A pressure cap that does not have a history of coolant loss should not be replaced just because it leaks slowly when tested with this tool. Add water to the tool. Turn tool upside down and recheck pressure cap to confirm that cap is bad.

INSPECTION

Hold the cap in hand, **right side up** (Fig. 7). The vent valve at the bottom of the cap should open. If the rubber gasket has swollen and prevents the valve from opening, replace the cap.


Hold the cleaned cap in hand **upside down**. If any light can be seen between vent valve and rubber gasket, replace cap. **Do not use a replacement cap that has a spring to hold the vent shut.**

Replacement cap must be of the type designed for coolant reserve systems. This design assures coolant return to radiator.

RADIATORS

The radiators are crossflow types (horizontal tubes) with design features that provide greater strength as well as sufficient heat transfer capabilities to keep the engine satisfactorily cooled.

CAUTION: Plastic tanks, while stronger than brass are subject to damage by impact, such as wrenches.





J9107-28

Fig. 8 Pressure Testing Radiator Cap**RADIATOR DRAINCOCK SERVICE****REMOVAL**

(1) Turn the drain cock stem counterclockwise to unscrew the stem. When the stem is unscrewed to the end of the threads, pull the stem (Fig. 10) from the radiator tank.

INSTALLATION

(1) Push the draincock assembly body into the tank opening until it snaps into place.



9207-21

Fig. 10 Draincock Assembly—Typical


(2) Tighten the draincock stem by turning clockwise to 2.0-2.7 N•m (18-25 in. lbs.) torque.

RADIATOR COOLANT FLOW CHECK

To determine whether coolant is flowing through the cooling system, use the following procedure:

(1) If engine is cold, idle engine until normal operating temperature is reached. Then feel the upper radiator hose. If it is hot, coolant is circulating.

WARNING: DO NOT REMOVE RADIATOR PRESSURE CAP WITH THE SYSTEM HOT AND UNDER PRESSURE BECAUSE SERIOUS BURNS FROM COOLANT CAN OCCUR.



9207-20

Fig. 9 Radiator Module—Typical

(2) Remove radiator pressure cap when engine is cold. Idle engine until thermostat opens, you should observe coolant flow while looking down the filler neck. Once flow is detected install radiator pressure cap.

RADIATOR

REMOVAL

- (1) Disconnect negative battery cable from battery.

WARNING: DO NOT REMOVE THE CYLINDER BLOCK PLUG OR THE RADIATOR DRAINCOCK WITH THE SYSTEM HOT AND UNDER PRESSURE BECAUSE SERIOUS BURNS FROM COOLANT CAN OCCUR.

(2) Drain cooling system. Refer to Draining Cooling System of this section.

(3) Remove hose clamps and hoses from the radiator (Fig. 11). Remove coolant reserve system tank to filler neck tube.

(4) Remove automatic transmission hoses, if equipped.

(5) Remove fan and fan support assembly by disconnecting fan motor electrical connector. Remove fan shroud retaining clips, located on the top and bottom of the shroud for AA, AG, AJ and AP vehicles. AC/AY vehicle retainer clips are located on the top only. Lift shroud up and out of bottom shroud attachment clips separating shroud from radiator. Fan damage should always be avoided.

(6) Remove upper radiator mounting screws. Disconnect the engine block heater wire if equipped.

(7) Remove the air conditioning condenser attaching screws located at the top front of the radiator, if equipped.

Radiator can now be lifted free from engine compartment. **Care should be taken not to damage radiator cooling fins or water tubes during removal.**

INSTALLATION

(1) Slide radiator down into position behind radiator support (yoke).

(2) Attach air conditioning condenser to radiator, if equipped, with a force of approximately 10 lbs. to seat the radiator assembly lower rubber isolators in the mount holes provided.

(3) Tighten radiator mounting screws to 11.9N•m (105 in. lbs.).

(4) Connect automatic transmission hoses, if equipped. Tighten hose clamps to 4 N•m (35 in. lbs.).

(5) Slide fan shroud, fan and motor down into clips on lower radiator flange. Replace shroud retaining clips.

(6) Install upper and lower radiator hoses (including coolant reserve hose).

(7) Connect fan motor electrical connection and connect negative battery cable.

(8) Fill cooling system with coolant. Refer to **Refilling Cooling Systems** in this group.

(9) Operate engine until it reaches normal operating temperature. Check cooling system and automatic transmission for correct fluid levels.

RADIATOR HOSES

The hoses are removed using Constant Tension Clamp pliers to compress hose clamp.




Fig. 11 Radiator Modules—All Models




Fig. 12 Servicing Fan Module

A hardened, cracked, swollen or restricted hose should be replaced. Do not damage radiator inlet and outlet when loosening hoses.

Radiator hoses should be routed without any kinks and indexed as designed. The use of molded hoses is recommended.

Spring type hose clamps are used in all applications. If replacement is necessary replace with the original style spring type clamp.

FANS

All models use electric motor driven cooling system fans. The fan modules include a motor support which may (depending on model) include a shroud. The module is fastened to the radiator by screws with U-nuts and retaining clips (Fig. 12).

All fan motors are one speed. Attempts to reduce high temperature gauge reading by increasing engine speed, at the same vehicle speed, can increase high temperature.

SINGLE FAN

There are no repairs to be made to the fan. If the fan is warped, cracked, or otherwise damaged, it must be replaced with **only** the recommended part for adequate strength, performance and safety (Fig. 13).




Fig. 13 Radiator Fan Retaining Clip—Typical

DUAL FAN MODULE—AC/AY BODY

The dual fan module (Fig. 13) is a combination of 2 fans mounted in a one piece shroud which are simultaneously activated. The dual fan system improves engine cooling and air conditioning performance in hot weather and severe driving conditions, while reducing fan noise and power consumption.

REMOVAL

Disconnect electric motor lead. Remove fan module to radiator fasteners and retaining clips. Remove assembly from radiator support.

To remove fan from motor shaft, bench support the motor and motor shaft, while removing the fan retaining clip, so that the shaft and motor will not be damaged by excessive force. **Surface or burr removal may be required to remove fan from motor shaft.** (Fig. 13). Do not permit the fan blades to touch the bench.

INSTALLATION

Slide the fan on motor shaft. Support motor and shaft as above while installing fan retaining clip. Install assembly into pocket on lower radiator tank. Attach retaining clips and fasteners to radiator tank. **Right side fastener is longer on A/C equipped vehicles.** Connect fan motor lead. **For wiring diagrams of fan motor systems see Wiring Diagrams Manual**

RADIATOR FAN CONTROL—ALL EXCEPT AC, AY BODY V-6 ENGINE

Fan control is accomplished two ways. The fan always runs when the air conditioning compressor clutch is engaged. In addition to this control, the fan is turned on by the temperature of the coolant which is sensed by the coolant temperature sensor which sends the message to the Engine Controller. The Engine Controller turns on the fan through the fan relay. See Wiring Diagrams Manual for circuitry and diagnostics provided.

Switching through the Engine Controller provides fan control for the following conditions.

- The fan will not run during cranking until the engine starts no matter what the coolant temperature is.
- Fan will always run when the air conditioning clutch is engaged.
- The fan will run at vehicle speeds above about 40 mph only if coolant temperature reaches 110°C (230°F). It will turn off when the temperature drops to 104°C (220°F). At speeds below 40 mph the fan switches on at 99°C (210°F) and off at 93°C (200°F).
- This is to help prevent steaming. The fan will run only below 16°C (60°F) ambient. Between 38°C (100°F) to 97°C (195°F) coolant temperature, at idle and then only for three minutes.

RADIATOR FAN CONTROL—AC/AY BODY V-6 ONLY

For this application, fan control is accomplished based on coolant temperature, and on A/C head pressure. These vehicles receive the variable displacement compressor. The fan will go on when;

- Coolant temperature reaches 98.9°C (210°F) and off at 93.4°C (200°F) regardless of vehicle speed.
- When the head pressure reaches 1516.9 kPa (220 psi) and turn off when the pressure reaches 1103 kPa (160 psi).

TEMPERATURE GAUGE INDICATION

At idle the temperature gauge will rise slowly to about 5/8 gauge travel. The fan will come on and the gauge will drop to about 1/2 gauge travel, this is normal.

ELECTRIC FAN MOTOR

To check out the electric fan motor, disconnect the fan motor wire connector and connect it with #14 gauge wires to a good 12-volt battery observing correct polarity per (Fig. 14). If the fan runs normally, the motor is functioning properly. If not, replace fan module using the removal and installation instructions contained in the Fan Section. If the motor is noticeably overheated (i.e.; wire insulation melted, motor charred) the system voltage may be too high. Check charging system, see Group 8A, Battery/Starting/Charging System Diagnostics.

ELECTRIC FAN MOTOR TEST

Equipment required

- Diagnostic Tool DRB II or equivalent
- Volt/Ohm Meter
- Wiring Diagram Manual

(1) Run the engine to normal operating temperature.

(2) Check wiring connector in C25, C9, and C26 for proper engagement, see Wiring Diagram Manual




Fig. 14 Electric Fan Motor—Typical

(3) Using a diagnostic tool, plugged into the diagnostic connector rearward of the battery, check the On-Board Diagnostics (OBD) in the Engine Controller for fault codes, see Group 14, Fuel Injection for instructions.

(4) If fault code 88-12-35-55 is detected, proceed to Step 5.

(5) With the ignition switch in the run position, test for battery voltage (single pin connector) at the fan relay. Voltage reading OK, proceed to Step 6a. Voltage at 0-1 volt, proceed to Step 6b.

6(a) With the ignition off, disconnect the 60-way connector from the Engine Controller (outboard of battery) and return the ignition to the run position. Test for battery voltage at cavity 31 of the 60-way connector (Fig. 15). Voltage reading OK and female terminal is not damaged, replace the Engine Controller. Voltage reading 0, repair open or short in C27 circuit.


(b) With the ignition off, disconnect the 60-way connector from the Engine Controller (outboard of battery) and return the ignition to the run position. Test for battery voltage at the single pin connector at the fan relay. Voltage reading OK, replace the Engine Controller. Voltage reading 0-1 volt, proceed to Step 7.

(7) With ignition in the run position, test for battery voltage at the wire (C27) in the 3-way connector of the fan relay. Voltage reading OK, replace the fan relay. Voltage reading 0, repair open or short in C27 circuit.

(8) Turn ignition off, connect the 60-way connector at the Engine Controller and test the system.


FAN SHROUD

All vehicles have fan shrouds to improve fan air flow efficiency. These fan shrouds cover less than full radiator frontal area to prevent the shroud from restricting air flow at high speeds.



9207-13

Fig. 15 Engine Controller 60-Way Connector from Terminal End



9107-19

Fig. 16 Transmission Oil Cooler

The shroud supports the electric fan motor and fan. For removal and installation see Radiator Section.

AUTOMATIC TRANSMISSION OIL COOLERS

Oil coolers are internal oil to coolant type, mounted in the radiator left tank (Fig. 16). Rubber oil lines feed the oil cooler and the automatic transmission. Use only approved transmission oil cooler hose. Since these are molded to fit space available, molded hoses are recommended. Tighten Oil Cooler Hose Clamps to 4 N•m (35 in. lbs.).

ACCESSORY DRIVE BELTS

INDEX

| | page | | page |
|---|------|--|------|
| 2.2/2.5L Engine Belts Remove/Install-Adjust | 26 | 3.3/3.8L and Turbo III Engine Accessory Drive Belt | |
| 3.0L Engine Belts Remove/Install and Adjust | 26 | Remove and Install | 28 |
| | | General Information | 25 |

GENERAL INFORMATION

PROPER BELT TENSION

Satisfactory performance of the belt driven accessories depends on belt condition (Fig. 1) and proper belt tension. Three tensioning methods are given in order of preference:

- Belt tension gauge method.
- Torque equivalent method.

The belt tension gauge method is usually restricted to use after the vehicle has been raised on a hoist and the splash shield has been removed.

BELT TENSION GAUGE METHOD

Use belt tensioning Special Tool Kit C-4162 for:

- For conventional belts and Poly-V belts.
- Adjust the belt tension for a **New** or **Used** belt as prescribed in the Belt Tension Chart.


TORQUE EQUIVALENT METHOD

Adjustable accessory brackets provided with a 13mm (1/2 in.) square hole for a torque wrench can use an equivalent torque value for belt adjustment.

Equivalent torque values for adjusting these accessory drive belts are specified on the Belt Tension Charts .

BELT REPLACEMENT UNDER ANY OR ALL OF THE FOLLOWING CONDITIONS IS REQUIRED, EXCESSIVE WEAR, FRAYED CORDS OR SEVERE GLAZING.

V-RIBBED BELT SYSTEM WITH BACK DRIVE PULLEY MAY DEVELOP MINOR CRACKS ACROSS THE RIBBED SIDE (DUE TO REVERSE BENDING). THESE MINOR CRACKS ARE CONSIDERED NORMAL AND ACCEPTABLE. CRACKS PARALLEL ARE NOT.



DO NOT USE ANY TYPE OF BELT DRESSING OR RESTORER ON V-RIBBED BELTS.


9207-16

Fig. 1 Drive Belt Inspection

ACCESSORY DRIVE BELTS DIAGNOSIS

| Condition | Possible Cause | Correction |
|---|---|--|
| INSUFFICIENT ACCESSORY OUTPUT DUE TO BELT SLIPPAGE | (a) Belt too loose. (b) Belt excessively glazed or worn. | (a) Adjust belt tension. (b) Replace and tighten as specified. |
| BELT SQUEAL WHEN ACCELERATING ENGINE | (a) Belts too loose. (b) Belts glazed. | (a) Adjust belt tension. (b) Replace belts. |
| BELT SQUEAK AT IDLE | (a) Belts too loose. (b) Dirt and paint imbedded in belt. (c) Non-uniform belt. (d) Misaligned pulleys. (e) Non-uniform groove or eccentric pulley. | (a) Adjust belt tension. (b) Replace belt. (c) Replace belt. (d) Align accessories (file brackets or use spacers as required). (e) Replace pulley. |
| BELT ROLLED OVER IN GROOVE OR BELT JUMPS OFF | (a) Broken cord in belt. (b) Belt too loose, or too tight. (c) Misaligned pulleys. (d) Non-uniform groove or eccentric pulley. | (a) Replace belt. (b) Adjust belt tension. (c) Align accessories. (d) Replace pulley. |

9107-27



9107-20

Fig. 2 Accessory Drive Belts—2.2 and 2.5L Engines**2.2/2.5L ENGINE BELTS REMOVE/INSTALL-ADJUST****AIR CONDITIONING COMPRESSOR**

(1) Loosen the idler bracket pivot screw A and locking screws B (Fig. 2) to remove and install belt and/or adjust belt tension.

(2) Adjust belt tension by applying torque to square hole C on idler bracket. Adjust tension to specification given in Belt Tension Chart.

(3) Tighten in order, first, locking screws B then pivot screw A to 54 N•m (40 ft. lbs.).

POWER STEERING PUMP—ZF AND TC TYPES

(1) Loosen locking nut and locking screw G and pivot nut H.

(2) Loosen adjusting screw J to release belt tension. Tighten adjusting nut J to adjust belt tension to specification.

(3) Tighten locking nut G and screw H to 54 N•m (40 ft. lbs. torque).

(4) Tighten locking screw G to 28 N•m (250 in. lbs.).

POWER STEERING PUMP—S TYPE

(1) From on top of the vehicle loosen locking screw G.

(2) From under the vehicle loosen the pivot screw and pivot nut H.

(3) After installing a new belt adjust belt tension with 1/2 in. breaker bar installed in adjusting bracket. See tension specification in chart.

(4) Tighten locking screw G to 54 N•m (40 ft. lbs.).

(5) Tighten pivot screw H and the pivot nut to 54 N•m (40 ft. lbs.).

ALTERNATOR BELT

(1) Loosen T-Bolt locking nut E and adjusting screw F to remove and install Poly V belt and/or adjust belt tension.

(2) Tighten adjusting screw F to adjust belt tension to specification shown in Belt Tension Chart.

(3) Tighten T-Bolt locking nut E to 54 N•m (40 ft. lbs.).

3.0L ENGINE BELTS REMOVE/INSTALL AND ADJUST**AIR CONDITIONING BELT**

To remove and install the air conditioning compressor drive belt, first loosen the idler pulley lock nut, then turn the adjusting screw to raise or lower the idler pulley (Figs. 3 and 4).




Fig. 3 Accessory Drive Belts—3.0L Engine




Fig. 4 Air Conditioning Belt Idler




Fig. 5 Release Belt Tensioner

To adjust the air conditioning drive belt, loosen the idler pulley nut (Fig. 3) and adjust belt tension by tightening adjusting screw (Figs. 3 and 4). Tighten pulley nut to 54 N•m (40 ft. lbs.) after adjustment.

ALTERNATOR/POWER STEERING PUMP BELT

The Poly-V alternator/power steering pump belt is provided with a dynamic tensioner (Fig. 5) to maintain proper belt tension. To remove or install this belt, Release tension by rotating the tensioner clockwise.

| ACCESSORY DRIVE BELT | | GAUGE | TORQUE |
|---|------|-------------------|----------------------|
| 2.2/2.5L ENGINE | | | |
| AIR CONDITIONING COMPRESSOR | NEW | 125 LB. | 47 N·m (35 FT. LBS.) |
| | USED | 80 LB. | 27 N·m (20 FT. LBS.) |
| ALTERNATOR/WATER PUMP POLY "V" | NEW | 130 LB. | |
| | USED | 80 LB. | |
| POWER STEERING PUMP | NEW | 105 LB. | 58 N·m (43 FT. LBS.) |
| | USED | 80 LB. | 43 N·m (32 FT. LBS.) |
| 3.0L ENGINE | | | |
| AIR CONDITIONING COMPRESSOR | NEW | 125 LB. | |
| | USED | 80 LB. | |
| ALTERNATOR/WATER PUMP/POWER STEERING PUMP | NEW | DYNAMIC TENSIONER | |
| | USED | | |
| 2.2L TURBO III 3.3L AND 3.8L ENGINE | | | |
| AIR CONDITIONING COMPRESSOR | NEW | DYNAMIC TENSIONER | |
| ALTERNATOR/WATER PUMP/POWER STEERING PUMP | | | |
| | USED | | |

Fig. 6 Belt Tension Chart

9207-24

3.3/3.8L AND TURBO III ENGINE ACCESSORY DRIVE BELT REMOVE AND INSTALL

ALTERNATOR, POWER STEERING PUMP, AIR CONDITIONING COMPRESSOR AND WATER PUMP DRIVE BELT

The Poly-V Drive belt is provided with a dynamic tensioner (Figs. 7 and 8) to maintain proper belt tension. To remove or install this belt.

- (1) Raise vehicle on hoist.
- (2) Remove right front splash shield.
- (3) Release tension by rotating the tensioner clockwise (Figs. 7 and 8).
- (4) Reverse above procedure to install.




Fig. 7 Accessory Drive Belt—2.2L Turbo III Engine




Fig. 8 Accessory Drive Belt—3.3/3.8L Engines

ENGINE BLOCK HEATER

DESCRIPTION AND OPERATION

On all models an engine block heater is available as an optional accessory. The heater, operated by ordinary house current (110 Volt A.C.) through a power cord and connector behind the radiator grille, provides easier engine starting and faster warm-up when vehicle is operated in areas having extremely low temperatures. The heater is mounted in a core hole (in place of a core hole plug) in the engine block, with the heating element immersed in coolant (Fig. 9).

The power cord must be secured in its retainer clips, and not positioned so it could contact linkages or exhaust manifolds and become damaged.

If unit does not operate, trouble can be in either the power cord or the heater element. Test power cord for continuity with a 110-volt voltmeter or 110-volt test light; test heater element continuity with an ohmmeter or 12-volt test light.

REMOVAL

- (1) Drain coolant from radiator and cylinder block. Refer to Cooling System Drain, Clean, Flush and Refill of this section for procedure.
- (2) Detach power cord plug from heater.
- (3) Loosen screw in center of heater. Remove heater assembly.

INSTALLATION

- (1) Thoroughly clean core hole and heater seat.
- (2) Insert heater assembly with element loop positioned **upward**.
- (3) With heater seated, tighten center screw securely to assure a positive seal.
- (4) Fill cooling system with coolant to the proper level, vent air, and inspect for leaks. Pressurize system with Radiator Pressure Tool before looking for leaks.




Fig. 9 Engine Block Heater



SPECIFICATIONS

TORQUE

| DESCRIPTION | TORQUE |
|---------------------------------------|-----------------------|
| A/C Condenser to Radiator (All) | 4 N·m (35 in. lbs.) |
| Thermostat Housing Bolt Nut | |
| 2.2/2.5L | 28 N·m (250 in. lbs.) |
| 3.0L | 13 N·m (113 in. lbs.) |
| 3.3/3.8L | 28 N·m (250 in. lbs.) |
| Water Pump Mounting Bolts | |
| Upper 2.2/2.5L | 28 N·m (250 in. lbs.) |
| Lower 2.2/2.5L | 54 N·m (40 ft. lbs.) |
| 3.0L | 27 N·m (240 in. lbs.) |
| 3.3/3.8L | 12 N·m (105 in. lbs.) |

| DESCRIPTION | TORQUE |
|--------------------------------------|-----------------------|
| Water Pump Cover to | |
| Housing Bolts 2.2/2.5L | 12 N·m (105 in. lbs.) |
| Water Pump Pulley Screws | |
| 2.2/2.5L | 28 N·m (250 in. lbs.) |
| 3.3/3.8L | 28 N·m (250 in. lbs.) |
| Water Inlet Pipe (Bracket to | |
| Cylinder Head Screws) 3.0L | 11 N·m (94 in. lbs.) |
| Fan Module to Radiator, All | 7 N·m (65 in. lbs.) |
| Upper Radiator Mounting Screws | 12 N·m (105 in. lbs.) |
| Turbocharger Coolant Tubes | 41 N·m (30 ft. lbs.) |
| Turbocharger Oil Tube Nuts | 14 N·m (125 in. lbs.) |

*Connectors, Elbows & Tube Nuts: Apply Sealant to Threads, Full Length.

9207-26

COOLING SYSTEM CAPACITY

| ENGINE | 2.2, 2.5L | 2.5L | TURBO | 2.5L | 3.0L | 3.0 W/A.C. 3.3, 3.8L |
|--|--------------|---------------|---------------|------|--------------------------------|-------------------------|
| BODY | AP | AA, AG, AJ | AA, AG, AJ | AC | AA AC, AY HEATER ONLY | AC, AY |
| LITERS | 8.5 | 8.5 | 8.5 | 8.5 | 9.0 | 9.5 |
| U.S. QTS. | 9.0 | 9.0 | 9.0 | 9.0 | 9.5 | 10.0 |
| CAPACITY Includes Heater and Coolant Recovery System | | | | | | |

9207-27