

DIFFERENTIAL AND DRIVELINE

CONTENTS

	page		page
194 FIA AXLE	24	FRONT AXLE DRIVESHAFTS	15
8 1/4 AND 9 1/4 AXLE	53	PROPELLER SHAFTS	1

PROPELLER SHAFTS

INDEX

	page		page
GENERAL INFORMATION		FRONT PROPELLER SHAFT	7
CENTER BEARINGS	2	REAR PROPELLER SHAFT	7
LUBRICATION	2	DISASSEMBLY AND ASSEMBLY	
PRECAUTIONS	2	DOUBLE CARDAN JOINT	10
PROPELLER SHAFT JOINT ANGLE	2	SINGLE CARDAN UNIVERSAL JOINT	8
PROPELLER SHAFTS	1	CLEANING AND INSPECTION	
DIAGNOSIS AND TESTING		PROPELLER SHAFT	13
RUNOUT	4	ADJUSTMENTS	
UNBALANCE	3	ADJUSTMENT AT AXLE WITH LEAF SPRINGS .	14
VIBRATION	3	CENTER BEARING ADJUSTMENT	14
SERVICE PROCEDURES		SPECIFICATIONS	
DRIVELINE ANGLE MEASUREMENT		TORQUE	14
PREPARATION	5	SPECIAL TOOLS	
PROPELLER SHAFT ANGLE MEASUREMENT ...	5	PROPELLER SHAFT	14
REMOVAL AND INSTALLATION			
CENTER BEARING	8		

GENERAL INFORMATION

PROPELLER SHAFTS

The propeller shaft (Fig. 1) transmits power from one point to another in a smooth and continuous action. The shaft is designed to send torque through an angle from the transmission (transfer case on 4WD vehicles) to the axle.

The propeller shaft must operate through constantly changing relative angles between the transmission and axle. It must also be capable of changing length while transmitting torque. The axle rides suspended by springs in a floating motion. This means the propeller shaft must be able to contract, expand and change operating angles when going over various road surfaces. This is accomplished through universal joints, which permit the propeller shaft to operate at different angles. The slip joints (or yokes) permit contraction or expansion.

Tubular propeller shafts are balanced by the manufacturer with weights spot welded to the tube.

The propeller shaft is designed and built with the yoke lugs in line with each other. This is called phasing. This design produces the smoothest running condition. An out of phase shaft can cause a vibration.

Before undercoating a vehicle, the propeller shaft and the U-joints should be removed if possible. If removal is not possible, make sure that the propellor shaft and u-joints are fully covered. This will prevent the undercoating from causing an out of balance condition and vibration.

CAUTION: Use exact replacement parts for attaching the propeller shafts. This will ensure safe operation. The specified torque must always be applied when tightening the fasteners.

GENERAL INFORMATION (Continued)




Fig. 1 Front & Rear Propeller Shafts—4WD

CENTER BEARINGS

Vehicles equipped with a two-piece propeller shaft uses a rubber insulated center bearing. The bearing is used to support the shafts where they are joined together.

LUBRICATION

The slip yoke on the front propeller shaft is equipped with a lubrication fitting. Use a multi-purpose NLGI Grade 2 EP lubricant. The factory installed universal joints are lubricated for the life of the vehicle and do not need lubrication. All universal joints should be inspected for leakage and damage each time the vehicle is serviced. If seal leakage or damage exists, the universal joint should be replaced. Refer to Group 0, Lubrication and Maintenance, for additional information.

PROPELLER SHAFT JOINT ANGLE

When two shafts come together at a common joint, the bend that is formed is called the operating angle. The larger the angle, the larger the amount of angular acceleration and deceleration of the joint. This speeding up and slowing down of the joint must be cancelled to produce a smooth power flow. This is done through the phasing of a propeller shaft and ensuring that the proper propeller shaft joint working angles are maintained.

A propeller shaft is properly phased when the yoke ends are in the same plane, or in line. A twisted shaft will make the yokes out of phase and cause a noticeable vibration.

When taking propeller shaft joint angle measurements, or checking the phasing, of two piece shafts, consider each shaft separately.

Ideally the driveline system should have;

- Angles that are equal or opposite within 1 degree of each other.
- Have a 3 degree maximum operating angle.
- Have at least a 1/2 degree continuous operating (propeller shaft) angle.

Engine speed (rpm) is the main factor in determining the maximum allowable operating angle. As a guide to the maximum normal operating angles refer to (Fig. 2).

PROPELLER SHAFT R.P.M.	MAX. NORMAL OPERATING ANGLES
5000	3°
4500	3°
4000	4°
3500	5°
3000	5°
2500	7°
2000	8°
1500	11°

J9316-4


Fig. 2 Maximum Angles And Engine Speed

PRECAUTIONS

Use the exact replacement parts when installing the propeller shafts. The use of the correct replacement parts helps to ensure safe operation. All fasteners must be torqued to the specified values for safe operation.

GENERAL INFORMATION (Continued)

Also make alignment reference marks (Fig. 3) on the propeller shaft yoke and axle, or transmission, yoke prior to servicing. This helps to eliminate possible vibration.



J9316-2

Fig. 3 Reference Marks on Yokes

CAUTION: Do not allow the propeller shaft to drop or hang from any propeller shaft joint during removal. Attach the propeller shaft to the vehicle underside with wire to prevent damage to the joints.

CAUTION: It is very important to protect the external machined surface of the slip yoke from damage during and after propeller shaft removal. If the yoke is damaged, the transmission extension seal may be damaged and therefore cause a leak.

DIAGNOSIS AND TESTING

VIBRATION

Tires that are out-of-round, or wheels that are unbalanced, will cause a low frequency vibration. Refer to Group 22, Tires and Wheels, for additional information.

Brake drums that are unbalanced will cause a harsh, low frequency vibration. Refer to Group 5, Brakes, for additional information.

Driveline vibration can also result from loose or damaged engine mounts. Refer to Group 9, Engines, for additional information.

Propeller shaft vibration increases as the vehicle speed is increased. A vibration that occurs within a specific speed range is not usually caused by a propeller shaft being unbalanced. Defective universal joints, or an incorrect propeller shaft angle, are usually the cause of such a vibration.

UNBALANCE

NOTE: Removing and re-indexing the propeller shaft 180° relative to the yoke may eliminate some vibrations.

If propeller shaft is suspected of being unbalanced, it can be verified with the following procedure:

- (1) Raise the vehicle.
- (2) Clean all the foreign material from the propeller shaft and the universal joints.
- (3) Inspect the propeller shaft for missing balance weights, broken welds, and bent areas. **If the propeller shaft is bent, it must be replaced.**

Drive Condition	Possible Cause	Correction
PROPELLER SHAFT	<ol style="list-style-type: none"> a. Undercoating or other foreign material on shaft. b. Loose U-joint clamp screws. c. Loose or bent U-joint yoke or excessive runout. d. Incorrect drive line angularity. e. Rear spring center bolt not in seat. f. Worn U-joint bearings. g. Propeller shaft damaged (bent tube) or out of balance. h. Broken rear spring. i. Excessive runout or unbalanced condition. j. Excessive drive pinion gear shaft yoke runout. 	<ol style="list-style-type: none"> a. Clean exterior of shaft and wash with solvent. b. Tighten screws properly. c. Install replacement yoke. d. Correct angularity e. Loosen spring U-bolts and seat center bolts. f. Replace U-joint. g. Install replacement propeller shaft. h. Replace rear spring. i. Reindex propeller shaft 180°, test and correct as necessary. j. Reindex propeller shaft 180° and evaluate.
UNIVERSAL JOINT NOISE	<ol style="list-style-type: none"> a. U-joint clamp screws loose. b. Lack of lubrication. 	<ol style="list-style-type: none"> a. Tighten screws with specified torque. b. Replace U-joint.

J9216-7

DIAGNOSIS AND TESTING (Continued)

(4) Inspect the universal joints to ensure that they are not worn, are properly installed, and are correctly aligned with the shaft.

(5) Check the universal joint clamp screws torque.

(6) Remove the wheels and tires. Install the wheel lug nuts to retain the brake drums or rotors.

(7) Mark and number the shaft six inches from the yoke end at four positions 90° apart.

(8) Run and accelerate the vehicle until vibration occurs. Note the intensity and speed the vibration occurred. Stop the engine.

(9) Install a screw clamp at position 1 (Fig. 4).




Fig. 4 Clamp Screw At Position 1

(10) Start the engine and re-check for vibration. If there is little or no change in vibration, move the clamp to one of the other three positions. Repeat the vibration test.

(11) If there is no difference in vibration at the other positions, the source of the vibration may not be propeller shaft.

(12) If the vibration decreased, install a second clamp (Fig. 5) and repeat the test.




Fig. 5 Two Clamp Screws At The Same Position

(13) If the additional clamp causes an additional vibration, separate the clamps (1/4 inch above and below the mark). Repeat the vibration test (Fig. 6).




Fig. 6 Clamp Screws Separated

(14) Increase distance between the clamp screws and repeat the test until the amount of vibration is at the lowest level. Bend the slack end of the clamps so the screws will not loosen.

(15) If the vibration remains unacceptable, apply the same steps to the front end of the propeller shaft.

(16) Install the wheel and tires. Lower the vehicle.

RUNOUT

(1) Remove dirt, rust, paint, and undercoating from the propeller shaft surface where the dial indicator will contact the shaft.

(2) The dial indicator must be installed perpendicular to the shaft surface.

(3) Measure runout at the center and ends of the shaft sufficiently far away from weld areas to ensure that the effects of the weld process will not enter into the measurements.

(4) Refer to Runout Specifications chart.

(5) If the propeller shaft runout is out of specification, remove the propeller shaft, index the shaft 180°, and re-install the propeller shaft. Measure shaft runout again.

(6) If the propeller shaft runout is now within specifications, mark the shaft and yokes for proper orientation.

(7) If the propeller shaft runout is not within specifications, verify that the runout of the transmission/transfer case and axle are within specifications. Correct as necessary and re-measure propeller shaft runout.

(8) Replace the propeller shaft if the runout still exceeds the limits.

DIAGNOSIS AND TESTING (Continued)

RUNOUT SPECIFICATIONS

Front of Shaft	0.020 in. (0.50 mm)
Center of Shaft	0.025 in. (0.63 mm)
Rear of Shaft	0.020 in. (0.50 mm)
Note: Measure front/rear runout approximately 3 inches (76 mm) from the weld seam at each end of the shaft tube for tube lengths over 30 inches. For tube lengths under 30 inches, the maximum allowed runout is 0.020 in. (0.50 mm) for the full length of the tube.	

SERVICE PROCEDURES

DRIVELINE ANGLE MEASUREMENT PREPARATION

Before measuring universal joint angles, the following must be done;

- Inflate all tires to correct pressure.
- Check the angles in the same loaded or unloaded condition as when the vibration occurred. Propeller shaft angles change according to the amount of load in the vehicle.
- Check the condition of all suspension components and verify all fasteners are torqued to specifications.
- Check the condition of the engine and transmission mounts and verify all fasteners are torqued to specifications.

PROPELLER SHAFT ANGLE MEASUREMENT

ONE-PIECE PROPELLER SHAFT


To accurately check driveline alignment, raise and support the vehicle at the axles as level as possible. Allow the wheels and propeller shaft to turn. Remove any external bearing snap rings (if equipped) from universal joint so that the inclinometer base sits flat.

(1) Rotate the shaft until transmission/transfer case output yoke bearing cap is facing downward.

Always make measurements from front to rear.

(2) Place Inclinometer on yoke bearing cap (A) parallel to the shaft (Fig. 7). Center bubble in sight glass and record measurement.

This measurement will give you the transmission or Output Yoke Angle (A).




J9216-13

Fig. 7 Front (Output) Angle Measurement (A)

(3) Rotate propeller shaft 90 degrees and place Inclinometer on yoke bearing cap parallel to the shaft (Fig. 8). Center bubble in sight glass and record measurement. This measurement can also be taken at the rear end of the shaft.

This measurement will give you the propeller shaft angle (C).



J9216-9

Fig. 8 Propeller Shaft Angle Measurement (C)

(4) Subtract smaller figure from larger (C minus A) to obtain transmission output operating angle.

(5) Rotate propeller shaft 90 degrees and place Inclinometer on pinion yoke bearing cap parallel to the shaft (Fig. 9). Center bubble in sight glass and record measurement.

SERVICE PROCEDURES (Continued)

This measurement will give you the pinion shaft or input yoke angle (B).




Fig. 9 Rear (Input) Angle Measurement (B)

(6) Subtract smaller figure from larger (C minus B) to obtain axle Input Operating Angle.


Refer to rules given below and the example in for additional information.

- Good cancellation of U-joint operating angles (within 1°).
- Operating angles less than 3°.
- At least 1/2 of one degree continuous operating (propeller shaft) angle.

TWO-PIECE PROPELLER SHAFT

The procedure to measure the propeller shaft angles involved with a two-piece propeller shaft is the same as those for a one-piece propeller shaft. The following additional conditions also apply:

- The front half-shaft must be parallel to the rear axle pinion gear shaft.
- The front and rear half-shafts must be offset by a minimum of 1/2 of a degree. From the transmission/transfer case output shaft and from each other.
- Excessive variation in measurement angles of A, B or C indicate propeller mis-alignment.
- Vertical alignment of a two-piece shaft at the yokes should be greater than one-half degree and as close to one degree as possible.



Horizontal Level

(A) Output Yoke = 3.0° or 4.9°
(C) Prop. Shaft = 4.9° or -3.0°

Transmission Output
Operating Angle 1.9°

(B) Axle Input Yoke = 3.2° or 4.9°
(C) Prop. Shaft = 4.9° or -3.2°

Axle Input
Operating Angle 1.7°

Trans. Output Operating Angle 1.9°
Axle Input Operating Angle -1.7°

Amount of U-Joint Cancellation 0.2°

J9316-3

Fig. 10 Universal Joint Angle Example

SERVICE PROCEDURES (Continued)




Fig. 11 Universal Joint Angle—Two-Piece Shaft

REMOVAL AND INSTALLATION

FRONT PROPELLER SHAFT

REMOVAL

- (1) Shift the transmission and transfer case to their neutral positions. Raise and support vehicle. Remove skid plate, if equipped.
- (2) Using a suitable marker, mark a line across the yoke at the transfer case, the link yoke, and propeller shaft yoke at the rear of the front propeller shaft for installation reference.
- (3) Mark a line across the propeller shaft yoke and the pinion shaft yoke for installation reference.
- (4) Remove the universal joint strap bolts at the pinion shaft yoke (Fig. 12).
- (5) Remove the bolts holding the propeller shaft to the transfer case yoke.
- (6) Remove the propeller shaft.

INSTALLATION

- (1) Position front propeller shaft under vehicle with rear universal joint over the transfer case yoke flange.
- (2) Place front universal joint into the axle pinion yoke.
- (3) Align mark on the link yoke and universal joint to the mark on the transfer case yoke flange.
- (4) Loosely install bolts to hold universal joint to transfer case yoke.
- (5) Align mark on front universal joint to the mark on the axle pinion yoke.
- (6) Install bolts to hold front universal joint to axle pinion yoke. Tighten bolts to 19 N·m (14 ft. lbs.).
- (7) Tighten bolts to hold universal joint to transfer case yoke to 27 N·m (20 ft. lbs.).
- (8) Install skid plate, if equipped.
- (9) Lower vehicle and road test to verify repair.




Fig. 12 Front Propeller Shaft

REAR PROPELLER SHAFT

REMOVAL

- (1) Raise and support vehicle on safety stands.
- (2) Shift the transmission to the Neutral position.
- (3) Using a suitable marker, mark a line across the axle pinion yoke and the propeller shaft yoke for installation reference.
- (4) Using a suitable marker, mark the outline of the center bearing on the support bracket for installation reference, if equipped.
- (5) Using a suitable marker, mark the outline of the heat shield on the center bearing for installation reference, if equipped.

REMOVAL AND INSTALLATION (Continued)

(6) Remove bolts that attach the center bearing and heat shield to the support bracket, if equipped.

(7) Remove the bolts holding the universal joint clamps to the pinion yoke.

(8) Slide the slip yoke off of the transmission, or transfer case, output shaft and remove the propeller shaft (Fig. 13).




Fig. 13 Rear Propeller Shaft

INSTALLATION

(1) Slide the slip yoke onto the transmission, or transfer case, output shaft.

(2) Align the installation reference marks made on the propeller shaft and pinion yoke.

(3) Align and install the center bearing and heat shield to the support bracket, if necessary.

(4) Install the bolts and tighten to 68 N·m (50 ft. lbs.) torque.

(5) Position universal joint into the axle yoke.

(6) Tighten the universal joint strap bolts to 19 N·m (14 ft. lbs.) torque.

(7) Lower the vehicle.

CENTER BEARING

REMOVAL

(1) Remove rear propeller shaft.

(2) Remove slip joint boot clamp and separate the two half-shafts.

(3) Use hammer and punch to tap slinger away from shaft to provide room for bearing splitter.

(4) Position Bearing Splitter Tool 1130 between slinger and shaft.

CAUTION: Do not damage shaft spline during removal of center bearing.

(5) Set shaft in press and press bearing off the shaft.

INSTALLATION

(1) Install new slinger on shaft and drive into position with appropriate installer tool.

(2) Install new center bearing on shaft with Bearing Installer Tool 6052. Drive on shaft with hammer until bearing is seated.

(3) Clean shaft splines and apply a coat of multi-purpose grease.

(4) Align master splines and slide front and rear half-shafts together. Reposition slip yoke boot and install new clamp.

(5) Install propeller shaft in vehicle.

DISASSEMBLY AND ASSEMBLY

SINGLE CARDAN UNIVERSAL JOINT

DISASSEMBLY

Individual components of cardan universal joints are not serviceable. If worn or leaking, they must be replaced as an assembly.

(1) Remove the propeller shaft.

(2) Using a soft drift, tap the outside of the bearing cap assembly to loosen snap ring.

(3) Remove snap rings from both sides of yoke (Fig. 14).




Fig. 14 Remove Snap Ring

(4) Set the yoke in an arbor press or vise with a socket whose inside diameter is large enough to receive the bearing cap positioned beneath the yoke.

DISASSEMBLY AND ASSEMBLY (Continued)

(5) Position the yoke with the grease fitting, if equipped, pointing up.

(6) Place a socket with an outside diameter smaller than the upper bearing cap on the upper bearing cap and press the cap through the yoke to release the lower bearing cap (Fig. 15).




Fig. 15 Press Out Bearing

(7) If the bearing cap will not pull out of the yoke by hand after pressing, tap the yoke ear near the bearing cap to dislodge the cap.

(8) To remove the opposite bearing cap, turn the yoke over and straighten the cross in the open hole. Then, carefully press the end of the cross until the remaining bearing cap can be removed (Fig. 16).

CAUTION: If the cross or bearing cap are not straight during installation, the bearing cap will score the walls of the yoke bore and damage can occur.

ASSEMBLY

(1) Apply extreme pressure (EP) N.L.G.I. Grade 1 or 2 grease to inside of yoke bores to aid in installation.

(2) Position the cross in the yoke with its lube fitting, if equipped, pointing up (Fig. 17).




Fig. 16 Press Out Remaining Bearing




Fig. 17 Install Cross In Yoke

DISASSEMBLY AND ASSEMBLY (Continued)

(3) Place a bearing cap over the trunnion and align the cap with the yoke bore (Fig. 18). Keep the needle bearings upright in the bearing assembly. A needle bearing lying at the bottom of the cap will prevent proper assembly.




Fig. 18 Install Bearing On Trunnion

- (4) Press the bearing cap into the yoke bore enough to install a snap ring.
- (5) Install a snap ring.
- (6) Repeat Step 3 and Step 4 to install the opposite bearing cap. If the joint is stiff or binding, strike the yoke with a soft hammer to seat the needle bearings.
- (7) Add grease to lube fitting, if equipped.
- (8) Install the propeller shaft.

DOUBLE CARDAN JOINT

DISASSEMBLY

Individual components of cardan universal joints are not serviceable. If worn or leaking, they must be replaced as an assembly.

- (1) Remove the propeller shaft.
- (2) Using a soft drift, tap the outside of the bearing cap assembly to loosen snap ring.
- (3) Remove all the bearing cap snap rings (Fig. 19).
- (4) Set the joint in an arbor press or vise with a socket whose inside diameter is large enough to receive the bearing cap positioned beneath the link yoke.
- (5) Place a socket with an outside diameter smaller than the upper bearing cap on the upper bearing cap and partially press one bearing cap from




Fig. 19 Remove Snap Rings

the outboard side of the link yoke enough to grasp the bearing cap with vise jaws (Fig. 20). Be sure to remove grease fittings that interfere with removal.





Fig. 20 Press Out Bearing

- (6) Grasp the protruding bearing by vise jaws. Tap the link yoke with a mallet and drift to dislodge the bearing cap from the yoke (Fig. 21).

(7) Flip assembly and repeat Step 4, Step 5, and Step 6 to remove the opposite bearing cap. This will then allow removal of the cross centering kit assembly and spring (Fig. 22).


DISASSEMBLY AND ASSEMBLY (Continued)



J9316-7

Fig. 21 Remove Bearing From Yoke


- (1) Apply extreme pressure (EP) N.L.G.I. Grade 1 or 2 grease to inside of yoke bores to aid in installation.
- (2) Fit a cross into the propeller shaft yoke (Fig. 23).



J9316-9

Fig. 23 Install Cross In Yoke

- (3) Place a bearing cap over the trunnion and align the cap with the yoke bore (Fig. 24). Keep the needle bearings upright in the bearing assembly. A needle bearing lying at the bottom of the cap will prevent proper assembly.




J9316-8

Fig. 22 Remove Centering Kit

- (8) Press the remaining bearing caps out the other end of the link yoke as described above to complete the disassembly.

ASSEMBLY

During assembly, ensure that the alignment marks on the link yoke and propeller shaft yoke are aligned.



J9316-10

Fig. 24 Install Bearing Cap

- (4) Press the bearing cap into the yoke bore enough to install a snap ring (Fig. 25).

DISASSEMBLY AND ASSEMBLY (Continued)

(5) Install a snap ring.




Fig. 25 Press In Bearing Cap

(6) Flip the propeller shaft yoke and install the bearing cap onto the opposite trunnion. Install a snap ring (Fig. 26).




Fig. 26 Press In Bearing Cap

(7) Fit the link yoke on the remaining two trunnions and press both bearing caps into place (Fig. 27).

(8) Install snap rings.




Fig. 27 Install Link Yoke

(9) Install the centering kit assembly inside the link yoke making sure the spring is properly positioned (Fig. 28).





Fig. 28 Install Centering Kit

DISASSEMBLY AND ASSEMBLY (Continued)


(10) Place two bearing caps on opposite trunnions of the remaining cross. Fit the open trunnions into the link yoke bores and the bearing caps into the centering kit (Fig. 29).



J9316-15

Fig. 29 Install Remaining Cross

(11) Press the remaining two bearing caps into place and install snap rings (Fig. 30).




J9316-16

Fig. 30 Press In Bearing Cap

(12) Tap the snap rings to allow them to seat into the grooves (Fig. 31).


(13) Check for proper assembly. Flex the joint beyond center, it should snap over-center in both directions when correctly assembled (Fig. 32).

(14) Install the propeller shaft.



J9316-17

Fig. 31 Seat Snap Rings In Groove



J9316-18

Fig. 32 Check Assembly

CLEANING AND INSPECTION

PROPELLER SHAFT

(1) Clean all universal joint bores with cleaning solvent and a wire brush.

(2) Inspect the yokes for distortion, cracks, and worn bearing cap bores.

ADJUSTMENTS

ADJUSTMENT AT AXLE WITH LEAF SPRINGS

Adjust the pinion shaft angle at the springs with tapered shims (Fig. 33). Install tapered shims between the springs and axle pad to correct the angle. Refer to Group 2, Suspension, for additional information.




Fig. 33 Angle Adjustment at Leaf Springs

CENTER BEARING ADJUSTMENT

Drive away shudder is a vibration that occurs at first acceleration from a stop. Shudder vibration usually peaks at the engine's highest torque output. Shudder is a symptom associated with vehicles using a two-piece propeller shaft. To decrease shudder, lower the center bearing in 1/8 inch increments. Use shim stock or fabricated plates. Plate stock must be used to maintain compression of the rubber insulator around the bearing. Do not use washers. Replace the original bolts with the appropriate increased length bolts.


SPECIFICATIONS

TORQUE


DESCRIPTION	TORQUE
Bolts, Center Bearing68 N·m (50 ft. lbs.)
Bolts, Transfer Case Yoke27 N·m (20 ft. lbs.)
Bolts, Axle Yoke19 N·m (14 ft. lbs.)

SPECIAL TOOLS


PROPELLER SHAFT



Inclinometer—7663



Bearing Splitter—1130



Installer, Bearing—6052

FRONT AXLE DRIVESHAFTS

INDEX

	page		page
GENERAL INFORMATION		FRONT DRIVESHAFT	16
FRONT AXLE DRIVESHAFTS	15	DISASSEMBLY AND ASSEMBLY	
DIAGNOSIS AND TESTING		INNER C/V JOINT	18
CLUNKING NOISE DURING ACCELERATION ...	16	OUTER C/V JOINT	19
NOISE AND/OR VIBRATION IN TURNS	16	CLEANING AND INSPECTION	
SHUDDER OR VIBRATION DURING		C/V JOINT	22
ACCELERATION	16	C/V JOINT BOOTS	23
VEHICLE INSPECTION	16	SPECIFICATIONS	
VIBRATION AT HIGHWAY SPEEDS	16	TORQUE	23
REMOVAL AND INSTALLATION		SPECIAL TOOLS	
C/V JOINT BOOTS	17	C/V JOINT DRIVESHAFT	23


GENERAL INFORMATION

FRONT AXLE DRIVESHAFTS

The two constant velocity (C/V) drive shafts are identical and interchangeable. They are comprised of three major components (Fig. 1):

- An inner, tripod C/V joint

- A short, solid interconnecting shaft
 - An outer, Rzeppa C/V joint with stub shaft
- The inner tripod-joints are attached to the axle shaft flanges (Fig. 1). The outer joint is splined and mates with the hub bearing on the knuckle.
- The lubricant amounts included with replacement rubber boots are different for inner and outer C/V



80aa0eb6

Fig. 1 C/V Drive Shaft Components

GENERAL INFORMATION (Continued)

joints. Apply only the specified lubricant amount to each C/V joint.

CAUTION: Proper C/V joint boot sealing is critical for retaining the special lubricant. Prevent foreign material from entering and contaminating the C/V joints. Mishandling a C/V drive shaft can cause a boot to be punctured or damage within the joints. Always support both ends of the C/V drive shaft during removal and installation to avoid damage.

When replacing C/V drive shaft components, ensure that only exact replacements parts are installed.

DIAGNOSIS AND TESTING

VEHICLE INSPECTION

(1) Check for grease in the vicinity of the inboard tripod joint and outboard C/V joint; this is a sign of inner or outer joint seal boot or seal boot clamp damage.

(2) A light film of grease may appear on the right inner tripod joint seal boot; this is considered normal and should not require replacement of the seal boot.

NOISE AND/OR VIBRATION IN TURNS

A clicking noise and/or a vibration in turns could be caused by one of the following conditions:

- Damaged outer C/V or inner tripod joint seal boot or seal boot clamps. This will result in the loss and/or contamination of the joint grease, resulting in inadequate lubrication of the joint.
- Noise may also be caused by another component of the vehicle coming in contact with the driveshafts.

CLUNKING NOISE DURING ACCELERATION

This noise may be a result of one of the following conditions:

- A torn seal boot on the inner or outer joint of the driveshaft assembly which has allowed the C/V joint to become damaged.
- A loose or missing clamp on the inner or outer joint of the driveshaft assembly which has allowed the C/V joint to become damaged.
- A damaged or worn driveshaft C/V joint.

SHUDDER OR VIBRATION DURING ACCELERATION

This problem could be a result of:

- A worn or damaged driveshaft inner tripod joint.
- A sticking tripod joint spider assembly (inner tripod joint only).
- Improper wheel alignment. Refer to Group 2, Suspension, for alignment checking and setting procedures and specifications.

VIBRATION AT HIGHWAY SPEEDS

This problem could be a result of:

- Foreign material (mud, etc.) packed on the back-side of the wheel(s).
- Out of balance front tires or wheels. Refer to Group 22, Wheels And Tires, for the required balancing procedure.
- Improper tire and/or wheel runout. Refer to Group 22, Wheels And Tires, for the required runout checking procedure.

REMOVAL AND INSTALLATION

FRONT DRIVESHAFT

REMOVAL

(1) Remove the cotter pin, nut lock, and spring washer from the stub shaft (Fig. 2).




Fig. 2 Cotter Pin, Nut Lock & Spring Washer Removal

(2) Loosen the lug nuts and hub nut while the vehicle is on the surface with the brakes applied (Fig. 3).




Fig. 3 Loosening Wheel Hub Nut

- (3) Raise the vehicle.
- (4) Remove the skid plate, if equipped.

REMOVAL AND INSTALLATION (Continued)

- (5) Remove the hub nut and washer from the stub shaft (Fig. 4).
- (6) Remove the wheel and tire.




Fig. 4 Hub Nut & Washer

- (7) Loosen the bolts that attach the inner C/V joint to the axle shaft.
- (8) Remove the brake caliper and rotor. Refer to Group 5, Brakes, for proper procedures.
- (9) Remove the ABS wheel speed sensor, if equipped. Refer to Group 5, Brakes, for proper procedures.
- (10) Remove the bolts holding the hub bearing to the knuckle.
- (11) Remove hub bearing from axle driveshaft and steering knuckle.
- (12) Support the drive shaft at the C/V joint housings.
- (13) Remove bolts that attach the inner C/V joint to the axle shaft.
- (14) Remove the driveshaft from the vehicle.

INSTALLATION

- (1) Insert the CV drive shaft stub into the hub bearing bore of the steering knuckle.
- (2) Attach the inner joint flange to the axle shaft flange. Tighten the bolts to 90 N·m (65 ft. lbs.) torque.
- (3) Clean hub bearing bore, axle driveshaft splines, and hub bearing mating surface of all foreign materials. Apply light coating of grease to all mating surfaces.
- (4) Install the hub bearing to the axle driveshaft and the steering knuckle.
- (5) Install the bolts to hold the hub bearing to the steering knuckle. Tighten bolts to 166 N·m (123 ft. lbs.).
- (6) Clean all foreign material from the stub shaft threads. Install the hub nut and washer.

(7) Install the ABS wheel speed sensor, if equipped. Refer to Group 5, Brakes, for proper procedures.

(8) Install the brake caliper and rotor. Refer to Group 5, Brakes, for proper procedures.

(9) Apply the brakes and tighten hub nut to 244 N·m (180 ft. lbs.) torque.

(10) Install the spring washer, nut lock and cotter pin on the stub shaft (Fig. 5).




Fig. 5 Cotter Pin Installation

- (11) Install the skid plate, if equipped.
- (12) Install the wheel and tire.

C/V JOINT BOOTS

REMOVAL

- (1) Remove axle driveshaft from vehicle.
- (2) Remove outer C/V joint.
- (3) Remove outer C/V joint small clamp and remove boot (Fig. 6).
- (4) Remove inner C/V joint boot clamps and remove boot.




Fig. 6 Boot Retaining Clamp Locations

INSTALLATION

The lubricant amounts included with replacement boots are different for inner and outer C/V joints.

REMOVAL AND INSTALLATION (Continued)

Apply only the specified lubricant amount to each C/V joint.

(1) Clean the C/V joints and shaft of all old grease and foreign matter.

(2) Slide the inner C/V joint boot up the shaft and insert the lip located within the small-diameter end of the boot into the shaft groove (Fig. 6).

(3) Retain the small-diameter of the boot on the shaft with a ladder-type clamp in the boot groove (Fig. 6). Verify that the boot and lip are properly positioned on the intermediate shaft. Position the clamp locating tabs in the slots and tighten the clamp.

(4) Compress the clamp bridge with Remover/Installer C-4124. Squeeze the tool handles to complete the tightening of the clamp (Fig. 7). **Care must be exercised when using the tool to avoid cutting through the clamp bridge or damaging the boot.**




Fig. 7 Compressing Clamp Bridge

(5) Position the large-diameter end of the boot on the C/V joint housing.

(6) After the inner joint boot small clamp is installed, the inboard hub must be set to a service build length.

(a) Compress the inner hub down the connector shaft.

(b) Use a small blunt drift between the large end and the boot seal to relieve the pressure.

(c) The distance edge of the lip to the edge of the flange should be 181.00 mm (7.13 in.). This will eliminate excess air that can cause a ballooning affect and possibly cause damage to the boot.

(7) Verify that the boot is not twisted and that it is correctly positioned on the housing.

(8) Install the large ladder clamp on the boot and secure as done with the small ladder clamps (Fig. 7).

(9) Slide the outer C/V joint boot small clamp onto shaft.

(10) Slide outer C/V joint boot onto shaft and into position on shaft.

(11) Install small clamp to boot as done above.

(12) Install large boot clamp over outer C/V joint.

(13) Install outer C/V joint to shaft.

(14) Install large boot clamp to boot and C/V joint.

(15) Install the C/V driveshaft.

DISASSEMBLY AND ASSEMBLY

INNER C/V JOINT

DISASSEMBLY

(1) Remove the axle driveshaft.

(2) Place the inner C/V joint housing in a vise.

(3) Remove the inner boot retaining clamps. Pull the inner boot back onto the interconnecting shaft. Discard the retaining clamps.

(4) Pull the tripod and shaft straight out from the inner C/V joint housing.

(5) Remove the snap retaining ring from the groove behind the tripod (Fig. 8). Slide the tripod toward the center of the shaft. Remove the C-clip on the outer end of the shaft (Fig. 9).




Fig. 8 Snap Retaining Ring Removal

(6) Remove the tripod from the shaft. Replace the boot, if necessary.

(7) Remove the lubricant from the interior of the housing and from the tripod.

(8) Inspect the needle bearing raceways in the housing and tripod components for excessive wear and damage. Replace the tripod as a unit only if necessary.

DISASSEMBLY AND ASSEMBLY (Continued)




Fig. 9 C-Clip Removal/Installation

ASSEMBLY

- (1) Slide the boot down enough for work access.
- (2) Install the snap ring past the ring groove (toward the center of the shaft). Slide the tripod onto the end of the interconnecting shaft. Be sure the chamfered end of the tripod is adjacent to the C-clip retaining ring groove (Fig. 9).
- (3) Install the C-clip in the groove. Slide the tripod out against the clip. Install the snap ring in the inner groove. Be sure the snap ring and C-clip are seated.
- (4) Apply the required quantity of lubricant to the housing and boot. Coat the interior of the joint housing and the tripod.
- (5) Insert and seat the tripod and shaft in the housing.
- (6) Position the large-diameter end of the inner C/V joint boot over the edge of the housing. Insert the lip of the boot into the locating groove at the edge of the housing (Fig. 10).




Fig. 10 Inner C/V Joint Boot

(7) Insert the small lip into the locating groove in the interconnecting shaft.

(8) Retain the small-diameter of the boot on the shaft with a ladder-type clamp in the boot groove (Fig. 6). Verify that the boot and lip are properly positioned on the intermediate shaft. Position the clamp locating tabs in the slots and tighten the clamp.

(9) Compress the clamp bridge with Remover/Installer C-4124. Squeeze the tool handles to complete the tightening of the clamp (Fig. 11). **Care must be exercised when using the tool to avoid cutting through the clamp bridge or damaging the boot.**




Fig. 11 Compressing Clamp Bridge

(10) Position the large-diameter end of the boot on the C/V joint housing.

(11) After the inner joint boot small clamp is installed, the inboard hub must be set to a service build length.

(a) Compress the inner hub down the connector shaft.

(b) Use a small blunt drift between the large end and the boot seal to relieve the pressure.

(c) The distance edge of the lip to the edge of the flange should be 181.00 mm (7.13 in.). This will eliminate excess air that can cause a ballooning affect and possibly cause damage to the boot.

(12) Verify that the boot is not twisted and that it is correctly positioned on the housing.

(13) Install the large ladder clamp on the boot and secure as done with the small ladder clamp (Fig. 11).

OUTER C/V JOINT

If the outer C/V joint is excessively worn, replace the entire C/V joint and boot.

DISASSEMBLY AND ASSEMBLY (Continued)

DISASSEMBLY

(1) Remove retaining clamps from the outer C/V joint and discard. Slide the boot off the outer joint and down the shaft.

(2) Remove the lubricant to expose the outer C/V joint components (Fig. 12).




Fig. 12 Outer C/V Joint Components

(3) Clamp the shaft in a vise (with soft jaws). Support the outer C/V joint.

(4) Use snap ring pliers to release the clip from the groove.

(5) Slide the outer C/V joint from the shaft (Fig. 13).




Fig. 13 Outer C/V Joint Removal

(6) Remove the slinger, if damaged, from the outer C/V joint. Use a brass drift and a hammer. Tap slinger ring off C/V joint and discard.

(7) Remove the old lubricant. Apply installation alignment marks on the bearing hub, bearing cage and housing with dabs of paint (Fig. 14).

(8) Clamp the outer C/V joint in a vertical position. Place the stub shaft in a soft-jawed vise.




Fig. 14 Ball Access

(9) Press down on one side of the bearing cage/hub to tilt the cage. This will provide access to a ball at the opposite side of the cage. If the C/V joint is tight, use a hammer and brass drift to loosen the bearing hub. **Do not contact the bearing cage with the drift.**

(10) Remove the ball from the bearing cage (Fig. 15). If necessary, a small pry bar can be used to pry the ball loose from the cage.




Fig. 15 Ball Removal

(11) Repeat the step above until all six balls are removed from the bearing cage.

(12) Tilt the bearing cage and hub to a vertical position. Remove the cage from the housing. Pull cage upward and away from the housing (Fig. 16).

(13) Turn the bearing hub 90° from the bearing cage. Align one pair of the hub lands with the cage windows. Raise and insert one of the lands into the adjacent cage window. Remove the bearing hub by rolling it out of the cage (Fig. 17).

ASSEMBLY

(1) Lightly apply lubricating oil to all the outer C/V joint components before assembling them.

DISASSEMBLY AND ASSEMBLY (Continued)




Fig. 16 Bearing Cage & Hub Removal




Fig. 17 Bearing Hub Removal

(2) Align the bearing hub, cage and housing (Fig. 14) according to the alignment reference marks.

(3) Insert one of the bearing hub lands into a bearing cage window (Fig. 17). Roll the hub into the cage (Fig. 18). Rotate the bearing hub 90° to complete the installation (Fig. 19).





Fig. 18 Bearing Hub Installation



RN312

Fig. 19 Assembled Bearing Cage & Hub

(4) Insert bearing cage/hub into the housing (Fig. 20). Rotate the cage/hub 90° to complete the installation (Fig. 21).




Fig. 20 Bearing Cage & Hub Installation




Fig. 21 Bearing Cage & Hub Installed In Housing

(5) Apply the lubricant included with the replacement boot to the ball raceways. Spread the lubricant

DISASSEMBLY AND ASSEMBLY (Continued)

equally between all the raceways. One packet of lubricant is sufficient to lubricate the complete C/V joint.

(6) Tilt the bearing hub and cage and install the balls in the raceways (Fig. 22).




Fig. 22 Ball Installation In Raceway

(7) Apply a small amount of lubricant to inner diameter of slinger. Place slinger squarely on the outer C/V joint. Use installer tool L-4518-1 from tool set L-4518 and hammer slinger onto joint until it seats (Fig. 23).




Fig. 23 Slinger Installation

CAUTION: Prevent damage to the slinger after installation or a when a replacement outer C/V joint is installed.

(8) Position the small-diameter end of the replacement boot on the interconnecting shaft. Retain the boot with a replacement clamp.

(9) Apply the required amount of lubricant to the outer C/V joint and boot.

(10) Align the shaft splines to the outer C/V joint splines. Push the outer C/V joint until the snap ring seats in the groove (Fig. 24).




Fig. 24 Outer C/V Joint Installation

(11) Ensure that the snap ring is properly seated in the housing. Pull the outer C/V joint from the interconnecting shaft to test.

(12) Place the large-diameter end of the replacement boot over the edge of the C/V joint housing. Ensure that the boot is not twisted.

(13) Retain the boot on the housing with a replacement retaining clamps.

CLEANING AND INSPECTION

C/V JOINT

Inspect the lubricant for contamination. Inspect the C/V joint components for defects according to the following instructions.

(1) Clean all the components with an appropriate solvent and dry them with compressed air.

(2) Inspect the ball raceways in the housing for excessive wear and scoring.


(3) Examine the stub shaft splines and threads for damage.

(4) Inspect the balls for pitting, cracks, scoring and excessive wear. A dull exterior surface is normal.

(5) Inspect the bearing cage for wear, grooves, ripples, cracks and chipping.

(6) Inspect the bearing hub (Fig. 25) for excessive wear and scoring on ball raceways.

CLEANING AND INSPECTION (Continued)



80aa0eb6

Fig. 25 Drive Shaft Components


Polished contact surface areas on the raceways and on the bearing cage spheres are normal. If the joints cause a noise or a vibration, replace them.

SPECIAL TOOLS

C/V JOINT DRIVESHAFT

C/V JOINT BOOTS

Look for lubricant around the exterior of a boot. When a C/V drive shaft is removed from the vehicle for service, the boot should be properly cleaned. Inspect for cracks, tears and scuffed areas on the surfaces. If any of these conditions exist, boot replacement is recommended.




SPECIFICATIONS

Tool Set—L-4518

TORQUE

DESCRIPTION	TORQUE
Bolts, Axle Flange	90 N·m (65 ft. lbs.)
Nut, Axle	244 N·m (180 ft. lbs.)



Remover/Installer—C-4124

194 FIA AXLE

INDEX

	page		page
GENERAL INFORMATION		DIFFERENTIAL SIDE BEARINGS	36
194 FIA AXLE	24	DIFFERENTIAL SIDE BEARINGS	36
LUBRICANT SPECIFICATIONS	24	FINAL ASSEMBLY	40
DESCRIPTION AND OPERATION		FRONT AXLE	29
STANDARD DIFFERENTIAL	25	PINION GEAR	36
DIAGNOSIS AND TESTING		PINION SHAFT SEAL	30
BEARING NOISE	26	DISASSEMBLY AND ASSEMBLY	
DRIVELINE SNAP	26	STANDARD DIFFERENTIAL	41
FRONT AXLES	27	CLEANING AND INSPECTION	
GEAR NOISE	25	AXLE COMPONENTS	41
GENERAL INFORMATION	25	ADJUSTMENTS	
LOW SPEED KNOCK	26	DIFFERENTIAL BEARING PRELOAD AND	
VIBRATION	26	GEAR BACKLASH	44
SERVICE PROCEDURES		GEAR CONTACT PATTERN ANALYSIS	47
LUBRICANT CHANGE	29	PINION GEAR DEPTH	42
REMOVAL AND INSTALLATION		SPECIFICATIONS	
AXLE SHAFT	34	194 FIA AXLE	49
AXLE SHAFT SEAL AND BEARING	34	194 FIA AXLE	49
COLLAPSIBLE SPACER	31	SPECIAL TOOLS	
DIFFERENTIAL	34	194 FIA AXLE	49

GENERAL INFORMATION

194 FIA AXLE

The 194 Front Independent-design Aluminum (FIA) axle consists of an aluminum center section with an axle tube extending from one side. The tube is pressed into the differential housing and welded.

The integral type housing, hypoid gear design has the centerline of the pinion set below the centerline of the ring gear.

The axle has a fitting for a vent hose used to relieve internal pressure caused by vaporization and internal expansion.

The power is transferred from the axle through two constant velocity (C/V) drive shafts to the wheel hubs. The drive shafts are identical and interchangeable.

The cover provides a means for inspection and service without removing the axle from the vehicle.

The 194 FIA axle has the assembly part number and gear ratio listed on a tag. The tag is attached to the housing cover by a cover bolt.

The differential case is a one-piece design. The differential pinion mate shaft is retained with a roll-

pin. Differential bearing preload and ring gear backlash is adjusted by the use of shims (select thickness). The shims are located between the differential bearing cones and the differential case. Pinion bearing preload is set and maintained by the use of a collapsible spacer.

LUBRICANT SPECIFICATIONS

A multi-purpose, hypoid gear lubricant which conforms to the following specifications should be used. Mopar® Hypoid Gear Lubricant conforms to all of these specifications.

- The lubricant should have MIL-L-2105C and API GL 5 quality specifications.
- Lubricant is a thermally stable SAE 80W-90 gear lubricant.

The 194 FIA axle lubricant capacity is 1.72 L (3.6 pts.).

CAUTION: If axle is submerged in water, lubricant must be replaced immediately to avoid possible premature axle failure.

DESCRIPTION AND OPERATION

STANDARD DIFFERENTIAL

The differential gear system divides the torque between the axle shafts. It allows the axle shafts to rotate at different speeds when turning corners.

Each differential side gear is splined to an axle shaft. The pinion gears are mounted on a pinion mate shaft and are free to rotate on the shaft. The pinion gear is fitted in a bore in the differential case and is positioned at a right angle to the axle shafts.

In operation, power flow occurs as follows:

- The pinion gear rotates the ring gear
- The ring gear (bolted to the differential case) rotates the case
- The differential pinion gears (mounted on the pinion mate shaft in the case) rotate the side gears
- The side gears (splined to the axle shafts) rotate the shafts

During straight-ahead driving, the differential pinion gears do not rotate on the pinion mate shaft. This occurs because input torque applied to the gears is divided and distributed equally between the two side gears. As a result, the pinion gears revolve with the pinion mate shaft but do not rotate around it (Fig. 1).




Fig. 1 Differential Operation—Straight Ahead Driving

When turning corners, the outside wheel must travel a greater distance than the inside wheel to complete a turn. The difference must be compensated for to prevent the tires from scuffing and skidding through turns. To accomplish this, the differential allows the axle shafts to turn at unequal speeds (Fig. 2). In this instance, the input torque applied to the pinion gears is not divided equally. The pinion gears now rotate around the pinion mate shaft in opposite directions. This allows the side gear and axle shaft attached to the outside wheel to rotate at a faster speed.




Fig. 2 Differential Operation—On Turns

DIAGNOSIS AND TESTING

GENERAL INFORMATION

Axle bearing problem conditions are usually caused by:

- Insufficient or incorrect lubricant.
- Foreign matter/water contamination.
- Incorrect bearing preload torque adjustment.
- Incorrect backlash.

Axle gear problem conditions are usually the result of:

- Insufficient lubrication.
- Incorrect or contaminated lubricant.
- Overloading (excessive engine torque) or exceeding vehicle weight capacity.
- Incorrect clearance or backlash adjustment.

Axle component breakage is most often the result of:

- Severe overloading.
- Insufficient lubricant.
- Incorrect lubricant.
- Improperly tightened components.

GEAR NOISE

Axle gear noise can be caused by insufficient lubricant, incorrect backlash, tooth contact, or worn/damaged gears.

Gear noise usually happens at a specific speed range. The range is 30 to 40 mph, or above 50 mph. The noise can also occur during a specific type of driving condition. These conditions are acceleration, deceleration, coast, or constant load.

When road testing, accelerate the vehicle to the speed range where the noise is the greatest. Shift out-of-gear and coast through the peak-noise range. If the noise stops or changes greatly:

- Check for insufficient lubricant.
- Incorrect ring gear backlash.
- Gear damage.

DIAGNOSIS AND TESTING (Continued)

Differential side and pinion gears can be checked by turning the vehicle. They usually do not cause noise during straight-ahead driving when the gears are unloaded. The side gears are loaded during vehicle turns. A worn pinion gear mate shaft can also cause a snapping or a knocking noise.

BEARING NOISE

The axle shaft, differential and pinion gear bearings can all produce noise when worn or damaged. Bearing noise can be either a whining, or a growling sound.

Pinion gear bearings have a constant-pitch noise. This noise changes only with vehicle speed. Pinion bearing noise will be higher because it rotates at a faster rate. Drive the vehicle and load the differential. If bearing noise occurs, the rear pinion bearing is the source of the noise. If the bearing noise is heard during a coast, the front pinion bearing is the source.

Worn or damaged differential bearings usually produce a low pitch noise. Differential bearing noise is similar to pinion bearing noise. The pitch of differential bearing noise is also constant and varies only with vehicle speed.

Axle shaft bearings produce noise and vibration when worn or damaged. The noise generally changes when the bearings are loaded. Road test the vehicle. Turn the vehicle sharply to the left and to the right. This will load the bearings and change the noise level. Where axle bearing damage is slight, the noise is usually not noticeable at speeds above 30 mph.

LOW SPEED KNOCK

Low speed knock is generally caused by a worn U-joint or by worn side-gear thrust washers. A worn pinion gear shaft bore will also cause low speed knock.

VIBRATION

Vibration at the rear of the vehicle is usually caused by a:

- Damaged drive shaft.
- Missing drive shaft balance weight(s).
- Worn or out-of-balance wheels.
- Loose wheel lug nuts.
- Worn U-joint(s).
- Loose/broken springs.
- Damaged axle shaft bearing(s).
- Loose pinion gear nut.
- Excessive pinion yoke run out.
- Bent axle shaft(s).

Check for loose or damaged front-end components or engine/transmission mounts. These components can contribute to what appears to be a rear-end vibration. Do not overlook engine accessories, brackets and drive belts.

All driveline components should be examined before starting any repair.

Refer to Group 22, Wheels and Tires, for additional vibration information.

DRIVELINE SNAP

A snap or clunk noise when the vehicle is shifted into gear (or the clutch engaged), can be caused by:

- High engine idle speed
- Loose engine/transmission/transfer case mounts
- Worn U-joints
- Loose spring mounts
- Loose pinion gear nut and yoke
- Excessive ring gear backlash
- Excessive side gear/case clearance

The source of a snap or a clunk noise can be determined with the assistance of a helper. Raise the vehicle on a hoist with the wheels free to rotate. Instruct the helper to shift the transmission into gear. Listen for the noise, a mechanics stethoscope is helpful in isolating the source of a noise.

DIAGNOSIS AND TESTING (Continued)

FRONT AXLES

CONDITION	POSSIBLE CAUSES	CORRECTION
WHEEL NOISE	<ol style="list-style-type: none"> 1. Wheel loose. 2. Faulty, brinelled wheel bearing. 	<ol style="list-style-type: none"> 1. Tighten loose nuts. 2. Faulty or brinelled bearings must be replaced.
AXLE SHAFT NOISE	<ol style="list-style-type: none"> 1. Misaligned axle shaft tube. 2. Bent or sprung axle shaft. 3. End play in drive pinion bearings. 4. Excessive gear backlash between ring gear and pinion gear. 5. Improper adjustment of drive pinion gear shaft bearings. 6. Loose drive pinion gearshaft yoke nut. 7. Improper wheel bearing adjustment. 8. Scuffed gear tooth contact surfaces. 	<ol style="list-style-type: none"> 1. Inspect axle shaft tube alignment. Correct as necessary. 2. Replace bent or sprung axle shaft. 3. Refer to Drive Pinion Bearing Pre-Load Adjustment. 4. Check adjustment of ring gear backlash and pinion gear. Correct as necessary. 5. Adjust drive pinion shaft bearings. 6. Tighten drive pinion gearshaft yoke nut with specified torque. 7. Readjust as necessary. 8. If necessary, replace scuffed gears.
AXLE SHAFT BROKE	<ol style="list-style-type: none"> 1. Misaligned axle shaft tube. 2. Vehicle overloaded. 3. Erratic clutch operation. 4. Grabbing clutch. 	<ol style="list-style-type: none"> 1. Replace broken axle shaft after correcting axle shaft tube alignment. 2. Replace broken axle shaft. Avoid excessive weight on vehicle. 3. Replace broken axle shaft after inspecting for other possible causes. Avoid erratic use of clutch. 4. Replace broken axle shaft. Inspect clutch and make necessary repairs or adjustments.
DIFFERENTIAL CASE CRACKED	<ol style="list-style-type: none"> 1. Improper adjustment of differential bearings. 2. Excessive ring gear backlash. 3. Vehicle overloaded. 4. Erratic clutch operation. 	<ol style="list-style-type: none"> 1. Replace cracked case; examine gears and bearings for possible damage. At reassembly, adjust differential bearings properly. 2. Replace cracked case; examine gears and bearings for possible damage. At reassembly, adjust ring gear backlash properly. 3. Replace cracked case; examine gears and bearings for possible damage. Avoid excessive weight on vehicle. 4. Replace cracked case. After inspecting for other possible causes, examine gears and bearings for possible damage. Avoid erratic use of clutch.
DIFFERENTIAL GEARS SCORED	<ol style="list-style-type: none"> 1. Insufficient lubrication. 2. Improper grade of lubricant. 3. Excessive spinning of one wheel/tire. 	<ol style="list-style-type: none"> 1. Replace scored gears. Scoring marks on the drive face of gear teeth or in the bore are caused by instantaneous fusing of the mating surfaces. Scored gears should be replaced. Fill rear differential housing to required capacity with proper lubricant. Refer to Specifications. 2. Replace scored gears. Inspect all gears and bearings for possible damage. Clean and refill differential housing to required capacity with proper lubricant. 3. Replace scored gears. Inspect all gears, pinion bores and shaft for damage. Service as necessary.
LOSS OF LUBRICANT	<ol style="list-style-type: none"> 1. Lubricant level too high. 	<ol style="list-style-type: none"> 1. Drain excess lubricant by removing fill plug and allow lubricant to level at lower edge of fill plug hole.

DIAGNOSIS AND TESTING (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
LOSS OF LUBRICANT	<ol style="list-style-type: none"> 2. Worn axle shaft seals. 3. Cracked differential housing. 4. Worn drive pinion gear shaft seal. 5. Scored and worn yoke. 6. Axle cover not properly sealed. 	<ol style="list-style-type: none"> 2. Replace worn seals. 3. Repair or replace housing as necessary. 4. Replace worn drive pinion gear shaft seal. 5. Replace worn or scored yoke and seal. 6. Remove cover and clean flange and reseal.
AXLE OVERHEATING	<ol style="list-style-type: none"> 1. Lubricant level too low. 2. Incorrect grade of lubricant. 3. Bearings adjusted too tight. 4. Excessive gear wear. 5. Insufficient ring gear backlash. 	<ol style="list-style-type: none"> 1. Refill differential housing. 2. Drain, flush and refill with correct amount of the correct lubricant. 3. Readjust bearings. 4. Inspect gears for excessive wear or scoring. Replace as necessary. 5. Readjust ring gear backlash and inspect gears for possible scoring.
GEAR TEETH BROKE (RING GEAR AND PINION)	<ol style="list-style-type: none"> 1. Overloading. 2. Erratic clutch operation. 3. Ice-spotted pavements. 4. Improper adjustments. 	<ol style="list-style-type: none"> 1. Replace gears. Examine other gears and bearings for possible damage. 2. Replace gears and examine the remaining parts for possible damage. Avoid erratic clutch operation. 3. Replace gears. Examine the remaining parts for possible damage. Replace parts as required. 4. Replace gears. Examine other parts for possible damage. Ensure ring gear backlash is correct.
AXLE NOISE	<ol style="list-style-type: none"> 1. Insufficient lubricant. 2. Improper ring gear and drive pinion gear adjustment. 3. Unmatched ring gear and drive pinion gear. 4. Worn teeth on ring gear or drive pinion gear. 5. Loose drive pinion gear shaft bearings. 6. Loose differential bearings. 7. Misaligned or sprung ring gear. 8. Loose differential bearing cap bolts 	<ol style="list-style-type: none"> 1. Refill axle with correct amount of the proper lubricant. Also inspect for leaks and correct as necessary. 2. Check ring gear and pinion gear teeth contact pattern. 3. Remove unmatched ring gear and drive pinion gear. Replace with matched gear and drive pinion gear set. 4. Check teeth on ring gear and drive pinion gear for correct contact. If necessary, replace with new matched set. 5. Adjust drive pinion gearshaft bearing preload torque. 6. Adjust differential bearing preload torque. 7. Measure ring gear runout. 8. Tighten with specified torque

SERVICE PROCEDURES

LUBRICANT CHANGE

- (1) Raise and support the vehicle.
- (2) Remove the lubricant fill hole plug from the differential housing cover.
- (3) Remove the differential housing cover and drain the lubricant from the housing.
- (4) Clean the housing cavity with a flushing oil, light engine oil or lint free cloth. **Do not use water, steam, kerosene or gasoline for cleaning.**
- (5) Remove the sealant from the housing and cover surfaces. Use solvent to clean the mating surfaces.
- (6) Apply a bead of Mopar® Silicone Rubber Sealant, or equivalent, to the housing cover (Fig. 3).




Fig. 3 Typical Housing Cover With Sealant

Install the housing cover within 5 minutes after applying the sealant.

- (7) Install the cover and any identification tag. Tighten the cover bolts in a criss-cross pattern to 41 N·m (30 ft. lbs.) torque.
- (8) Refill the differential with Mopar® Hypoid Gear Lubricant, or equivalent, to bottom of the fill plug hole. Refer to the Lubricant Specifications in this group for the quantity necessary.
- (9) Install the fill hole plug and lower the vehicle. Tighten fill plug to 34 N·m (25 ft. lbs.).

REMOVAL AND INSTALLATION

FRONT AXLE

REMOVAL

- (1) Raise and support the vehicle.
- (2) Remove the skid plate, if equipped.
- (3) Remove skid plate support crossmember.
- (4) Mark the C/V driveshaft and axle shaft flanges for installation alignment reference.
- (5) Remove the bolts holding the C/V driveshafts to the axle shaft flanges.
- (6) Separate the C/V driveshafts from the axle shaft flanges.
- (7) Mark the propeller shaft, transfer case, and pinion yokes for installation alignment reference.
- (8) Remove the front propeller shaft.
- (9) Remove the axle vent tube.
- (10) Use an adjustable and movable jack to support the differential housing.
- (11) Remove bolts holding the axle to the engine-to-transmission brackets (Fig. 4) and (Fig. 5).
- (12) Remove bolts holding the axle to the engine mounts.
- (13) Lower the jack and housing.
- (14) Remove the axle from vehicle.





Fig. 4 Left Side Axle Mounting

REMOVAL AND INSTALLATION (Continued)

**Fig. 5 Right Side Axle Mounting****INSTALLATION**

(1) Raise the axle into position. Loosely install the bolts and nuts to the brackets.

(2) Tighten all the bolts finger-tight, then tighten according to the following specifications:

- Axle to engine mount bolts and nuts to 102 N·m (75 ft. lbs.).
- Axle to engine-to-transmission bracket bolts 54 N·m (40 ft. lbs.).

(3) Install the axle vent tube.

(4) Align the reference marks on the propeller shaft, transfer case, and pinion yokes.

(5) Install propeller shaft.

(6) Align the reference marks made on the C/V driveshaft and axle flanges.

(7) Install the C/V driveshafts to the axle shaft flanges.

(8) Install the skid plate support crossmember.

(9) Install the skid plate, if necessary. Tighten the bolts to 23 N·m (200 in. lbs.) torque.


(10) Adjust the vehicle in a level position. Check the differential housing lubricant level.

(11) Check differential lubricant level and add lubricant, if necessary. Refer to Lubricant Specifications in this group for lubricant requirements.

(12) Remove the supports and lower the vehicle.

PINION SHAFT SEAL**REMOVAL**

- (1) Raise and support the vehicle.
- (2) Remove skid plate, if equipped.
- (3) Mark the C/V driveshaft and axle flanges for installation alignment reference.
- (4) Remove the bolts holding the driveshafts to the axle shafts.
- (5) Separate the driveshaft from the axle shafts.
- (6) Mark the propeller shaft and pinion yoke for installation alignment reference.
- (7) Remove the propeller shaft from the yoke.
- (8) Rotate the pinion gear three or four times.
- (9) Measure the amount of torque necessary to rotate the pinion gear with a (in. lbs.) dial-type torque wrench. Record the torque reading for installation reference.
- (10) Using Yoke Holder 6958, remove the pinion nut and washer.
- (11) Use Remover C-452 and Wrench C-3281 to remove the pinion yoke (Fig. 6).

**Fig. 6 Pinion Yoke Removal**

(12) Remove the pinion seal excluder from the pinion yoke.

(13) Using a suitable pry tool, or a slide hammer mounted screw, remove the pinion seal.

INSTALLATION

(1) Apply a light coating of gear lubricant on the lip of pinion seal.

(2) Install seal with Installer D-163 and Handle C-4171 (Fig. 7).

(3) Install new pinion seal excluder to pinion yoke.

REMOVAL AND INSTALLATION (Continued)




Fig. 7 Pinion Seal Installation

(4) Install yoke on the pinion gear with Screw 8112, Cup 8109, and Holder 6958 (Fig. 8).

CAUTION: Do not exceed the minimum tightening torque when installing the pinion yoke at this point. Damage to the collapsible spacer or bearings may result.

(5) Install the yoke washer and a new nut on the pinion gear and tighten the pinion nut until there is zero bearing end-play.

(6) Tighten the nut to 271 N·m (200 ft. lbs.).




Fig. 8 Pinion Yoke Installation

CAUTION: Never loosen pinion gear nut to decrease pinion gear bearing rotating torque and never exceed specified preload torque. If preload torque or rotating torque is exceeded a new collapsible spacer must be installed. The torque sequence will then have to be repeated.

(7) Rotate the pinion shaft using a (in. lbs.) torque wrench. Rotating torque should be equal to the reading recorded during removal plus an additional 0.56 N·m (5 in. lbs.) (Fig. 9).

(8) If the rotating torque is low, use Holder 6958 to hold the pinion yoke, and tighten the pinion shaft




Fig. 9 Check Pinion Rotation Torque

nut in 6.8 N·m (5 ft. lbs.) increments until the proper rotating torque is achieved.

CAUTION: If the maximum tightening torque is reached prior to reaching the required rotating torque, the collapsible spacer may have been damaged. Replace the collapsible spacer.

(9) Align the installation reference marks on the propeller shaft and yoke and install the propeller shaft.

(10) Add gear lubricant to the differential housing, if necessary. Refer to the Lubricant Specifications for gear lubricant requirements.

(11) Align the reference marks on the driveshaft and axle shaft flanges and install bolts to hold the driveshafts to the axle shafts.

(12) Install skid plate, if equipped.

(13) Lower the vehicle.

COLLAPSIBLE SPACER

REMOVAL W/PINION INSTALLED

- (1) Raise and support the vehicle.
- (2) Remove skid plate, if equipped.
- (3) Mark C/V driveshaft and axle shaft flanges for installation alignment reference.
- (4) Remove bolts holding the driveshafts to the axle shafts.
- (5) Separate the driveshafts from the axle shafts.
- (6) Mark the propeller shaft and pinion yoke for installation reference.
- (7) Remove the propeller shaft from the yoke.
- (8) Rotate the pinion gear three or four times.

REMOVAL AND INSTALLATION (Continued)

(9) Measure the amount of torque necessary to rotate the pinion gear with a (in. lbs.) dial-type torque wrench. Record the torque reading for installation reference.

(10) Using a short piece of pipe and Holder 6958 to hold the pinion yoke, remove the pinion nut and washer.

(11) Use Remover C-452 and Wrench C-3281 to remove the pinion yoke and pinion seal excluder (Fig. 10).

(12) Using a suitable pry tool, or a slide hammer mounted screw, remove the pinion seal.

(13) Remove the front pinion bearing using a pair of suitable pick tools to pull the bearing straight off the pinion gear shaft. It may be necessary to lightly tap the end of the pinion gear with a rawhide or rubber mallet if the bearing becomes bound on the pinion shaft.

(14) Remove the collapsible spacer.




Fig. 10 Pinion Yoke Removal

REMOVAL W/PINION REMOVED

- (1) Raise and support the vehicle.
- (2) Remove skid plate, if equipped.
- (3) Mark C/V driveshaft and axle shaft flanges for installation alignment reference.
- (4) Remove bolts holding the driveshafts to the axle shafts.
- (5) Separate the driveshafts from the axle shafts.
- (6) Mark the propeller shaft and pinion yoke for installation reference.
- (7) Remove the propeller shaft from the yoke.
- (8) Rotate the pinion gear three or four times.
- (9) Measure the amount of torque necessary to rotate the pinion gear with a (in. lbs.) dial-type torque wrench. Record the torque reading for installation reference.
- (10) Remove differential assembly from axle housing.

(11) Using Holder 6958 to hold yoke and a short length of 1 in. pipe, remove the pinion yoke nut and washer.

(12) Using Remover C-452 and Wrench C-3281, remove the pinion yoke and pinion seal excluder from pinion shaft (Fig. 10).

(13) Remove the pinion gear from housing (Fig. 11). Catch the pinion with your hand to prevent it from falling and being damaged.

(14) Remove collapsible spacer from pinion shaft.




Fig. 11 Remove Pinion Gear

INSTALLATION

- (1) Install a new collapsible preload spacer on pinion shaft (Fig. 12).
- (2) If pinion gear was removed, install pinion gear in housing.
- (3) Install pinion front bearing, if necessary.
- (4) Apply a light coating of gear lubricant on the lip of pinion seal. Install seal with Installer D-163 and Handle C-4171 (Fig. 13).
- (5) Inspect pinion seal excluder. Replace if necessary, and install pinion seal excluder on pinion yoke.
- (6) Install yoke with Screw 8112, Cup 8109, and Holder 6958 (Fig. 14).
- (7) If the original pinion bearings are being used, install differential assembly and axle shafts, if necessary.

NOTE: If new pinion bearings were installed, do not install the differential assembly and axle shafts until after the pinion bearing preload and rotating torque are set.

REMOVAL AND INSTALLATION (Continued)




Fig. 12 Collapsible Preload Spacer




Fig. 13 Pinion Seal Installation




Fig. 14 Pinion Yoke Installation

(8) Install the yoke washer and a new nut on the pinion gear. Tighten the pinion nut until there is zero bearing end-play.

(9) Tighten the nut to 271 N·m (200 ft. lbs.).

CAUTION: Never loosen pinion gear nut to decrease pinion gear bearing rotating torque and never exceed specified preload torque. If preload torque or rotating torque is exceeded a new collapsible spacer must be installed. The torque sequence will then have to be repeated.

(10) Using yoke holder 6958, a short length of 1 in. pipe, and a torque wrench set at 474 N·m (350 ft. lbs.), crush collapsible spacer until bearing end play is taken up.

NOTE: If more than 474 N·m (350 ft. lbs.) of torque is necessary to remove the bearing end play, the collapsible spacer is defective and must be replaced.

(11) Slowly tighten the nut in 6.8 N·m (5 ft. lbs.) increments until the rotating torque is achieved. Measure the rotating torque frequently to avoid over crushing the collapsible spacer (Fig. 15).

(12) Check rotating torque with an inch pound torque wrench (Fig. 15). The torque necessary to rotate the pinion gear should be:

- Original Bearings — The reading recorded during removal, plus an additional 0.56 N·m (5 in. lbs.).
- New Bearings — 2 to 5 N·m (15 to 35 in. lbs.).




Fig. 15 Check Pinion Gear Rotation Torque

REMOVAL AND INSTALLATION (Continued)

(13) Install differential assembly and axle shafts, if necessary.

(14) Align marks made previously on yoke and propeller shaft and install propeller shaft.

(15) Align marks made previously on the drive shafts and axle shafts and install driveshafts.

(16) Add gear lubricant, if necessary. Refer to Lubricant Specifications of this section for lubricant requirements.

(17) Install skid plate, if equipped.

(18) Lower vehicle.

AXLE SHAFT

REMOVAL

(1) Raise and support vehicle. Ensure that the transmission is in neutral.

(2) Remove C/V driveshaft from vehicle.

(3) Remove shock absorber, if removing the right axle shaft. Refer to Group 2, Suspension, for proper procedures.

(4) Remove the skid plate, if equipped, if removing the left axle shaft.

(5) Clean all foreign material from housing cover area.

(6) Loosen housing cover bolts. Drain lubricant from the housing. Remove housing cover.

(7) Remove E-clip retaining axle shaft into differential side gears.

(8) Remove axle shaft. Use care to prevent damage to axle shaft bearing and seal, which will remain in axle shaft tube.

(9) Inspect axle shaft seal for leakage or damage.

(10) Inspect roller bearing contact surface on axle shaft for signs of brinelling, galling and pitting. If any of these conditions exist, the axle shaft and/or bearing and seal must be replaced.

INSTALLATION

(1) Lubricate bearing bore and seal lip with gear lubricant. Insert axle shaft through seal, bearing, and engage it into side gear splines.

NOTE: Use care to prevent shaft splines from damaging axle shaft seal lip.

(2) Insert E-clip lock in end of axle shaft.

(3) Install cover and add fluid. Refer to Lubricant Specifications in this group for lubricant requirements.

(4) Install shock absorber, if necessary. Refer to Group 2 Suspension, for proper procedures.

(5) Install skid plate, if necessary.

(6) Install C/V driveshaft.

(7) Lower vehicle.

AXLE SHAFT SEAL AND BEARING

REMOVAL

(1) Remove the axle shaft.

(2) Remove the axle shaft seal from the end of the axle shaft tube with a small pry bar.

NOTE: The seal and bearing can be removed at the same time with the bearing removal tool.

(3) Remove the axle shaft bearing from the axle tube with Bearing Removal Tool C-4660 and Cup 8150.

(4) Inspect the axle shaft tube bore for roughness and burrs. Remove as necessary.

INSTALLATION

Do not install the original axle shaft seal. Always install a new seal.

(1) Wipe the axle shaft tube bore clean.

(2) Install axle shaft bearing with Installer 6436 and Handle C-4171. Ensure that the part number on the bearing is against the installer.

(3) Install the new axle shaft seal with Installer 6437 and Handle C-4171 (Fig. 16).




Fig. 16 Axle Shaft Seal Installation—Typical

(4) Install the axle shaft.

DIFFERENTIAL

REMOVAL

(1) Raise and support vehicle.

(2) Remove the lubricant fill hole plug from the differential housing cover.

(3) Remove the differential housing cover and allow fluid to drain.

(4) Remove axle shafts.

(5) Note the installation reference letters stamped on the bearing caps and housing machined sealing surface (Fig. 17).

REMOVAL AND INSTALLATION (Continued)




Fig. 17 Bearing Cap Identification

- (6) Loosen the differential bearing cap bolts.
- (7) Position Spreader Adapters 8142 on differential case.
- (8) Install bolts to hold Adapters 8142 to differential case.
- (9) Position Spreader W-129-B, with the tool dowel pins seated in the locating holes of Adapters 8142. Tighten the tool turnbuckle finger-tight.
- (10) Install a Pilot Stud L-4438 at the left side of the differential housing. Attach Dial Indicator C-3339 to pilot stud. Load the indicator plunger against the opposite side of the housing and zero the indicator.

CAUTION: Do not spread over 0.38 mm (0.015 in). If the housing is over-spread, it could be distorted or damaged.

- (11) Spread the housing enough to remove the differential case from the housing. Measure the distance with the dial indicator (Fig. 18).
- (12) Remove the dial indicator.
- (13) While holding the differential case in position, remove the differential bearing cap bolts and caps.
- (14) Remove the differential from the housing. Ensure that the differential bearing cups remain in position on the differential bearings.
- (15) Mark or tag the differential bearing cups to indicate which side of the differential they were removed from.
- (16) Remove spreader from housing.




Fig. 18 Spread Axle Housing—Typical

INSTALLATION

If replacement differential bearings or differential case are being installed, differential side bearing shim requirements may change. Refer to the Differential Bearing Preload and Gear Backlash procedures in this section to determine the proper shim selection.

- (1) Position Spreader W-129-B with the tool dowel pins seated in the locating holes of Adapters 8142. Tighten the tool turnbuckle finger-tight.
- (2) Install a Pilot Stud L-4438 at the left side of the differential housing. Attach Dial Indicator C-3339 to pilot stud. Load the indicator plunger against the opposite side of the housing and zero the indicator.

CAUTION: Do not spread over 0.38 mm (0.015 in). If the housing is over-spread, it could be distorted or damaged.

- (3) Spread the housing enough to install the case in the housing. Measure the distance with the dial indicator.
- (4) Remove the dial indicator.
- (5) Install differential case in the housing. Ensure that the differential bearing cups remain in position on the differential bearings. Tap the differential case to ensure the bearings cups are fully seated in the housing.

REMOVAL AND INSTALLATION (Continued)

(6) Install the bearing caps at their original locations (Fig. 19).




Fig. 19 Differential Bearing Cap Reference Letters

- (7) Loosely install differential bearing cap bolts.
- (8) Remove axle housing spreader.
- (9) Tighten the bearing cap bolts to 61 N·m (45 ft. lbs.) torque.
- (10) Install the axle shafts.

DIFFERENTIAL SIDE BEARINGS

REMOVAL

- (1) Remove differential from axle housing.
- (2) Remove the bearings from the differential case with Puller/Press C-293-PA, C-293-39 Blocks, and Plug SP-3289 (Fig. 20).

INSTALLATION

- (1) Using tool C-3716-A with handle C-4171, install differential side bearings (Fig. 21).
- (2) Install differential in axle housing.

DIFFERENTIAL SIDE BEARINGS

REMOVAL

- (1) Remove differential from axle housing.
- (2) Remove the bearings from the differential case with Puller/Press C-293-PA, C-293-39 Blocks, and Plug SP-3289 (Fig. 22).

INSTALLATION

- (1) Using tool C-3716-A with handle C-4171, install differential side bearings (Fig. 23).
- (2) Install differential in axle housing.

PINION GEAR

NOTE: The ring and pinion gears are serviced in a matched set. Do not replace the pinion gear without replacing the ring gear.




Fig. 20 Differential Bearing Removal




Fig. 21 Install Differential Side Bearings

REMOVAL

- (1) Remove differential from the axle housing.
- (2) Mark pinion yoke and propeller shaft for installation alignment.

REMOVAL AND INSTALLATION (Continued)




Fig. 22 Differential Bearing Removal




Fig. 23 Install Differential Side Bearings

- (3) Disconnect propeller shaft from pinion yoke. Using suitable wire, tie propeller shaft to underbody.
- (4) Using Holder 6958 to hold yoke and a short length of 1 in. pipe, remove the pinion yoke nut and washer.

- (5) Using Remover C-452 and Wrench C-3281, remove the pinion yoke and pinion seal excluder from pinion shaft.

- (6) Remove the pinion gear from housing (Fig. 24). Catch the pinion with your hand to prevent it from falling and being damaged.




Fig. 24 Remove Pinion Gear

- (7) Using a suitable pry tool, or a slide hammer mounted screw, remove the pinion seal.

- (8) Remove oil slinger, if equipped, and front pinion bearing.

- (9) Remove the front pinion bearing cup with Remover C-4345 and Handle C-4171 (Fig. 25).




Fig. 25 Front Bearing Cup Removal

REMOVAL AND INSTALLATION (Continued)

(10) Remove the rear bearing cup from housing (Fig. 26). Use Remover 8132 and Handle C-4171.




Fig. 26 Rear Bearing Cup Removal

(11) Remove the collapsible preload spacer (Fig. 27).




Fig. 27 Collapsible Spacer

(12) Remove the rear bearing from the pinion with Puller/Press C-293-PA and Adapters C-293-40 (Fig. 28).

Place 4 adapter blocks so they do not damage the bearing cage.




Fig. 28 Rear Bearing Removal

(13) Remove the depth shims from the pinion gear shaft. Record the thickness of the depth shims.

INSTALLATION

(1) Apply Mopar® Door Ease, or equivalent, stick lubricant to outside surface of bearing cup.

(2) Install the pinion rear bearing cup with Installer D-146 and Driver Handle C-4171 (Fig. 29). Ensure cup is correctly seated.




Fig. 29 Pinion Rear Bearing Cup Installation

REMOVAL AND INSTALLATION (Continued)

(3) Apply Mopar® Door Ease, or equivalent, stick lubricant to outside surface of bearing cup.

(4) Install the pinion front bearing cup with Installer D-130 and Handle C-4171 (Fig. 30).




Fig. 30 Pinion Front Bearing Cup Installation

(5) Install pinion front bearing, and oil slinger, if equipped.

(6) Apply a light coating of gear lubricant on the lip of pinion seal. Install seal with Installer D-163 and Handle C-4171 (Fig. 31).




Fig. 31 Pinion Seal Installation

NOTE: Pinion depth shims are placed between the rear pinion bearing cone and pinion gear to achieve proper ring and pinion gear mesh. If the factory installed ring and pinion gears are reused, the pinion depth shim should not require replacement. If required, refer to Pinion Gear Depth to select the proper thickness shim before installing rear pinion bearing.

(7) Place the proper thickness depth shim on the pinion gear.

(8) Install the rear bearing and slinger, if equipped, on the pinion gear with Installer W-262 (Fig. 32).




Fig. 32 Shaft Rear Bearing Installation

(9) Install a new collapsible preload spacer on pinion shaft and install pinion gear in housing (Fig. 33).

(10) Install pinion gear in housing.




Fig. 33 Collapsible Preload Spacer

REMOVAL AND INSTALLATION (Continued)

(11) Install yoke with Installer Screw 8112, Cup 8109, and holder 6958 (Fig. 34).




Fig. 34 Pinion Yoke Installation

(12) Install the yoke washer and a new nut on the pinion gear and tighten the pinion nut until there is zero bearing end-play.

(13) Tighten the nut to 271 N·m (200 ft. lbs.).

CAUTION: Never loosen pinion gear nut to decrease pinion gear bearing rotating torque and never exceed specified preload torque. If preload torque or rotating torque is exceeded a new collapsible spacer must be installed. The torque sequence will then have to be repeated.

(14) Using yoke holder 6958, a short length of 1 in. pipe, and a torque wrench set at 474 N·m (350 ft. lbs.), crush collapsible spacer until bearing end play is taken up.

NOTE: If the spacer requires more than 474 N·m (350 ft. lbs.) torque to crush, the collapsible spacer is defective and must be replaced.

(15) Slowly tighten the nut in 6.8 N·m (5 ft. lbs.) increments until the rotating torque is achieved. Measure the rotating torque frequently to avoid over crushing the collapsible spacer (Fig. 35).

(16) Check bearing rotating torque with an inch pound torque wrench (Fig. 35). The torque necessary to rotate the pinion gear should be:

- Original Bearings — 1 to 3 N·m (10 to 20 in. lbs.).
 - New Bearings — 2 to 5 N·m (15 to 35 in. lbs.).
- (17) Install differential in housing.

FINAL ASSEMBLY

(1) Scrape the residual sealant from the housing and cover mating surfaces. Clean the mating surfaces with mineral spirits. Apply a bead of Mopar® Silicone




Fig. 35 Check Pinion Gear Rotating Torque

Rubber Sealant, or equivalent, on the housing cover (Fig. 36).




Fig. 36 Typical Housing Cover With Sealant

Install the housing cover within 5 minutes after applying the sealant.

REMOVAL AND INSTALLATION (Continued)

(2) Install the cover on the differential with the attaching bolts. Install the identification tag. Tighten the cover bolts to 41 N·m (30 ft. lbs.) torque.

CAUTION: Overfilling the differential can result in lubricant foaming and overheating.

(3) Refill the differential housing with gear lubricant. Refer to the Lubricant Specifications section of this group for the gear lubricant requirements.

(4) Install the fill hole plug.

DISASSEMBLY AND ASSEMBLY

STANDARD DIFFERENTIAL

DISASSEMBLY

- (1) Remove ring gear.
- (2) Remove roll-pin holding mate shaft in housing.
- (3) Remove pinion gear mate shaft (Fig. 37).
- (4) Rotate the differential side gears and remove the pinion mate gears and thrust washers (Fig. 38).




Fig. 37 Pinion Mate Shaft Removal

- (5) Remove the differential side gears and thrust washers.

ASSEMBLY

- (1) Install the differential side gears and thrust washers.
- (2) Install the pinion mate gears and thrust washers.
- (3) Install the pinion gear mate shaft.
- (4) Align the hole in the pinion gear mate shaft with the hole in the differential case.
- (5) Install and seat the pinion mate shaft roll-pin in the differential case and mate shaft with a punch and hammer (Fig. 39). Peen the edge of the roll-pin hole in the differential case slightly in two places, 180° apart.




Fig. 38 Pinion Mate Gear Removal

- (6) Lubricate all differential components with hypoid gear lubricant.
- (7) Install ring gear.




Fig. 39 Pinion Mate Shaft Roll-Pin Installation

CLEANING AND INSPECTION

AXLE COMPONENTS

Wash differential components with cleaning solvent and dry with compressed air. **Do not steam clean the differential components.**

CLEANING AND INSPECTION (Continued)

Wash bearings with solvent and towel dry, or dry with compressed air. DO NOT spin bearings with compressed air. **Cup and bearing must be replaced as matched sets only.**

Clean axle shaft tubes and oil channels in housing. Inspect for;

- Smooth appearance with no broken/dented surfaces on the bearing rollers or the roller contact surfaces.
- Bearing cups must not be distorted or cracked.
- Machined surfaces should be smooth and without any raised edges.
- Raised metal on shoulders of cup bores should be removed with a hand stone.
- Wear and damage to pinion gear mate shaft, pinion gears, side gears and thrust washers. Replace as a matched set only.
- Ring and pinion gear for worn and chipped teeth.
- Ring gear for damaged bolt threads. Replaced as a matched set only.
- Pinion yoke for cracks, worn splines, pitted areas, and a rough/corroded seal contact surface. Repair or replace as necessary.
- Preload shims for damage and distortion. Install new shims, if necessary.

ADJUSTMENTS


PINION GEAR DEPTH

GENERAL INFORMATION

Ring and pinion gears are supplied as matched sets only. The identifying numbers for the ring and pinion gear are etched into the face of each gear (Fig. 40). A plus (+) number, minus (-) number or zero (0) is etched into the face of the pinion gear. This number is the amount (in thousandths of an inch) the depth varies from the standard depth setting of a pinion etched with a (0). The standard setting from the center line of the ring gear to the back face of the pinion is 96.850 mm (3.813 in.). The standard depth provides the best teeth contact pattern. Refer to Backlash and Contact Pattern Analysis Paragraph in this section for additional information.


Compensation for pinion depth variance is achieved with select shims. The shims are placed under the inner pinion bearing cone (Fig. 41).

If a new gear set is being installed, note the depth variance etched into both the original and replacement pinion gear. Add or subtract the thickness of the original depth shims to compensate for the difference in the depth variances. Refer to the Depth Variance charts.



J9003-100

Fig. 40 Pinion Gear ID Numbers



80a9834d

Fig. 41 Shim Locations

Note where Old and New Pinion Marking columns intersect. Intersecting figure represents plus or minus amount needed.

Note the etched number on the face of the drive pinion gear (-1, -2, 0, +1, +2, etc.). The numbers represent thousands of an inch deviation from the standard. If the number is negative, add that value to the required thickness of the depth shim(s). If the number is positive, subtract that value from the thickness of the depth shim(s). If the number is 0 no change is necessary. Refer to the Pinion Gear Depth Variance Chart.


ADJUSTMENTS (Continued)

Original Pinion Gear Depth Variance	Replacement Pinion Gear Depth Variance								
	-4	-3	-2	-1	0	+1	+2	+3	+4
+4	+0.008	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0
+3	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001
+2	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002
+1	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003
0	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004
-1	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005
-2	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006
-3	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007
-4	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007	-0.008

J8902-46

PINION DEPTH MEASUREMENT AND ADJUSTMENT

Measurements are taken with pinion cups and pinion bearings installed in housing. Take measurements with a Pinion Gauge Set, Pinion Block 8159, Arbor Discs 6927A, and Dial Indicator C-3339 (Fig. 42).



J9403-45

Fig. 42 Pinion Gear Depth Gauge Tools—Typical

(1) Assemble Pinion Height Block 6739, Pinion Block 8159, and rear pinion bearing onto Screw 6741 (Fig. 42).

(2) Insert assembled height gauge components, rear bearing and screw into axle housing through pinion bearing cups (Fig. 43).

(3) Install front pinion bearing and Cone 6740 hand tight (Fig. 42).




Fig. 43 Pinion Height Block—Typical

ADJUSTMENTS (Continued)

(4) Place Arbor Disc 6927A on Arbor D-115-3 in position in axle housing side bearing cradles (Fig. 44). Install differential bearing caps on Arbor Discs and tighten cap bolts. Refer to the Torque Specifications in this section.




Fig. 44 Gauge Tools In Housing—Typical

(5) Assemble Dial Indicator C-3339 into Scooter Block D-115-2 and secure set screw.

(6) Place Scooter Block/Dial Indicator in position in axle housing so dial probe and scooter block are flush against the surface of the pinion height block. Hold scooter block in place and zero the dial indicator face to the pointer. Tighten dial indicator face lock screw.

(7) With scooter block still in position against the pinion height block, slowly slide the dial indicator probe over the edge of the pinion height block. Observe how many revolutions counterclockwise the dial pointer travels (approximately 0.125 in.) to the out-stop of the dial indicator.

(8) Slide the dial indicator probe across the gap between the pinion height block and the arbor bar with the scooter block against the pinion height block (Fig. 45). When the dial probe contacts the arbor bar, the dial pointer will turn clockwise. Bring dial pointer back to zero against the arbor bar, do not turn dial face. Continue moving the dial probe to the crest of the arbor bar and record the highest reading. If the dial indicator can not achieve the zero reading, the rear bearing cup or the pinion depth gauge set is not installed correctly.

(9) Select a shim equal to the dial indicator reading plus the drive pinion gear depth variance number etched in the face of the pinion gear (Fig. 40) using the opposite sign on the variance number. For example, if the depth variance is -2, add +0.002 in. to the dial indicator reading.

(10) Remove the pinion depth gauge components from the axle housing.




Fig. 45 Pinion Gear Depth Measurement—Typical

DIFFERENTIAL BEARING PRELOAD AND GEAR BACKLASH

INTRODUCTION

Differential side bearing preload and gear backlash is achieved by selective shims positioned behind the differential side bearing cones. The proper shim thickness can be determined using slip-fit dummy bearings 6928 in place of the differential side bearings and a dial indicator C-3339. Before proceeding with the differential bearing preload and gear backlash measurements, measure the pinion gear depth and prepare the pinion gear for installation. Establishing proper pinion gear depth is essential to establishing gear backlash and tooth contact patterns. After the overall shim thickness to take up differential side play is measured, the pinion gear is installed, and the gear backlash shim thickness is measured. The overall shim thickness is the total of the dial indicator reading and the preload specification added together. The gear backlash measurement determines the thickness of the shim used on the ring gear side of the differential case. Subtract the gear backlash shim thickness from the total overall shim thickness and select that amount for the pinion gear side of the differential (Fig. 46). Differential shim measurements are performed with axle spreader W-129-B removed.

SHIM SELECTION

NOTE: It is difficult to salvage the differential side bearings during the removal procedure. Install replacement bearings if necessary.

(1) Remove differential side bearings from differential case.

(2) Remove factory installed shims from differential case.

ADJUSTMENTS (Continued)




Fig. 46 Axle Adjustment Shim Locations

(3) Install ring gear on differential case and tighten bolts to specification.

(4) Install dummy side bearings 6928 on differential case.

(5) Install differential case in axle housing.

(6) Install the marked bearing caps in their correct positions. Install and snug the bolts (Fig. 47).




Fig. 47 Tighten Bolts Holding Bearing Caps—Typical

(7) Using a dead-blow type mallet, seat the differential dummy bearings to each side of the axle housing (Fig. 48) and (Fig. 49).




Fig. 48 Seat Pinion Gear Side Differential Dummy Side Bearing—Typical




Fig. 49 Seat Ring Gear Side Differential Dummy Side Bearing—Typical

(8) Thread Guide Stud L-4438 into rear cover bolt hole below ring gear.

(9) Attach a dial indicator C-3339 to guide stud. Position the dial indicator plunger on a flat surface between the ring gear bolt heads.

(10) Firmly push and hold differential case to pinion gear side of axle housing (Fig. 50).

(11) Zero dial indicator face to pointer.

ADJUSTMENTS (Continued)

(12) Firmly push and hold differential case to ring gear side of the axle housing (Fig. 51).

(13) Record dial indicator reading (Fig. 51).




Fig. 50 Hold Differential Case and Zero Dial Indicator—Typical




Fig. 51 Hold Differential Case and Read Dial Indicator—Typical

(14) Add 0.010 in. (0.25 mm) to the zero end play total. This new total represents the thickness of shims to compress, or preload the new bearings when the differential is installed.

(15) Rotate dial indicator out of the way on the guide stud.

(16) Remove differential case and dummy bearings from axle housing.

(17) Install the pinion gear in axle housing. Install the pinion yoke, or flange, and establish the correct pinion rotating torque.

(18) Install differential case and dummy bearings 6928 in axle housing (without shims), install bearing caps and tighten bolts snug.

(19) Seat ring gear side dummy bearing (Fig. 49).

(20) Position the dial indicator plunger on a flat surface between the ring gear bolt heads.

(21) Push and hold differential case toward pinion gear (Fig. 52).

(22) Zero dial indicator face to pointer (Fig. 52).




Fig. 52 Hold Differential Case and Zero Dial Indicator—Typical

(23) Push and hold differential case to ring gear side of the axle housing (Fig. 53).

(24) Record dial indicator reading (Fig. 53).




Fig. 53 Hold Differential Case and Read Dial Indicator—Typical

(25) Subtract 0.002 in. (0.05 mm) from the dial indicator reading to compensate for backlash between ring and pinion gears. This total is the thickness shim required to achieve proper backlash.

(26) Subtract the backlash shim thickness from the total preload shim thickness. The remainder is the shim thickness required on the pinion side of the axle housing.

(27) Rotate dial indicator out of the way on guide stud.

ADJUSTMENTS (Continued)

(28) Remove differential case and dummy bearings from axle housing.

(29) Install side bearing shims on differential case hubs.

(30) Install side bearings and cups on differential case.

(31) Install Adapters 8142 and Spreader W-129-B on axle housing and spread axle opening enough to receive differential case.

(32) Install differential case in axle housing.

(33) Remove spreader from axle housing.

(34) Rotate the differential case several times to seat the side bearings.

(35) Position the indicator plunger against a ring gear tooth (Fig. 54).

(36) Push and hold ring gear upward while not allowing the pinion gear to rotate.

(37) Zero dial indicator face to pointer.

(38) Push and hold ring gear downward while not allowing the pinion gear to rotate. Dial indicator reading should be between 0.12 mm (0.005 in.) and 0.20 mm (0.008 in.). If backlash is not within specifications transfer the necessary amount of shim thickness from one side of the axle housing to the other (Fig. 55).

(39) Verify differential case and ring gear runout by measuring ring to pinion gear backlash at several locations around the ring gear. Readings should not vary more than 0.05 mm (0.002 in.). If readings vary more than specified, the ring gear or the differential case is defective.

After the proper backlash is achieved, perform Gear Contact Pattern Analysis procedure.




Fig. 54 Ring Gear Backlash Measurement




Fig. 55 Backlash Shim Adjustment

GEAR CONTACT PATTERN ANALYSIS

The ring and pinion gear teeth contact patterns will show if the pinion gear depth is correct in the axle housing. It will also show if the ring gear backlash has been adjusted correctly. The backlash can be adjusted within specifications to achieve desired tooth contact patterns.

(1) Apply a thin coat of hydrated ferric oxide, or equivalent, to the drive and coast side of the ring gear teeth.

(2) Wrap, twist, and hold a shop towel around the pinion yoke to increase the turning resistance of the pinion gear. This will provide a more distinct contact pattern.

(3) Using a boxed end wrench on a ring gear bolt, Rotate the differential case one complete revolution in both directions while a load is being applied from shop towel.

The areas on the ring gear teeth with the greatest degree of contact against the pinion gear teeth will squeegee the compound to the areas with the least amount of contact. Note and compare patterns on the ring gear teeth to Gear Tooth Contact Patterns chart (Fig. 56) and adjust pinion depth and gear backlash as necessary.

ADJUSTMENTS (Continued)












<p>DRIVE SIDE OF RING GEAR TEETH</p> <p>HEEL TOE</p> 	<p>COAST SIDE OF RING GEAR TEETH</p> <p>TOE HEEL</p> 	<p>DESIRABLE CONTACT PATTERN. PATTERN SHOULD BE CENTERED ON THE DRIVE SIDE OF TOOTH. PATTERN SHOULD BE CENTERED ON THE COAST SIDE OF TOOTH, BUT MAY BE SLIGHTLY TOWARD THE TOE. THERE SHOULD ALWAYS BE SOME CLEARANCE BETWEEN CONTACT PATTERN AND TOP OF THE TOOTH.</p>
		<p>RING GEAR BACKLASH CORRECT. THINNER PINION GEAR DEPTH SHIM REQUIRED.</p>
		<p>RING GEAR BACKLASH CORRECT. THICKER PINION GEAR DEPTH SHIM REQUIRED.</p>
		<p>PINION GEAR DEPTH SHIM CORRECT. DECREASE RING GEAR BACKLASH.</p>
		<p>PINION GEAR DEPTH SHIM CORRECT. INCREASE RING GEAR BACKLASH.</p>

Fig. 56 Gear Tooth Contact Patterns


SPECIFICATIONS

194 FIA AXLE

DESCRIPTION	SPECIFICATION
Axle Type	Semi-Floating Hypoid
Lubricant	SAE Thermally Stable 80W-90
Lube Capacity	1.72 L (3.60 pts.)
Axle Ratios	3.21, 3.55, 3.92
Differential Bearing Preload	0.1 mm (0.005 in.)
Differential Side Gear Clearance	0-0.15 mm (0-0.006 in.)
Ring Gear Diameter	19.4 cm (7.562 in.)
Ring Gear Backlash	0.12-0.20 mm (0.005-0.008 in.)
Pinion Std. Depth	96.850 mm (3.813 in.)
Pinion Bearing Preload-Original Bearings ...	1-3 N·m (10-20 in. lbs.)
Pinion Bearing Preload-New Bearings	2-5 N·m (15-35 in. lbs.)




Adapter—C-293-40



Plug—SP-3289

194 FIA AXLE


DESCRIPTION	TORQUE
Bolt, Diff. Cover	41 N·m (30 ft. lbs.)
Bolt, Bearing Cap	61 N·m (45 ft. lbs.)
Nut, Pinion	271-474 N·m (200-350 ft. lbs.)
Bolt, Ring Gear	95-122 N·m (70-90 ft. lbs.)




Puller—C-452

SPECIAL TOOLS


194 FIA AXLE



Puller—C-293-PA











Adapter—C-293-39




Wrench—C-3281


SPECIAL TOOLS (Continued)

**Installer—D-163****Handle—C-4171****Spanner—6958****Installer Screw—8112****Driver—C-3716-A****Cup—8109****Installer—D-130****Installer—D-146**


SPECIAL TOOLS (Continued)




Remover—C-4345




Cup—8150




Remover—8132



Installer—6436




Installer—W-262



Installer—6437








Bearing Remover—C-4660



Gauge Block—8159

SPECIAL TOOLS (Continued)

***Tool Set, Pinion Depth—6774******Spreader—W-129-B******Holder—6965******Guide Pin—L-4438******Spreader Adapters—8142***

8011d42b

Dial Indicator—C-3339

8 1/4 AND 9 1/4 AXLE

INDEX

	page		page
GENERAL INFORMATION		PINION GEAR	67
8 1/4 AND 9 1/4 AXLES	53	PINION SEAL	63
AXLE IDENTIFICATION	53	REAR AXLE	60
LUBRICANTS	55	RING GEAR AND EXCITER RING	66
DESCRIPTION AND OPERATION		DISASSEMBLY AND ASSEMBLY	
STANDARD DIFFERENTIAL	55	8 1/4 TRAC-LOK DIFFERENTIAL	72
TRAC-LOK OPERATION	56	9 1/4 TRAC-LOK DIFFERENTIAL	76
DIAGNOSIS AND TESTING		STANDARD DIFFERENTIAL	71
BEARING NOISE	57	CLEANING AND INSPECTION	
DRIVELINE SNAP	57	8 1/4 AND 9 1/4 AXLES	79
GEAR NOISE	56	TRAC-LOK	80
GENERAL INFORMATION	56	ADJUSTMENTS	
LOW SPEED KNOCK	57	8 1/4 AXLE PINION GEAR DEPTH	80
TRAC-LOK DIFFERENTIAL NOISE	57	9 1/4 AXLE PINION GEAR DEPTH	82
TRAC-LOK TEST	60	DIFFERENTIAL BEARING PRELOAD AND	
VIBRATION	57	GEAR BACKLASH	84
SERVICE PROCEDURES		GEAR CONTACT PATTERN ANALYSIS	85
LUBRICANT CHANGE	60	SIDE GEAR CLEARANCE	87
REMOVAL AND INSTALLATION		SPECIFICATIONS	
8 1/4 AND 9 1/4 LD AXLE SEAL AND BEARING .	62	8 1/4 INCH AXLE	87
AXLE SHAFT	61	8 1/4 and 9 1/4 INCH AXLE	88
DIFFERENTIAL	64	9 1/4 INCH AXLE	87
DIFFERENTIAL SIDE BEARINGS	65	SPECIAL TOOLS	
FINAL ASSEMBLY	71	8 1/4 AND 9 1/4 AXLES	88

GENERAL INFORMATION

8 1/4 AND 9 1/4 AXLES

The 8 1/4 and 9 1/4 Inch axle housings consist of a cast iron center section with axle shaft tubes extending from either side. The tubes are pressed into and welded to the differential housing to form a one-piece axle housing (Fig. 1).

The axles have a vent hose to relieve internal pressure caused by lubricant vaporization and internal expansion.

The axles are equipped with semi-floating axle shafts, meaning vehicle loads are supported by the axle shaft and bearings. The axle shafts are retained by C-clips in the differential side gears.

The removable, stamped steel cover provides a means for inspection and service without removing the complete axle from the vehicle.

Both axles have the assembly part number and gear ratio listed on tag. The tag is attached to the differential housing by a cover bolt.

The rear wheel anti-lock (RWAL) brake speed sensor is attached to the top, forward exterior of the dif-

ferential housing. A seal is located between the sensor and the wire harness connector. The seal must be in place when the wire connector is connected to the sensor. The RWAL brake exciter ring is press-fitted onto the differential case against the ring gear flange.

The differential case is a one-piece design. The differential pinion mate shaft is retained with a threaded pin. Differential bearing preload and ring gear backlash are set and maintained by threaded adjusters at the outside of the differential housing. Pinion bearing preload is set and maintained by the use of a collapsible spacer.

Axles equipped with a Trac-Lok[™] differential are optional. A Trac-Lok differential has a one-piece differential case, and the same internal components as a standard differential, plus two clutch disc packs.

AXLE IDENTIFICATION

The axle differential covers can be used for identification of the axle (Fig. 2) and (Fig. 3). A tag is also attached to the cover.

GENERAL INFORMATION (Continued)





Fig. 1 8 1/4 or 9 1/4 Axle


J9003-109

GENERAL INFORMATION (Continued)



J9203-11

Fig. 2 Differential Cover 8 1/4 Inch Axle



J9203-32

Fig. 3 Differential Cover 9 1/4 Inch Axle

LUBRICANTS

Multi-purpose, hypoid gear lubricant should be used for rear axles with a standard differential. The lubricant should have a MIL-L-2105C and API GL 5 quality specifications.

Trac-Lok differentials require the addition of 5 oz. of friction modifier to the axle lubricant after service. The 8 1/4 axle lubricant capacity is 2.22 L (4.7 pts.) total, including the friction modifier, if necessary. The

9 1/4 axle lubricant capacity is 2.32 L (4.9 pts.) total, including friction modifier, if necessary.

NOTE: If the rear axle is submerged in water, the lubricant must be replaced immediately. Avoid the possibility of premature axle failure resulting from water contamination of the lubricant.

DESCRIPTION AND OPERATION

STANDARD DIFFERENTIAL


The differential gear system divides the torque between the axle shafts. It allows the axle shafts to rotate at different speeds when turning corners.

Each differential side gear is splined to an axle shaft. The pinion gears are mounted on a pinion mate shaft and are free to rotate on the shaft. The pinion gear is fitted in a bore in the differential case and is positioned at a right angle to the axle shafts.

In operation, power flow occurs as follows:

- The pinion gear rotates the ring gear
- The ring gear (bolted to the differential case) rotates the case
- The differential pinion gears (mounted on the pinion mate shaft in the case) rotate the side gears
- The side gears (splined to the axle shafts) rotate the shafts

During straight-ahead driving, the differential pinion gears do not rotate on the pinion mate shaft. This occurs because input torque applied to the gears is divided and distributed equally between the two side gears. As a result, the pinion gears revolve with the pinion mate shaft but do not rotate around it (Fig. 4).



J9303-13

Fig. 4 Differential Operation—Straight Ahead Driving

When turning corners, the outside wheel must travel a greater distance than the inside wheel to complete a turn. The difference must be compensated for to prevent the tires from scuffing and skidding through turns. To accomplish this, the differential

DESCRIPTION AND OPERATION (Continued)

allows the axle shafts to turn at unequal speeds (Fig. 5). In this instance, the input torque applied to the pinion gears is not divided equally. The pinion gears now rotate around the pinion mate shaft in opposite directions. This allows the side gear and axle shaft attached to the outside wheel to rotate at a faster speed.




Fig. 5 Differential Operation—On Turns

TRAC-LOK OPERATION

In a conventional differential, if one wheel spins, the opposite wheel will generate only as much torque as the spinning wheel.

In the Trac-lok differential, part of the ring gear torque is transmitted through clutch packs which contain multiple discs. The clutches will have radial grooves on the plates, and concentric grooves on the discs or bonded fiber material that is smooth in appearance.

In operation, the Trac-lok clutches are engaged by two concurrent forces. The first being the preload force exerted through Belleville spring washers within the clutch packs. The second is the separating forces generated by the side gears as torque is applied through the ring gear (Fig. 6).

The Trac-lok design provides the differential action needed for turning corners and for driving straight ahead during periods of unequal traction. When one wheel loses traction, the clutch packs transfer additional torque to the wheel having the most traction. Trac-lok differentials resist wheel spin on bumpy roads and provide more pulling power when one wheel loses traction. Pulling power is provided continuously until both wheels lose traction. If both wheels slip due to unequal traction, Trac-lok operation is normal. In extreme cases of differences of traction, the wheel with the least traction may spin.




Fig. 6 Trac-lok Limited Slip Differential Operation

DIAGNOSIS AND TESTING

GENERAL INFORMATION

Axle bearing problem conditions are usually caused by:

- Insufficient or incorrect lubricant.
- Foreign matter/water contamination.
- Incorrect bearing preload torque adjustment.
- Incorrect backlash.

Axle gear problem conditions are usually the result of:

- Insufficient lubrication.
- Incorrect or contaminated lubricant.
- Overloading (excessive engine torque) or exceeding vehicle weight capacity.

- Incorrect clearance or backlash adjustment.

Axle component breakage is most often the result of:

- Severe overloading.
- Insufficient lubricant.
- Incorrect lubricant.
- Improperly tightened components.

GEAR NOISE

Axle gear noise can be caused by insufficient lubricant, incorrect backlash, tooth contact, or worn/damaged gears.

DIAGNOSIS AND TESTING (Continued)

Gear noise usually happens at a specific speed range. The range is 30 to 40 mph, or above 50 mph. The noise can also occur during a specific type of driving condition. These conditions are acceleration, deceleration, coast, or constant load.

When road testing, accelerate the vehicle to the speed range where the noise is the greatest. Shift out-of-gear and coast through the peak-noise range. If the noise stops or changes greatly:

- Check for insufficient lubricant.
- Incorrect ring gear backlash.
- Gear damage.

Differential side and pinion gears can be checked by turning the vehicle. They usually do not cause noise during straight-ahead driving when the gears are unloaded. The side gears are loaded during vehicle turns. A worn pinion gear mate shaft can also cause a snapping or a knocking noise.

BEARING NOISE

The axle shaft, differential and pinion gear bearings can all produce noise when worn or damaged. Bearing noise can be either a whining, or a growling sound.

Pinion gear bearings have a constant-pitch noise. This noise changes only with vehicle speed. Pinion bearing noise will be higher because it rotates at a faster rate. Drive the vehicle and load the differential. If bearing noise occurs, the rear pinion bearing is the source of the noise. If the bearing noise is heard during a coast, the front pinion bearing is the source.

Worn or damaged differential bearings usually produce a low pitch noise. Differential bearing noise is similar to pinion bearing noise. The pitch of differential bearing noise is also constant and varies only with vehicle speed.

Axle shaft bearings produce noise and vibration when worn or damaged. The noise generally changes when the bearings are loaded. Road test the vehicle. Turn the vehicle sharply to the left and to the right. This will load the bearings and change the noise level. Where axle bearing damage is slight, the noise is usually not noticeable at speeds above 30 mph.

LOW SPEED KNOCK

Low speed knock is generally caused by a worn U-joint or by worn side-gear thrust washers. A worn pinion gear shaft bore will also cause low speed knock.

VIBRATION

Vibration at the rear of the vehicle is usually caused by a:

- Damaged drive shaft.
- Missing drive shaft balance weight(s).

- Worn or out-of-balance wheels.
- Loose wheel lug nuts.
- Worn U-joint(s).
- Loose/broken springs.
- Damaged axle shaft bearing(s).
- Loose pinion gear nut.
- Excessive pinion yoke run out.
- Bent axle shaft(s).

Check for loose or damaged front-end components or engine/transmission mounts. These components can contribute to what appears to be a rear-end vibration. Do not overlook engine accessories, brackets and drive belts.

All driveline components should be examined before starting any repair.

Refer to Group 22, Wheels and Tires, for additional vibration information.

DRIVELINE SNAP

A snap or clunk noise when the vehicle is shifted into gear (or the clutch engaged), can be caused by:

- High engine idle speed
- Loose engine/transmission/transfer case mounts
- Worn U-joints
- Loose spring mounts
- Loose pinion gear nut and yoke
- Excessive ring gear backlash
- Excessive side gear/case clearance

The source of a snap or a clunk noise can be determined with the assistance of a helper. Raise the vehicle on a hoist with the wheels free to rotate. Instruct the helper to shift the transmission into gear. Listen for the noise, a mechanics stethoscope is helpful in isolating the source of a noise.

TRAC-LOK DIFFERENTIAL NOISE

The most common problem is a chatter noise when turning corners. Before removing a Trac-lok unit for repair, drain, flush and refill the axle with the specified lubricant. Refer to Lubricant change in this Group.

A container of Mopar® Trac-lok Lubricant (friction modifier) should be added after repair service or during a lubricant change.

After changing the lubricant, drive the vehicle and make 10 to 12 slow, figure-eight turns. This maneuver will pump lubricant through the clutches. This will correct the condition in most instances. If the chatter persists, clutch damage could have occurred.

DIAGNOSIS AND TESTING (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
WHEEL NOISE	<ol style="list-style-type: none"> 1. Wheel loose. 2. Faulty, brinelled wheel bearing. 	<ol style="list-style-type: none"> 1. Tighten loose nuts. 2. Faulty or brinelled bearings must be replaced.
AXLE SHAFT NOISE	<ol style="list-style-type: none"> 1. Misaligned axle shaft tube. 2. Bent or sprung axle shaft. 3. End play in drive pinion bearings. 4. Excessive gear backlash between ring gear and pinion gear. 5. Improper adjustment of drive pinion gear shaft bearings. 6. Loose drive pinion gearshaft yoke nut. 7. Improper wheel bearing adjustment. 8. Scuffed gear tooth contact surfaces. 	<ol style="list-style-type: none"> 1. Inspect axle shaft tube alignment. Correct as necessary. 2. Replace bent or sprung axle shaft. 3. Refer to Drive Pinion Bearing Pre-Load Adjustment. 4. Check adjustment of ring gear backlash and pinion gear. Correct as necessary. 5. Adjust drive pinion shaft bearings. 6. Tighten drive pinion gearshaft yoke nut with specified torque. 7. Readjust as necessary. 8. If necessary, replace scuffed gears.
AXLE SHAFT BROKE	<ol style="list-style-type: none"> 1. Misaligned axle shaft tube. 2. Vehicle overloaded. 3. Erratic clutch operation. 4. Grabbing clutch. 	<ol style="list-style-type: none"> 1. Replace broken axle shaft after correcting axle shaft tube alignment. 2. Replace broken axle shaft. Avoid excessive weight on vehicle. 3. Replace broken axle shaft after inspecting for other possible causes. Avoid erratic use of clutch. 4. Replace broken axle shaft. Inspect clutch and make necessary repairs or adjustments.
DIFFERENTIAL CASE CRACKED	<ol style="list-style-type: none"> 1. Improper adjustment of differential bearings. 2. Excessive ring gear backlash. 3. Vehicle overloaded. 4. Erratic clutch operation. 	<ol style="list-style-type: none"> 1. Replace cracked case; examine gears and bearings for possible damage. At reassembly, adjust differential bearings properly. 2. Replace cracked case; examine gears and bearings for possible damage. At reassembly, adjust ring gear backlash properly. 3. Replace cracked case; examine gears and bearings for possible damage. Avoid excessive weight on vehicle. 4. Replace cracked case. After inspecting for other possible causes, examine gears and bearings for possible damage. Avoid erratic use of clutch.
DIFFERENTIAL GEARS SCORED	<ol style="list-style-type: none"> 1. Insufficient lubrication. 2. Improper grade of lubricant. 3. Excessive spinning of one wheel/tire. 	<ol style="list-style-type: none"> 1. Replace scored gears. Scoring marks on the drive face of gear teeth or in the bore are caused by instantaneous fusing of the mating surfaces. Scored gears should be replaced. Fill rear differential housing to required capacity with proper lubricant. Refer to Specifications. 2. Replace scored gears. Inspect all gears and bearings for possible damage. Clean and refill differential housing to required capacity with proper lubricant. 3. Replace scored gears. Inspect all gears, pinion bores and shaft for damage. Service as necessary.
LOSS OF LUBRICANT	<ol style="list-style-type: none"> 1. Lubricant level too high. 	<ol style="list-style-type: none"> 1. Drain excess lubricant by removing fill plug and allow lubricant to level at lower edge of fill plug hole.

DIAGNOSIS AND TESTING (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
LOSS OF LUBRICANT	<ol style="list-style-type: none"> 2. Worn axle shaft seals. 3. Cracked differential housing. 4. Worn drive pinion gear shaft seal. 5. Scored and worn yoke. 6. Axle cover not properly sealed. 	<ol style="list-style-type: none"> 2. Replace worn seals. 3. Repair or replace housing as necessary. 4. Replace worn drive pinion gear shaft seal. 5. Replace worn or scored yoke and seal. 6. Remove cover and clean flange and reseal.
AXLE OVERHEATING	<ol style="list-style-type: none"> 1. Lubricant level too low. 2. Incorrect grade of lubricant. 3. Bearings adjusted too tight. 4. Excessive gear wear. 5. Insufficient ring gear backlash. 	<ol style="list-style-type: none"> 1. Refill differential housing. 2. Drain, flush and refill with correct amount of the correct lubricant. 3. Readjust bearings. 4. Inspect gears for excessive wear or scoring. Replace as necessary. 5. Readjust ring gear backlash and inspect gears for possible scoring.
GEAR TEETH BROKE (RING GEAR AND PINION)	<ol style="list-style-type: none"> 1. Overloading. 2. Erratic clutch operation. 3. Ice-spotted pavements. 4. Improper adjustments. 	<ol style="list-style-type: none"> 1. Replace gears. Examine other gears and bearings for possible damage. 2. Replace gears and examine the remaining parts for possible damage. Avoid erratic clutch operation. 3. Replace gears. Examine the remaining parts for possible damage. Replace parts as required. 4. Replace gears. Examine other parts for possible damage. Ensure ring gear backlash is correct.
AXLE NOISE	<ol style="list-style-type: none"> 1. Insufficient lubricant. 2. Improper ring gear and drive pinion gear adjustment. 3. Unmatched ring gear and drive pinion gear. 4. Worn teeth on ring gear or drive pinion gear. 5. Loose drive pinion gear shaft bearings. 6. Loose differential bearings. 7. Misaligned or sprung ring gear. 8. Loose differential bearing cap bolts 	<ol style="list-style-type: none"> 1. Refill axle with correct amount of the proper lubricant. Also inspect for leaks and correct as necessary. 2. Check ring gear and pinion gear teeth contact pattern. 3. Remove unmatched ring gear and drive pinion gear. Replace with matched gear and drive pinion gear set. 4. Check teeth on ring gear and drive pinion gear for correct contact. If necessary, replace with new matched set. 5. Adjust drive pinion gearshaft bearing preload torque. 6. Adjust differential bearing preload torque. 7. Measure ring gear runout. 8. Tighten with specified torque


DIAGNOSIS AND TESTING (Continued)

TRAC-LOK TEST

WARNING: WHEN SERVICING VEHICLES WITH A TRAC-LOK DIFFERENTIAL DO NOT USE THE ENGINE TO TURN THE AXLE AND WHEELS. BOTH REAR WHEELS MUST BE RAISED AND THE VEHICLE SUPPORTED. A TRAC-LOK AXLE CAN EXERT ENOUGH FORCE IF ONE WHEEL IS IN CONTACT WITH A SURFACE TO CAUSE THE VEHICLE TO MOVE.

The differential can be tested without removing the differential case by measuring rotating torque. Make sure brakes are not dragging during this measurement.

- (1) Place blocks in front and rear of both front wheels.
- (2) Raise one rear wheel until it is completely off the ground.
- (3) Engine off, transmission in neutral, and parking brake off.
- (4) Remove wheel and bolt Special Tool 6790 to studs.
- (5) Use torque wrench on special tool to rotate wheel and read rotating torque (Fig. 7).



80a4d327

Fig. 7 Trac-lok Test —Typical

- (6) If rotating torque is less than 22 N·m (30 ft. lbs.) or more than 271 N·m (200 ft. lbs.) on either wheel the unit should be serviced.

SERVICE PROCEDURES


LUBRICANT CHANGE

- (1) Raise and support the vehicle.
- (2) Remove the lubricant fill hole plug from the differential housing cover.
- (3) Remove the differential housing cover and drain the lubricant from the housing.

- (4) Clean the housing cavity with a flushing oil, light engine oil, or lint free cloth. **Do not use water, steam, kerosene, or gasoline for cleaning.**

- (5) Remove the original sealant from the housing and cover surfaces.

- (6) Apply a bead of Mopar® Silicone Rubber Sealant, or equivalent, to the housing cover (Fig. 8).



80a534a8

Fig. 8 Apply Sealant

Install the housing cover within 5 minutes after applying the sealant.

- (7) Install the cover and any identification tag. Tighten the cover bolts to 41 N·m (30 ft. lbs.) torque.

- (8) For Trac-lok differentials, a quantity of Mopar® Trac-lok lubricant (friction modifier), or equivalent, must be added after repair service or a lubricant change. Refer to the Lubricant Specifications section of this group for the quantity necessary.

- (9) Fill differential with Mopar® Hypoid Gear Lubricant, or equivalent, to bottom of the fill plug hole. Refer to the Lubricant Specifications section of this group for the quantity necessary.

CAUTION: Overfilling the differential can result in lubricant foaming and overheating.

- (10) Install the fill hole plug and lower the vehicle.

- (11) Trac-lok differential equipped vehicles should be road tested by making 10 to 12 slow figure-eight turns. This maneuver will pump the lubricant through the clutch discs to eliminate a possible chatter noise complaint.

REMOVAL AND INSTALLATION

REAR AXLE

REMOVAL

- (1) Raise and support the vehicle.

REMOVAL AND INSTALLATION (Continued)

- (2) Position a suitable lifting device under the axle.
- (3) Secure axle to device.
- (4) Remove the wheels and tires.
- (5) Secure brake drums to the axle shaft.
- (6) Remove the RWAL sensor from the differential housing, if necessary. Refer to Group 5, Brakes, for proper procedures.
- (7) Disconnect the brake hose at the axle junction block. Do not disconnect the brake hydraulic lines at the wheel cylinders. Refer to Group 5, Brakes, for proper procedures.
- (8) Disconnect the parking brake cables and cable brackets.
- (9) Disconnect the vent hose from the axle shaft tube.
- (10) Mark the propeller shaft and yoke for installation alignment reference.
- (11) Remove propeller shaft.
- (12) Disconnect shock absorbers from axle.
- (13) Remove the spring clamps and spring brackets. Refer to Group 2, Suspension, for proper procedures.
- (14) Separate the axle from the vehicle.

INSTALLATION

- (1) Raise the axle with lifting device and align to the leaf spring centering bolts.
- (2) Install the spring clamps and spring brackets. Refer to Group 2, Suspension, for proper procedures.
- (3) Install shock absorbers and tighten nuts to 82 N·m (60 ft. lbs.) torque.
- (4) Install the RWAL sensor to the differential housing, if necessary. Refer to Group 5, Brakes, for proper procedures.
- (5) Connect the parking brake cables and cable brackets.
- (6) Install the brake drums. Refer to Group 5, Brakes, for proper procedures.
- (7) Connect the brake hose to the axle junction block. Refer to Group 5, Brakes, for proper procedures.
- (8) Install axle vent hose.
- (9) Align propeller shaft and pinion yoke reference marks. Install universal joint straps and bolts. Tighten to 19 N·m (14 ft. lbs.) torque.
- (10) Install the wheels and tires.
- (11) Add gear lubricant, if necessary. Refer to Lubricant Specifications in this section for lubricant requirements.
- (12) Remove lifting device from axle and lower the vehicle.

AXLE SHAFT

REMOVAL

- (1) Raise and support vehicle. Ensure that the transmission is in neutral.
- (2) Remove wheel and tire assembly.
- (3) Remove brake drum. Refer to Group 5, Brakes, for proper procedure.
- (4) Clean all foreign material from housing cover area.
- (5) Loosen housing cover bolts. Drain lubricant from the housing and axle shaft tubes. Remove housing cover.
- (6) Rotate differential case so that pinion mate gear shaft lock screw is accessible. Remove lock screw and pinion mate gear shaft from differential case (Fig. 9).




Fig. 9 Mate Shaft Lock Screw

- (7) Push axle shaft inward and remove axle shaft C-clip lock from the axle shaft (Fig. 10).




Fig. 10 Axle Shaft C-Clip Lock

REMOVAL AND INSTALLATION (Continued)

(8) Remove axle shaft. Use care to prevent damage to axle shaft bearing and seal, which will remain in axle shaft tube.

(9) Inspect axle shaft seal for leakage or damage.

(10) Inspect roller bearing contact surface on axle shaft for signs of brinelling, galling and pitting. If any of these conditions exist, the axle shaft and/or bearing and seal must be replaced.

INSTALLATION

(1) Lubricate bearing bore and seal lip with gear lubricant. Insert axle shaft through seal, bearing, and engage it into side gear splines.

NOTE: Use care to prevent shaft splines from damaging axle shaft seal lip.

(2) Insert C-clip lock in end of axle shaft. Push axle shaft outward to seat C-clip lock in side gear.

(3) Insert pinion mate shaft into differential case and through thrust washers and pinion gears.

(4) Align hole in shaft with hole in the differential case and install lock screw with Loctite® on the threads. Tighten lock screw to 11 N·m (8 ft. lbs.) torque.

(5) Install cover and add fluid. Refer to Lubricant Change procedure in this section for procedure and lubricant requirements.

(6) Install brake drum. Refer to Group 5, Brakes, for proper procedures.

(7) Install wheel and tire.

(8) Lower vehicle.

8 1/4 AND 9 1/4 LD AXLE SEAL AND BEARING

REMOVAL

(1) Remove axle shaft.

(2) Remove axle shaft seal from the end of the axle tube with a small pry bar (Fig. 11).

NOTE: The seal and bearing can be removed at the same time with the bearing removal tool.

(3) Remove the axle shaft bearing from the axle tube with Bearing Removal Tool Set 6310, using Adapter Foot 6310-9 (Fig. 12).

INSTALLATION

NOTE: Do not install the original axle shaft seal. Always install a new seal.

(1) Wipe the axle tube bore clean. Remove any old sealer or burrs from the tube.




Fig. 11 Axle Seal Removal




Fig. 12 Axle Shaft Bearing Removal Tool

(2) Install the axle shaft bearing with Installer C-4198 and Handle C-4171 (Fig. 13). Ensure that the bearing part number is against the installer. Verify that the bearing is installed straight and the tool fully contacts the axle tube when seating the bearing.

(3) Install a new axle seal with Installer C-4076-B and Handle C-4735-1. When the tool contacts the axle tube, the seal is installed to the correct depth.

(4) Coat the lip of the seal with axle lubricant for protection prior to installing the axle shaft.

(5) Install the axle shaft.

REMOVAL AND INSTALLATION (Continued)




Fig. 13 Axle Shaft Seal and Bearing Installation

PINION SEAL

REMOVAL

- (1) Raise and support the vehicle.
- (2) Scribe a mark on the universal joint, pinion yoke, and pinion shaft for reference.
- (3) Disconnect the propeller shaft from the pinion yoke. Secure the propeller shaft in an upright position to prevent damage to the rear universal joint.
- (4) Remove the wheel and tire assemblies.
- (5) Remove the brake drums to prevent any drag. The drag may cause a false bearing rotating torque measurement.
- (6) Rotate the pinion yoke three or four times.
- (7) Measure the amount of torque necessary to rotate the pinion gear with a (in. lbs.) dial-type torque wrench. Record the torque reading for installation reference.
- (8) Hold the yoke with Wrench 6719. Remove the pinion shaft nut and washer.
- (9) Remove the yoke with Remover C-452 (Fig. 14).




Fig. 14 Yoke Removal

- (10) Remove the pinion shaft seal with suitable pry tool or slide-hammer mounted screw.

INSTALLATION

- (1) Clean the seal contact surface in the housing bore.
- (2) Examine the splines on the pinion shaft for burrs or wear. Remove any burrs and clean the shaft.
- (3) Inspect pinion yoke for cracks, worn splines and worn seal contact surface. Replace yoke if necessary.

NOTE: The outer perimeter of the seal is pre-coated with a special sealant. An additional application of sealant is not required.

- (4) Apply a light coating of gear lubricant on the lip of pinion seal.
- (5) Install the new pinion shaft seal with:
 - 8 1/4 axle: Installer C-4076-B and Handle C-4735-1 (Fig. 15).
 - 9 1/4 axle: Installer C-3860-A and Handle C-4171.




Fig. 15 8 1/4 Axle Pinion Seal Installation

NOTE: The seal is correctly installed when the seal flange contacts the face of the differential housing flange.

- (6) Position the pinion yoke on the end of the shaft with the reference marks aligned.
- (7) Seat yoke on pinion shaft with Installer C-3718 and Wrench 6719.
- (8) Remove the tools and install the pinion yoke washer. The convex side of the washer must face outward.

CAUTION: Do not exceed the minimum tightening torque when installing the pinion yoke retaining nut at this point. Damage to collapsible spacer or bearings may result.

REMOVAL AND INSTALLATION (Continued)

(9) Hold pinion yoke with Yoke Holder 6719 and tighten shaft nut to 285 N·m (210 ft. lbs.) (Fig. 16). Rotate pinion shaft several revolutions to ensure the bearing rollers are seated.




Fig. 16 Tightening Pinion Shaft Nut

(10) Rotate the pinion shaft using an (in. lbs.) torque wrench. Rotating torque should be equal to the reading recorded during removal, plus an additional 0.56 N·m (5 in. lbs.) (Fig. 17).




Fig. 17 Check Pinion Rotation Torque

CAUTION: Never loosen pinion gear nut to decrease pinion gear bearing rotating torque and never exceed specified preload torque. If preload torque is exceeded a new collapsible spacer must be installed. The torque sequence will then have to be repeated.

(11) If the rotating torque is low, use Yoke Holder 6719 to hold the pinion yoke (Fig. 16) and tighten the pinion shaft nut in 6.8 N·m (5 ft. lbs.) increments until proper rotating torque is achieved.

NOTE: The bearing rotating torque should be constant during a complete revolution of the pinion. If the rotating torque varies, this indicates a binding condition.

(12) The seal replacement is unacceptable if the final pinion nut torque is less than 285 N·m (210 ft. lbs.).

(13) Install the propeller shaft with the installation reference marks aligned.

(14) Tighten the universal joint yoke clamp screws to 19 N·m (14 ft. lbs.).

(15) Install the brake drums.

(16) Install wheel and tire assemblies and lower the vehicle.

(17) Check the differential housing lubricant level.

DIFFERENTIAL

REMOVAL

- (1) Remove the axle shafts.
- (2) Remove RWAL/ABS sensor from housing.

NOTE: Side play resulting from bearing races being loose on case hubs requires replacement of the differential case.

(3) Mark the differential housing and the differential bearing caps for installation reference (Fig. 18).

(4) Remove bearing threaded adjuster lock from each bearing cap. Loosen the bolts, but do not remove the bearing caps.

(5) Loosen the threaded adjusters with Wrench C-4164 (Fig. 19).

(6) Hold the differential case while removing bearing caps and adjusters.

(7) Remove the differential case.

NOTE: Each differential bearing cup and threaded adjuster must be kept with their respective bearing.

INSTALLATION

(1) Apply a coating of hypoid gear lubricant to the differential bearings, bearing cups, and threaded adjusters. A dab of grease can be used to keep the

REMOVAL AND INSTALLATION (Continued)




Fig. 18 Mark For Installation Reference




Fig. 19 Threaded Adjuster Tool

adjusters in position. Carefully position the assembled differential case in the housing.

(2) Observe the reference marks and install the differential bearing caps at their original locations (Fig. 20).

(3) Install bearing cap bolts and tighten the upper bolts to 14 N·m (10 ft. lbs.). Tighten the lower bolts finger-tight until the bolt head is seated.

(4) Perform the differential bearing preload and adjustment procedure.

(5) Install axle shafts and differential housing cover.

DIFFERENTIAL SIDE BEARINGS

REMOVAL

- (1) Remove differential case from axle housing.
- (2) Remove the bearings from the differential case with Puller/Press C-293-PA and:




Fig. 20 Bearing Caps & Bolts

- Adapters C-293-48 and Plug SP-3289 for the 8 1/4 axle (Fig. 21).
- Adapters C-293-47 and Plug C-293-3 for the 9 1/4 axle (Fig. 22).





Fig. 21 Differential Bearing Removal—8 1/4 Axle

80a982f2

REMOVAL AND INSTALLATION (Continued)



80a982f3

Fig. 22 Differential Bearing Removal—9 1/4 Axle**INSTALLATION**


- (1) Install differential side bearings. Use:
 - Installer C-4340 with handle C-4171 for the 8 1/4 axle (Fig. 23).
 - Installer C-4213 and Handle C-4171 for the 9 1/4 axle.
- (2) Install differential case in axle housing.

RING GEAR AND EXCITER RING


NOTE: The ring and pinion gears are serviced in a matched set. Do not replace the ring gear without replacing the pinion gear.

REMOVAL

- (1) Remove differential from axle housing.
- (2) Place differential case in a suitable vise with soft metal jaw protectors. (Fig. 24).
- (3) Remove bolts holding ring gear to differential case.
- (4) Using a soft hammer, drive ring gear from differential case (Fig. 24).
- (5) Use a brass drift and slowly tap the exciter ring from the differential case.



80a0c4fe

Fig. 23 Install Differential Side Bearings—8 1/4 Axle

J9202-76

Fig. 24 Ring Gear Removal**INSTALLATION**

CAUTION: Do not reuse the bolts that held the ring gear to the differential case. The bolts can fracture causing extensive damage.

- (1) Invert the differential case.
- (2) Position exciter ring on differential case.
- (3) Using a brass drift, slowly and evenly tap the exciter ring into position.
- (4) Position ring gear on the differential case and start two ring gear bolts. This will provide case-to-ring gear bolt hole alignment.
- (5) Invert the differential case in the vise.
- (6) Install new ring gear bolts and alternately tighten to:

REMOVAL AND INSTALLATION (Continued)

- 102 N·m (75 ft. lbs.) torque (Fig. 25) for 8 1/4 axles.
- 157 N·m (115 ft. lbs.) torque (Fig. 25) for 9 1/4 axles.

(7) Install differential in axle housing and verify gear mesh and contact pattern.




Fig. 25 Ring Gear Bolt Installation

PINION GEAR

NOTE: The ring and pinion gears are serviced in a matched set. Do not replace the pinion gear without replacing the ring gear.

REMOVAL

- (1) Remove differential from the axle housing.
- (2) Mark pinion yoke and propeller shaft for installation alignment.
- (3) Disconnect propeller shaft from pinion yoke. Using suitable wire, tie propeller shaft to underbody.
- (4) Using Yoke Holder 6719 to hold yoke and remove the pinion yoke nut and washer.
- (5) Using Remover C-452, remove the pinion yoke from pinion shaft (Fig. 26).
- (6) Partially install pinion nut onto pinion to protect the threads.
- (7) Remove the pinion gear from housing (Fig. 27). Catch the pinion with your hand to prevent it from falling and being damaged.




Fig. 26 Pinion Yoke Removal




Fig. 27 Remove Pinion Gear

- (8) Remove the pinion shaft seal with suitable pry tool or slide-hammer mounted screw.
- (9) Remove oil slinger, if equipped, and front pinion bearing.
- (10) Remove the front pinion bearing cup with:
 - Remover C-4345 and Handle C-4171 for the 8 1/4 axles (Fig. 28).
 - Bearing Removal Tool Set 6310 and Adapter Foot 6310-9 for the 9 1/4 axles.

REMOVAL AND INSTALLATION (Continued)




Fig. 28 Front Bearing Cup Removal—8 1/4 Axle

(11) Remove the rear bearing cup from housing (Fig. 29). Use:

- Remover C-4307 and Handle C-4171 for the 8 1/4 axle.
- Remover C-4309 and Handle C-4171 for the 9 1/4 axle.




Fig. 29 Rear Bearing Cup Removal

(12) Remove the collapsible preload spacer (Fig. 30).

(13) Remove the rear bearing from the pinion (Fig. 31) with:




Fig. 30 Collapsible Spacer

- Puller/Press C-293-PA and Adapters C-293-47 for the 8 1/4 axle.
- Puller/Press C-293-PA and Adapters C-293-37 for the 9 1/4 axle.

Place 4 adapter blocks so they do not damage the bearing cage.




Fig. 31 Rear Bearing Removal

(14) Remove the depth shims from the pinion gear shaft. Record the thickness of the depth shims.

REMOVAL AND INSTALLATION (Continued)

INSTALLATION

(1) Apply Mopar® Door Ease, or equivalent, stick lubricant to outside surface of bearing cup.

(2) Install the pinion rear bearing cup (Fig. 32) with:

- Installer C-4308 and Driver Handle C-4171 for the 8 1/4 axle.
- Installer C-4310 and Driver Handle C-4171 for the 9 1/4 axle. Ensure cup is correctly seated.




Fig. 32 Pinion Rear Bearing Cup Installation

(3) Apply Mopar® Door Ease, or equivalent, stick lubricant to outside surface of bearing cup.

(4) Install the pinion front bearing cup (Fig. 33) with:

- Installer D-130 and Handle C-4171 for the 8 1/4 axle.
- Installer D-129 and Handle C-4171 for the 9 1/4 axle.

(5) Install pinion front bearing, and oil slinger, if equipped.

(6) Apply a light coating of gear lubricant on the lip of pinion seal. Install seal with:

- Installer C-4076-B and Handle C-4735-1 for the 8 1/4 axle (Fig. 34).
- Installer C-3860-A and Handle C-4171 for the 9 1/4 axle.




Fig. 33 Pinion Front Bearing Cup Installation




Fig. 34 Pinion Seal Installation—8 1/4 Axle

NOTE: Pinion depth shims are placed between the rear pinion bearing cone and pinion gear to achieve proper ring and pinion gear mesh. If the factory installed ring and pinion gears are reused, the pinion depth shim should not require replacement. If required, refer to Pinion Gear Depth to select the proper thickness shim before installing rear pinion bearing.

(7) Place the proper thickness depth shim on the pinion gear.

REMOVAL AND INSTALLATION (Continued)

(8) Install the rear bearing and slinger, if equipped, on the pinion gear (Fig. 35) with:

- Installer 6448 for the 8 1/4 axle.
- Installer C-3095 for the 9 1/4 axle.




Fig. 35 Shaft Rear Bearing Installation

(9) Install a new collapsible preload spacer on pinion shaft and install pinion gear in housing (Fig. 36).

(10) Install pinion gear in housing.




Fig. 36 Collapsible Preload Spacer

(11) Install yoke with Installer C-3718 and Yoke Holder 6719.

(12) Install the yoke washer and a new nut on the pinion gear and tighten the pinion nut until there is zero bearing end-play. It will not be possible at this point to achieve zero bearing end-play if a new collapsible spacer was installed.

(13) Tighten the nut to 285 N·m (210 ft. lbs.).

CAUTION: Never loosen pinion gear nut to decrease pinion gear bearing rotating torque and never exceed specified preload torque. If preload torque or rotating torque is exceeded a new collapsible spacer must be installed. The torque sequence will then have to be repeated.

(14) Using Yoke Holder 6719, crush collapsible spacer until bearing end play is taken up.

(15) Slowly tighten the nut in 6.8 N·m (5 ft. lbs.) increments until the desired rotating torque is achieved. Measure the rotating torque frequently to avoid over crushing the collapsible spacer (Fig. 37).

(16) Check bearing rotating torque with an inch pound torque wrench (Fig. 37). The torque necessary to rotate the pinion gear should be:

- Original Bearings — 1 to 3 N·m (10 to 20 in. lbs.).
- New Bearings — 2 to 5 N·m (15 to 35 in. lbs.).




Fig. 37 Check Pinion Gear Rotating Torque

(17) Install propeller shaft.

(18) Install differential in housing.

REMOVAL AND INSTALLATION (Continued)

FINAL ASSEMBLY

(1) Scrape the residual sealant from the housing and cover mating surfaces. Clean the mating surfaces with mineral spirits. Apply a bead of Mopar® Silicone Rubber Sealant, or equivalent, on the housing cover (Fig. 38).




Fig. 38 Typical Housing Cover With Sealant

Install the housing cover within 5 minutes after applying the sealant.

(2) Install the cover on the differential with the attaching bolts. Install the identification tag. Tighten the cover bolts to 41 N·m (30 ft. lbs.) torque.

CAUTION: Overfilling the differential can result in lubricant foaming and overheating.

(3) Refill the differential housing with gear lubricant. Refer to the Lubricant Specifications section of this group for the gear lubricant requirements.

(4) Install the fill hole plug.

DISASSEMBLY AND ASSEMBLY

STANDARD DIFFERENTIAL

DISASSEMBLY

(1) Remove pinion gear mate shaft lock screw (Fig. 39).

(2) Remove pinion gear mate shaft.

(3) Rotate the differential side gears and remove the pinion mate gears and thrust washers (Fig. 40).

(4) Remove the differential side gears and thrust washers.




Fig. 39 Pinion Gear Mate Shaft Lock Screw




Fig. 40 Pinion Mate Gear Removal

ASSEMBLY

(1) Install the differential side gears and thrust washers.


(2) Install the pinion mate gears and thrust washers.

(3) Install the pinion gear mate shaft.

(4) Align the hole in the pinion gear mate shaft with the hole in the differential case and install the pinion gear mate shaft lock screw.

(5) Lubricate all differential components with hypoid gear lubricant.

DISASSEMBLY AND ASSEMBLY (Continued)




80a77404

Fig. 41 Trac-lok Differential Components**8 1/4 TRAC-LOK DIFFERENTIAL**

The Trac-lok differential components are illustrated in (Fig. 41). Refer to this illustration during repair service.

DISASSEMBLY

- (1) Clamp Side Gear Holding Tool 8138 in a vise.
- (2) Position the differential case on Side Gear Holding Tool 8138 (Fig. 42).
- (3) Remove ring gear, if necessary. Ring gear removal is necessary only if the ring gear is to be replaced. The Trac-lok differential can be serviced with the ring gear installed.
- (4) Remove the pinion gear mate shaft lock screw (Fig. 43).
- (5) Remove the pinion gear mate shaft. If necessary, use a drift and hammer (Fig. 44).
- (6) Install and lubricate Step Plate 8140-2 (Fig. 45).
- (7) Assemble Threaded Adapter 8140-1 into top side gear. Thread Forcing Screw 6960-4 into adapter until it becomes centered in adapter plate.
- (8) Position a small screw driver in slot of Threaded Adapter 8140-1 (Fig. 46) to prevent adapter from turning.

**Fig. 42 Differential Case Holding Tool**

DISASSEMBLY AND ASSEMBLY (Continued)




Fig. 43 Mate Shaft Lock Screw




Fig. 44 Mate Shaft Removal




Fig. 45 Step Plate Tool Installation




Fig. 46 Threaded Adapter Installation

(9) Tighten forcing screw tool 122 N·m (90 ft. lbs.) maximum to compress Belleville springs in clutch packs (Fig. 47).





Fig. 47 Tighten Belleville Spring Compressor Tool

(10) Using an appropriate size feeler gauge, remove thrust washers from behind the pinion gears (Fig. 48).


DISASSEMBLY AND ASSEMBLY (Continued)



80a77406

Fig. 48 Remove Pinion Gear Thrust Washer


- (11) Insert Turning Bar 6960-2 in case (Fig. 49).
- (12) Loosen the Forcing Screw 6960-4 in small increments until the clutch pack tension is relieved and the differential case can be turned using Turning Bar 6960-2.
- (13) Rotate differential case until the pinion gears can be removed.
- (14) Remove pinion gears from differential case.



80a0c4f6

Fig. 49 Pinion Gear Removal

- (15) Remove Forcing Screw 6960-4, Step Plate 8140-2, and Threaded Adapter 8140-1.
- (16) Remove top side gear, clutch pack retainer, and clutch pack. Keep plates in correct order during removal (Fig. 50).
- (17) Remove differential case from Side Gear Holding Tool 8138. Remove side gear, clutch pack retainer, and clutch pack. Keep plates in correct order during removal.



80a98382


Fig. 50 Side Gear & Clutch Disc Removal

ASSEMBLY

NOTE: The clutch discs are replaceable as complete sets only. If one clutch disc pack is damaged, both packs must be replaced.

Lubricate each component with gear lubricant before assembly.

- (1) Assemble the clutch discs into packs and secure disc packs with retaining clips (Fig. 51).



J8903-50

Fig. 51 Clutch Disc Pack

DISASSEMBLY AND ASSEMBLY (Continued)

(2) Position assembled clutch disc packs on the side gear hubs.

(3) Install clutch pack and side gear in the ring gear side of the differential case (Fig. 52). **Be sure clutch pack retaining clips remain in position and are seated in the case pockets.**




Fig. 52 Clutch Discs & Lower Side Gear Installation

(4) Position the differential case on Side Gear Holding Tool 8138.

(5) Install lubricated Step Plate 8140-2 in lower side gear (Fig. 53).

(6) Install the upper side gear and clutch disc pack (Fig. 53).

(7) Hold assembly in position. Insert Threaded Adapter 8140-1 into top side gear.

(8) Insert Forcing Screw 6960-4.

(9) Tighten forcing screw tool to slightly compress clutch discs.




Fig. 53 Upper Side Gear & Clutch Disc Pack Installation

(10) Place pinion gears in position in side gears and verify that the pinion mate shaft holes are aligned.

(11) Rotate case with Turning Bar 6960-2 until the pinion mate shaft holes in pinion gears align with holes in case. It may be necessary to slightly tighten the forcing screw in order to install the pinion gears.

(12) Tighten forcing screw to 122 N·m (90 ft. lbs.) maximum to compress the Belleville springs.

(13) Lubricate and install thrust washers behind pinion gears and align washers with a small screw driver. Insert mate shaft into each pinion gear to verify alignment.


(14) Remove Forcing Screw 6960-4, Step Plate 8140-2, and Threaded Adapter 8140-1.

(15) Install pinion gear mate shaft and align holes in shaft and case.

(16) Install the pinion mate shaft lock screw finger tight to hold shaft during differential installation.

(17) Lubricate all differential components with hypoid gear lubricant.

DISASSEMBLY AND ASSEMBLY (Continued)




80a77404

Fig. 54 Trac-lok Differential Components**9 1/4 TRAC-LOK DIFFERENTIAL**

The Trac-lok differential components are illustrated in (Fig. 54). Refer to this illustration during repair service.

DISASSEMBLY

- (1) Clamp Side Gear Holding Tool 8136 in a vise.
- (2) Position the differential case on Side Gear Holding Tool 8136 (Fig. 55).
- (3) Remove ring gear, if necessary. Ring gear removal is necessary only if the ring gear is to be replaced. The Trac-lok differential can be serviced with the ring gear installed.
- (4) Remove the pinion gear mate shaft lock screw (Fig. 56).
- (5) Remove the pinion gear mate shaft. If necessary, use a drift and hammer (Fig. 57).
- (6) Install and lubricate Step Plate 8139-2 (Fig. 58).
- (7) Assemble Threaded Adapter 8139-1 into top side gear. Thread Forcing Screw C-4487-2 into adapter until it becomes centered in adapter plate.
- (8) Position a small screw driver in slot of Threaded Adapter 8139-1 (Fig. 59) to prevent adapter from turning.
- (9) Tighten forcing screw tool 122 N·m (90 ft. lbs.) maximum to compress Belleville springs in clutch packs (Fig. 60).

**Fig. 55 Differential Case Holding Tool**

DISASSEMBLY AND ASSEMBLY (Continued)




Fig. 56 Mate Shaft Lock Screw




Fig. 57 Mate Shaft Removal




Fig. 58 Step Plate Tool Installation




Fig. 59 Threaded Adapter Installation




Fig. 60 Tighten Belleville Spring Compressor Tool


(10) Using an appropriate size feeler gauge, remove thrust washers from behind the pinion gears (Fig. 61).

(11) Insert Turning Bar C-4487-4 in case (Fig. 62).

(12) Loosen the Forcing Screw C-4487-2 in small increments until the clutch pack tension is relieved and the differential case can be turned using Turning Bar C-4487-4.

(13) Rotate differential case until the pinion gears can be removed.


DISASSEMBLY AND ASSEMBLY (Continued)



80a77406

Fig. 61 Remove Pinion Gear Thrust Washer

(14) Remove pinion gears from differential case.



80a0c4f6

Fig. 62 Pinion Gear Removal


(15) Remove Forcing Screw C-4487-2, Step Plate 8139-2, and Threaded Adapter 8139-1.

(16) Remove top side gear, clutch pack retainer, and clutch pack. Keep plates in correct order during removal (Fig. 63).

(17) Remove differential case from Side Gear Holding Tool 8136. Remove side gear, clutch pack retainer, and clutch pack. Keep plates in correct order during removal.

ASSEMBLY

NOTE: The clutch discs are replaceable as complete sets only. If one clutch disc pack is damaged, both packs must be replaced.




80a98382

Fig. 63 Side Gear & Clutch Disc Removal

Lubricate each component with gear lubricant before assembly.

(1) Assemble the clutch discs into packs and secure disc packs with retaining clips (Fig. 64).



J8903-50

Fig. 64 Clutch Disc Pack

(2) Position assembled clutch disc packs on the side gear hubs.

(3) Install clutch pack and side gear in the ring gear side of the differential case (Fig. 65). **Be sure clutch pack retaining clips remain in position and are seated in the case pockets.**

DISASSEMBLY AND ASSEMBLY (Continued)




Fig. 65 Clutch Discs & Lower Side Gear Installation

(4) Position the differential case on Side Gear Holding Tool 8136.

(5) Install lubricated Step Plate 8139-2 in lower side gear (Fig. 66).




Fig. 66 Upper Side Gear & Clutch Disc Pack Installation

(6) Install the upper side gear and clutch disc pack (Fig. 66).

(7) Hold assembly in position. Insert Threaded Adapter 8139-1 into top side gear.

(8) Insert Forcing Screw C-4487-2.

(9) Tighten forcing screw tool to slightly compress clutch discs.

(10) Place pinion gears in position in side gears and verify that the pinion mate shaft holes are aligned.

(11) Rotate case with Turning Bar C-4487-4 until the pinion mate shaft holes in pinion gears align with holes in case. It may be necessary to slightly tighten the forcing screw in order to install the pinion gears.

(12) Tighten forcing screw to 122 N·m (90 ft. lbs.) maximum to compress the Belleville springs.

(13) Lubricate and install thrust washers behind pinion gears and align washers with a small screw driver. Insert mate shaft into each pinion gear to verify alignment.

(14) Remove Forcing Screw C-4487-2, Step Plate 8139-2, and Threaded Adapter 8139-1.

(15) Install pinion gear mate shaft and align holes in shaft and case.

(16) Install the pinion mate shaft lock screw finger tight to hold shaft during differential installation.

(17) Lubricate all differential components with hypoid gear lubricant.

CLEANING AND INSPECTION

8 1/4 AND 9 1/4 AXLES

Wash differential components with cleaning solvent and dry with compressed air. **Do not steam clean the differential components.**

Wash bearings with solvent and towel dry, or dry with compressed air. **DO NOT** spin bearings with compressed air. **Cup and bearing must be replaced as matched sets only.**

Clean axle shaft tubes and oil channels in housing. Inspect for:

- Smooth appearance with no broken/dented surfaces on the bearing rollers or the roller contact surfaces.
- Bearing cups must not be distorted or cracked.
- Machined surfaces should be smooth and without any raised edges.
- Raised metal on shoulders of cup bores should be removed with a hand stone.
- Wear and damage to pinion gear mate shaft, pinion gears, side gears and thrust washers. Replace as a matched set only.
- Ring and pinion gear for worn and chipped teeth.
- Ring gear for damaged bolt threads. Replaced as a matched set only.
- Pinion yoke for cracks, worn splines, pitted areas, and a rough/corroded seal contact surface. Repair or replace as necessary.

CLEANING AND INSPECTION (Continued)

- Pinion depth shims for damage and distortion. Install new shims if necessary.
- The differential case. Replace the case if cracked or damaged.
- The axle shaft C-clip locks for cracks and excessive wear. Replace them if necessary.
- Each threaded adjuster to determine if it rotates freely. If an adjuster binds, repair the damaged threads or replace the adjuster.
- The RWAL exciter ring for damage and missing teeth. Verify that the ring is fully seated to the differential case flange.

Polish each axle shaft sealing surface with No. 600 crocus cloth. This can remove slight surface damage. Do not reduce the diameter of the axle shaft seal contact surface. When polishing, the crocus cloth should be moved around the circumference of the shaft (not in-line with the shaft).

TRAC-LOK

Clean all components in cleaning solvent. Dry components with compressed air. Inspect clutch pack plates for wear, scoring or damage. Replace both clutch packs if any one component in either pack is damaged. Inspect side and pinion gears. Replace any gear that is worn, cracked, chipped or damaged. Inspect differential case and pinion shaft. Replace if worn or damaged.

PRESOAK PLATES AND DISC

Plates and discs with fiber coating (no grooves or lines) must be presoaked in Friction Modifier before assembly. Soak plates and discs for a minimum of 20 minutes.

ADJUSTMENTS

8 1/4 AXLE PINION GEAR DEPTH

GENERAL INFORMATION

Ring and pinion gears are supplied as matched sets only. The identifying numbers for the ring and pinion gear are marked on the face of each gear (Fig. 67). A plus (+) number, minus (-) number or zero (0) is marked on the face of the pinion gear. This number is the amount (in thousandths of an inch) the depth varies from the standard depth setting of a pinion marked with a (0). The standard depth provides the best teeth contact pattern. Refer to Backlash and Contact Pattern Analysis Paragraph in this section for additional information.

Compensation for pinion depth variance is achieved with select shims. The shims are placed under the rear pinion bearing cone (Fig. 68).




Fig. 67 Pinion Gear ID Numbers




Fig. 68 Shim Locations

If a new gear set is being installed, note the depth variance marked on both the original and replacement pinion gear. Add or subtract the thickness of the original depth shims to compensate for the difference in the depth variances. Refer to the Depth Variance charts.

Note where Old and New Pinion Marking columns intersect. Intersecting figure represents plus or minus amount needed.

Note the marked number on the face of the drive pinion gear (-1, -2, 0, +1, +2, etc.). The numbers represent thousands of an inch deviation from the standard. If the number is negative, add that value to the required thickness of the depth shim(s). If the number is positive, subtract that value from the thickness of the depth shim(s). If the number is 0 no change is necessary. Refer to the Pinion Gear Depth Variance Chart.

ADJUSTMENTS (Continued)

Original Pinion Gear Depth Variance	Replacement Pinion Gear Depth Variance								
	-4	-3	-2	-1	0	+1	+2	+3	+4
+4	+0.008	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0
+3	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001
+2	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002
+1	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003
0	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004
-1	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005
-2	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006
-3	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007
-4	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007	-0.008

J8902-46

PINION DEPTH MEASUREMENT AND ADJUSTMENT

- (1) Install front pinion bearing cup. Use Installer D-130 and Handle C-4171.
- (2) Install rear pinion bearing cup. Use Installer C-4308 and Handle C-4171.
- (3) Use Pinion Gear Adjustment Gauge Set C-3715-B (Fig. 69).
- (4) Position Spacer SP-6030 over Shaft SP-5385.
- (5) Position pinion rear bearing on shaft.
- (6) Position tools (with bearing) in the housing.
- (7) Install Sleeve SP-5382.
- (8) Install pinion front bearing.
- (9) Install Spacer SP-6022.
- (10) Install Sleeve SP-3194-B, Washer SP-534, and Nut SP-3193.




Fig. 69 8 1/4 Axle Pinion Adjustment Tools

- (11) Tighten the nut to seat the pinion bearings in the housing. Allow the sleeve to turn several times during tightening to prevent brinelling bearing cups or bearings.
- (12) Loosen the compression nut tool.
- (13) Lubricate the pinion gear front and rear bearings with gear lubricant.
- (14) Re-tighten the compression nut tool to 1-3 N·m (15-25 in. lbs.) torque.
- (15) Rotate the pinion gear several complete revolutions to align the bearing rollers.
- (16) Install Gauge Block (Fig. 70).




Fig. 70 Gauge Block

- (17) Install Gauge Block SP-5383 at the end of SP-5385.
- (18) Install Cap Screw SP-536 and tighten with Wrench SP-531.

ADJUSTMENTS (Continued)

(19) Position Crossbore Arbor SP-6029 in the differential housing (Fig. 71).




Fig. 71 Crossbore Arbor

- (20) Center the arbor tool.
- (21) Position the bearing caps on the arbor tool.
- (22) Install the attaching bolts.
- (23) Tighten the cap bolts to 14 N·m (10 ft. lbs.).
- (24) Trial fit depth shim(s) between the crossbore arbor and gauge block (Fig. 72). **The depth shim(s) fit must be snug but not tight (drag friction of a feeler gauge blade).**




Fig. 72 Depth Shim(s) Selection

(25) Select a shim equal to the shim selected above plus the drive pinion gear depth variance number marked on the face of the pinion gear (Fig. 67) using the opposite sign on the variance number. For example, if the depth variance is -2, add +0.002 in. to the dial indicator reading.

NOTE: Depth shims are available in 0.001-inch increments from 0.020 inch to 0.038 inch.

(26) Remove the tools from the differential housing.

9 1/4 AXLE PINION GEAR DEPTH

GENERAL INFORMATION

Ring and pinion gears are supplied as matched sets only. The identifying numbers for the ring and pinion gear are marked on the face of each gear (Fig. 73). A plus (+) number, minus (-) number or zero (0) is marked on the face of the pinion gear. This number is the amount (in thousandths of an inch) the depth varies from the standard depth setting of a pinion marked with a (0). The standard depth provides the best teeth contact pattern. Refer to Backlash and Contact Pattern Analysis Paragraph in this section for additional information.




Fig. 73 Pinion Gear ID Numbers

Compensation for pinion depth variance is achieved with select shims. The shims are placed under the rear pinion bearing cone (Fig. 74).




Fig. 74 Shim Locations

ADJUSTMENTS (Continued)

Original Pinion Gear Depth Variance	Replacement Pinion Gear Depth Variance								
	-4	-3	-2	-1	0	+1	+2	+3	+4
+4	+0.008	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0
+3	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001
+2	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002
+1	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003
0	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004
-1	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005
-2	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006
-3	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007
-4	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007	-0.008

J8902-46

If a new gear set is being installed, note the depth variance marked on both the original and replacement pinion gear. Add or subtract the thickness of the original depth shims to compensate for the difference in the depth variances. Refer to the Depth Variance charts.

Note where Old and New Pinion Marking columns intersect. Intersecting figure represents plus or minus amount needed.

Note the marked number on the face of the drive pinion gear (-1, -2, 0, +1, +2, etc.). The numbers represent thousands of an inch deviation from the standard. If the number is negative, add that value to the required thickness of the depth shim(s). If the number is positive, subtract that value from the thickness of the depth shim(s). If the number is 0 no change is necessary. Refer to the Pinion Gear Depth Variance Chart.

PINION DEPTH MEASUREMENT AND ADJUSTMENT

- (1) Install front bearing cup. Use Installer D-129 and Handle C-4171.
- (2) Install rear bearing cup. Use Installer C-4310 and Handle C-4171.
- (3) Use Pinion Gear Adjustment Gauge Set C-758-D6 (Fig. 75).
- (4) Position Spacer SP-6017 over Shaft SP-526.
- (5) Position pinion rear bearing on shaft.
- (6) Position tools (with bearing) in the housing.
- (7) Install Sleeve SP-1730.

- (8) Install pinion front bearing.
- (9) Install Spacer SP-6022.
- (10) Install Sleeve SP-535A, Washer SP-534, and Nut SP-533.





Fig. 75 9 1/4 Axle Pinion Adjustment Tools


- (11) Tighten the nut to seat the pinion bearings in the housing. Allow the sleeve to turn several times during tightening to prevent brinelling bearing cups or bearings.
- (12) Loosen the compression nut tool.
- (13) Lubricate the pinion gear front and rear bearings with gear lubricant.
- (14) Re-tighten the compression nut tool to 1-3 N·m (15-25 in. lbs.) torque.

ADJUSTMENTS (Continued)


- (15) Rotate the pinion gear several complete revolutions to align the bearing rollers.
 (16) Install Gauge Block (Fig. 76).

**Fig. 76 Gauge Block**

- (17) Install Gauge Block SP-6020 at the end of SP-526.
 (18) Install Cap Screw SP-536 and tighten with Wrench SP-531.
 (19) Position Crossbore Arbor SP-6018 in the differential housing (Fig. 77).

**Fig. 77 Crossbore Arbor**

- (20) Center the tool.
 (21) Position the bearing caps on the arbor tool.
 (22) Install the attaching bolts.
 (23) Tighten the cap bolts to 14 N·m (10 ft. lbs.).
 (24) Trial fit depth shim(s) between the crossbore arbor and gauge block (Fig. 78). **The depth shim(s) fit must be snug but not tight (drag friction of a feeler gauge blade).**
 (25) Select a shim equal to the shim selected above plus the drive pinion gear depth variance number marked on the face of the pinion gear (Fig. 73) using the opposite sign on the variance number. For exam-

**Fig. 78 Depth Shim(s) Selection**

ple, if the depth variance is -2, add +0.002 in. to the dial indicator reading.

NOTE: Depth shims are available in 0.001-inch increments from 0.020 inch to 0.038 inch.

- (26) Remove the tools from the differential housing.

DIFFERENTIAL BEARING PRELOAD AND GEAR BACKLASH

The following must be considered when adjusting bearing preload and gear backlash:

- The maximum ring gear backlash variation is 0.003 inch (0.076 mm).
- Mark the gears so the same teeth are meshed during all backlash measurements.
- Maintain the torque while adjusting the bearing preload and ring gear backlash.
- Excessive adjuster torque will introduce a high bearing load and cause premature bearing failure. Insufficient adjuster torque can result in excessive differential case free-play and ring gear noise.
- Insufficient adjuster torque will not support the ring gear correctly and can cause excessive differential case free-play and ring gear noise.

NOTE: The differential bearing cups will not always immediately follow the threaded adjusters as they are moved during adjustment. To ensure accurate bearing cup responses to the adjustments:

- Maintain the gear teeth engaged (meshed) as marked.
- The bearings must be seated by rapidly rotating the pinion gear a half turn back and forth.
- Do this five to ten times each time the threaded adjusters are adjusted.

- (1) Use Wrench C-4164 to adjust each threaded adjuster inward until the differential bearing free-

ADJUSTMENTS (Continued)

play is eliminated (Fig. 79). Allow some ring gear backlash (approximately 0.01 inch/0.25 mm) between the ring and pinion gear. Seat the bearing cups with the procedure described above.




Fig. 79 Threaded Adjuster Tool

(2) Install dial indicator and position the plunger against the drive side of a ring gear tooth (Fig. 80). Measure the backlash at 4 positions (90 degrees apart) around the ring gear. Locate and mark the area of minimum backlash.

(3) Rotate the ring gear to the position of the least backlash. Mark the gear so that all future backlash measurements will be taken with the same gear teeth meshed.




Fig. 80 Ring Gear Backlash Measurement

(4) Loosen the right-side, tighten the left-side threaded adjuster. Obtain backlash of 0.003 to 0.004 inch (0.076 to 0.102 mm) with each adjuster tightened to 14 N·m (10 ft. lbs.). Seat the bearing cups with the procedure described above.

(5) Tighten the differential bearing cap bolts;

- 8 1/4 axles: 95 N·m (70 ft. lbs.)
- 9 1/4 axles: 136 N·m (100 ft. lbs.)

(6) Tighten the right-side threaded adjuster to 102 N·m (75 ft. lbs.). Seat the bearing cups with the procedure described above. Continue to tighten the right-side adjuster and seat bearing cups until the torque remains constant at 102 N·m (75 ft. lbs.).

(7) Measure the ring gear backlash. The range of backlash is 0.006 to 0.008 inch (0.15 to 0.203 mm).

(8) Continue increasing the torque at the right-side threaded adjuster until the specified backlash is obtained.

NOTE: The left-side threaded adjuster torque should have approximately 102 N·m (75 ft. lbs.). If the torque is considerably less, the complete adjustment procedure must be repeated.

(9) Tighten the left-side threaded adjuster until 102 N·m (75 ft. lbs.) torque is indicated. Seat the bearing rollers with the procedure described above. Do this until the torque remains constant.

(10) Install the threaded adjuster locks and tighten the lock screws to 10 N·m (90 in. lbs.).

After the proper backlash is achieved, perform the Gear Contact Analysis procedure.

GEAR CONTACT PATTERN ANALYSIS

The ring and pinion gear teeth contact patterns will show if the pinion gear depth is correct in the axle housing. It will also show if the ring gear backlash has been adjusted correctly. The backlash can be adjusted within specifications to achieve desired tooth contact patterns.

(1) Apply a thin coat of hydrated ferric oxide, or equivalent, to the drive and coast side of the ring gear teeth.

(2) Wrap, twist, and hold a shop towel around the pinion yoke to increase the turning resistance of the pinion gear. This will provide a more distinct contact pattern.

(3) Using a boxed end wrench on a ring gear bolt, Rotate the differential case one complete revolution in both directions while a load is being applied from shop towel.

The areas on the ring gear teeth with the greatest degree of contact against the pinion gear teeth will squeegee the compound to the areas with the least amount of contact. Note and compare patterns on the ring gear teeth to Gear Tooth Contact Patterns chart (Fig. 81) and adjust pinion depth and gear backlash as necessary.

ADJUSTMENTS (Continued)











<p>DRIVE SIDE OF RING GEAR TEETH</p> <p>HEEL TOE</p> 	<p>COAST SIDE OF RING GEAR TEETH</p> <p>TOE HEEL</p> 	<p>DESIRABLE CONTACT PATTERN. PATTERN SHOULD BE CENTERED ON THE DRIVE SIDE OF TOOTH. PATTERN SHOULD BE CENTERED ON THE COAST SIDE OF TOOTH, BUT MAY BE SLIGHTLY TOWARD THE TOE. THERE SHOULD ALWAYS BE SOME CLEARANCE BETWEEN CONTACT PATTERN AND TOP OF THE TOOTH.</p>
		<p>RING GEAR BACKLASH CORRECT. THINNER PINION GEAR DEPTH SHIM REQUIRED.</p>
		<p>RING GEAR BACKLASH CORRECT. THICKER PINION GEAR DEPTH SHIM REQUIRED.</p>
		<p>PINION GEAR DEPTH SHIM CORRECT. DECREASE RING GEAR BACKLASH.</p>
		<p>PINION GEAR DEPTH SHIM CORRECT. INCREASE RING GEAR BACKLASH.</p>

Fig. 81 Gear Tooth Contact Patterns

ADJUSTMENTS (Continued)

SIDE GEAR CLEARANCE

When measuring side gear clearance, check each gear independently. If it necessary to replace a side gear, replace both gears as a matched set.

(1) Install the axle shafts and C-clip locks and pinion mate shaft.

(2) Measure each side gear clearance. Insert a matched pair of feeler gauge blades between the gear and differential housing on opposite sides of the hub- (Fig. 82).




Fig. 82 Side Gear Clearance Measurement

(3) If side gear clearances is no more than 0.005 inch. Determine if the shaft is contacting the pinion gear mate shaft. **Do not remove the feeler gauges, inspect the axle shaft with the feeler gauge inserted behind the side gear.** If the end of the axle shaft is not contacting the pinion gear mate shaft, the side gear clearance is acceptable.

(4) If clearance is more than 0.005 inch (axle shaft not contacting mate shaft), record the side gear clearance. Remove the thrust washer and measure its thickness with a micrometer. Add the washer thickness to the recorded side gear clearance. The sum of gear clearance and washer thickness will determine required thickness of replacement thrust washer (Fig. 83).

SIDE GEAR CLEARANCE	0.007
THRUST WASHER THICKNESS	+ 0.033
TOTAL	0.040
→	
REPLACEMENT WASHER THICKNESS	0.040
	- 0.037
NEW SIDE GEAR CLEARANCE	0.003

J9203-31

Fig. 83 Side Gear Calculations

In some cases, the end of the axle shaft will move and contact the mate shaft when the feeler gauge is inserted. The C-clip lock is preventing the side gear from sliding on the axle shaft.

(5) If there is no side gear clearance, remove the C-clip lock from the axle shaft. Use a micrometer to measure the thrust washer thickness. Record the thickness and re-install the thrust washer. Assemble the differential case without the C-clip lock installed and re-measure the side gear clearance.

(6) Compare both clearance measurements. If the difference is less than 0.012 inch (0.305 mm), add clearance recorded when the C-clip lock was installed to thrust washer thickness measured. The sum will determine the required thickness of the replacement thrust washer.

(7) If clearance is 0.012 inch (0.305 mm) or greater, both side gears must be replaced (matched set) and the clearance measurements repeated.

(8) If clearance (above) continues to be 0.012 inch (0.305 mm) or greater, the case must be replaced.

SPECIFICATIONS

8 1/4 INCH AXLE

Axle Type	Semi-floating, hypoid
Lubricant	SAE 80W-90
Lube Capacity	2.22 L (4.7 pts.)
Trac-Lok Additive	148 ml (5 oz.)
Axle Ratio	3.21, 3.55, 3.92

Differential

Case Clearance	0.12 mm (0.005 in.)
Case Flange Runout	0.076 mm (0.003 in.)

Ring Gear

Diameter	20.95 cm (8.25 in.)
Backlash	0.12-0.20 mm (0.005-0.008 in.)
Runout	0.127 mm (0.005 in.)

Pinion Bearing

Preload	1-2 N·m (10-20 in.lbs.)
---------	-------------------------

9 1/4 INCH AXLE

Axle Type	Semi-floating, hypoid
Lubricant	SAE 80W-90
Lube Capacity	2.32 L (4.9 pts.)
Trac-lok Additive	148 ml (5 oz.)
Axle Ratio	3.21, 3.55, 3.92

Differential

Case Clearance	0.12 mm (0.005 in.)
Case Flange Runout	0.076 mm (0.003 in.)

Ring gear

Diameter	23.50 cm (9.25 in.)
Backlash	0.12-0.20 mm (0.005-0.008 in.)
Runout	0.127 mm (0.005 in.)

Pinion Bearing Preload


Original	1-2 N·m (10-20 in.lbs.)
New	2-5 N·m (15-35 in. lbs.)

SPECIFICATIONS (Continued)

8 1/4 and 9 1/4 INCH AXLE







DESCRIPTION**TORQUE**

Diff. Cover Bolt	41 N·m (30 ft. lbs.)
Bearing Cap Bolt—8 1/4 Axle . . .	95 N·m (70 ft. lbs.)
Bearing Cap Bolt—9 1/4 Axle . . .	136 N·m (100 ft. lbs.)
Pinion Nut	285 N·m (210 ft. lbs.)
Ring Gear Bolt—8 1/4 Axle	102 N·m (75 ft. lbs.)
Ring Gear Bolt—9 1/4 Axle . . .	157 N·m (115 ft. lbs.)
Backing Plate Bolt	64 N·m (48 ft. lbs.)
RWAL/ABS Sensor Bolt	24 N·m (18 ft. lbs.)
Threaded Adjuster Lock Screw . . .	10 N·m (90 in. lbs.)


**Handle—C-4171**

SPECIAL TOOLS


8 1/4 AND 9 1/4 AXLES

**Puller, Hub—6790****Installer—C-4076-B****Remover, Bearing—6310****Handle—C-4735-1****Installer—C-4198****Remover—C-4828**


SPECIAL TOOLS (Continued)




Installer—C-4826




Installer—C-3718




Holder—6719




Adjustment Rod—C-4164




Puller—C-452



Puller/Press—C-293-PA











Installer—C-3860-A




Adapters—C-293-48


SPECIAL TOOLS (Continued)

***Plug—SP-3289******Installer—C-4213******Adapters—C-293-47******Holder—8136******Plug—C-293-3******Holder—8138******Installer—C-4340******Installer—C-4345***


SPECIAL TOOLS (Continued)




Remover—C-4307




Installer—C-4310




Remover—C-4309




Installer—D-130




Adapters—C-293-37



Installer—D-129










Installer—C-4308



Installer—6448

SPECIAL TOOLS (Continued)

**Installer—C-3095****Trac-lok Tools—C-4487****Trac-lok Tools—8140****Trac-lok Tools—8139****Trac-lok Tools—6960****Gauge Set—C-3715-B****Gauge Set—C-758-D6**