

Description	Group-Page	Description	Group-Page	Description	Group-Page
ABS BRAKE SYSTEM, BLEEDING	5-38	ALIGNMENT, SPECIAL TOOLS—		AXLE, REAR	3-60
ABS SERVICE PRECAUTIONS	5-33	HEADLAMP	8-6	AXLE SEAL AND BEARING, 8 1/4 AND 9 1/4 LD	3-62
ABS WARNING LAMP	5-38	ALIGNMENT, WHEEL	2-1,2-3	AXLE SHAFT	3-34,3-61
ABSOLUTE PRESSURE (MAP) SENSOR, MANIFOLD	8-14,8-4	ALL-WHEEL ANTI-LOCK BRAKES, 8W-35	8-1	AXLE SHAFT SEAL AND BEARING	3-34
ABSOLUTE PRESSURE (MAP) SENSOR TEST—3.9/5.2/5.9L ENGINES, MANIFOLD	14-39	ALUMINUM THREAD REPAIR	21-144,21-26	AXLE SKID PLATE, FRONT	13-5
ABSOLUTE PRESSURE (MAP) SENSOR—3.9/5.2/5.9L ENGINES, MANIFOLD	14-45	AMBIENT TEMPERATURE SENSOR	8-8	AXLE WITH LEAF SPRINGS, ADJUSTMENT AT	3-14
ABSOLUTE PRESSURE (MAP) SENSOR—3.9/5.2/5.9L ENGINES—PCM INPUT, MANIFOLD	14-29	AMPERAGE TEST, FUEL PUMP	14-8	AXLES, 8 1/4 AND 9 1/4	3-53,3-79,3-88
ABSORBER, SHOCK	2-14,2-6	AMPLIFIER	8-7	AXLES, FRONT	3-27
ACCELERATION, CLUNKING NOISE DURING	3-16	ANALYSIS, GEAR CONTACT PATTERN	3-47,3-85	BACK, 2ND ROW CENTER SEAT	23-13
ACCELERATION, SHUDDER OR VIBRATION DURING	3-16	ANALYSIS, STALL TEST	21-128,21-13	BACK, 2ND ROW SEAT	23-11
ACCELERATOR PEDAL	14-21	ANALYZING ROAD TEST	21-10,21-124	BACK, 3RD ROW SEAT	23-14
ACCESSORY DRIVE BELT	7-33	ANGLE MEASUREMENT PREPARATION, DRIVELINE	3-5	BACK, BUCKET SEAT	23-9
ACCESSORY DRIVE BELT DIAGNOSIS	7-18	ANGLE MEASUREMENT, PROPELLER SHAFT	3-5	BACK COVER, 2ND ROW CENTER SEAT	23-13
ACCESSORY DRIVE BELT TENSION	7-4	ANGLE, PROPELLER SHAFT JOINT	3-2	BACK COVER, 2ND ROW SEAT	23-11
ACCUMULATOR	21-210,21-91	ANTENNA	8-11,8-2,8-5,8-9	BACK COVER, 3RD ROW SEAT	23-14
ACTION TEST MODE, CIRCUIT	25-2	ANTILOCK BRAKE SYSTEM	5-36	BACK COVER/CUSHION, BUCKET SEAT	23-9
ACTUATOR, FRONT DOOR INSIDE HANDLE	23-30	ANTI-LOCK BRAKE SYSTEM LAMP	8-16,8-7	BACK FRAME, BUCKET SEAT	23-9
ACTUATOR, REAR DOOR INSIDE HANDLE	23-36	ANTILOCK BRAKES	5-38	BACKLASH, DIFFERENTIAL BEARING PRELOAD AND GEAR	3-44,3-84
ADDITIONAL, COOLANT—ADDING	7-22	ANTI-LOCK BRAKES, 8W-34 REAR WHEEL	8-1	BACKLITE, LIFTGATE	23-7
ADDITIVES, COOLANT SELECTION	7-7	ANTI-LOCK BRAKES, 8W-35 ALL-WHEEL	8-1	BACK-UP LAMP BULB, TAIL, STOP, TURN SIGNAL	8-8
ADJUSTER AND MOTORS, POWER SEAT	8-1, 8-2,8-3	ANTILOCK BRAKES, CONTROLLER	5-30,5-37, 5-39	BACK-UP LAMP, TAIL, STOP, TURN SIGNAL	8-13
ADJUSTMENT AT AXLE WITH LEAF SPRINGS	3-14	ANTILOCK BRAKES, FOUR WHEEL	5-36	BALANCE, TIRE AND WHEEL	22-9
ADJUSTMENT, CENTER BEARING	3-14	ANTILOCK BRAKES, REAR WHEEL	5-28	BALL JOINT, LOWER	2-6
ADJUSTMENT, COMPASS VARIATION	8-4	ANTILOCK CONTROL ASSEMBLY	5-39	BALL JOINT, UPPER	2-6
ADJUSTMENT, DOOR LATCH	23-59	ANTILOCK, REAR WHEEL	5-28,5-33	BAND ADJUSTMENT, FRONT	21-214
ADJUSTMENT, FRONT BAND	21-214	A-PILLAR GRAB HANDLE	23-45	BAND ADJUSTMENT, REAR	21-214
ADJUSTMENT, HEADLAMP	8-5	A-PILLAR TRIM	23-46	BAND ADJUSTMENTS	21-95
ADJUSTMENT, REAR BAND	21-214	APPLICATION, BULB	8-17	BAND OPERATION, AIR TESTING TRANSMISSION CLUTCH	21-128,21-14
ADJUSTMENT, SHIFT LINKAGE	21-255,21-283	ARM AND BLADE, WIPER	8-2	BAR, STABILIZER	2-10,2-14
ADJUSTMENT, TRANSMISSION THROTTLE VALVE CABLE	21-213,21-94	ARM, IDLER	19-27	BAR, TORSION	2-7
ADJUSTMENTS, BAND	21-95	ARM, LOWER SUSPENSION	2-8	BAR, TOWEL	23-8
AERATION, COOLANT—LOW LEVEL	7-21	ARM, PITMAN	19-27	BASE BRAKE SYSTEM	5-1,5-4
AFTERMARKET REPAIR PRODUCTS	23-3	ARM, UPPER SUSPENSION	2-9	BASE BRAKES	5-26,5-27
AIR CLEANER ELEMENT (FILTER)	14-47	ARM, WIPER	8-10	BASE COAT/CLEAR COAT FINISH	23-2
AIR CONDITIONING (A/C) CLUTCH RELAY—PCM OUTPUT	14-32	ARMING	8-1	BATTERY	8-14,8-16,8-2,8-3
AIR CONDITIONING (A/C) CONTROLS—PCM INPUT	14-27	ARMS AND PUSH RODS, ROCKER	9-59,9-93	BATTERY CHARGING	8-12
AIR CONDITIONING/HEATER, 8W-42	8-1	ASD AND FUEL PUMP RELAYS	14-38	BATTERY MOUNTING	8-3
AIR CONTROL (IAC) MOTOR—3.9/5.2/5.9L ENGINES, IDLE	14-41,14-44	ASH RECEIVER	8-31	BATTERY REPLACEMENT, REMOTE KEYLESS ENTRY TRANSMITTER	8-7
AIR CONTROL (IAC) MOTOR—3.9/5.2/5.9L ENGINES—PCM OUTPUT, IDLE	14-33	ASSEMBLY, ANTILOCK CONTROL	5-39	BATTERY SIZE AND RATINGS	8-2
AIR FLOW CHECK PROCEDURE, THROTTLE BODY MINIMUM	14-42	ASSEMBLY, CYLINDER HEAD	9-109	BATTERY TEMPERATURE SENSOR	8-2,8-5,8-7
AIR TEMPERATURE SENSOR, INTAKE MANIFOLD	8-14,8-4,8-8	ASSEMBLY, ENGINE	9-23,9-58,9-92	BATTERY TEMPERATURE SENSOR—PCM INPUT	14-28
AIR TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINE, INTAKE MANIFOLD	14-41	ASSEMBLY, FINAL	3-40,3-71	BATTERY VOLTAGE—PCM INPUT	14-28
AIR TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINES, INTAKE MANIFOLD	14-47	ASSEMBLY, INSTRUMENT PANEL	8-35	BEAM INDICATOR LAMP, HEADLAMP HIGH	8-10,8-20
AIR TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINES—PCM INPUT, INTAKE MANIFOLD	14-29	ASSEMBLY, PARK BRAKE PEDAL	5-19	BEARING, 8 1/4 AND 9 1/4 LD AXLE SEAL	3-62
AIR TESTING TRANSMISSION CLUTCH AND BAND OPERATION	21-128,21-14	ASSEMBLY, PISTON AND CONNECTING ROD	9-101,9-109,9-15,9-34, 9-50,9-67,9-75,9-84	BEARING ADJUSTMENT, CENTER	3-14
AIRBAG CONTROL MODULE	8-3,8-8	ASSIST HANDLE, OVERHEAD	23-57	BEARING, AXLE SHAFT SEAL	3-34
AIRBAG DOOR, PASSENGER SIDE	8-8	AUDIO SYSTEM	8-1,8-2	BEARING, CENTER	3-8
AIRBAG INDICATOR LAMP	8-16,8-7	AUDIO SYSTEM, 8W-47	8-1	BEARING NOISE	3-26,3-57
AIRBAG MODULE	8-2,8-5	AUTO SHUTDOWN (ASD) RELAY—PCM OUTPUT	14-32	BEARING, OUTPUT SHAFT FRONT	21-153,21-35
AIRBAG SYSTEM	8-1,8-3,8-4	(AUTO)—ACCESSORY DRIVE BELT, TENSIONER	7-6	BEARING, OUTPUT SHAFT REAR	21-152,21-35
AIRBAG SYSTEM, 8W-43	8-1	AUTOMATIC BELT TENSIONER	7-34	BEARING PRELOAD AND GEAR BACKLASH, DIFFERENTIAL	3-44,3-84
AIRBAG TRIM COVER AND HORN SWITCH, DRIVER SIDE	8-7	AUTOMATIC DAY/NIGHT MIRROR	8-4,8-5	BEARINGS, CAMSHAFT	9-32,9-65,9-99
AJAR LAMP, DOOR	8-19,8-9	AUTOMATIC DAY/NIGHT MIRROR SYSTEM	8-4	BEARINGS, CENTER	3-2
AJAR LAMP, LIFTGATE	8-10,8-20	AUTOMATIC SHUTDOWN (ASD) RELAY; FUEL SYSTEM	14-43	BEARINGS, CONNECTING ROD	9-20
AJAR SWITCH, DOOR	8-3,8-4	AUTOMATIC SHUTDOWN (ASD) RELAY; IGNITION SYSTEM	8-13,8-3	BEARINGS, CRANKSHAFT MAIN	9-100,9-21, 9-32,9-55,9-65
AJAR SWITCH, DRIVER DOOR	8-2,8-3	AUTOMATIC SHUTDOWN (ASD) RELAY SENSE—PCM INPUT	14-28	BEARINGS, DIFFERENTIAL SIDE	3-36,3-65
AJAR SWITCH, LIFTGATE	8-3,8-4	AUTOMATIC SHUTDOWN (ASD) RELAY TEST	8-4	BEARINGS, FITTING CONNECTING ROD	9-55, 9-89
ALERT, TAMPER	8-2	AUTOMATIC TRANSMISSION, 42/44RE	21-1	BEARINGS, FITTING CRANKSHAFT MAIN	9-89
ALIGNMENT	2-1,2-4	AUTOMATIC TRANSMISSION, 46RE	21-116	BELT, ACCESSORY DRIVE	7-33
ALIGNMENT, FOG LAMP	8-5	AUTOMATIC TRANSMISSION DIAGNOSIS	21-123,21-8	BELT BUCKLE, 2ND ROW SEAT	23-51
ALIGNMENT, HEADLAMP	8-4	AUTOMATIC TRANSMISSION OIL COOLER	7-5	BELT BUCKLE, 3RD ROW SEAT	23-52
ALIGNMENT PREPARATION, HEADLAMP	8-4	AUXILIARY OIL-TO-AIR COOLER	7-5	BELT BUCKLE, FRONT SEAT	23-50
		AXLE, 194 FIA	3-24,3-49	BELT DIAGNOSIS, ACCESSORY DRIVE	7-18
		AXLE, 8 1/4 AND 9 1/4	3-53	BELT REMINDER LAMP, SEAT	8-11,8-23
		AXLE, 8 1/4 AND 9 1/4 INCH	3-88	BELT RETRACTOR, 2ND ROW SEAT	23-50
		AXLE, 8 1/4 INCH	3-87	BELT RETRACTOR, 3RD ROW SEAT	23-51
		AXLE, 9 1/4 INCH	3-87	BELT RETRACTOR, FRONT SEAT	23-49
		AXLE COMPONENTS	3-41	BELT SWITCH, DRIVER SEAT	8-2,8-5
		AXLE DRIVESHAFTS, FRONT	3-15	BELT TENSION, ACCESSORY DRIVE	7-4
		AXLE, FRONT	3-29	BELT, TENSIONER (AUTO)—ACCESSORY DRIVE	7-6
		AXLE IDENTIFICATION	3-53	BELT TENSIONER, AUTOMATIC	7-34
		AXLE PINION GEAR DEPTH, 8 1/4	3-80		
		AXLE PINION GEAR DEPTH, 9 1/4	3-82		

Description	Group-Page	Description	Group-Page	Description	Group-Page
BELT WEATHERSTRIP, FRONT DOOR INNER	23-30	BRAKE WARNING LAMP	8-17,8-7	CAMSHAFT POSITION SENSOR; FUEL SYSTEM	14-46
BELT WEATHERSTRIP, FRONT DOOR OUTER	23-30	BRAKE WARNING LAMP, RED	5-2,5-7	CAMSHAFT POSITION SENSOR; IGNITION SYSTEM	8-14,8-3,8-7
BELT WEATHERSTRIP, REAR DOOR INNER	23-36	BRAKE WARNING LAMPS	5-32	CAMSHAFT POSITION SENSOR—PCM INPUT	14-28
BELT WEATHERSTRIP, REAR DOOR OUTER	23-36	BRAKES, 8W-34 REAR WHEEL ANTI-LOCK	8-1	CANISTER, EVAPORATION (EVAP)	25-13,25-17
BETTS CONNECTORS, TERMINAL/ CONNECTOR REPAIR—THOMAS	8-11	BRAKES, 8W-35 ALL-WHEEL ANTI-LOCK	8-1	CANISTER PURGE SOLENOID, DUTY CYCLE EVAP; EMISSION CONTROL SYSTEMS	25-14,25-18
BEZEL, CLUSTER	8-24	BRAKES, ANTILOCK	5-38	CANISTER PURGE SOLENOID, DUTY CYCLE EVAP; FUEL SYSTEM	14-46
BEZEL, INSTRUMENT PANEL LOWER	8-31	BRAKES, BASE	5-26,5-27	CAP, DISTRIBUTOR	8-6
BIN DOOR, GARAGE DOOR OPENER STORAGE	8-8	BRAKES, CONTROLLER ANTILOCK	5-30,5-37, 5-39	CAP, FUEL TANK FILLER TUBE	14-21,14-6
BIN DOOR, SUNGLASSES STORAGE	8-8	BRAKES, DRUM	5-4	CAP, RADIATOR	7-36
BIN, GARAGE DOOR OPENER STORAGE	8-2	BRAKES, FOUR WHEEL ANTILOCK	5-36	CAP, RADIATOR PRESSURE	7-3
BIN, SUNGLASSES STORAGE	8-3	BRAKES, FRONT DISC	5-3	CAPACITIES, COOLING SYSTEM	7-37
BLADE, FAN	7-36	BRAKES, PARKING	5-4	CAPACITIES, FLUID	0-2
BLADE, WIPER	8-10	BRAKES, REAR WHEEL ANTILOCK	5-28	CAPACITY, FUEL TANK	14-22
BLADE, WIPER ARM	8-2	BRAKER, CIRCUIT	8-2,8-3	CAPACITY TEST, FUEL PUMP	14-7
BLEEDING ABS BRAKE SYSTEM	5-38	BUCKET SEAT	23-52	CAP—PRESSURE TESTING, RADIATOR	7-21
BLEEDING, BRAKE	5-10	BUCKET SEAT BACK	23-9	CAP-TO-FILLER NECK SEAL—PRESSURE RELIEF CHECK, RADIATOR	7-20
BLEEDING, MASTER CYLINDER	5-9	BUCKET SEAT BACK COVER/CUSHION	23-9	CARDAN JOINT, DOUBLE	3-10
BLEEDING, RWAL BRAKE	5-33	BUCKET SEAT BACK FRAME	23-9	CARDAN UNIVERSAL JOINT, SINGLE	3-8
BLENDS, GASOLINE/OXYGENATE	14-1	BUCKET SEAT CUSHION FRAME	23-10	CARGO STORAGE DOOR, FLOOR	23-55
BLOCK, 8W-11 FUSE/FUSE	8-1	BUCKET SEAT CUSHION/COVER	23-9	CARPET, FLOOR	23-54
BLOCK, 8W-12 JUNCTION	8-1	BUCKET SEAT RECLINER	23-10	CASE IDENTIFICATION, TRANSFER	21-235, 21-259
BLOCK, CYLINDER	9-106,9-111,9-41,9-44,9-74, 9-77	BUCKET SEAT TRACK	23-8	CASE, NV231 TRANSFER	21-235,21-239,21-253
BLOCK HEATER	7-33,7-6	BUCKLE, 2ND ROW SEAT BELT	23-51	CASE, NV242 TRANSFER	21-259,21-263,21-282
BLOCK, JUNCTION	8-29,8-4	BUCKLE, 3RD ROW SEAT BELT	23-52	CASE SKID PLATE, TRANSFER	13-6
BLOCK, RELAY AND FUSE	8-4	BUCKLE, FRONT SEAT BELT	23-50	CASE, TRANSFER	21-237,21-261
BLOCKER, STEERING COLUMN OPENING COVER AND KNEE	8-27	BUFFING, AND POLISHING, FINESSE SANDING	23-2	CATALYTIC CONVERTER	11-1,11-3
BODY	23-60	BUILT-IN TEST INDICATOR	8-5	CAUSES OF BURNT FLUID	21-119,21-4
BODY CODE EMBOSS	Intro-2	BULB, 2ND SEAT DOME/READING LAMP	8-10	CAUTIONS, AND WARNINGS, NOTES	8-7
BODY COMPONENT SERVICE	23-15	BULB APPLICATION	8-17	CAUTIONS, SERVICE WARNINGS & CCD BUS (+/-) CIRCUITS-PCM OUTPUTS	5-2 14-32
BODY LUBRICATION	23-17	BULB, CENTER HIGH MOUNTED STOP LAMP (CHMSL)	8-8	CENTER BEARING	3-8
BODY MINIMUM AIR FLOW CHECK PROCEDURE, THROTTLE	14-42	BULB, CLUSTER	8-27	CENTER BEARING ADJUSTMENT	3-14
BODY SIDE MOLDINGS	23-40	BULB, DOME LAMP	8-9	CENTER BEARINGS	3-2
BODY, VALVE	21-148,21-153,21-207,21-215, 21-32,21-36,21-90,21-96	BULB, FOG LAMP	8-7	CENTER HIGH MOUNTED STOP LAMP (CHMSL)	8-12
BODY—3.9/5.2/5.9L ENGINES, THROTTLE	14-35,14-43	BULB, FRONT SIDE MARKER LAMP	8-8	CENTER HIGH MOUNTED STOP LAMP (CHMSL) BULB	8-8
BOOSTER, MASTER CYLINDER/POWER	5-7	BULB, HEADLAMP	8-7	CENTER LINK	19-27
BOOSTER, POWER BRAKE	5-13,5-2	BULB, LICENSE PLATE LAMP	8-9	CENTER SEAT BACK, 2ND ROW	23-13
BOOTS, C/V JOINT	3-17,3-23	BULB, LIFTGATE/CARGO LAMP	8-8	CENTER SEAT BACK COVER, 2ND ROW	23-13
BORES, HONING CYLINDER	9-5	BULB, OVERHEAD CONSOLE READING LAMP	8-10	CENTER SEAT CUSHION, 2ND ROW	23-13
BOX COMPONENTS, GLOVE	8-34	BULB, READING AND COURTESY LAMP	8-7	CENTER SEAT CUSHION COVER, 2ND ROW	23-12
BOX, GLOVE	8-33	BULB SERVICE, LAMP	8-7	CENTER SEAT CUSHION/COVER	23-10
BOX LAMP AND SWITCH, GLOVE	8-32	BULB, TAIL, STOP, TURN SIGNAL AND BACK-UP LAMP	8-8	CENTER SEAT/CONSOLE	23-10
BOX LATCH STRIKER, GLOVE	8-33	BULB, UNDERHOOD LAMP	8-9	CENTER SUPPORT BRACKET, INSTRUMENT PANEL	8-30
B-PILLAR SEAL	23-32	BULBS, PARK AND TURN SIGNAL LAMP	8-8	CENTERING, CLOCKS/SPRING	8-11
B-PILLAR TRIM	23-46	BUMPER FASCIA, FRONT	13-1	CENTRAL TIMER MODULE; CHIME/ BUZZER WARNING SYSTEMS	8-1,8-3
BRACKET, FRONT BUMPER INNER	13-1	BUMPER FASCIA, REAR	13-3	CENTRAL TIMER MODULE; HORN SYSTEMS	8-2
BRACKET, INSTRUMENT PANEL CENTER SUPPORT	8-30	BUMPER, FRONT	13-1	CENTRAL TIMER MODULE; INSTRUMENT PANEL SYSTEMS	8-34,8-4
BRACKET, REARVIEW MIRROR SUPPORT	23-56	BUMPER INNER BRACKET, FRONT	13-1	CENTRAL TIMER MODULE; POWER LOCK SYSTEMS	8-2,8-5
BRAKE BLEEDING	5-10	BUMPER, REAR	13-2	CENTRAL TIMER MODULE; VEHICLE THEFT/SECURITY SYSTEMS	8-2
BRAKE BLEEDING, RWAL	5-33	BUMPERS	13-1	CENTRAL TIMER MODULE; WIPER AND WASHER SYSTEMS	8-3
BRAKE BOOSTER, POWER	5-13,5-2	BURNT FLUID, CAUSES OF	21-119,21-4	CENTRAL TIMER MODULE, 8W-45	8-1
BRAKE CABLE, FRONT PARK	5-18	BUS (+/-) CIRCUITS-PCM OUTPUTS, CCD	14-32	CERTIFICATION LABEL, VEHICLE SAFETY	Intro-1
BRAKE CABLE TENSIONER, PARK	5-26	BUSHING AND SEAL, REAR RETAINER	21-238, 21-262	CHAIN AND TENSIONER, TIMING	9-30
BRAKE CABLES, REAR PARK	5-18	BUSHING, DISTRIBUTOR DRIVE SHAFT	9-27, 9-65	CHAIN COVER, TIMING	9-28,9-62,9-96
BRAKE CALIPER, DISC	5-14,5-21	BUSHING, OVERDRIVE HOUSING	21-152,21-34	CHAIN STRETCH, MEASURING TIMING	9-53, 9-87
BRAKE DRUM	5-9	BUSHINGS, SPRING EYE	2-15	CHAIN STRETCH, TIMING	9-19
BRAKE DRUM MACHINING	5-11	BYPASS HOSE, WATER PUMP	7-26,7-4	CHAIN, TIMING	9-63,9-97
BRAKE FLUID	5-26	CABLE ADJUSTMENT, TRANSMISSION THROTTLE VALVE	21-213,21-94	CHANGE, LUBRICANT	3-29,3-60
BRAKE FLUID CONTAMINATION	5-9	CABLE, FRONT PARK BRAKE	5-18	CHANNELS, FRONT DOOR LOWER GLASS RUN	23-31
BRAKE FLUID LEVEL	5-9	CABLE, GEARSHIFT	21-124,21-147,21-214, 21-29,21-9,21-95	CHANNELS, REAR DOOR GLASS RUN	23-38
BRAKE HOSES AND LINES	5-4	CABLE, HOOD RELEASE	23-20	CHARACTERISTICS, RWAL PERFORMANCE	5-28
BRAKE LINE	5-11	CABLE RESISTANCE, SPARK PLUG	8-19	CHARGING, BATTERY	8-12
BRAKE LINE AND HOSES	5-9	CABLE, SERVO	8-2,8-5	CHARGING SYSTEM	8-2
BRAKE PEDAL	5-12,5-2	CABLE TENSIONER, PARK BRAKE	5-26	CHARGING SYSTEM, 8W-20	8-1
BRAKE PEDAL ASSEMBLY, PARK	5-19	CABLE, THROTTLE	14-21	CHARGING SYSTEM, ON-BOARD DIAGNOSTIC TEST	8-5
BRAKE, REAR DRUM	5-23,5-24	CABLE, THROTTLE VALVE	21-124,21-9	CHARGING SYSTEM OPERATION	8-1
BRAKE RELEASE HANDLE, PARK	8-29	CABLES, REAR PARK BRAKE	5-18		
BRAKE ROTOR, DISC	5-15,5-8	CABLES, SPARK PLUG	8-11,8-2,8-8		
BRAKE SHOES, DISC	5-14	CALIBRATION, COMPASS	8-5		
BRAKE SHOES, REAR	5-16	CALIPER	5-23		
BRAKE SUPPORT PLATE	5-18	CALIPER, DISC BRAKE	5-14,5-21		
BRAKE SWITCH—PCM INPUT	14-28	CAM/OVERDRIVE PISTON RETAINER, OVERRUNNING CLUTCH	21-181,21-61		
BRAKE SYSTEM	5-2	CAMSHAFT	9-31,9-63,9-98		
BRAKE SYSTEM, ANTILOCK	5-36	CAMSHAFT AND CRANKSHAFT POSITION SENSORS	14-40		
BRAKE SYSTEM, BASE	5-1,5-4	CAMSHAFT BEARINGS	9-32,9-65,9-99		
BRAKE SYSTEM, BLEEDING ABS	5-38	CAMSHAFT PLUGS, ENGINE CORE OIL	9-38, 9-71		
BRAKE SYSTEM LAMP, ANTI-LOCK	8-16,8-7				

Description	Group-Page	Description	Group-Page	Description	Group-Page
CHARGING SYSTEM RESISTANCE TESTS	8-3	COIL, TESTING FOR SPARK AT	8-4	CONTROL SOLENOIDS—PCM OUTPUT, SPEED	14-34
CHART, TORQUE; BRAKES	5-27,5-35,5-41	COIL—3.9/5.2/5.9L ENGINES, IGNITION	8-13	CONTROL SWITCHES, SPEED	8-1,8-3,8-5
CHART, TORQUE; CHARGING SYSTEM	8-7	COIL—3.9/5.2/5.9L ENGINES—PCM OUTPUT, IGNITION	14-34	CONTROL SWITCHES—PCM INPUT, SPEED	14-31
CHART, TORQUE; EMISSION CONTROL SYSTEMS	25-20	COLD CRANKING TEST	8-3	CONTROL SYSTEM, 8W-31 TRANSMISSION	8-1
CHART, TORQUE; FUEL SYSTEM	14-22,14-48	COLLAPSIBLE SPACER	3-31	CONTROL SYSTEM, EVAPORATION	25-13
CHART, TORQUE; IGNITION SYSTEM	8-20	COLUMN OPENING COVER AND KNEE BLOCKER, STEERING	8-27	CONTROL SYSTEM, HYDRAULIC	21-122,21-7
CHART, TORQUE; SPEED CONTROL SYSTEM	8-7	COLUMN SHIFT INTERLOCK	8-19	CONTROL SYSTEM, ON-BOARD DIAGNOSTIC TEST FOR SPEED	8-2
CHART, TORQUE; STEERING	19-21,19-25,19-28, 19-9	COLUMN, STEERING	19-22,19-23	CONTROL UNIT, HYDRAULIC	5-37
CHART, TORQUE; SUSPENSION	2-12,2-16	COMBINATION FLASHER	8-1,8-5	CONTROLLER	5-34
CHART, TORQUE; TIRES AND WHEELS	22-9	COMBINATION VALVE	5-13,5-3,5-8	CONTROLLER ANTILOCK BRAKES	5-30,5-37, 5-39
CHARTS—RE TRANSMISSION, DIAGNOSIS TABLES	21-129,21-15	COMBUSTION PRESSURE LEAKAGE TEST, CYLINDER	9-8	CONTROLS, EVAPORATIVE EMISSION	25-13
CHECK, COOLANT LEVEL	7-22	COMPASS	8-2,8-8	CONTROLS, OVERDRIVE ELECTRICAL	21-124, 21-9
CHECK, COOLANT—ROUTINE LEVEL	7-22	COMPASS, AND THERMOMETER DISPLAY MODULE, TRIP COMPUTER	8-3,8-7	CONTROLS—PCM INPUT, AIR CONDITIONING (A/C)	14-27
CHECK, FLUID LEVEL	21-141,21-23	COMPASS CALIBRATION	8-5	CONVERTER, CATALYTIC	11-1,11-3
CHECK GAUGES LAMP	8-17,8-8	COMPASS DEMAGNETIZING	8-5	CONVERTER CLUTCH ENGAGEMENT	21-123, 21-8
CHECK, OIL PUMP VOLUME	21-143,21-25	COMPASS VARIATION ADJUSTMENT	8-4	CONVERTER DRAINBACK CHECK VALVE SERVICE	21-142,21-25
CHECK PROCEDURE, THROTTLE BODY MINIMUM AIR FLOW	14-42	COMPONENTS—IN VEHICLE SERVICE, CYLINDER HEAD	9-24	CONVERTER DRAINBACK VALVE	21-123,21-8
CHECK, RADIATOR CAP-TO-FILLER NECK SEAL—PRESSURE RELIEF	7-20	COMPRESSION PRESSURE TEST, CYLINDER	9-7	CONVERTER, ELECTRONIC LOCK-UP TORQUE	21-120,21-5
CHECK, RADIATOR COOLANT FLOW	7-16	COMPUTER, COMPASS, AND THERMOMETER DISPLAY MODULE, TRIP	8-3,8-7	CONVERTER HOUSING FLUID LEAK DIAGNOSIS	21-129,21-14
CHECK VALVE SERVICE, CONVERTER DRAINBACK	21-142,21-25	COMPUTER, TRIP	8-1	CONVERTER STALL TEST	21-127,21-13
CHECKS, PRELIMINARY	7-9	CONDITIONING (A/C) CLUTCH RELAY—PCM OUTPUT, AIR	14-32	CONVERTER, TORQUE	21-146,21-28
CHIME WARNING SYSTEM	8-1	CONDITIONING (A/C) CONTROLS—PCM INPUT, AIR	14-27	CONVERTOR CLUTCH (TCC) SOLENOID—PCM OUTPUT, TORQUE	14-34
CHIME WARNING SYSTEM SWITCHES	8-5	CONDITIONING/HEATER, 8W-42 AIR	8-1	COOLANT	7-2
CIGAR LIGHTER	8-17,8-8	CONDITIONS, SPARK PLUG	8-9	COOLANT FLOW CHECK, RADIATOR	7-16
CIGAR LIGHTER AND POWER OUTLET	8-32	CONNECTING ROD ASSEMBLY, PISTON	9-101, 9-109,9-15,9-34,9-50,9-67,9-75,9-84	COOLANT LEVEL CHECK	7-22
CIRCUIT ACTUATION TEST MODE	25-2	CONNECTING ROD BEARINGS	9-20	COOLANT PERFORMANCE	7-6
CIRCUIT BREAKER	8-2,8-3	CONNECTING ROD BEARINGS, FITTING	9-55, 9-89	COOLANT RESERVE/OVERFLOW SYSTEM	7-2
CIRCUIT FUNCTIONS	8-4	CONNECTING ROD INSPECTION, PISTON	9-41	COOLANT RESERVE/OVERFLOW TANK	7-24
CIRCUIT INFORMATION	8-4	CONNECTIONS, INTERMITTENT AND POOR	8-8	COOLANT SELECTION AND ADDITIVES	7-7
CIRCUIT SENSE—PCM INPUT, IGNITION	14-29	CONNECTOR AND TERMINAL REPLACEMENT	8-12	COOLANT SERVICE	7-22
CIRCUIT TEST, CONTROL	8-5	CONNECTOR INFORMATION	8-7	COOLANT TEMPERATURE GAUGE	8-14,8-5
CIRCUIT TEST, FEED	8-4	CONNECTOR LOCATIONS, 8W-90	8-1	COOLANT TEMPERATURE SENSOR, ENGINE	8-14,8-4,8-8
CIRCUITS, NON-MONITORED	25-11	CONNECTOR PIN-OUTS, 8W-80	8-1	COOLANT TEMPERATURE SENSOR—3.9/ 5.2/5.9L ENGINE, ENGINE	14-40
CIRCUITS, SPEED CONTROL SOLENOID	8-1	CONNECTOR REPLACEMENT	8-11	COOLANT TEMPERATURE SENSOR—3.9/ 5.2/5.9L ENGINES, ENGINE	14-47
CIRCUITS-PCM OUTPUTS, CCD BUS (+/-)	14-32	CONNECTOR/GROUND LOCATIONS	8-1	COOLANT TEMPERATURE SENSOR—3.9/ 5.2/5.9L ENGINES—PCM INPUT, ENGINE	14-29
CIRCULATION, COOLING SYSTEM	7-2	CONNECTOR—PCM INPUT AND OUTPUT, DATA LINK	14-32	COOLANT—ADDING ADDITIONAL	7-22
CLAMPS, COOLING SYSTEM HOSES	7-7	CONNECTORS, TERMINAL/CONNECTOR REPAIR—MOLEX	8-11	COOLANT—LOW LEVEL AERATION	7-21
CLAMPS, FUEL TUBES/LINES/HOSES	14-11	CONNECTORS, TERMINAL/CONNECTOR REPAIR—THOMAS AND BETTS	8-11	COOLANT—ROUTINE LEVEL CHECK	7-22
CLASSIFICATION OF LUBRICANTS	0-1	CONSOLE, 8W-49 OVERHEAD	8-1	COOLER, AUTOMATIC TRANSMISSION OIL	7-5
CLEANER ELEMENT (FILTER), AIR	14-47	CONSOLE, FLOOR	23-54	COOLER, AUXILIARY OIL-TO-AIR	7-5
CLEANING TIRES	22-6	CONSOLE, OVERHEAD	8-1,8-6	COOLERS AND TUBES, FLUSHING	21-143,21-25
CLEANUP PROCEDURE	8-4	CONSOLE READING LAMP BULB, OVERHEAD	8-10	COOLING	7-37
CLEARANCE, SIDE GEAR	3-87	CONSOLE READING LAMP, OVERHEAD	8-15	COOLING SYSTEM	7-1,7-10,7-37
CLOCKSPRING	8-3,8-9	CONTACT PATTERN ANALYSIS, GEAR	3-47,3-85	COOLING SYSTEM CAPACITIES	7-37
CLOCKSPRING CENTERING	8-11	CONTAMINATION, BRAKE FLUID	5-9	COOLING SYSTEM CIRCULATION	7-2
CLUNKING NOISE DURING ACCELERATION	3-16	CONTAMINATION, FLUID	21-119,21-4	COOLING SYSTEM COMPONENTS	7-2
CLUSTER, 8W-40 INSTRUMENT	8-1	CONTROL, 8W-33 VEHICLE SPEED	8-1	COOLING SYSTEM HOSES AND CLAMPS	7-7
CLUSTER BEZEL	8-24	CONTROL AND DISPLAY SYMBOLS, INTERNATIONAL VEHICLE	Intro-3	COOLING SYSTEM—CLEANING/REVERSE FLUSHING	7-23
CLUSTER BULB	8-27	CONTROL ASSEMBLY, ANTILOCK	5-39	COOLING SYSTEM—DEAERATION	7-21
CLUSTER COMPONENTS	8-26	CONTROL CIRCUIT TEST	8-5	COOLING SYSTEM—DRAINING AND FILLING	7-22
CLUSTER ILLUMINATION LAMP	8-18,8-8	CONTROL (IAC) MOTOR—3.9/5.2/5.9L ENGINES, IDLE AIR	14-41,14-44	COOLING SYSTEM—TESTING FOR LEAKS	7-16
CLUSTER, INSTRUMENT; CHIME/BUZZER WARNING SYSTEMS	8-2,8-5	CONTROL (IAC) MOTOR—3.9/5.2/5.9L ENGINES—PCM OUTPUT, IDLE AIR	14-33	CORE OIL AND CAMSHAFT PLUGS, ENGINE	9-38,9-71
CLUSTER, INSTRUMENT; INSTRUMENT PANEL SYSTEMS	8-12,8-2,8-26	CONTROL INFORMATION (VEC) LABEL, VEHICLE EMISSION	25-16	CORE PLUGS, ENGINE	9-105
CLUTCH AND BAND OPERATION, AIR TESTING TRANSMISSION	21-128,21-14	CONTROL MODULE, AIRBAG	8-3,8-8	COURTESY LAMP BULB, READING	8-7
CLUTCH CAM/OVERDRIVE PISTON RETAINER, OVERRUNNING	21-181,21-61	CONTROL MODULE (PCM), POWERTRAIN; FUEL SYSTEM	14-26,14-46	COURTESY LAMP, READING	8-2,8-7
CLUTCH ENGAGEMENT, CONVERTER	21-123, 21-8	CONTROL MODULE (PCM), POWERTRAIN; IGNITION SYSTEM	8-16	COVER, 2ND ROW CENTER SEAT BACK	23-13
CLUTCH, FRONT	21-186,21-211,21-66,21-92	CONTROL MODULE, POWERTRAIN; IGNITION SYSTEM	8-2	COVER, 2ND ROW CENTER SEAT CUSHION	23-12
CLUTCH, REAR	21-188,21-212,21-68,21-92	CONTROL MODULE, POWERTRAIN; SPEED CONTROL SYSTEM	8-2	COVER, 2ND ROW SEAT BACK	23-11
CLUTCH RELAY—PCM OUTPUT, AIR CONDITIONING (A/C)	14-32	CONTROL SERVO, SPEED	8-1,8-3,8-4	COVER, 2ND ROW SEAT CUSHION	23-11
CLUTCH (TCC) SOLENOID—PCM OUTPUT, TORQUE CONVERTER	14-34	CONTROL SET, OVERSHOOT/ UNDERSHOOT FOLLOWING SPEED	8-4	COVER, 3RD ROW SEAT BACK	23-14
CLUTCH/LOW-REVERSE DRUM/ OVERDRIVE PISTON RETAINER, OVERRUNNING	21-210,21-91	CONTROL SOLENOID CIRCUITS, SPEED	8-1	COVER, 3RD ROW SEAT CUSHION	23-13
C—PILLAR SEAL	23-38			COVER AND HORN SWITCH, DRIVER SIDE AIRBAG TRIM	8-7
COAT FINISH, BASE COAT/CLEAR	23-2			COVER AND KNEE BLOCKER, STEERING COLUMN OPENING	8-27
COAT HOOK	23-57				
COAT/CLEAR COAT FINISH, BASE	23-2				
CODE EMBOSS, BODY	Intro-2				
CODE, PAINT	23-2				
CODES, DIAGNOSTIC TROUBLE	25-2				
COIL, IGNITION	8-3				
COIL RESISTANCE, IGNITION	8-20				
COIL TEST, IGNITION	8-5				

Description	Group-Page	Description	Group-Page	Description	Group-Page
COVER, COWL TRIM	23-45	CYLINDER SWITCH, LIFTGATE LOCK	8-3,8-5	DISTRIBUTOR	8-2
COVER, CYLINDER HEAD	9-24,9-41,9-59,9-75,9-93	CYLINDER, WHEEL	5-17,5-23,5-24	DISTRIBUTOR CAP	8-6
COVER, INSTRUMENT PANEL TOP	8-38	CYLINDER/POWER BOOSTER, MASTER	5-7	DISTRIBUTOR DRIVE SHAFT BUSHING	9-27,9-65
COVER, TIMING CHAIN	9-28,9-62,9-96	DAMAGED OR WORN THREADS, REPAIR	9-5	DISTRIBUTOR ROTOR	8-7
COVER/CUSHION, BUCKET SEAT BACK	23-9	DAMPER, VIBRATION	9-28,9-61,9-95	DISTRIBUTORS—3.9/5.2/5.9L ENGINES	8-14
COWL GRILLE	23-21	DATA LINK CONNECTOR—PCM INPUT AND OUTPUT	14-32	DOME LAMP	8-14
COWL SEAL	23-21	DAY/NIGHT MIRROR, AUTOMATIC	8-4,8-5	DOME LAMP BULB	8-9
COWL TRIM COVER	23-45	DAY/NIGHT MIRROR SYSTEM, AUTOMATIC	8-4	DOME/READING LAMP, 2ND SEAT	8-14
C-PILLAR TRIM	23-47	DAYTIME RUNNING LAMP MODULE (DRLM)	8-1,8-16	DOME/READING LAMP BULB, 2ND SEAT	8-10
CRANKCASE VENTILATION (PCV) SYSTEM, POSITIVE	25-15	DECAL	23-24	DOOR	23-58
CRANKING TEST, COLD	8-3	DEFINITION, TRIP	25-10	DOOR AJAR LAMP	8-19,8-9
CRANKSHAFT	9-101,9-21,9-34,9-55,9-68	DEFOGGER, 8W-48 REAR WINDOW	8-1	DOOR AJAR SWITCH	8-3,8-4
CRANKSHAFT FRONT OIL SEAL	9-35	DEFOGGER SWITCH	8-1,8-3,8-4	DOOR AJAR SWITCH, DRIVER	8-2,8-3
CRANKSHAFT JOURNAL INSPECTION	9-41,9-75	DEFOGGER SYSTEM	8-2	DOOR, FLOOR CARGO STORAGE	23-55
CRANKSHAFT MAIN BEARINGS	9-100,9-21,9-32,9-55,9-65	DEFOGGER SYSTEM, REAR WINDOW	8-1	DOOR, FRONT	23-27
CRANKSHAFT MAIN BEARINGS, FITTING	9-89	DELIVERY SYSTEM, FUEL	14-3	DOOR, FUEL FILLER	23-41
CRANKSHAFT OIL SEAL—FRONT	9-103,9-69	DEMAGNETIZING, COMPASS	8-5	DOOR, GARAGE DOOR OPENER STORAGE BIN	8-8
CRANKSHAFT OIL SEALS—REAR	9-69	DEPTH, 8 1/4 AXLE PINION GEAR	3-80	DOOR GLASS, FRONT	23-30
CRANKSHAFT POSITION SENSOR; FUEL SYSTEM	14-46	DEPTH, 9 1/4 AXLE PINION GEAR	3-82	DOOR GLASS, REAR	23-38
CRANKSHAFT POSITION SENSOR; IGNITION SYSTEM	8-7	DEPTH, PINION GEAR	3-42	DOOR GLASS RUN CHANNELS, REAR	23-38
CRANKSHAFT POSITION SENSOR—3.9/5.2/5.9L ENGINES	8-13	DESCRIPTION, ENGINE	9-16	DOOR GLASS RUN WEATHERSTRIP, FRONT	23-32
CRANKSHAFT POSITION SENSOR—3.9/5.2/5.9L ENGINES—PCM INPUT	14-28	DESCRIPTION, SYSTEM	25-1	DOOR GLASS RUN WEATHERSTRIP, REAR	23-37
CRANKSHAFT POSITION SENSOR—3.9L V-6 ENGINE	8-3	DETECTION PUMP (LDP), LEAK DEVICES, ELECTROSTATIC DISCHARGE (ESD) SENSITIVE	9-84,25-14,25-17,25-18,8-8	DOOR HINGE, FRONT	23-28
CRANKSHAFT POSITION SENSOR—5.2/5.9L V-8 ENGINE	8-3	DIAGNOSIS, ACCESSORY DRIVE BELT	7-18	DOOR HINGE, REAR	23-34
CRANKSHAFT POSITION SENSORS, CAMSHAFT	14-40	DIAGNOSIS, AUTOMATIC TRANSMISSION	21-123,21-8	DOOR INNER BELT WEATHERSTRIP, FRONT	23-30
CRANKSHAFT REAR OIL SEALS	9-103,9-36	DIAGNOSIS, CONVERTER HOUSING FLUID LEAK	21-129,21-14	DOOR INNER BELT WEATHERSTRIP, REAR	23-36
CRANKSHAFT SERVICE	9-90	DIAGNOSIS, ENGINE	9-7	DOOR INSIDE HANDLE ACTUATOR, FRONT	23-30
CRUISE-ON INDICATOR LAMP	8-18,8-9	DIAGNOSIS, ENGINE CYLINDER HEAD GASKET FAILURE	9-7	DOOR INSIDE HANDLE ACTUATOR, REAR	23-36
CURRENT OUTPUT TEST	8-4	DIAGNOSIS, ENGINE PERFORMANCE/MECHANICAL	9-11	DOOR LATCH ADJUSTMENT	23-59
CURVES, GOVERNOR PRESSURE	21-121,21-6	DIAGNOSIS, INTAKE MANIFOLD LEAKAGE	9-7	DOOR LATCH, FRONT	23-29
CUSHION, 2ND ROW CENTER SEAT	23-13	DIAGNOSIS, LAMP	8-1	DOOR LATCH, REAR	23-35
CUSHION, 2ND ROW SEAT	23-11	DIAGNOSIS, NV231	21-236	DOOR LATCH STRIKER, FRONT	23-30
CUSHION COVER, 2ND ROW CENTER SEAT	23-12	DIAGNOSIS, NV242	21-260	DOOR LATCH STRIKER, REAR	23-35
CUSHION COVER, 2ND ROW SEAT	23-11	DIAGNOSIS, POWER STEERING GEAR LEAKAGE	19-12	DOOR LOCK CYLINDER, FRONT	23-29
CUSHION COVER, 3RD ROW SEAT	23-13	DIAGNOSIS, PRELIMINARY	21-123,21-8	DOOR LOCK CYLINDER SWITCH	8-3,8-4
CUSHION FRAME, 3RD ROW SEAT	23-14	DIAGNOSIS, SHOCK	2-6	DOOR LOCKS, 8W-61 POWER	8-1
CUSHION FRAME, BUCKET SEAT	23-10	DIAGNOSIS, SPRING AND SHOCK	2-13	DOOR LOWER GLASS RUN CHANNELS, FRONT	23-31
CUSHION/COVER, BUCKET SEAT	23-9	DIAGNOSIS, SYSTEM	8-1	DOOR OPENER STORAGE BIN DOOR, GARAGE	8-8
CUSHION/COVER, CENTER SEAT	23-10	DIAGNOSIS TABLES AND CHARTS—RE TRANSMISSION	21-129,21-15	DOOR OPENER STORAGE BIN, GARAGE	8-2
C/V JOINT	3-22	DIAGNOSTIC TEST FOR CHARGING SYSTEM, ON-BOARD	8-5	DOOR OPENING WEATHERSTRIP, FRONT	23-32
C/V JOINT BOOTS	3-17,3-23	DIAGNOSTIC TEST FOR SPEED CONTROL SYSTEM, ON-BOARD	8-2	DOOR OPENING WEATHERSTRIP, REAR	23-36
C/V JOINT DRIVESHAFT	3-23	DIAGNOSTIC TROUBLE CODES	25-2	DOOR OUTER BELT WEATHERSTRIP, FRONT	23-30
C/V JOINT, INNER	3-18	DIAGNOSTICS (OBD), ON-BOARD	7-9	DOOR OUTER BELT WEATHERSTRIP, REAR	23-36
C/V JOINT, OUTER	3-19	DIAGNOSTICS, ON-BOARD	25-1	DOOR OUTSIDE HANDLE, FRONT	23-28
CYCLE EVAP CANISTER PURGE SOLENOID, DUTY; EMISSION CONTROL SYSTEMS	25-14,25-18	DIFFERENTIAL	3-34,3-64	DOOR OUTSIDE HANDLE, REAR	23-35
CYCLE EVAP CANISTER PURGE SOLENOID, DUTY; FUEL SYSTEM	14-46	DIFFERENTIAL, 8 1/4 TRAC-LOK	3-72	DOOR, PASSENGER SIDE AIRBAG	8-8
CYCLE EVAP PURGE SOLENOID VALVE-PCM OUTPUT, DUTY	14-33	DIFFERENTIAL, 9 1/4 TRAC-LOK	3-76	DOOR, REAR	23-34
CYLINDER BLEEDING, MASTER	5-9	DIFFERENTIAL BEARING PRELOAD AND GEAR BACKLASH	3-44,3-84	DOOR SECONDARY SEAL, FRONT	23-32
CYLINDER BLOCK	9-106,9-111,9-41,9-44,9-74,9-77	DIFFERENTIAL NOISE, TRAC-LOK	3-57	DOOR SECONDARY SEAL, REAR	23-38
CYLINDER BORES, HONING	9-5	DIFFERENTIAL SIDE BEARINGS	3-36,3-65	DOOR SILL TRIM	23-46
CYLINDER COMBUSTION PRESSURE LEAKAGE TEST	9-8	DIFFERENTIAL, STANDARD	3-25,3-41,3-55,3-71	DOOR STATIONARY GLASS, REAR	23-6
CYLINDER COMPRESSION PRESSURE TEST	9-7	DIMENSIONS, VEHICLE; FRAME AND BUMPERS	13-8	DOOR, SUNGLASSES STORAGE BIN	8-8
CYLINDER, FRONT DOOR LOCK	23-29	DIMENSIONS, VEHICLE; INTRODUCTION	Intro-2	DOOR TRIM PANEL, FRONT	23-26
CYLINDER HEAD	9-41,9-60,9-94	DIODE REPLACEMENT	8-14	DOOR TRIM PANEL, REAR	23-33
CYLINDER HEAD ASSEMBLY	9-109	DISARMING	8-2	DOOR WATERDAM, FRONT	23-27
CYLINDER HEAD COMPONENTS—IN VEHICLE SERVICE	9-24	DISC BRAKE CALIPER	5-14,5-21	DOOR WATERDAM, REAR	23-34
CYLINDER HEAD COVER	9-24,9-41,9-59,9-75,9-93	DISC BRAKE ROTOR	5-15,5-8	DOOR WINDOW REGULATOR, FRONT	23-31
CYLINDER HEAD GASKET FAILURE DIAGNOSIS, ENGINE	9-7	DISC BRAKE SHOES	5-14	DOOR WINDOW REGULATOR, REAR	23-37
CYLINDER HEADS	9-25,9-75	DISC BRAKES, FRONT	5-3	DOUBLE CARDAN JOINT	3-10
CYLINDER, IGNITION SWITCH AND KEY	8-16	DISC ROTOR MACHINING	5-11	D-PILLAR TRIM	23-48
CYLINDER, IGNITION SWITCH AND KEY LOCK	8-4	DISCHARGE (ESD) SENSITIVE DEVICES, ELECTROSTATIC	8-8	DRAINBACK CHECK VALVE SERVICE, CONVERTER	21-142,21-25
CYLINDER, LIFTGATE LOCK	23-44	DISPLAY MODULE, TRIP COMPUTER, COMPASS, AND THERMOMETER	8-3,8-7	DRAINBACK VALVE, CONVERTER	21-123,21-8
CYLINDER, LIFTGATE SUPPORT	23-42	DISPLAY SYMBOLS, INTERNATIONAL VEHICLE CONTROL	Intro-3	DRAINCOCK, RADIATOR	7-35
CYLINDER, MASTER	5-13,5-3	DISPLAY TEST MODE, STATE	25-2	DRAW FUSE, IGNITION-OFF	8-1
CYLINDER RESERVOIR, MASTER	5-20	DISTANCE—PCM INPUT, VEHICLE SPEED	14-32	DRAW TEST, IGNITION-OFF	8-10
CYLINDER SWITCH, DOOR LOCK	8-3,8-4	DISTRIBUTION, 8W-10 POWER	8-2	DRB SCAN TOOL	7-9
		DISTRIBUTION, 8W-15 GROUND	8-1	DRIVE BELT, ACCESSORY	7-33
				DRIVE BELT DIAGNOSIS, ACCESSORY	7-18
				DRIVE BELT TENSION, ACCESSORY	7-4
				DRIVE BELT, TENSIONER (AUTO)—ACCESSORY	7-6
				DRIVE INDICATOR LAMP, FOUR-WHEEL	8-19,8-9
				DRIVE SHAFT BUSHING, DISTRIBUTOR	9-27,9-65
				DRIVE, VISCOUS FAN	7-18

Description	Group-Page	Description	Group-Page	Description	Group-Page
DRIVELINE ANGLE MEASUREMENT		ENGINE MOUNTS—FRONT	9-56,9-90	EXHAUST PIPE	11-3
PREPARATION	3-5	ENGINE OIL	9-3	EXHAUST SYSTEM	11-11,11-2
DRIVELINE SNAP	3-26,3-57	ENGINE OIL LEAK INSPECTION	9-8	EXTERIOR LAMPS	8-17
DRIVER DOOR AJAR SWITCH	8-2,8-3	ENGINE OIL PRESSURE	9-10	EXTERIOR MIRRORS	8-1
DRIVER (-)—PCM OUTPUT, GENERATOR		ENGINE, PCV VALVE TEST—3.9/5.2/5.9L	25-16	EXTERIOR NAMEPLATES	23-24
FIELD	14-33	ENGINE PERFORMANCE	9-2	EYE BUSHINGS, SPRING	2-15
DRIVER SEAT BELT SWITCH	8-2,8-5	ENGINE PERFORMANCE/MECHANICAL		FAILURE DIAGNOSIS, ENGINE CYLINDER	
DRIVER SIDE AIRBAG TRIM COVER AND		DIAGNOSIS	9-11	HEAD GASKET	9-7
HORN SWITCH	8-7	ENGINE SPECIFICATIONS, 3.9L	9-44	FAILURE TO START TEST	8-5
DRIVER UNLOCK RELAY	8-4,8-8	ENGINE SPECIFICATIONS, 5.2L	9-78	FAN BLADE	7-36
DRIVESHAFT, C/V JOINT	3-23	ENGINE SPECIFICATIONS, 5.9L	9-112	FAN DRIVE, VISCOUS	7-18
DRIVESHAFT, FRONT	3-16	ENGINE, THROTTLE POSITION SENSOR		FAN/DRIVE, VISCOUS	7-35,7-8
DRIVESHAFTS, FRONT AXLE	3-15	(TPS)—3.9/5.2/5.9L	14-41	FASCIA, FRONT BUMPER	13-1
DROP TEST, VOLTAGE	8-11	ENGINE—PCM INPUT, THROTTLE		FASCIA, REAR BUMPER	13-3
DRUM, BRAKE	5-9	POSITION SENSOR (TPS)—3.9/5.2/		FASTENER IDENTIFICATION	Intro-3
DRUM BRAKE, REAR	5-23,5-24	5.9L	14-31	FASTENER USAGE	Intro-6
DRUM BRAKES	5-4	ENGINES, CRANKSHAFT POSITION		FEED CIRCUIT TEST	8-4
DRUM MACHINING, BRAKE	5-11	SENSOR—3.9/5.2/5.9L	8-13	FENDER, LEFT FRONT	23-22
DRUM/OVERDRIVE PISTON RETAINER,		ENGINES, DISTRIBUTORS—3.9/5.2/5.9L	8-14	FENDER, RIGHT FRONT	23-23
OVERRUNNING CLUTCH/LOW-		ENGINES, ENGINE COOLANT		FIA AXLE, 194	3-24,3-49
REVERSE	21-210,21-91	TEMPERATURE SENSOR—3.9/5.2/5.9L	14-47	FIELD DRIVER (-)—PCM OUTPUT,	
DUTY CYCLE EVAP CANISTER PURGE		ENGINES, ENGINE FIRING ORDER—5.2L/		GENERATOR	14-33
SOLENOID; EMISSION CONTROL		5.9L V-8	8-19	FIELD SOURCE (+)—PCM OUTPUT,	
SYSTEMS	25-14,25-18	ENGINES, FUEL INJECTOR RAIL—3.9/		GENERATOR	14-33
DUTY CYCLE EVAP CANISTER PURGE		5.2/5.9L	14-17	FILL LEVEL, RECOMMENDED	
SOLENOID; FUEL SYSTEM	14-46	ENGINES, FUEL RAIL—3.9/5.2/5.9L	14-6	LUBRICANT	21-235,21-260
DUTY CYCLE EVAP PURGE SOLENOID		ENGINES, IDLE AIR CONTROL (IAC)		FILL PROCEDURE, TRANSMISSION	21-142,
VALVE-PCM OUTPUT	14-33	MOTOR—3.9/5.2/5.9L	14-41,14-44	21-24	
EFFECTS OF INCORRECT FLUID LEVEL	21-119,	ENGINES, IGNITION COIL—3.9/5.2/5.9L	8-13	FILL VALVE, QUICK	21-123,21-8
21-4		ENGINES, INTAKE MANIFOLD AIR		FILLER DOOR, FUEL	23-41
ELECTRICAL CONTROLS, OVERDRIVE	21-124,	TEMPERATURE SENSOR—3.9/5.2/5.9L	14-47	FILLER TUBE CAP, FUEL TANK	14-21,14-6
21-9		ENGINES, MANIFOLD ABSOLUTE		FILLING, COOLING SYSTEM—DRAINING	7-22
ELECTRONIC GOVERNOR	21-120,21-5	PRESSURE (MAP) SENSOR TEST—3.9/		FILTER, FUEL PUMP INLET	14-16
ELECTRONIC LOCK-UP TORQUE		5.2/5.9L	14-39	FILTER REPLACEMENT, FLUID	21-141,21-24
CONVERTER	21-120,21-5	ENGINES, MANIFOLD ABSOLUTE		FILTER/FUEL PRESSURE REGULATOR,	
ELECTRONIC VOLTAGE REGULATOR	8-2	PRESSURE (MAP) SENSOR—3.9/5.2/		FUEL	14-15,14-4
ELECTROSTATIC DISCHARGE (ESD)		5.9L	14-45	FINAL ASSEMBLY	3-40,3-71
SENSITIVE DEVICES	8-8	ENGINES, THERMOSTAT—GAS	7-20	FINESSE SANDING, BUFFING, AND	
ELEMENT (FILTER), AIR CLEANER	14-47	ENGINES, THROTTLE BODY—3.9/5.2/		POLISHING	23-2
EMBOSS, BODY CODE	Intro-2	5.9L	14-35,14-43	FINISH, BASE COAT/CLEAR COAT	23-2
EMISSION CONTROL INFORMATION		ENGINES, THROTTLE POSITION SENSOR		FIRING ORDER—3.9L V-6 ENGINE,	
(VECI) LABEL, VEHICLE	25-16	(TPS)—3.9/5.2/5.9L	14-44	ENGINE	8-19
EMISSION CONTROLS, EVAPORATIVE	25-13	ENGINES, VISUAL INSPECTION—3.9/5.2/		FIRING ORDER—5.2L/5.9L V-8 ENGINES,	
ENABLING	8-1	5.9L	14-35	ENGINE	8-19
END, INNER TIE ROD	19-27	ENGINES WITH PRESSURE TEST PORT,		FITTING CONNECTING ROD BEARINGS	9-55,
END PLUG, HOUSING	19-13	FUEL PUMP PRESSURE TEST—ALL	14-6	9-89	
END, TIE ROD	19-26	ENGINES—PCM INPUT, CRANKSHAFT		FITTING CRANKSHAFT MAIN BEARINGS	9-89
ENGAGEMENT, CONVERTER CLUTCH	21-123,	POSITION SENSOR—3.9/5.2/5.9L	14-28	FITTING PISTON RINGS	9-54,9-88
21-8		ENGINES—PCM INPUT, ENGINE		FITTING PISTONS	9-19,9-54,9-88
ENGINE, 3.9L	9-15,9-48	COOLANT TEMPERATURE SENSOR—		FITTING RINGS	9-19
ENGINE, 5.2L	9-50	3.9/5.2/5.9L	14-29	FITTINGS, QUICK-CONNECT	14-11,14-6
ENGINE, 5.9L	9-116,9-82,9-84	ENGINES—PCM INPUT, INTAKE		FIVE VOLT SENSOR SUPPLY—PRIMARY	14-29
ENGINE ASSEMBLY	9-23,9-58,9-92	MANIFOLD AIR TEMPERATURE		FIVE VOLT SENSOR SUPPLY—	
ENGINE COMPONENTS	9-18,9-53,9-87	SENSOR—3.9/5.2/5.9L	14-29	SECONDARY	14-29
ENGINE COOLANT TEMPERATURE		ENGINES—PCM INPUT, MANIFOLD		FLASHER, COMBINATION	8-1,8-5
SENSOR	8-14,8-4,8-8	ABSOLUTE PRESSURE (MAP)		FLOOR CARGO STORAGE DOOR	23-55
ENGINE COOLANT TEMPERATURE		SENSOR—3.9/5.2/5.9L	14-29	FLOOR CARPET	23-54
SENSOR—3.9/5.2/5.9L ENGINE	14-40	ENGINES—PCM OUTPUT, FUEL		FLOOR CONSOLE	23-54
ENGINE COOLANT TEMPERATURE		INJECTORS—3.9/5.2/5.9L	14-33	FLOW CHECK PROCEDURE, THROTTLE	
SENSOR—3.9/5.2/5.9L ENGINES	14-47	ENGINES—PCM OUTPUT, IDLE AIR		BODY MINIMUM AIR	14-42
ENGINE COOLANT TEMPERATURE		CONTROL (IAC) MOTOR—3.9/5.2/5.9L	14-33	FLOW CHECK, RADIATOR COOLANT	7-16
SENSOR—3.9/5.2/5.9L ENGINES—PCM		ENGINES—PCM OUTPUT, IGNITION		FLOW RATE AND PRESSURE, PUMP	19-4
INPUT	14-29	COIL—3.9/5.2/5.9L	14-34	FLUID AND FILTER REPLACEMENT	21-141,21-24
ENGINE CORE OIL AND CAMSHAFT		ENTRY RECEIVER, REMOTE KEYLESS	8-3	FLUID, BRAKE	5-26
PLUGS	9-38,9-71	ENTRY SYSTEM, POWER LOCK SYSTEM		FLUID CAPACITIES	0-2
ENGINE CORE PLUGS	9-105	AND REMOTE KEYLESS	8-4	FLUID, CAUSES OF BURNT	21-119,21-4
ENGINE, CRANKSHAFT POSITION		ENTRY SYSTEM, REMOTE KEYLESS	8-1	FLUID CONTAMINATION	21-119,21-4
SENSOR—3.9L V-6	8-3	ENTRY TRANSMITTER BATTERY		FLUID CONTAMINATION, BRAKE	5-9
ENGINE, CRANKSHAFT POSITION		REPLACEMENT, REMOTE KEYLESS	8-7	FLUID LEAK DIAGNOSIS, CONVERTER	
SENSOR—5.2/5.9L V-8	8-3	ENTRY TRANSMITTER PROGRAMMING,		HOUSING	21-129,21-14
ENGINE CYLINDER HEAD GASKET		REMOTE KEYLESS	8-7	FLUID LEVEL, BRAKE	5-9
FAILURE DIAGNOSIS	9-7	ENTRY TRANSMITTER, REMOTE		FLUID LEVEL CHECK	21-141,21-23
ENGINE DESCRIPTION	9-16	KEYLESS	8-3,8-6	FLUID LEVEL, EFFECTS OF INCORRECT	21-119,
ENGINE DESCRIPTION/IDENTIFICATION	9-84	EVAP CANISTER PURGE SOLENOID,		21-4	
ENGINE DIAGNOSIS	9-7	DUTY CYCLE; EMISSION CONTROL		FLUID LEVEL SENSOR, WASHER	8-5
ENGINE, ENGINE COOLANT		SYSTEMS	25-14,25-18	FLUID, RECOMMENDED	21-119,21-4
TEMPERATURE SENSOR—3.9/5.2/5.9L	14-40	EVAP CANISTER PURGE SOLENOID,		FLUID WARNING LAMP, LOW WASHER	8-10,
ENGINE, ENGINE FIRING ORDER—3.9L		DUTY CYCLE; FUEL SYSTEM	14-46	8-21	
V-6	8-19	EVAP PURGE SOLENOID VALVE-PCM		FLUSHING COOLERS AND TUBES	21-143,21-25
ENGINE FIRING ORDER—3.9L V-6		OUTPUT, DUTY CYCLE	14-33	FLUSHING, COOLING SYSTEM—	
ENGINE	8-19	EVAPORATION CONTROL SYSTEM	25-13	CLEANING/REVERSE	7-23
ENGINE FIRING ORDER—5.2L/5.9L V-8		EVAPORATION (EVAP) CANISTER	25-13,25-17	FOG LAMP	8-11
ENGINES	8-19	EVAPORATIVE EMISSION CONTROLS	25-13	FOG LAMP ALIGNMENT	8-5
ENGINE, INTAKE MANIFOLD AIR		EXCITER RING	5-35,5-41	FOG LAMP BULB	8-7
TEMPERATURE SENSOR—3.9/5.2/5.9L	14-41	EXCITER RING, REAR WHEEL SPEED		FOG LAMP SWITCH	8-25
ENGINE LUBRICATION SYSTEM	9-16	SENSOR	5-31	FOLLOWING SPEED CONTROL SET,	
ENGINE MOUNT—REAR	9-22,9-57,9-91	EXCITER RING, RING GEAR	3-66	OVERSHOOT/UNDERSHOOT	8-4
ENGINE MOUNTS—FRONT	9-21	EXHAUST MANIFOLD	11-11,11-2,11-9	FORM-IN-PLACE GASKETS	9-1

Description	Group-Page	Description	Group-Page	Description	Group-Page
FOUR WHEEL ANTILOCK BRAKES	5-36	FUEL SYSTEM PRESSURE	14-22	GOVERNOR, ELECTRONIC	21-120,21-5
FOUR-WHEEL DRIVE INDICATOR LAMP	8-19,8-9	FUEL SYSTEM PRESSURE RELEASE		GOVERNOR PRESSURE CURVES	21-121,21-6
FOUR-WHEEL-DRIVE VEHICLE TOWING	0-9	PROCEDURE	14-10	GOVERNOR PRESSURE SENSOR—PCM	
FRAME	13-4	FUEL TANK	14-19,14-5	INPUT, TRANSMISSION	14-31
FRAME, 3RD ROW SEAT CUSHION	23-14	FUEL TANK CAPACITY	14-22	GOVERNOR PRESSURE SOLENOID—	
FRAME, BUCKET SEAT BACK	23-9	FUEL TANK FILLER TUBE CAP	14-21,14-6	PCM OUTPUT	14-35
FRAME, BUCKET SEAT CUSHION	23-10	FUEL TANK SKID PLATE—4WD		GOVERNOR SOLENOID AND PRESSURE	
FRAME SERVICE	13-4	VEHICLES	13-6	SENSOR	21-148,21-30
FREQUENCY INTERFERENCE, RADIO	8-6	FUEL TUBES/LINES/HOSES AND CLAMPS	14-11	GRAB HANDLE, A-PILLAR	23-45
FRONT AXLE	3-29	FUEL WARNING LAMP, LOW	8-10,8-21	GRID, REAR GLASS HEATING	8-1,8-2
FRONT AXLE DRIVESHAFTS	3-15	FUEL/IGNITION SYSTEMS, 8W-30	8-1	GRID REPAIR, REAR GLASS HEATING	8-3
FRONT AXLE SKID PLATE	13-5	FUNCTIONS, CIRCUIT	8-4	GRILLE	23-18
FRONT AXLES	3-27	FUSE BLOCK, RELAY	8-4	GRILLE, COWL	23-21
FRONT BAND ADJUSTMENT	21-214	FUSE, IGNITION-OFF DRAW	8-1	GROUND DISTRIBUTION, 8W-15	8-1
FRONT BEARING, OUTPUT SHAFT	21-153,21-35	FUSE/FUSE BLOCK, 8W-11	8-1	GROUND, POWER	14-31
FRONT BUMPER	13-1	GARAGE DOOR OPENER STORAGE BIN	8-2	GROUND—PCM INPUT, SIGNAL	14-31
FRONT BUMPER FASCIA	13-1	GARAGE DOOR OPENER STORAGE BIN		GUIDES AND SPRINGS, VALVES	9-39
FRONT BUMPER INNER BRACKET	13-1	DOOR	8-8	HANDLE ACTUATOR, FRONT DOOR	
FRONT CLUTCH	21-186,21-211,21-66,21-92	GASKET FAILURE DIAGNOSIS, ENGINE		INSIDE	23-30
FRONT DISC BRAKES	5-3	CYLINDER HEAD	9-7	HANDLE ACTUATOR, REAR DOOR	
FRONT DOOR	23-27	GASKETS, FORM-IN-PLACE	9-1	INSIDE	23-36
FRONT DOOR GLASS	23-30	GASOLINE/OXYGENATE BLENDS	14-1	HANDLE, A-PILLAR GRAB	23-45
FRONT DOOR GLASS RUN		GAUGE	8-3	HANDLE, FRONT DOOR OUTSIDE	23-28
WEATHERSTRIP	23-32	GAUGE, COOLANT TEMPERATURE	8-14,8-5	HANDLE, LIFTGATE OUTSIDE	23-43
FRONT DOOR HINGE	23-28	GAUGE, FUEL	8-14,8-5	HANDLE, OVERHEAD ASSIST	23-57
FRONT DOOR INNER BELT		GAUGE, OIL PRESSURE	8-15,8-6	HANDLE, PARK BRAKE RELEASE	8-29
WEATHERSTRIP	23-30	GAUGE SENDING UNIT, FUEL	14-10,14-17,14-4	HANDLE, REAR DOOR OUTSIDE	23-35
FRONT DOOR INSIDE HANDLE		GAUGES LAMP, CHECK	8-17,8-8	HAZARD WARNING SWITCH, TURN	
ACTUATOR	23-30	GAUGES, PRESSURE	22-3	SIGNAL SWITCH	8-2
FRONT DOOR LATCH	23-29	GEAR AND EXCITER RING, RING	3-66	HAZARD WARNING SYSTEM	8-1
FRONT DOOR LATCH STRIKER	23-30	GEAR BACKLASH, DIFFERENTIAL		HAZARD WARNING SYSTEMS, TURN	
FRONT DOOR LOCK CYLINDER	23-29	BEARING PRELOAD	3-44,3-84	SIGNAL	8-3
FRONT DOOR LOWER GLASS RUN		GEAR CLEARANCE, SIDE	3-87	HEAD ASSEMBLY, CYLINDER	9-109
CHANNELS	23-31	GEAR CONTACT PATTERN ANALYSIS	3-47,3-85	HEAD COMPONENTS—IN VEHICLE	
FRONT DOOR OPENING WEATHERSTRIP	23-32	GEAR DEPTH, 8 1/4 AXLE PINION	3-80	SERVICE, CYLINDER	9-24
FRONT DOOR OUTER BELT		GEAR DEPTH, 9 1/4 AXLE PINION	3-82	HEAD COVER, CYLINDER	9-24,9-41,9-59,9-75,
WEATHERSTRIP	23-30	GEAR DEPTH, PINION	3-42		9-93
FRONT DOOR OUTSIDE HANDLE	23-28	GEAR LEAKAGE DIAGNOSIS, POWER		HEAD, CYLINDER	9-41,9-60,9-94
FRONT DOOR SECONDARY SEAL	23-32	STEERING	19-12	HEAD GASKET FAILURE DIAGNOSIS,	
FRONT DOOR TRIM PANEL	23-26	GEAR NOISE	3-25,3-56	ENGINE CYLINDER	9-7
FRONT DOOR WATERDAM	23-27	GEAR, PINION	3-36,3-67	HEAD REMOVED, VALVES AND VALVE	
FRONT DOOR WINDOW REGULATOR	23-31	GEAR, POWER STEERING	19-10,19-21	SPRINGS—CYLINDER	9-26
FRONT DRIVESHAFT	3-16	GEAR RATIOS, TRANSMISSION	21-120,21-5	HEAD RESTRAINT SLEEVE	23-14
FRONT, ENGINE MOUNTS—	9-21	GEAR SELECTOR INDICATOR	8-28,8-9	HEADLAMP	8-11
FRONT FENDER, LEFT	23-22	GEAR SHIFT LEVER	19-25	HEADLAMP ADJUSTMENT	8-5
FRONT FENDER, RIGHT	23-23	GEAR, STEERING	19-12,19-19	HEADLAMP ALIGNMENT	8-4
FRONT LIGHTING, 8W-50	8-1	GEARSHIFT CABLE	21-124,21-147,21-214,21-29,	HEADLAMP ALIGNMENT PREPARATION	8-4
FRONT OIL SEAL, CRANKSHAFT	9-35		21-9,21-95	HEADLAMP BULB	8-7
FRONT OUTPUT SHAFT SEAL	21-237,21-261	GEARSHIFT MECHANISM	21-120,21-5	HEADLAMP HIGH BEAM INDICATOR	
FRONT PARK BRAKE CABLE	5-18	GEARTRAIN, PLANETARY	21-93	LAMP	8-10,8-20
FRONT PROPELLER SHAFT	3-7	GEARTRAIN/OUTPUT SHAFT,		HEADLAMP RELAY: POWER LOCK	
FRONT SEAT BELT BUCKLE	23-50	PLANETARY	21-189,21-212,21-70	SYSTEMS	8-4,8-9
FRONT SEAT BELT RETRACTOR	23-49	GENERAL INFORMATION: BODY	23-1	HEADLAMP RELAY: VEHICLE THEFT/	
FRONT SERVO	21-210,21-91	GENERAL INFORMATION: DIFFERENTIAL		SECURITY SYSTEMS	8-3,8-5
FRONT SERVO PISTON	21-183,21-62	AND DRIVELINE	3-25,3-56	HEADLAMP SWITCH; CHIME/BUZZER	
FRONT SIDE MARKER LAMP BULB	8-8	GENERAL INFORMATION: ENGINE	9-51,9-7	WARNING SYSTEMS	8-2,8-4
FRONT SUSPENSION	2-12,2-5	GENERAL INFORMATION: FRAME AND		HEADLAMP SWITCH; INSTRUMENT	
FRONT WHEEL SPEED SENSOR-4WD	5-40	BUMPERS	13-4	PANEL SYSTEMS	8-25
FRONT WHEELHOUSE LINER	23-21	GENERAL INFORMATION: FUEL SYSTEM	14-1	HEADLINER	23-57
FUEL DELIVERY SYSTEM	14-3	GENERAL INFORMATION: LAMPS	8-1,8-17	HEADS, CYLINDER	9-25,9-75
FUEL FILLER DOOR	23-41	GENERAL INFORMATION: LUBRICATION		HEAT SHIELDS	11-1,11-5
FUEL FILTER/FUEL PRESSURE		AND MAINTENANCE	0-1	HEATER, BLOCK	7-33,7-6
REGULATOR	14-15,14-4	GENERAL INFORMATION, 8W-01	8-1	HEATING GRID, REAR GLASS	8-1,8-2
FUEL GAUGE	8-14,8-5	GENERATOR	8-2,8-6	HEATING GRID REPAIR, REAR GLASS	8-3
FUEL GAUGE SENDING UNIT	14-10,14-17,14-4	GENERATOR FIELD DRIVER (-)—PCM		HEIGHT, SUSPENSION	2-3
FUEL INJECTION SYSTEM	14-23	OUTPUT	14-33	HIGH AND LOW LIMITS	25-12
FUEL INJECTOR RAIL—3.9/5.2/5.9L		GENERATOR FIELD SOURCE (+)—PCM		HIGH BEAM INDICATOR LAMP,	
ENGINES	14-17	OUTPUT	14-33	HEADLAMP	8-10,8-20
FUEL INJECTOR TEST	14-10	GENERATOR LAMP—PCM OUTPUT	14-33	HIGH MOUNTED STOP LAMP (CHMSL)	
FUEL INJECTOR(S)	14-19	GENERATOR RATINGS	8-7	BULB, CENTER	8-8
FUEL INJECTORS	14-5	GLASS, FRONT DOOR	23-30	HIGH MOUNTED STOP LAMP (CHMSL),	
FUEL INJECTORS—3.9/5.2/5.9L		GLASS HEATING GRID, REAR	8-1,8-2	CENTER	8-12
ENGINES—PCM OUTPUT	14-33	GLASS HEATING GRID REPAIR, REAR	8-3	HIGH SPEED OPERATION, TIRE	
FUEL LEVEL SENSOR—PCM INPUT	14-29	GLASS, QUARTER WINDOW	23-6	PRESSURE	22-3
FUEL PRESSURE LEAK DOWN TEST	14-7	GLASS, REAR DOOR	23-38	HIGHWAY SPEEDS, VIBRATION AT	3-16
FUEL PUMP	14-4	GLASS, REAR DOOR STATIONARY	23-6	HINGE, FRONT DOOR	23-28
FUEL PUMP AMPERAGE TEST	14-8	GLASS RUN CHANNELS, FRONT DOOR		HINGE, HOOD	23-19
FUEL PUMP CAPACITY TEST	14-7	LOWER	23-31	HINGE, LIFTGATE	23-42
FUEL PUMP INLET FILTER	14-16	GLASS RUN CHANNELS, REAR DOOR	23-38	HINGE, REAR DOOR	23-34
FUEL PUMP MODULE	14-16,14-3	GLASS RUN WEATHERSTRIP, FRONT		HITCH, TRAILER	13-7
FUEL PUMP PRESSURE TEST—ALL		DOOR	23-32	HOISTING, JUMP STARTING, TOWING	0-8
ENGINES WITH PRESSURE TEST PORT	14-6	GLASS RUN WEATHERSTRIP, REAR		HOISTING RECOMMENDATIONS	0-10
FUEL PUMP RELAY	14-43	DOOR	23-37	HOLE REPAIR, THREADED	Intro-6
FUEL PUMP RELAY-PCM OUTPUT	14-33	GLASS, STATIONARY	23-4	HONING CYLINDER BORES	9-5
FUEL PUMP RELAYS, ASD	14-38	GLOVE BOX	8-33	HOOD	23-18,23-58
FUEL RAIL—3.9/5.2/5.9L ENGINES	14-6	GLOVE BOX COMPONENTS	8-34	HOOD HINGE	23-19
FUEL REQUIREMENTS	14-1	GLOVE BOX LAMP AND SWITCH	8-32	HOOD LATCH	23-20,23-58
FUEL SYSTEM	14-49	GLOVE BOX LATCH STRIKER	8-33	HOOD LATCH STRIKER	23-20,23-58

Description	Group-Page	Description	Group-Page	Description	Group-Page
HOOD RELEASE CABLE	23-20	INDICATORS, TREAD WEAR	22-3	INSTRUMENT PANEL	8-2
HOOD SAFETY LATCH	23-19	INFLATION PRESSURES, TIRE	22-2	INSTRUMENT PANEL ASSEMBLY	8-35
HOOD SEAL	23-21	INITIAL OPERATION, POWER STEERING		INSTRUMENT PANEL CENTER SUPPORT	
HOOD SILENCER PAD	23-18	PUMP	19-6	BRACKET	8-30
HOOK, COAT	23-57	INJECTION SYSTEM, FUEL	14-23	INSTRUMENT PANEL LOWER BEZEL	8-31
HORN	8-1,8-3,8-4	INJECTOR RAIL—3.9/5.2/5.9L ENGINES,		INSTRUMENT PANEL LOWER	
HORN RELAY; HORN SYSTEMS	8-1,8-2,8-3	FUEL	14-17	REINFORCEMENT	8-30
HORN RELAY; POWER LOCK SYSTEMS	8-4,8-9	INJECTOR TEST, FUEL	14-10	INSTRUMENT PANEL TOP COVER	8-38
HORN RELAY; VEHICLE THEFT/SECURITY		INJECTOR(S), FUEL	14-19	INTAKE MANIFOLD	11-11,11-2,11-6
SYSTEMS	8-3,8-6	INJECTORS, FUEL	14-5	INTAKE MANIFOLD AIR TEMPERATURE	
HORN SWITCH	8-1,8-3,8-4	INJECTORS—3.9/5.2/5.9L ENGINES—		SENSOR	8-14,8-4,8-8
HORN SWITCH, DRIVER SIDE AIRBAG		PCM OUTPUT, FUEL	14-33	INTAKE MANIFOLD AIR TEMPERATURE	
TRIM COVER	8-7	INLET FILTER, FUEL PUMP	14-16	SENSOR—3.9/5.2/5.9L ENGINE	14-41
HORN SYSTEM	8-1	INNER BELT WEATHERSTRIP, FRONT		INTAKE MANIFOLD AIR TEMPERATURE	
HORN/CIGAR LIGHTER/POWER OUTLET,		DOOR	23-30	SENSOR—3.9/5.2/5.9L ENGINES	14-47
8W-41	8-1	INNER BELT WEATHERSTRIP, REAR		INTAKE MANIFOLD AIR TEMPERATURE	
HOSE, WATER PUMP BYPASS	7-26,7-4	DOOR	23-36	SENSOR—3.9/5.2/5.9L ENGINES—PCM	14-29
HOSES AND CLAMPS, COOLING SYSTEM	7-7	INNER BRACKET, FRONT BUMPER	13-1	INPUT	14-29
HOSES AND LINES, BRAKE	5-4	INNER C/V JOINT	3-18	INTAKE MANIFOLD LEAKAGE DIAGNOSIS	9-7
HOSES, BRAKE LINE	5-9	INNER TIE ROD END	19-27	INTERFERENCE, RADIO FREQUENCY	8-6
HOUSE LINER, REAR WHEEL	23-41	INPUT, AIR CONDITIONING (A/C)		INTERIOR LAMPS	8-17
HOUSING BUSHING, OVERDRIVE	21-152,21-34	CONTROLS—PCM	14-27	INTERIOR LIGHTING, 8W-44	8-1
HOUSING END PLUG	19-13	INPUT AND OUTPUT, DATA LINK		INTERIOR MIRRORS	8-4
HOUSING FLUID LEAK DIAGNOSIS,		CONNECTOR—PCM	14-32	INTERIOR TRIM PANELS	23-16
CONVERTER	21-129,21-14	INPUT, AUTOMATIC SHUTDOWN (ASD)		INTERLOCK, COLUMN SHIFT	8-19
HUB/BEARING	2-10	RELAY SENSE—PCM	14-28	INTERMITTENT AND POOR	
HYDRAULIC CONTROL SYSTEM	21-122,21-7	INPUT, BATTERY TEMPERATURE		CONNECTIONS	8-8
HYDRAULIC CONTROL UNIT	5-37	SENSOR—PCM	14-28	INTERMITTENT WIPE RELAY	8-14,8-4,8-9
HYDRAULIC PRESSURE TEST	21-10,21-125	INPUT, BATTERY VOLTAGE—PCM	14-28	INTERNATIONAL SYMBOLS	0-1
HYDRAULIC SCHEMATICS	21-216,21-97	INPUT, BRAKE SWITCH—PCM	14-28	INTERNATIONAL VEHICLE CONTROL	
HYDRAULIC TAPPETS	9-10,9-106,9-27,9-38,	INPUT, CAMSHAFT POSITION SENSOR—		AND DISPLAY SYMBOLS	Intro-3
	9-61,9-72,9-95	PCM	14-28	INTRODUCTION; AUDIO SYSTEMS	8-1
HYDROMETER TEST	8-6	INPUT, CRANKSHAFT POSITION		INTRODUCTION; BATTERY	8-1
HYDROSTATIC LOCK	9-6	SENSOR—3.9/5.2/5.9L ENGINES—PCM	14-28	INTRODUCTION; CHIME/BUZZER	
IDENTIFICATION, AXLE	3-53	INPUT, ENGINE COOLANT		WARNING SYSTEMS	8-1
IDENTIFICATION, FASTENER	Intro-3	TEMPERATURE SENSOR—3.9/5.2/5.9L		INTRODUCTION; ELECTRICALLY HEATED	
IDENTIFICATION NUMBER (VIN) PLATE,		ENGINES—PCM	14-29	SYSTEMS	8-1
VEHICLE	Intro-1	INPUT, FUEL LEVEL SENSOR—PCM	14-29	INTRODUCTION; FUEL SYSTEM	14-1,14-24
IDENTIFICATION, SECTION	8-5	INPUT, IGNITION CIRCUIT SENSE—PCM	14-29	INTRODUCTION; HORN SYSTEMS	8-1
IDENTIFICATION, TRANSFER CASE	21-235,	INPUT, INTAKE MANIFOLD AIR		INTRODUCTION; IGNITION SYSTEM	8-1
	21-259	TEMPERATURE SENSOR—3.9/5.2/5.9L		INTRODUCTION; INSTRUMENT PANEL	
IDENTIFICATION, TRANSMISSION	21-119,21-4	ENGINES—PCM	14-29	SYSTEMS	8-2
IDLE AIR CONTROL (IAC) MOTOR—3.9/		INPUT, MANIFOLD ABSOLUTE		INTRODUCTION; LUBRICATION AND	
5.2/5.9L ENGINES	14-41,14-44	PRESSURE (MAP) SENSOR—3.9/5.2/		MAINTENANCE	0-1
IDLE AIR CONTROL (IAC) MOTOR—3.9/		5.9L ENGINES—PCM	14-29	INTRODUCTION; OVERHEAD CONSOLE	
5.2/5.9L ENGINES—PCM OUTPUT	14-33	INPUT, OIL PRESSURE SENSOR—PCM	14-30	SYSTEMS	8-1
IDLER ARM	19-27	INPUT, OUTPUT SHAFT SPEED		INTRODUCTION; PASSIVE RESTRAINT	
IGNITION CIRCUIT SENSE—PCM INPUT	14-29	SENSOR—PCM	14-30	SYSTEMS	8-1
IGNITION COIL	8-3	INPUT, OVERDRIVE/OVERRIDE		INTRODUCTION; POWER LOCK	
IGNITION COIL RESISTANCE	8-20	SWITCH—PCM	14-30	SYSTEMS	8-1
IGNITION COIL TEST	8-5	INPUT, OXYGEN SENSOR—PCM	14-30	INTRODUCTION; POWER MIRROR	
IGNITION COIL—3.9/5.2/5.9L ENGINES	8-13	INPUT, SENSOR RETURN—PCM	14-31	SYSTEMS	8-1,8-4
IGNITION COIL—3.9/5.2/5.9L ENGINES—		INPUT, SIGNAL GROUND—PCM	14-31	INTRODUCTION; POWER SEAT SYSTEMS	8-1
PCM OUTPUT	14-34	INPUT, SPEED CONTROL SWITCHES—		INTRODUCTION; POWER WINDOW	
IGNITION SWITCH	19-23	PCM	14-31	SYSTEMS	8-1
IGNITION SWITCH AND KEY CYLINDER	8-16	INPUT, THROTTLE POSITION SENSOR		INTRODUCTION; SPEED CONTROL	
IGNITION SWITCH AND KEY LOCK		(TPS)—3.9/5.2/5.9L ENGINE—PCM	14-31	SYSTEM	8-1
CYLINDER	8-4	INPUT, TRANSMISSION GOVERNOR		INTRODUCTION; STARTING SYSTEMS	8-1
IGNITION SWITCH, KEY-IN	8-2,8-4	PRESSURE SENSOR—PCM	14-31	INTRODUCTION; TURN SIGNAL AND	
IGNITION SYSTEM	8-2	INPUT, TRANSMISSION PARK/NEUTRAL		HAZARD WARNING SYSTEMS	8-1,8-3
IGNITION TIMING	8-19,8-7	SWITCH—PCM	14-31	INTRODUCTION; VEHICLE THEFT/	
IGNITION-OFF DRAW FUSE	8-1	INPUT, TRANSMISSION TEMPERATURE		SECURITY SYSTEMS	8-1
IGNITION-OFF DRAW TEST	8-10	SENSOR—PCM	14-31	INTRODUCTION; WIPER AND WASHER	
ILLUMINATION LAMP, CLUSTER	8-18,8-8	INPUT, VEHICLE SPEED	8-2	SYSTEMS	8-1
INCH AXLE, 8 1/4	3-87	INPUT, VEHICLE SPEED AND		INTRODUCTION; WIRING DIAGRAMS	8-1
INCH AXLE, 8 1/4 AND 9 1/4	3-88	DISTANCE—PCM	14-32	JOINT ANGLE, PROPELLER SHAFT	3-2
INCH AXLE, 9 1/4	3-87	INSIDE HANDLE ACTUATOR, FRONT		JOINT BOOTS, C/V	3-17,3-23
INCORRECT FLUID LEVEL, EFFECTS OF	21-119,	DOOR	23-30	JOINT, C/V	3-22
	21-4	INSIDE HANDLE ACTUATOR, REAR		JOINT, DOUBLE CARDAN	3-10
INDEX, 8W-02 COMPONENT	8-1	DOOR	23-36	JOINT DRIVESHAFT, C/V	3-23
INDICATOR, BUILT-IN TEST	8-5	INSPECTION, CRANKSHAFT JOURNAL	9-41,9-75	JOINT, INNER C/V	3-18
INDICATOR, GEAR SELECTOR	8-28,8-9	INSPECTION, ENGINE OIL LEAK	9-8	JOINT, LOWER BALL	2-6
INDICATOR LAMP	8-3	INSPECTION FOR REAR SEAL AREA		JOINT, OUTER C/V	3-19
INDICATOR LAMP, AIRBAG	8-16,8-7	LEAKS	9-9	JOINT, SINGLE CARDAN UNIVERSAL	3-8
INDICATOR LAMP, CRUISE-ON	8-18,8-9	INSPECTION, PISTON AND CONNECTING		JOINT, UPPER BALL	2-6
INDICATOR LAMP, FOUR-WHEEL DRIVE	8-19,8-9	ROD	9-41	JOURNAL INSPECTION, CRANKSHAFT	9-41,9-75
INDICATOR LAMP, HEADLAMP HIGH		INSPECTION, PRE-ALIGNMENT	2-2	JUMP STARTING PROCEDURE	0-8
BEAM	8-10,8-20	INSPECTION, UNSCHEDULED	0-3	JUMP STARTING, TOWING AND	
INDICATOR LAMP, MALFUNCTION	8-10,8-22	INSPECTION, VEHICLE	3-16	HOISTING	0-8
INDICATOR LAMP (MIL), MALFUNCTION	25-2	INSPECTION, WHEEL	22-7	JUNCTION BLOCK	8-29,8-4
INDICATOR LAMP, OVERDRIVE-OFF	8-11,8-22	INSPECTION—3.9/5.2/5.9L ENGINES,		JUNCTION BLOCK, 8W-12	8-1
INDICATOR LAMP, TURN SIGNAL;		VISUAL	14-35	KEY CYLINDER, IGNITION SWITCH	8-16
INSTRUMENT PANEL SYSTEMS	8-12,8-24	INSTALLATION, WHEEL	22-8	KEY LOCK CYLINDER, IGNITION SWITCH	8-4
INDICATOR LAMP, TURN SIGNAL; TURN		INSTRUMENT CLUSTER; CHIME/BUZZER		KEY-IN IGNITION SWITCH	8-2,8-4
SIGNAL AND HAZARD WARNING		WARNING SYSTEMS	8-2,8-5	KEYLESS ENTRY RECEIVER, REMOTE	8-3
SYSTEMS	8-3	INSTRUMENT CLUSTER; INSTRUMENT		KEYLESS ENTRY SYSTEM, POWER LOCK	
INDICATOR LAMP—PCM OUTPUT,		PANEL SYSTEMS	8-12,8-2,8-26	SYSTEM AND REMOTE	8-4
MALFUNCTION	14-34	INSTRUMENT CLUSTER, 8W-40	8-1	KEYLESS ENTRY SYSTEM, REMOTE	8-1

Description	Group-Page	Description	Group-Page	Description	Group-Page
KEYLESS ENTRY TRANSMITTER		LAMP, TURN SIGNAL INDICATOR: TURN		LINE AND HOSES, BRAKE	5-9
BATTERY REPLACEMENT, REMOTE	8-7	SIGNAL AND HAZARD WARNING		LINE, BRAKE	5-11
KEYLESS ENTRY TRANSMITTER		SYSTEMS	8-3	LINER, FRONT WHEELHOUSE	23-21
PROGRAMMING, REMOTE	8-7	LAMP, UNDERHOOD	8-13	LINER, REAR WHEEL HOUSE	23-41
KEYLESS ENTRY TRANSMITTER,		LAMP—PCM OUTPUT, GENERATOR	14-33	LINES, BRAKE HOSES	5-4
REMOTE	8-3,8-6	LAMP—PCM OUTPUT, MALFUNCTION		LINK, CENTER	19-27
KNEE BLOCKER, STEERING COLUMN		INDICATOR	14-34	LINK CONNECTOR—PCM INPUT AND	
OPENING COVER	8-27	LAMP—PCM OUTPUT, OVERDRIVE	14-34	OUTPUT, DATA	14-32
KNOCK, LOW SPEED	3-26,3-57	LAMPS, BRAKE WARNING	5-32	LINKAGE ADJUSTMENT, SHIFT	21-255,21-283
KNUCKLE, STEERING	2-7	LAMPS, EXTERIOR	8-17	LINKAGE AND PIVOT, WIPER	8-12,8-2
LABEL, VECI; FUEL SYSTEM	14-22,14-48	LAMPS, INTERIOR	8-17	LINKAGE, STEERING	19-26,19-28
LABEL, VECI; IGNITION SYSTEM	8-19	LATCH ADJUSTMENT, DOOR	23-59	LOAD TEST	8-8
LABEL, VEHICLE EMISSION CONTROL		LATCH, FRONT DOOR	23-29	LOAD VALUE	25-12
INFORMATION (VECI)	25-16	LATCH, HOOD	23-20,23-58	LOCATION, RWAL COMPONENT	5-30
LABEL, VEHICLE SAFETY CERTIFICATION	Intro-1	LATCH, HOOD SAFETY	23-19	LOCATIONS, 8W-90 CONNECTOR	8-1
LAMP, 2ND SEAT DOME/READING	8-14	LATCH, LIFTGATE	23-44	LOCATIONS, 8W-95 SPLICE	8-1
LAMP, ABS WARNING	5-38	LATCH, REAR DOOR	23-35	LOCATIONS, CONNECTOR/GROUND	8-1
LAMP, AIRBAG INDICATOR	8-16,8-7	LATCH STRIKER, FRONT DOOR	23-30	LOCATIONS, SPLICE	8-1,8-7
LAMP ALIGNMENT, FOG	8-5	LATCH STRIKER, GLOVE BOX	8-33	LOCK CYLINDER, FRONT DOOR	23-29
LAMP AND SWITCH, GLOVE BOX	8-32	LATCH STRIKER, HOOD	23-20,23-58	LOCK CYLINDER, IGNITION SWITCH AND	
LAMP, ANTI-LOCK BRAKE SYSTEM	8-16,8-7	LATCH STRIKER, LIFTGATE	23-44	KEY	8-4
LAMP, BRAKE WARNING	8-17,8-7	LATCH STRIKER, REAR DOOR	23-35	LOCK CYLINDER, LIFTGATE	23-44
LAMP BULB, 2ND SEAT DOME/READING	8-10	LATCHES, 2ND ROW SEAT	23-12	LOCK CYLINDER SWITCH, DOOR	8-3,8-4
LAMP BULB, DOME	8-9	LD AXLE SEAL AND BEARING, 8 1/4		LOCK CYLINDER SWITCH, LIFTGATE	8-3,8-5
LAMP BULB, FOG	8-7	AND 9 1/4	3-62	LOCK, HYDROSTATIC	9-6
LAMP BULB, FRONT SIDE MARKER	8-8	LEAF SPRINGS	2-15	LOCK MOTOR, POWER	8-3,8-6,8-8
LAMP BULB, LICENSE PLATE	8-9	LEAF SPRINGS, ADJUSTMENT AT AXLE		LOCK SWITCH, POWER	8-3,8-4,8-8
LAMP BULB, LIFTGATE/CARGO	8-8	WITH	3-14	LOCK SYSTEM AND REMOTE KEYLESS	
LAMP BULB, OVERHEAD CONSOLE		LEAK DETECTION PUMP (LDP)	25-14,25-17, 25-18	ENTRY SYSTEM, POWER	8-4
READING	8-10	LEAK DIAGNOSIS, CONVERTER		LOCK SYSTEM, POWER	8-1
LAMP BULB, READING AND COURTESY	8-7	HOUSING FLUID	21-129,21-14	LOCKS, 8W-61 POWER DOOR	8-1
LAMP BULB SERVICE	8-7	LEAK DOWN TEST, FUEL PRESSURE	14-7	LOCK-UP TORQUE CONVERTER,	
LAMP BULB, TAIL, STOP, TURN SIGNAL		LEAK INSPECTION, ENGINE OIL	9-8	ELECTRONIC	21-120,21-5
AND BACK-UP	8-8	LEAKAGE DIAGNOSIS, INTAKE		LOW FUEL WARNING LAMP	8-10,8-21
LAMP BULB, UNDERHOOD	8-9	MANIFOLD	9-7	LOW LIMITS, HIGH	25-12
LAMP BULBS, PARK AND TURN SIGNAL	8-8	LEAKAGE DIAGNOSIS, POWER		LOW SPEED KNOCK	3-26,3-57
LAMP, CHECK GAUGES	8-17,8-8	STEERING GEAR	19-12	LOW WASHER FLUID WARNING LAMP	8-10, 8-21
LAMP (CHMSL) BULB, CENTER HIGH		LEAKAGE, PUMP	19-6	LOWER BALL JOINT	2-6
MOUNTED STOP	8-8	LEAKAGE TEST, CYLINDER COMBUSTION		LOWER BEZEL, INSTRUMENT PANEL	8-31
LAMP (CHMSL), CENTER HIGH		PRESSURE	9-8	LOWER GLASS RUN CHANNELS, FRONT	
MOUNTED STOP	8-12	LEAKS, COOLING SYSTEM—TESTING	7-16	DOOR	23-31
LAMP, CLUSTER ILLUMINATION	8-18,8-8	LEAKS, INSPECTION FOR REAR SEAL		LOWER REINFORCEMENT, INSTRUMENT	
LAMP, CRUISE-ON INDICATOR	8-18,8-9	AREA	9-9	PANEL	8-30
LAMP DIAGNOSIS	8-1	LEAKS, REPAIRING	22-5	LOWER SUSPENSION ARM	2-8
LAMP, DOME	8-14	LEAKS, WATER	23-16	LUBRICANT AND FILL LEVEL,	
LAMP, DOOR AJAR	8-19,8-9	LEFT FRONT FENDER	23-22	RECOMMENDED	21-235,21-260
LAMP, FOG	8-11	LEVEL AERATION, COOLANT—LOW	7-21	LUBRICANT CHANGE	3-29,3-60
LAMP, FOUR-WHEEL DRIVE INDICATOR	8-19,8-9	LEVEL, BRAKE FLUID	5-9	LUBRICANT RECOMMENDATIONS,	
LAMP, HEADLAMP HIGH BEAM		LEVEL CHECK, COOLANT	7-22	PARTS	0-1
INDICATOR	8-10,8-20	LEVEL CHECK, COOLANT—ROUTINE	7-22	LUBRICANT SPECIFICATIONS	3-24
LAMP, INDICATOR	8-3	LEVEL CHECK, FLUID	21-141,21-23	LUBRICANTS	3-55
LAMP, LICENSE PLATE	8-13	LEVEL, EFFECTS OF INCORRECT FLUID	21-119, 21-4	LUBRICANTS, CLASSIFICATION OF	0-1
LAMP, LIFTGATE AJAR	8-10,8-20	LEVEL, RECOMMENDED LUBRICANT		LUBRICATION	3-2
LAMP, LIFTGATE/CARGO	8-12	AND FILL	21-235,21-260	LUBRICATION, BODY	23-17
LAMP, LOW FUEL WARNING	8-10,8-21	LEVEL SENSOR, WASHER FLUID	8-5	LUBRICATION SYSTEM	9-51,9-85
LAMP, LOW WASHER FLUID WARNING	8-10, 8-21	LEVEL SENSOR—PCM INPUT, FUEL	14-29	LUBRICATION SYSTEM, ENGINE	9-16
LAMP, MALFUNCTION INDICATOR	8-10,8-22	LEVER, GEAR SHIFT	19-25	LUGGAGE RACK	23-45
LAMP (MIL), MALFUNCTION INDICATOR	25-2	LEVER, SHIFT	21-237,21-261	MACHINING, BRAKE DRUM	5-11
LAMP MODULE (DRLM), DAYTIME		LICENSE PLATE LAMP	8-13	MACHINING, DISC ROTOR	5-11
RUNNING	8-1,8-16	LICENSE PLATE LAMP BULB	8-9	MAIN BEARINGS, CRANKSHAFT	9-100,9-21, 9-32,9-55,9-65
LAMP, OVERDRIVE-OFF INDICATOR	8-11,8-22	LIFTGATE	23-43,23-59	MAIN BEARINGS, FITTING CRANKSHAFT	9-89
LAMP, OVERHEAD CONSOLE READING	8-15	LIFTGATE AJAR LAMP	8-10,8-20	MAINTENANCE SCHEDULES	0-3
LAMP, PARK, TURN SIGNAL AND SIDE		LIFTGATE AJAR SWITCH	8-3,8-4	MALFUNCTION INDICATOR LAMP	8-10,8-22
MARKER	8-12	LIFTGATE BACKLITE	23-7	MALFUNCTION INDICATOR LAMP (MIL)	25-2
LAMP, READING AND COURTESY	8-2,8-7	LIFTGATE HINGE	23-42	MALFUNCTION INDICATOR LAMP—PCM	
LAMP, RED BRAKE WARNING	5-2,5-7	LIFTGATE LATCH	23-44	OUTPUT	14-34
LAMP, SEAT BELT REMINDER	8-11,8-23	LIFTGATE LATCH STRIKER	23-44	MANIFOLD ABSOLUTE PRESSURE (MAP)	
LAMP, SECURITY; INSTRUMENT PANEL		LIFTGATE LOCK CYLINDER	23-44	SENSOR	8-14,8-4
SYSTEMS	8-11,8-23	LIFTGATE LOCK CYLINDER SWITCH	8-3,8-5	MANIFOLD ABSOLUTE PRESSURE (MAP)	
LAMP, SECURITY; VEHICLE THEFT/		LIFTGATE MOLDING	23-45	SENSOR TEST—3.9/5.2/5.9L ENGINES	14-39
SECURITY SYSTEMS	8-3	LIFTGATE OPENING UPPER TRIM	23-47	MANIFOLD ABSOLUTE PRESSURE (MAP)	
LAMP SERVICE	8-11	LIFTGATE OPENING WEATHERSTRIP	23-44	SENSOR—3.9/5.2/5.9L ENGINES	14-45
LAMP SWITCH, FOG	8-25	LIFTGATE OUTSIDE HANDLE	23-43	MANIFOLD ABSOLUTE PRESSURE (MAP)	
LAMP SWITCH, STOP; BRAKES	5-12,5-2,5-24, 5-33,5-7	LIFTGATE SCUFF PLATE	23-49	SENSOR—3.9/5.2/5.9L ENGINES—PCM	
LAMP SWITCH, STOP; SPEED CONTROL		LIFTGATE SUPPORT CYLINDER	23-42	INPUT	14-29
SYSTEM	8-2,8-3,8-5	LIFTGATE TRIM PANEL	23-42	MANIFOLD AIR TEMPERATURE SENSOR,	
LAMP SYSTEMS	8-16	LIFTGATE/CARGO LAMP	8-12	INTAKE	8-14,8-4,8-8
LAMP, TAIL, STOP, TURN SIGNAL AND		LIFTGATE/CARGO LAMP BULB	8-8	MANIFOLD AIR TEMPERATURE	
BACK-UP	8-13	LIGHTER AND POWER OUTLET, CIGAR	8-32	SENSOR—3.9/5.2/5.9L ENGINE,	
LAMP, TRANSMISSION OIL		LIGHTER, CIGAR	8-17,8-8	INTAKE	14-41
TEMPERATURE WARNING	8-11,8-24	LIGHTER/POWER OUTLET, 8W-41		MANIFOLD AIR TEMPERATURE	
LAMP, TURN SIGNAL	8-3	HORN/CIGAR	8-1	SENSOR—3.9/5.2/5.9L ENGINES,	
LAMP, TURN SIGNAL INDICATOR;		LIGHTING, 8W-44 INTERIOR	8-1	INTAKE	14-47
INSTRUMENT PANEL SYSTEMS	8-12,8-24	LIGHTING, 8W-50 FRONT	8-1	MANIFOLD AIR TEMPERATURE	
		LIGHTING, 8W-51 REAR	8-1	SENSOR—3.9/5.2/5.9L ENGINES—PCM	
		LIMITS, HIGH AND LOW	25-12	INPUT, INTAKE	14-29

Description	Group-Page	Description	Group-Page	Description	Group-Page
MANIFOLD, EXHAUST	11-11,11-2,11-9	MOUNT—REAR, ENGINE	9-22,9-57,9-91	ORDER—5.2L/5.9L V-8 ENGINES,	
MANIFOLD, INTAKE	11-11,11-2,11-6	MOUNTS— FRONT, ENGINE	9-21	ENGINE FIRING	8-19
MANIFOLD LEAKAGE DIAGNOSIS,		MOUNTS—FRONT, ENGINE	9-56,9-90	OUTER BELT WEATHERSTRIP, FRONT	
INTAKE	9-7	(-)—PCM OUTPUT, GENERATOR FIELD		DOOR	23-30
MAP SENSOR	8-7	DRIVER	14-33	OUTER BELT WEATHERSTRIP, REAR	
MARKER LAMP BULB, FRONT SIDE	8-8	(+)-PCM OUTPUT, GENERATOR FIELD		DOOR	23-36
MARKER LAMP, PARK, TURN SIGNAL		SOURCE	14-33	OUTER C/V JOINT	3-19
AND SIDE	8-12	MUFFLER	11-4	OUTLET, 8W-41 HORN/CIGAR	
MASTER CYLINDER	5-13,5-3	MULTI-FUNCTION SWITCH	8-4,8-5	LIGHTER/POWER	8-1
MASTER CYLINDER BLEEDING	5-9	NAMEPLATES, EXTERIOR	23-24	OUTLET, CIGAR LIGHTER AND POWER	8-32
MASTER CYLINDER RESERVOIR	5-20	NECK SEAL—PRESSURE RELIEF CHECK,		OUTLET, POWER	8-11,8-22
MASTER CYLINDER/POWER BOOSTER	5-7	RADIATOR CAP-TO-FILLER	7-20	OUTPUT, AIR CONDITIONING (A/C)	
MATCH MOUNTING	22-4	NOISE AND/OR VIBRATION IN TURNS	3-16	CLUTCH RELAY—PCM	14-32
MEASUREMENT PREPARATION,		NOISE, BEARING	3-26,3-57	OUTPUT, AUTO SHUTDOWN (ASD)	
DRIVELINE ANGLE	3-5	NOISE DURING ACCELERATION,		RELAY—PCM	14-32
MEASUREMENT, PROPELLER SHAFT		CLUNKING	3-16	OUTPUT, DATA LINK CONNECTOR—PCM	
ANGLE	3-5	NOISE, GEAR	3-25,3-56	INPUT	14-32
MEASURING TIMING CHAIN STRETCH	9-53,9-87	NOISE OR VIBRATION, TIRE	22-4	OUTPUT, DUTY CYCLE EVAP PURGE	
MEASURING WITH PLASTIGAGE	9-2	NOISE SUPPRESSION, RADIO	8-2	SOLENOID VALVE—PCM	14-33
MECHANISM, GEARSHIFT	21-120,21-5	NOISE, TRAC-LOK DIFFERENTIAL	3-57	OUTPUT, FUEL INJECTORS—3.9/5.2/5.9L	
METRIC SYSTEM	Intro-6	NOISE, WIND	23-17	ENGINES—PCM	14-33
MILE, TIRES REVOLUTIONS PER	22-6	NON-MONITORED CIRCUITS	25-11	OUTPUT, FUEL PUMP RELAY-PCM	14-33
MINIMUM AIR FLOW CHECK		NOTES, CAUTIONS, AND WARNINGS	8-7	OUTPUT, GENERATOR FIELD DRIVER	
PROCEDURE, THROTTLE BODY	14-42	NOZZLE AND PLUMBING, WASHER	8-5	(-)-PCM	14-33
MIRROR, AUTOMATIC DAY/NIGHT	8-4,8-5	NUMBER (VIN) PLATE, VEHICLE		OUTPUT, GENERATOR FIELD SOURCE	
MIRROR, POWER	8-1,8-3	IDENTIFICATION	Intro-1	(+)-PCM	14-33
MIRROR, REARVIEW	23-55	NV231	21-256	OUTPUT, GENERATOR LAMP—PCM	14-33
MIRROR, SIDE VIEW	23-25	NV231 DIAGNOSIS	21-236	OUTPUT, GOVERNOR PRESSURE	
MIRROR SUPPORT BRACKET, REARVIEW	23-56	NV231 TRANSFER CASE	21-235,21-239,21-253	SOLENOID—PCM	14-35
MIRROR SWITCH, POWER	8-1,8-2	NV242	21-284	OUTPUT, IDLE AIR CONTROL (IAC)	
MIRROR SYSTEM, AUTOMATIC		NV242 DIAGNOSIS	21-260	MOTOR—3.9/5.2/5.9L ENGINES—PCM	14-33
DAY/NIGHT	8-4	NV242 TRANSFER CASE	21-259,21-263,21-282	OUTPUT, IGNITION COIL—3.9/5.2/5.9L	
MIRROR SYSTEM, POWER	8-1	ODOMETER AND TRIP ODOMETER	8-15,8-5	ENGINES—PCM	14-34
MIRRORS, 8W-62 POWER	8-1	ODOMETER, ODOMETER AND TRIP	8-15,8-5	OUTPUT, MALFUNCTION INDICATOR	
MIRRORS, EXTERIOR	8-1	OFF SWITCH, OVERDRIVE	21-122,21-7	LAMP—PCM	14-34
MIRRORS, INTERIOR	8-4	OIL AND CAMSHAFT PLUGS, ENGINE		OUTPUT, OVERDRIVE LAMP—PCM	14-34
MODE, CIRCUIT ACTUATION TEST	25-2	CORE	9-38,9-71	OUTPUT SHAFT FRONT BEARING	21-153,21-35
MODE, POWER-UP	8-2	OIL COOLER, AUTOMATIC		OUTPUT SHAFT REAR BEARING	21-152,21-35
MODE, STATE DISPLAY TEST	25-2	TRANSMISSION	7-5	OUTPUT SHAFT SEAL, FRONT	21-237,21-261
MODES OF OPERATION	14-24	OIL, ENGINE	9-3	OUTPUT SHAFT SPEED SENSOR—PCM	
MODULE, 8W-45 CENTRAL TIMER	8-1	OIL LEAK INSPECTION, ENGINE	9-8	INPUT	14-30
MODULE, AIRBAG	8-2,8-5	OIL PAN	9-100,9-109,9-33,9-43,9-66,9-75	OUTPUT, SPEED CONTROL	
MODULE, AIRBAG CONTROL	8-3,8-8	OIL PRESSURE, ENGINE	9-10	SOLENOIDS—PCM	14-34
MODULE, CENTRAL TIMER: CHIME/		OIL PRESSURE GAUGE	8-15,8-6	OUTPUT, TACHOMETER—PCM	14-34
BUZZER WARNING SYSTEMS	8-1,8-3	OIL PRESSURE SENSOR—PCM INPUT	14-30	OUTPUT TEST, CURRENT	8-4
MODULE, CENTRAL TIMER; HORN		OIL PUMP	9-103,9-109,9-110,9-34,9-40,9-42,	OUTPUT, THREE-FOUR SHIFT	
SYSTEMS	8-2		9-68,9-74,9-76	SOLENOID—PCM	14-34
MODULE, CENTRAL TIMER:		OIL PUMP AND REACTION SHAFT		OUTPUT, TORQUE CONVERTOR CLUTCH	
INSTRUMENT PANEL SYSTEMS	8-34,8-4	SUPPORT	21-184,21-211,21-63,21-92	(TCC) SOLENOID—PCM	14-34
MODULE, CENTRAL TIMER: POWER		OIL PUMP PRESSURE	9-15,9-50,9-84	OUTPUT, TRANSMISSION RELAY—PCM	14-35
LOCK SYSTEMS	8-2,8-5	OIL PUMP VOLUME CHECK	21-143,21-25	OUTPUTS, CCD BUS (+/-) CIRCUITS-PCM	14-32
MODULE, CENTRAL TIMER: VEHICLE		OIL SEAL, CRANKSHAFT FRONT	9-35	OUTS, TAKE	8-8
THEFT/SECURITY SYSTEMS	8-2	OIL SEAL—FRONT, CRANKSHAFT	9-103,9-69	OUTSIDE HANDLE, FRONT DOOR	23-28
MODULE, CENTRAL TIMER: WIPER AND		OIL SEALS, CRANKSHAFT REAR	9-103,9-36	OUTSIDE HANDLE, LIFTGATE	23-43
WASHER SYSTEMS	8-3	OIL SEALS—REAR, CRANKSHAFT	9-69	OUTSIDE HANDLE, REAR DOOR	23-35
MODULE (DRLM), DAYTIME RUNNING		OIL TEMPERATURE WARNING LAMP,		OVERDRIVE ELECTRICAL CONTROLS	21-124,
LAMP	8-1,8-16	TRANSMISSION	8-11,8-24		21-9
MODULE, FUEL PUMP	14-16,14-3	OIL-TO-AIR COOLER, AUXILIARY	7-5	OVERDRIVE HOUSING BUSHING	21-152,21-34
MODULE (PCM), POWERTRAIN		ON-BOARD DIAGNOSTIC TEST FOR		OVERDRIVE LAMP—PCM OUTPUT	14-34
CONTROL; FUEL SYSTEM	14-26,14-46	CHARGING SYSTEM	8-5	OVERDRIVE OFF SWITCH	21-122,21-7
MODULE (PCM), POWERTRAIN		ON-BOARD DIAGNOSTIC TEST FOR		OVERDRIVE UNIT	21-151,21-193,21-212,21-33,
CONTROL; IGNITION SYSTEM	8-16	SPEED CONTROL SYSTEM	8-2		21-75,21-93
MODULE, POWERTRAIN CONTROL;		ON-BOARD DIAGNOSTICS	25-1	OVERDRIVE-OFF INDICATOR LAMP	8-11,8-22
IGNITION SYSTEM	8-2	ON-BOARD DIAGNOSTICS (OBD)	7-9	OVERDRIVE/OVERRIDE SWITCH—PCM	
MODULE, POWERTRAIN CONTROL;		OPEN-CIRCUIT VOLTAGE TEST	8-8	INPUT	14-30
SPEED CONTROL SYSTEM	8-2	OPENER STORAGE BIN DOOR, GARAGE		OVERHEAD ASSIST HANDLE	23-57
MODULE, TRIP COMPUTER, COMPASS,		DOOR	8-8	OVERHEAD CONSOLE	8-1,8-6
AND THERMOMETER DISPLAY	8-3,8-7	OPENER STORAGE BIN, GARAGE DOOR	8-2	OVERHEAD CONSOLE, 8W-49	8-1
MOLDING, LIFTGATE	23-45	OPENING COVER AND KNEE BLOCKER,		OVERHEAD CONSOLE READING LAMP	8-15
MOLDING, WHEEL OPENING	23-40	STEERING COLUMN	8-27	OVERHEAD CONSOLE READING LAMP	
MOLDINGS, BODY SIDE	23-40	OPENING MOLDING, WHEEL	23-40	BULB	8-10
MONITORED SYSTEMS	25-8	OPENING UPPER TRIM, LIFTGATE	23-47	OVERRUNNING CLUTCH CAM/	
MONITORS, COMPONENT	25-11	OPENING WEATHERSTRIP, FRONT DOOR	23-32	OVERDRIVE PISTON RETAINER	21-181,21-61
MOTOR, POWER LOCK	8-3,8-6,8-8	OPENING WEATHERSTRIP, LIFTGATE	23-44	OVERRUNNING CLUTCH/LOW-REVERSE	
MOTOR, POWER WINDOW	8-2,8-4	OPENING WEATHERSTRIP, REAR DOOR	23-36	DRUM/OVERDRIVE PISTON RETAINER	21-210,
MOTOR, WIPER	8-12,8-2	OPERATION, AIR TESTING			21-91
MOTOR—3.9/5.2/5.9L ENGINES, IDLE		TRANSMISSION CLUTCH AND BAND	21-128,	OVERSHOOT/UNDERSHOOT FOLLOWING	
AIR CONTROL (IAC)	14-41,14-44		21-14	SPEED CONTROL SET	8-4
MOTOR—3.9/5.2/5.9L ENGINES—PCM		OPERATION, CHARGING SYSTEM	8-1	OVERVIEW; BATTERY	8-1
OUTPUT, IDLE AIR CONTROL (IAC)	14-33	OPERATION, MODES OF	14-24	OVERVIEW; CHARGING SYSTEM	8-1
MOTORS, POWER SEAT ADJUSTER	8-1,8-2,8-3	OPERATION, POWER STEERING PUMP -		OVERVIEW; STARTING SYSTEMS	8-1
MOUNTED STOP LAMP (CHMSL) BULB,		INITIAL	19-6	OXYGEN SENSOR	14-46
CENTER HIGH	8-8	OPERATION, SHIFT VALVE	21-122,21-7	OXYGEN SENSOR—PCM INPUT	14-30
MOUNTED STOP LAMP (CHMSL),		OPERATION, TIRE PRESSURE FOR HIGH		OXYGEN SENSORS	14-40
CENTER HIGH	8-12	SPEED	22-3	PAD, HOOD SILENCER	23-18
MOUNTING, BATTERY	8-3	OPERATION, TRAC-LOK	3-56	PAINT	23-2
MOUNTING, MATCH	22-4	ORDER—3.9L V-6 ENGINE, ENGINE		PAINT CODE	23-2
MOUNTING STUDS, WHEEL	2-11	FIRING	8-19	PAINTED SURFACE TOUCH-UP	23-2

Description	Group-Page	Description	Group-Page	Description	Group-Page
PAN, OIL	9-100,9-109,9-33,9-43,9-66,9-75	PLUGS, ENGINE CORE OIL AND CAMSHAFT	9-38,9-71	PRELIMINARY CHECKS	7-9
PANEL ASSEMBLY, INSTRUMENT	8-35	PLUGS, SPARK	8-12,8-19,8-2	PRELIMINARY DIAGNOSIS	21-123,21-8
PANEL CENTER SUPPORT BRACKET, INSTRUMENT	8-30	PLUMBING, WASHER NOZZLE	8-5	PRELOAD AND GEAR BACKLASH, DIFFERENTIAL BEARING	3-44,3-84
PANEL, FRONT DOOR TRIM	23-26	POLISHING, FINESSE SANDING, BUFFING	23-2	PREPARATION, DRIVELINE ANGLE MEASUREMENT	3-5
PANEL, INSTRUMENT	8-2	POOR CONNECTIONS, INTERMITTENT	8-8	PREPARATION, HEADLAMP ALIGNMENT	8-4
PANEL, LIFTGATE TRIM	23-42	PORT, FUEL PUMP PRESSURE TEST—ALL ENGINES WITH PRESSURE TEST	14-6	PRESSURE CAP, RADIATOR	7-3
PANEL LOWER BEZEL, INSTRUMENT	8-31	POSITION SENSOR, CAMSHAFT; FUEL SYSTEM	14-46	PRESSURE CURVES, GOVERNOR	21-121,21-6
PANEL LOWER REINFORCEMENT, INSTRUMENT	8-30	POSITION SENSOR, CAMSHAFT; IGNITION SYSTEM	8-14,8-3,8-7	PRESSURE, ENGINE OIL	9-10
PANEL, REAR DOOR TRIM	23-33	POSITION SENSOR, CRANKSHAFT; FUEL SYSTEM	14-46	PRESSURE FOR HIGH SPEED OPERATION, TIRE	22-3
PANEL TOP COVER, INSTRUMENT	8-38	POSITION SENSOR, CRANKSHAFT; IGNITION SYSTEM	8-7	PRESSURE, FUEL SYSTEM	14-22
PANEL TRIM, QUARTER	23-48	POSITION SENSOR, THROTTLE	8-14,8-4	PRESSURE GAUGE, OIL	8-15,8-6
PANELS, INTERIOR TRIM	23-16	POSITION SENSOR (TPS)—3.9/5.2/5.9L ENGINE, THROTTLE	14-41	PRESSURE GAUGES	22-3
PARK AND TURN SIGNAL LAMP BULBS	8-8	POSITION SENSOR (TPS)—3.9/5.2/5.9L ENGINE—PCM INPUT, THROTTLE	14-31	PRESSURE LEAK DOWN TEST, FUEL	14-7
PARK BRAKE CABLE, FRONT	5-18	POSITION SENSOR (TPS)—3.9/5.2/5.9L ENGINES, THROTTLE	14-44	PRESSURE LEAKAGE TEST, CYLINDER COMBUSTION	9-8
PARK BRAKE CABLE TENSIONER	5-26	POSITION SENSOR—3.9/5.2/5.9L ENGINES, CRANKSHAFT	8-13	PRESSURE (MAP) SENSOR, MANIFOLD ABSOLUTE	8-14,8-4
PARK BRAKE CABLES, REAR	5-18	POSITION SENSOR—3.9/5.2/5.9L ENGINES, CRANKSHAFT	14-28	PRESSURE (MAP) SENSOR TEST—3.9/5.2/5.9L ENGINES, MANIFOLD ABSOLUTE	14-39
PARK BRAKE PEDAL ASSEMBLY	5-19	POSITION SENSOR—3.9L V-6 ENGINE, CRANKSHAFT	8-3	PRESSURE (MAP) SENSOR—3.9/5.2/5.9L ENGINES—PCM INPUT, MANIFOLD ABSOLUTE	14-45
PARK BRAKE RELEASE HANDLE	8-29	POSITION SENSOR—5.2/5.9L V-8 ENGINE, CRANKSHAFT	8-3	PRESSURE, OIL PUMP	9-15,9-50,9-84
PARK, TURN SIGNAL AND SIDE MARKER LAMP	8-12	POSITION SENSOR—PCM INPUT, CAMSHAFT	14-28	PRESSURE, PUMP FLOW RATE	19-4
PARKING BRAKES	5-4	POSITION SENSORS, CAMSHAFT AND CRANKSHAFT	14-40	PRESSURE REGULATOR, FUEL FILTER/FUEL	14-15,14-4
PARK/NEUTRAL POSITION SWITCH	21-124, 21-147,21-29,21-9	POSITION SWITCH, PARK/NEUTRAL	21-124, 21-147,21-29,21-9	PRESSURE RELEASE PROCEDURE, FUEL SYSTEM	14-10
PARK/NEUTRAL SWITCH—PCM INPUT, TRANSMISSION	14-31	POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM	25-15	PRESSURE SENSOR, GOVERNOR SOLENOID	21-148,21-30
PARTS AND LUBRICANT RECOMMENDATIONS	0-1	POWER BRAKE BOOSTER	5-13,5-2	PRESSURE SENSOR—PCM INPUT, OIL	14-30
PASSENGER SIDE AIRBAG DOOR	8-8	POWER DISTRIBUTION, 8W-10	8-2	PRESSURE SENSOR—PCM INPUT, TRANSMISSION GOVERNOR	14-31
PATTERN ANALYSIS, GEAR CONTACT	3-47,3-85	POWER DOOR LOCKS, 8W-61	8-1	PRESSURE SOLENOID—PCM OUTPUT, GOVERNOR	14-35
PATTERNS, TIRE WEAR	22-3	POWER GROUND	14-31	PRESSURE TEST, CYLINDER COMPRESSION	9-7
PCV VALVE TEST—3.9/5.2/5.9L ENGINE	25-16	POWER LOCK MOTOR	8-3,8-6,8-8	PRESSURE TEST, HYDRAULIC	21-10,21-125
PEDAL, ACCELERATOR	14-21	POWER LOCK SWITCH	8-3,8-4,8-8	PRESSURE TEST PORT, FUEL PUMP	14-6
PEDAL ASSEMBLY, PARK BRAKE	5-19	POWER LOCK SYSTEM	8-1	PRESSURE TEST—ALL ENGINES WITH PRESSURE TEST PORT, FUEL PUMP	14-6
PEDAL, BRAKE	5-12,5-2	POWER LOCK SYSTEM AND REMOTE KEYLESS ENTRY SYSTEM	8-4	PRESSURES, TIRE INFLATION	22-2
PER MILE, TIRES REVOLUTIONS	22-6	POWER MIRROR	8-1,8-3	PROBLEMS, TROUBLESHOOTING WIRING	8-10
PERFORMANCE CHARACTERISTICS, RWAL	5-28	POWER MIRROR SWITCH	8-1,8-2	PRODUCTS, AFTERMARKET REPAIR	23-3
PERFORMANCE, COOLANT	7-6	POWER MIRROR SYSTEM	8-1	PROGRAMMING, REMOTE KEYLESS ENTRY TRANSMITTER	8-7
PERFORMANCE, ENGINE	9-2	POWER MIRRORS, 8W-62	8-1	PROPELLER SHAFT	3-13,3-14
PERFORMANCE/MECHANICAL DIAGNOSIS, ENGINE	9-11	POWER OUTLET	8-11,8-22	PROPELLER SHAFT ANGLE MEASUREMENT	3-5
PINION GEAR	3-36,3-67	POWER OUTLET, CIGAR LIGHTER	8-32	PROPELLER SHAFT, FRONT	3-7
PINION GEAR DEPTH	3-42	POWER SEAT, 8W-63	8-1	PROPELLER SHAFT JOINT ANGLE	3-2
PINION GEAR DEPTH, 8 1/4 AXLE	3-80	POWER SEAT ADJUSTER AND MOTORS	8-1,8-2, 8-3	PROPELLER SHAFT, REAR	3-7
PINION GEAR DEPTH, 9 1/4 AXLE	3-82	POWER SEAT SWITCH	8-1,8-2,8-3	PROPELLER SHAFTS	3-1
PINION SEAL	3-63	POWER SEAT SYSTEM	8-1,8-2	P-SERIES PUMP RESERVOIR	19-8
PINION SHAFT SEAL	3-30	POWER STEERING	19-1	PULLEY, PUMP	19-7
PIN-OUTS, 8W-80 CONNECTOR	8-1	POWER STEERING GEAR	19-10,19-21	PUMP - INITIAL OPERATION, POWER STEERING	19-6
PIPE, EXHAUST	11-3	POWER STEERING GEAR LEAKAGE DIAGNOSIS	19-12	PUMP AMPERAGE TEST, FUEL	14-8
PISTON AND CONNECTING ROD ASSEMBLY	9-101,9-109,9-15,9-34,9-50,9-67, 9-75,9-84	POWER STEERING PUMP	19-4,19-7,19-9	PUMP AND REACTION SHAFT SUPPORT, OIL	21-184,21-211,21-63,21-92
PISTON AND CONNECTING ROD INSPECTION	9-41	POWER STEERING PUMP - INITIAL OPERATION	19-6	PUMP BYPASS HOSE, WATER	7-26,7-4
PISTON AND WORM SHAFT, RACK	19-17	POWER STEERING SYSTEM	19-2	PUMP CAPACITY TEST, FUEL	14-7
PISTON, FRONT SERVO	21-183,21-62	POWER WINDOW MOTOR	8-2,8-4	PUMP FLOW RATE AND PRESSURE	19-4
PISTON, REAR SERVO	21-183,21-63	POWER WINDOW SWITCH	8-1,8-3,8-4	PUMP, FUEL	14-4
PISTON RETAINER, OVERRUNNING CLUTCH CAM/OVERDRIVE	21-181,21-61	POWER WINDOW SYSTEM	8-1,8-2	PUMP INLET FILTER, FUEL	14-16
PISTON RETAINER, OVERRUNNING CLUTCH/LOW-REVERSE DRUM/OVERDRIVE	21-210,21-91	POWER WINDOWS, 8W-60	8-1	PUMP (LDP), LEAK DETECTION	25-14,25-17, 25-18
PISTON RINGS, FITTING	9-54,9-88	POWERTRAIN CONTROL MODULE; IGNITION SYSTEM	8-2	PUMP LEAKAGE	19-6
PISTONS, FITTING	9-19,9-54,9-88	POWERTRAIN CONTROL MODULE; SPEED CONTROL SYSTEM	8-2	PUMP MODULE, FUEL	14-16,14-3
PITMAN ARM	19-27	POWERTRAIN CONTROL MODULE (PCM); FUEL SYSTEM	14-26,14-46	PUMP, OIL	9-103,9-109,9-110,9-34,9-40,9-42, 9-68,9-74,9-76
PITMAN SHAFT/SEALS/BEARING	19-14	POWERTRAIN CONTROL MODULE (PCM); IGNITION SYSTEM	8-16	PUMP, POWER STEERING	19-4,19-7,19-9
PIVOT, WIPER LINKAGE	8-12,8-2	POWER-UP MODE	8-2	PUMP PRESSURE, OIL	9-15,9-50,9-84
PLANETARY GEARTRAIN	21-93	PRE-ALIGNMENT INSPECTION	2-2	PUMP PRESSURE TEST—ALL ENGINES WITH PRESSURE TEST PORT, FUEL	14-6
PLANETARY GEARTRAIN/OUTPUT SHAFT	21-189,21-212,21-70	PRECAUTIONS	3-2	PUMP PULLEY	19-7
PLASTIGAGE, MEASURING WITH	9-2	PRECAUTIONS, ABS SERVICE	5-33	PUMP RELAY, FUEL	14-43
PLATE, BRAKE SUPPORT	5-18	PRECAUTIONS AND WARNINGS, SAFETY	23-1	PUMP RELAY-PCM OUTPUT, FUEL	14-33
PLATE, FRONT AXLE SKID	13-5	PRECAUTIONS, SAFETY; BODY	23-4	PUMP RELAYS, ASD AND FUEL	14-38
PLATE LAMP BULB, LICENSE	8-9	PRECAUTIONS, SAFETY; LAMPS	8-1	PUMP RESERVOIR, P-SERIES	19-8
PLATE LAMP, LICENSE	8-13				
PLATE, LIFTGATE SCUFF	23-49				
PLATE, TRANSFER CASE SKID	13-6				
PLATE, VEHICLE IDENTIFICATION NUMBER (VIN)	Intro.-1				
PLATE—4WD VEHICLES, FUEL TANK SKID	13-6				
PLUG CABLE RESISTANCE, SPARK	8-19				
PLUG CABLES, SPARK	8-11,8-2,8-8				
PLUG CONDITIONS, SPARK	8-9				
PLUG, HOUSING END	19-13				
PLUGS, ENGINE CORE	9-105				

Description	Group-Page	Description	Group-Page	Description	Group-Page
PUMP VOLUME CHECK, OIL	21-143,21-25	REAR WHEEL ANTILOCK	5-28,5-33	REPAIR-MOLEX CONNECTORS,	
PUMP, WASHER	8-5	REAR WHEEL ANTILOCK BRAKES	5-28	TERMINAL/CONNECTOR	8-11
PUMP, WATER	7-24,7-36,7-4,7-7	REAR WHEEL ANTI-LOCK BRAKES,		REPAIR—THOMAS AND BETTS	
PURGE SOLENOID, DUTY CYCLE EVAP		8W-34	8-1	CONNECTORS, TERMINAL/CONNECTOR	8-11
CANISTER; EMISSION CONTROL		REAR WHEEL HOUSE LINER	23-41	REPLACEMENT-IN VEHICLE, VALVE	
SYSTEMS	25-14,25-18	REAR WHEEL SPEED SENSOR AND		SPRING AND STEM SEAL	9-59,9-94
PURGE SOLENOID, DUTY CYCLE EVAP		EXCITER RING	5-31	REQUIREMENTS, FUEL	14-1
CANISTER; FUEL SYSTEM	14-46	REAR WINDOW DEFOGGER, 8W-48	8-1	RESERVE/OVERFLOW SYSTEM,	
PURGE SOLENOID VALVE-PCM OUTPUT,		REAR WINDOW DEFOGGER SYSTEM	8-1	COOLANT	7-2
DUTY CYCLE EVAP	14-33	REAR WIPER AND WASHER SYSTEM	8-2	RESERVE/OVERFLOW TANK, COOLANT	7-24
PUSH RODS, ROCKER ARMS	9-59,9-93	REARVIEW MIRROR	23-55	RESERVOIR, MASTER CYLINDER	5-20
QUARTER PANEL TRIM	23-48	REARVIEW MIRROR SUPPORT BRACKET	23-56	RESERVOIR, P-SERIES PUMP	19-8
QUARTER WINDOW GLASS	23-6	RECEIVER, ASH	8-31	RESERVOIR, VACUUM	8-2,8-6
QUICK FILL VALVE	21-123,21-8	RECEIVER, REMOTE KEYLESS ENTRY	8-3	RESERVOIR, WASHER	8-4
QUICK-CONNECT FITTINGS	14-11,14-6	RECLINER, BUCKET SEAT	23-10	RESISTANCE, IGNITION COIL	8-20
RACK, LUGGAGE	23-45	RECOMMENDATIONS, HOISTING	0-10	RESISTANCE, SPARK PLUG CABLE	8-19
RACK PISTON AND WORM SHAFT	19-17	RECOMMENDATIONS, PARTS AND		RESISTANCE TESTS, CHARGING SYSTEM	8-3
RADIAL-PLY TIRES	22-2	LUBRICANT	0-1	RESTRAINT SLEEVE, HEAD	23-14
RADIATOR	7-31,7-36,7-4	RECOMMENDATIONS, TOWING	0-9	RETAINER BUSHING AND SEAL, REAR	21-238,
RADIATOR CAP	7-36	RECOMMENDED FLUID	21-119,21-4	21-262	
RADIATOR CAP—PRESSURE TESTING	7-21	RECOMMENDED LUBRICANT AND FILL			
RADIATOR CAP-TO-FILLER NECK		LEVEL	21-235,21-260	RETAINER, OVERRUNNING CLUTCH	
SEAL—PRESSURE RELIEF CHECK	7-20	RED BRAKE WARNING LAMP	5-2,5-7	CAM/OVERDRIVE PISTON	21-181,21-61
RADIATOR COOLANT FLOW CHECK	7-16	REFERENCES, TORQUE	Intro-8	RETAINER, OVERRUNNING CLUTCH/	
RADIATOR DRAINCOCK	7-35	REGULATOR, ELECTRONIC VOLTAGE	8-2	LOW-REVERSE DRUM/OVERDRIVE	
RADIATOR PRESSURE CAP	7-3	REGULATOR, FRONT DOOR WINDOW	23-31	PISTON	21-210,21-91
RADIO	8-1,8-4,8-6	REGULATOR, FUEL FILTER/FUEL		RETAINER, ROOF RAIL WEATHERSTRIP	23-39
RADIO FREQUENCY INTERFERENCE	8-6	PRESSURE	14-15,14-4	RETRACTOR, 2ND ROW SEAT BELT	23-50
RADIO NOISE SUPPRESSION	8-2	REGULATOR, REAR DOOR WINDOW	23-37	RETRACTOR, 3RD ROW SEAT BELT	23-51
RAIL WEATHERSTRIP AND RETAINER,		REINFORCEMENT, INSTRUMENT PANEL		RETRACTOR, FRONT SEAT BELT	23-49
ROOF	23-39	LOWER	8-30	RETURN—PCM INPUT, SENSOR	14-31
RAIL—3.9/5.2/5.9L ENGINES, FUEL	14-6	RELAY AND FUSE BLOCK	8-4	REVOLUTIONS PER MILE, TIRES	22-6
RAIL—3.9/5.2/5.9L ENGINES, FUEL		RELAY, AUTOMATIC SHUTDOWN (ASD);		RIGHT FRONT FENDER	23-23
INJECTOR	14-17	FUEL SYSTEM	14-43	RING, EXCITER	5-35,5-41
RATE AND PRESSURE, PUMP FLOW	19-4	RELAY, AUTOMATIC SHUTDOWN (ASD);		RING GEAR AND EXCITER RING	3-66
RATINGS, BATTERY SIZE	8-2	IGNITION SYSTEM	8-13,8-3	RING, REAR WHEEL SPEED SENSOR	
RATINGS, GENERATOR	8-7	RELAY, DRIVER UNLOCK	8-4,8-8	AND EXCITER	5-31
RATIOS, TRANSMISSION GEAR	21-120,21-5	RELAY, FUEL PUMP	14-43	RING, RING GEAR AND EXCITER	3-66
RE TRANSMISSION	21-229,21-230	RELAY, HEADLAMP; POWER LOCK		RINGS, FITTING	9-19
RE TRANSMISSION, 42/44	21-2	SYSTEMS	8-4,8-9	RINGS, FITTING PISTON	9-54,9-88
RE TRANSMISSIONS	21-112	RELAY, HEADLAMP; VEHICLE THEFT/		ROAD TEST	8-2
REACTION SHAFT SUPPORT, OIL PUMP	21-184,	SECURITY SYSTEMS	8-3,8-5	ROAD TEST, ANALYZING	21-10,21-124
21-211,21-63,21-92		RELAY, HORN; HORN SYSTEMS	8-1,8-2,8-3	ROAD TESTING	21-124,21-9
READING AND COURTESY LAMP	8-2,8-7	RELAY, HORN; POWER LOCK SYSTEMS	8-4,8-9	ROCKER ARMS AND PUSH RODS	9-59,9-93
READING AND COURTESY LAMP BULB	8-7	RELAY, HORN; VEHICLE THEFT/		ROD ASSEMBLY, PISTON AND	
READING LAMP BULB, OVERHEAD		SECURITY SYSTEMS	8-3,8-6	CONNECTING	9-101,9-109,9-15,9-34,9-50,9-67,
CONSOLE	8-10	RELAY, INTERMITTENT WIPE	8-14,8-4,8-9	9-75,9-84	
READING LAMP, OVERHEAD CONSOLE	8-15	RELAY SENSE—PCM INPUT, AUTOMATIC		ROD BEARINGS, CONNECTING	9-20
REAR AXLE	3-60	SHUTDOWN (ASD)	14-28	ROD BEARINGS, FITTING CONNECTING	9-55,
REAR BAND ADJUSTMENT	21-214	RELAY, STARTER	8-2,8-7	9-89	
REAR BEARING, OUTPUT SHAFT	21-152,21-35	RELAY TEST, AUTOMATIC SHUTDOWN		ROD END, INNER TIE	19-27
REAR BRAKE SHOES	5-16	(ASD)	8-4	ROD END, TIE	19-26
REAR BUMPER	13-2	RELAY—PCM OUTPUT, AIR		ROD INSPECTION, PISTON AND	
REAR BUMPER FASCIA	13-3	CONDITIONING (A/C) CLUTCH	14-32	CONNECTING	9-41
REAR CLUTCH	21-188,21-212,21-68,21-92	RELAY—PCM OUTPUT, AUTO		RODS, ROCKER ARMS AND PUSH	9-59,9-93
REAR DOOR	23-34	SHUTDOWN (ASD)	14-32	ROLLOVER VALVE	25-13
REAR DOOR GLASS	23-38	RELAY—PCM OUTPUT, TRANSMISSION	14-35	ROLLOVER VALVE(S); EMISSION	
REAR DOOR GLASS RUN CHANNELS	23-38	RELAY-PCM OUTPUT, FUEL PUMP	14-33	CONTROL SYSTEMS	25-18
REAR DOOR GLASS RUN		RELAYS; POWER LOCK SYSTEMS	8-7	ROLLOVER VALVE(S); FUEL SYSTEM	14-5
WEATHERSTRIP	23-37	RELAYS; VEHICLE THEFT/SECURITY		ROOF RAIL WEATHERSTRIP AND	
REAR DOOR HINGE	23-34	SYSTEMS	8-4	RETAINER	23-39
REAR DOOR INNER BELT		RELAYS, ASD AND FUEL PUMP	14-38	ROTATION	22-4
WEATHERSTRIP	23-36	RELEASE CABLE, HOOD	23-20	ROTOR, DISC BRAKE	5-15,5-8
REAR DOOR INSIDE HANDLE ACTUATOR	23-36	RELEASE HANDLE, PARK BRAKE	8-29	ROTOR, DISTRIBUTOR	8-7
REAR DOOR LATCH	23-35	RELEASE PROCEDURE, FUEL SYSTEM		ROTOR MACHINING, DISC	5-11
REAR DOOR LATCH STRIKER	23-35	PRESSURE	14-10	RUN CHANNELS, FRONT DOOR LOWER	
REAR DOOR OPENING WEATHERSTRIP	23-36	RELIEF CHECK, RADIATOR CAP-TO-		GLASS	23-31
REAR DOOR OUTER BELT		FILLER NECK SEAL—PRESSURE	7-20	RUN CHANNELS, REAR DOOR GLASS	23-38
WEATHERSTRIP	23-36	REMINDER LAMP, SEAT BELT	8-11,8-23	GLASS	23-32
REAR DOOR OUTSIDE HANDLE	23-35	REMOTE KEYLESS ENTRY RECEIVER	8-3	RUN WEATHERSTRIP, FRONT DOOR	
REAR DOOR SECONDARY SEAL	23-38	REMOTE KEYLESS ENTRY SYSTEM	8-1	GLASS	23-37
REAR DOOR STATIONARY GLASS	23-6	REMOTE KEYLESS ENTRY SYSTEM,		RUNNING LAMP MODULE (DRLM),	
REAR DOOR TRIM PANEL	23-33	POWER LOCK SYSTEM	8-4	DAYTIME	8-1,8-16
REAR DOOR WATERDAM	23-34	REMOTE KEYLESS ENTRY	8-3,8-6	RUNOUT	3-4
REAR DOOR WINDOW REGULATOR	23-37	TRANSMITTER		RUNOUT, TIRE AND WHEEL	22-7
REAR DRUM BRAKE	5-23,5-24	REMOTE KEYLESS ENTRY		RWAL BRAKE BLEEDING	5-33
REAR GLASS HEATING GRID	8-1,8-2	TRANSMITTER BATTERY		RWAL COMPONENT LOCATION	5-30
REAR GLASS HEATING GRID REPAIR	8-3	REPLACEMENT	8-7	RWAL PERFORMANCE	
REAR LIGHTING, 8W-51	8-1	REMOTE KEYLESS ENTRY		CHARACTERISTICS	5-28
REAR OIL SEALS, CRANKSHAFT	9-103,9-36	TRANSMITTER PROGRAMMING	8-7	RWAL VALVE	5-31,5-34
REAR PARK BRAKE CABLES	5-18	REPAIR, ALUMINUM THREAD	21-144,21-26	SAFETY CERTIFICATION LABEL, VEHICLE	Intro-1
REAR PROPELLER SHAFT	3-7	REPAIR DAMAGED OR WORN THREADS	9-5	SAFETY LATCH, HOOD	23-19
REAR RETAINER BUSHING AND SEAL	21-238,	REPAIR PRODUCTS, AFTERMARKET	23-3	SAFETY PRECAUTIONS; BODY	23-4
21-262		REPAIR, REAR GLASS HEATING GRID	8-3	SAFETY PRECAUTIONS; LAMPS	8-1
REAR SEAL AREA LEAKS, INSPECTION	9-9	REPAIR, THREADED HOLE	Intro-6	SAFETY PRECAUTIONS AND WARNINGS	23-1
REAR SERVO	21-211,21-92	REPAIR, WIRING	8-10	SANDING, BUFFING, AND POLISHING,	
REAR SERVO PISTON	21-183,21-63	REPAIRING LEAKS	22-5	FINESSE	23-2
REAR SUSPENSION	2-13,2-16			SCAN TOOL, DRB	7-9

Description	Group-Page	Description	Group-Page	Description	Group-Page
SCHEDULE—A	0-3	SENSITIVE DEVICES, ELECTROSTATIC		SERVO PISTON, FRONT	21-183,21-62
SCHEDULE—B	0-4	DISCHARGE (ESD)	8-8	SERVO PISTON, REAR	21-183,21-63
SCHEDULES, MAINTENANCE	0-3	SENSOR, AMBIENT TEMPERATURE	8-8	SERVO, REAR	21-211,21-92
SCHEMATICS, HYDRAULIC	21-216,21-97	SENSOR AND EXCITER RING, REAR		SERVO, SPEED CONTROL	8-1,8-3,8-4
SCHEMATICS, VACUUM	25-17	WHEEL SPEED	5-31	SET, OVERSHOOT/UNDERSHOOT	
SCUFF PLATE, LIFTGATE	23-49	SENSOR, BATTERY TEMPERATURE	8-2,8-5,8-7	FOLLOWING SPEED CONTROL	8-4
SEAL AND BEARING, 8 1/4 AND 9 1/4		SENSOR, CAMSHAFT POSITION; FUEL	14-46	SHAFT ANGLE MEASUREMENT, PROPELLER	3-5
LD AXLE	3-62	SYSTEM		SHAFT, AXLE	3-34,3-61
SEAL AND BEARING, AXLE SHAFT	3-34	SENSOR, CAMSHAFT POSITION; IGNITION SYSTEM	8-14,8-3,8-7	SHAFT BUSHING, DISTRIBUTOR DRIVE	9-27, 9-65
SEAL AREA LEAKS, INSPECTION FOR REAR	9-9	SENSOR, CRANKSHAFT POSITION; FUEL SYSTEM	14-46	SHAFT FRONT BEARING, OUTPUT	21-153,21-35
SEAL, B-PILLAR	23-32	SENSOR, CRANKSHAFT POSITION; IGNITION SYSTEM	8-7	SHAFT, FRONT PROPELLER	3-7
SEAL, C—PILLAR	23-38	SENSOR, ENGINE COOLANT TEMPERATURE	8-14,8-4,8-8	SHAFT JOINT ANGLE, PROPELLER	3-2
SEAL, COWL	23-21	SENSOR, GOVERNOR SOLENOID AND PRESSURE	21-148,21-30	SHAFT, PLANETARY	
SEAL, CRANKSHAFT FRONT OIL	9-35	SENSOR, INTAKE MANIFOLD AIR TEMPERATURE	8-14,8-4,8-8	GEARTRAIN/OUTPUT	21-189,21-212,21-70
SEAL, FRONT DOOR SECONDARY	23-32	SENSOR, MAP	8-7	SHAFT, PROPELLER	3-13,3-14
SEAL, FRONT OUTPUT SHAFT	21-237,21-261	SENSOR, OXYGEN	14-46	SHAFT, RACK PISTON AND WORM	19-17
SEAL, HOOD	23-21	SENSOR RETURN—PCM INPUT	14-31	SHAFT REAR BEARING, OUTPUT	21-152,21-35
SEAL, PINION	3-63	SENSOR SUPPLY—PRIMARY, FIVE VOLT	14-29	SHAFT, REAR PROPELLER	3-7
SEAL, PINION SHAFT	3-30	SENSOR SUPPLY—SECONDARY, FIVE VOLT	14-29	SHAFT SEAL AND BEARING, AXLE	3-34
SEAL, REAR DOOR SECONDARY	23-38	SENSOR TEST—3.9/5.2/5.9L ENGINES, MANIFOLD ABSOLUTE PRESSURE (MAP)	14-39	SHAFT SEAL, FRONT OUTPUT	21-237,21-261
SEAL, REAR RETAINER BUSHING	21-238,21-262	SENSOR, THROTTLE POSITION	8-14,8-4	SHAFT SEAL, PINION	3-30
SEAL REPLACEMENT, YOKE	21-146,21-29	SENSOR (TPS)—3.9/5.2/5.9L ENGINE, THROTTLE POSITION	14-41	SHAFT SPEED SENSOR—PCM INPUT, OUTPUT	14-30
SEAL REPLACEMENT-IN VEHICLE, VALVE SPRING AND STEM	9-59,9-94	SENSOR (TPS)—3.9/5.2/5.9L ENGINE—PCM INPUT, THROTTLE POSITION	14-31	SHAFT SUPPORT, OIL PUMP AND REACTION	21-184,21-211,21-63,21-92
SEAL—FRONT, CRANKSHAFT OIL	9-103,9-69	SENSOR (TPS)—3.9/5.2/5.9L ENGINES, THROTTLE POSITION	14-44	SHAFTS, PROPELLER	3-1
SEAL—PRESSURE RELIEF CHECK, RADIATOR CAP-TO-FILLER NECK	7-20	SENSOR, WASHER FLUID LEVEL	8-5	SHAFT/SEALS/BEARING, PITMAN	19-14
SEALS, CRANKSHAFT REAR OIL	9-103,9-36	SENSOR, WHEEL SPEED	5-34,5-38,5-41	SHIELD, SIDE	23-8
SEALS—REAR, CRANKSHAFT OIL	9-69	SENSOR—3.9/5.2/5.9L ENGINE, ENGINE COOLANT TEMPERATURE	14-40	SHIELDS, HEAT	11-1,11-5
SEAT, 2ND ROW	23-53	SENSOR—3.9/5.2/5.9L ENGINE, CRANKSHAFT POSITION	8-13	SHIFT INTERLOCK, COLUMN	8-19
SEAT, 3RD ROW	23-53	SENSOR—3.9/5.2/5.9L ENGINES, ENGINE COOLANT TEMPERATURE	14-47	SHIFT LEVER	21-237,21-261
SEAT, 8W-63 POWER	8-1	SENSOR—3.9/5.2/5.9L ENGINES, INTAKE MANIFOLD AIR TEMPERATURE	14-41	SHIFT LEVER, GEAR	19-25
SEAT ADJUSTER AND MOTORS, POWER	8-1, 8-2,8-3	SENSOR—3.9/5.2/5.9L ENGINES, INTAKE MANIFOLD AIR TEMPERATURE	14-47	SHIFT LINKAGE ADJUSTMENT	21-255,21-283
SEAT BACK, 2ND ROW	23-11	SENSOR—3.9L V-6 ENGINE, CRANKSHAFT POSITION	8-3	SHIFT SEQUENCE, 3-4	21-122,21-7
SEAT BACK, 2ND ROW CENTER	23-13	SENSOR—5.2/5.9L V-8 ENGINE, CRANKSHAFT POSITION	8-3	SHIFT SOLENOID—PCM OUTPUT, THREE-FOUR	14-34
SEAT BACK, 3RD ROW	23-14	SENSOR—PCM INPUT, BATTERY TEMPERATURE	14-28	SHIFT VALVE OPERATION	21-122,21-7
SEAT BACK, BUCKET	23-9	SENSOR—PCM INPUT, CAMSHAFT POSITION	14-28	SHOCK ABSORBER	2-14,2-6
SEAT BACK COVER, 2ND ROW	23-11	SENSOR—PCM INPUT, FUEL LEVEL	14-29	SHOCK DIAGNOSIS	2-6
SEAT BACK COVER, 2ND ROW CENTER	23-13	SENSOR—PCM INPUT, OIL PRESSURE	14-30	SHOCK DIAGNOSIS, SPRING	2-13
SEAT BACK COVER, 3RD ROW	23-14	SENSOR—PCM INPUT, OUTPUT SHAFT SPEED	14-30	SHOES, DISC BRAKE	5-14
SEAT BACK COVER/CUSHION, BUCKET	23-9	SENSOR—PCM INPUT, OXYGEN	14-30	SHOES, REAR BRAKE	5-16
SEAT BACK FRAME, BUCKET	23-9	SENSOR—PCM INPUT, TRANSMISSION GOVERNOR PRESSURE	14-31	SHUDDER OR VIBRATION DURING ACCELERATION	3-16
SEAT BELT BUCKLE, 2ND ROW	23-51	SENSOR—PCM INPUT, TRANSMISSION TEMPERATURE	14-31	SHUTDOWN (ASD) RELAY, AUTOMATIC; FUEL SYSTEM	14-43
SEAT BELT BUCKLE, 3RD ROW	23-52	SENSOR—4WD, FRONT WHEEL SPEED	5-40	SHUTDOWN (ASD) RELAY, AUTOMATIC; IGNITION SYSTEM	8-13,8-3
SEAT BELT BUCKLE, FRONT	23-50	SENSORS, CAMSHAFT AND CRANKSHAFT POSITION	14-40	SHUTDOWN (ASD) RELAY SENSE—PCM INPUT, AUTOMATIC	14-28
SEAT BELT REMINDER LAMP	8-11,8-23	SENSORS, OXYGEN	14-40	SHUTDOWN (ASD) RELAY TEST, AUTOMATIC	8-4
SEAT BELT RETRACTOR, 2ND ROW	23-50	SEQUENCE, 3-4 SHIFT	21-122,21-7	SHUTDOWN (ASD) RELAY—PCM OUTPUT, AUTO	14-32
SEAT BELT RETRACTOR, 3RD ROW	23-51	SERVO CABLE	8-2,8-5	SIDE AIRBAG DOOR, PASSENGER	8-8
SEAT BELT RETRACTOR, FRONT	23-49	SERVO, FRONT	21-210,21-91	SIDE AIRBAG TRIM COVER AND HORN SWITCH, DRIVER	8-7
SEAT BELT SWITCH, DRIVER	8-2,8-5			SIDE BEARINGS, DIFFERENTIAL	3-36,3-65
SEAT, BUCKET	23-52			SIDE GEAR CLEARANCE	3-87
SEAT CUSHION, 2ND ROW	23-11			SIDE MARKER LAMP BULB, FRONT	8-8
SEAT CUSHION, 2ND ROW CENTER	23-13			SIDE MARKER LAMP, PARK, TURN SIGNAL	8-12
SEAT CUSHION COVER, 2ND ROW	23-11			SIDE MOLDINGS, BODY	23-40
SEAT CUSHION COVER, 2ND ROW CENTER	23-12			SIDE SHIELD	23-8
SEAT CUSHION COVER, 3RD ROW	23-13			SIDE VIEW MIRROR	23-25
SEAT CUSHION FRAME, 3RD ROW	23-14			SIGNAL AND BACK-UP LAMP BULB, TAIL, STOP, TURN	8-8
SEAT CUSHION FRAME, BUCKET	23-10			SIGNAL AND BACK-UP LAMP, TAIL, STOP, TURN	8-13
SEAT CUSHION/COVER, BUCKET	23-9			SIGNAL AND HAZARD WARNING SYSTEMS, TURN	8-3
SEAT CUSHION/COVER, CENTER	23-10			SIGNAL AND SIDE MARKER LAMP, PARK, TURN	8-12
SEAT DOME/READING LAMP, 2ND	8-14			SIGNAL GROUND—PCM INPUT	14-31
SEAT DOME/READING LAMP BULB, 2ND	8-10			SIGNAL INDICATOR LAMP, TURN; INSTRUMENT PANEL SYSTEMS	8-12,8-24
SEAT LATCHES, 2ND ROW	23-12			SIGNAL INDICATOR LAMP, TURN; SIGNAL AND HAZARD WARNING SYSTEMS	8-3
SEAT RECLINER, BUCKET	23-10			SIGNAL LAMP BULBS, PARK AND TURN	8-8
SEAT SWITCH, POWER	8-1,8-2,8-3			SIGNAL LAMP, TURN	8-3
SEAT SYSTEM, POWER	8-1,8-2			SIGNAL SWITCH AND HAZARD WARNING SWITCH, TURN	8-2
SEAT TRACK, BUCKET	23-8			SIGNAL SYSTEM, TURN	8-1
SEAT/CONSOLE, CENTER	23-10			SIGNALS, 8W-52 TURN	8-1
SEATS	23-8			SILENCER PAD, HOOD	23-18
SECONDARY SEAL, FRONT DOOR	23-32				
SECONDARY SEAL, REAR DOOR	23-38				
SECTION IDENTIFICATION	8-5				
SECURITY LAMP; INSTRUMENT PANEL SYSTEMS	8-11,8-23				
SECURITY LAMP; VEHICLE THEFT/SECURITY SYSTEMS	8-3				
SECURITY SYSTEM, 8W-39 VEHICLE THEFT	8-1				
SECURITY SYSTEM, VEHICLE THEFT	8-1,8-3				
SELECTION AND ADDITIVES, COOLANT	7-7				
SELECTOR INDICATOR, GEAR	8-28,8-9				
SENDING UNIT, FUEL GAUGE	14-10,14-17,14-4				
SENSE—PCM INPUT, AUTOMATIC SHUTDOWN (ASD) RELAY	14-28				
SENSE—PCM INPUT, IGNITION CIRCUIT	14-29				

Description	Group-Page	Description	Group-Page	Description	Group-Page
SILL TRIM, DOOR	23-46	SPRINGS, VALVES AND VALVE	9-15,9-50,9-61, 9-95	SUSPENSION HEIGHT	2-3
SINGLE CARDAN UNIVERSAL JOINT	3-8	SPRINGS, VALVES, GUIDES	9-39	SUSPENSION, REAR	2-13,2-16
SIZE AND RATINGS, BATTERY	8-2	SPRINGS—CYLINDER HEAD REMOVED, VALVES AND VALVE	9-26	SWITCH AND HAZARD WARNING SWITCH, TURN SIGNAL	8-2
SKID PLATE, FRONT AXLE	13-5	STABILIZER BAR	2-10,2-14	SWITCH AND KEY CYLINDER, IGNITION	8-16
SKID PLATE, TRANSFER CASE	13-6	STALL TEST ANALYSIS	21-128,21-13	SWITCH AND KEY LOCK CYLINDER, IGNITION	8-4
SKID PLATE—4WD VEHICLES, FUEL TANK	13-6	STALL TEST, CONVERTER	21-127,21-13	SWITCH AND WASHER SWITCH, WIPER	8-14, 8-3,8-8
SLEEVE, HEAD RESTRAINT	23-14	STANDARD DIFFERENTIAL	3-25,3-41,3-55,3-71	SWITCH, DEFOGGER	8-1,8-3,8-4
SNAP, DRIVELINE	3-26,3-57	STANDARD SERVICE INFORMATION	9-1	SWITCH, DOOR AJAR	8-3,8-4
SOLENOID AND PRESSURE SENSOR, GOVERNOR	21-148,21-30	START TEST, FAILURE TO	8-5	SWITCH, DOOR LOCK CYLINDER	8-3,8-4
SOLENOID CIRCUITS, SPEED CONTROL	8-1	STARTER	8-2,8-7	SWITCH, DRIVER DOOR AJAR	8-2,8-3
SOLENOID, DUTY CYCLE EVAP CANISTER PURGE; EMISSION CONTROL SYSTEMS	25-14,25-18	STARTER RELAY	8-2,8-7	SWITCH, DRIVER SEAT BELT	8-2,8-5
SOLENOID, DUTY CYCLE EVAP CANISTER PURGE; FUEL SYSTEM	14-46	STARTING PROCEDURE, JUMP	0-8	SWITCH, DRIVER SIDE AIRBAG TRIM COVER AND HORN	8-7
SOLENOID VALVE-PCM OUTPUT, DUTY CYCLE EVAP PURGE	14-33	STARTING SYSTEM	8-1,8-2,8-8	SWITCH, FOG LAMP	8-25
SOLENOID—PCM OUTPUT, GOVERNOR PRESSURE	14-35	STARTING SYSTEM, 8W-21	8-1	SWITCH, GLOVE BOX LAMP	8-32
SOLENOID—PCM OUTPUT, THREE-FOUR SHIFT	14-34	STARTING, TOWING AND HOISTING, JUMP	0-8	SWITCH, HEADLAMP; CHIME/BUZZER WARNING SYSTEMS	8-2,8-4
SOLENOID—PCM OUTPUT, TORQUE CONVERTOR CLUTCH (TCC)	14-34	STATE DISPLAY TEST MODE	25-2	SWITCH, HEADLAMP; INSTRUMENT PANEL SYSTEMS	8-25
SOLENOIDS—PCM OUTPUT, SPEED CONTROL	14-34	STATIONARY GLASS	23-4	SWITCH, HORN	8-1,8-3,8-4
SOURCE (+)—PCM OUTPUT, GENERATOR FIELD	14-33	STATIONARY GLASS, REAR DOOR	23-6	SWITCH, IGNITION	19-23
SPACER, COLLAPSIBLE	3-31	STEERING COLUMN	19-22,19-23	SWITCH, KEY-IN IGNITION	8-2,8-4
SPARE TIRE WINCH	13-6	STEERING COLUMN OPENING COVER AND KNEE BLOCKER	8-27	SWITCH, LIFTGATE AJAR	8-3,8-4
SPARE TIRE—TEMPORARY	22-2	STEERING GEAR	19-12,19-19	SWITCH, LIFTGATE LOCK CYLINDER	8-3,8-5
SPARK AT COIL, TESTING	8-4	STEERING GEAR LEAKAGE DIAGNOSIS, POWER	19-12	SWITCH, MULTI-FUNCTION	8-4,8-5
SPARK PLUG CABLE RESISTANCE	8-19	STEERING GEAR, POWER	19-10,19-21	SWITCH, OVERDRIVE OFF	21-122,21-7
SPARK PLUG CABLES	8-11,8-2,8-8	STEERING KNUCKLE	2-7	SWITCH, PARK/NEUTRAL POSITION	21-124, 21-147,21-29,21-9
SPARK PLUG CONDITIONS	8-9	STEERING LINKAGE	19-26,19-28	SWITCH, POWER LOCK	8-3,8-4,8-8
SPARK PLUGS	8-12,8-19,8-2	STEERING, POWER	19-1	SWITCH, POWER MIRROR	8-1,8-2
SPEAKER	8-1,8-4,8-8	STEERING PUMP - INITIAL OPERATION, POWER	19-6	SWITCH, POWER SEAT	8-1,8-2,8-3
SPECIAL TOOLS—HEADLAMP ALIGNMENT	8-6	STEERING PUMP, POWER	19-4,19-7,19-9	SWITCH, POWER WINDOW	8-1,8-3,8-4
SPECIFICATIONS, 3.9L ENGINE	9-44	STEERING SYSTEM	19-1	SWITCH, STOP LAMP; BRAKES	5-12,5-2,5-24, 5-33,5-7
SPECIFICATIONS, 5.2L ENGINE	9-78	STEERING SYSTEM, POWER	19-2	SWITCH, STOP LAMP; SPEED CONTROL SYSTEM	8-2,8-3,8-5
SPECIFICATIONS, 5.9L ENGINE	9-112	STEERING WHEEL	8-12	SWITCH, TURN SIGNAL SWITCH AND HAZARD WARNING	8-2
SPECIFICATIONS, LUBRICANT	3-24	STEM SEAL REPLACEMENT-IN VEHICLE, VALVE SPRING	9-59,9-94	SWITCH, WIPER SWITCH AND WASHER	8-14, 8-3,8-8
SPECIFICATIONS, TORQUE; BODY	23-59	STOP LAMP (CHMSL) BULB, CENTER HIGH MOUNTED	8-8	SWITCHES, CHIME WARNING SYSTEM	8-5
SPECIFICATIONS, TORQUE; ENGINE	9-115,9-47, 9-81	STOP LAMP (CHMSL), CENTER HIGH MOUNTED	8-12	SWITCHES, SPEED CONTROL	8-1,8-3,8-5
SPECIFICATIONS, TORQUE; EXHAUST SYSTEM AND INTAKE MANIFOLD	11-11	STOP LAMP SWITCH; BRAKES	5-12,5-2,5-24, 5-33,5-7	SWITCHES—PCM INPUT, SPEED CONTROL	14-31
SPECIFICATIONS, TORQUE; FRAME AND BUMPERS	13-12	STOP LAMP SWITCH; SPEED CONTROL SYSTEM	8-2,8-3,8-5	SWITCH—PCM INPUT, BRAKE	14-28
SPEED AND DISTANCE—PCM INPUT, VEHICLE	14-32	STOP, TURN SIGNAL AND BACK-UP LAMP BULB, TAIL	8-8	SWITCH—PCM INPUT, OVERDRIVE/OVERRIDE	14-30
SPEED CONTROL, 8W-33 VEHICLE	8-1	STOP, TURN SIGNAL AND BACK-UP LAMP, TAIL	8-13	SWITCH—PCM INPUT, TRANSMISSION PARK/NEUTRAL	14-31
SPEED CONTROL SERVO	8-1,8-3,8-4	STORAGE BIN DOOR, GARAGE DOOR OPENER	8-8	SYMBOLS	8-5
SPEED CONTROL SET, OVERSHOOT/UNDERSHOOT FOLLOWING	8-4	STORAGE BIN DOOR, SUNGLASSES	8-8	SYMBOLS, INTERNATIONAL	0-1
SPEED CONTROL SOLENOID CIRCUITS	8-1	STORAGE BIN, GARAGE DOOR OPENER	8-2	SYMBOLS, INTERNATIONAL VEHICLE CONTROL AND DISPLAY	Intro-3
SPEED CONTROL SOLENOIDS—PCM OUTPUT	14-34	STORAGE BIN, SUNGLASSES	8-3	SYSTEM, 8W-20 CHARGING	8-1
SPEED CONTROL SWITCHES	8-1,8-3,8-5	STORAGE DOOR, FLOOR CARGO	23-55	SYSTEM, 8W-21 STARTING	8-1
SPEED CONTROL SWITCHES—PCM INPUT	14-31	STRETCH, MEASURING TIMING CHAIN	9-53, 9-87	SYSTEM, 8W-31 TRANSMISSION CONTROL	8-1
SPEED CONTROL SYSTEM, ON-BOARD DIAGNOSTIC TEST	8-2	STRETCH, TIMING CHAIN	9-19	SYSTEM, 8W-39 VEHICLE THEFT SECURITY	8-1
SPEED INPUT, VEHICLE	8-2	STRIKER, FRONT DOOR LATCH	23-30	SYSTEM, 8W-43 AIRBAG	8-1
SPEED KNOCK, LOW	3-26,3-57	STRIKER, GLOVE BOX LATCH	8-33	SYSTEM, 8W-47 AUDIO	8-1
SPEED OPERATION, TIRE PRESSURE FOR HIGH	22-3	STRIKER, HOOD LATCH	23-20,23-58	SYSTEM, AIRBAG	8-1,8-3,8-4
SPEED SENSOR AND EXCITER RING, REAR WHEEL	5-31	STRIKER, LIFTGATE LATCH	23-44	SYSTEM AND REMOTE KEYLESS ENTRY SYSTEM, POWER LOCK	8-4
SPEED SENSOR, WHEEL	5-34,5-38,5-41	STRIKER, REAR DOOR LATCH	23-35	SYSTEM, ANTILOCK BRAKE	5-36
SPEED SENSOR—PCM INPUT, OUTPUT SHAFT	14-30	STRIPE, TAPE	23-39	SYSTEM, AUDIO	8-1,8-2
SPEED SENSOR—4WD, FRONT WHEEL	5-40	STUDS, WHEEL MOUNTING	2-11	SYSTEM, AUTOMATIC DAY/NIGHT MIRROR	8-4
SPEEDOMETER	8-15,8-6	SUNGLASSES STORAGE BIN	8-3	SYSTEM, BASE BRAKE	5-1,5-4
SPEEDS, VIBRATION AT HIGHWAY	3-16	SUNGLASSES STORAGE BIN DOOR	8-8	SYSTEM, BLEEDING ABS BRAKE	5-38
SPLICE INFORMATION, 8W-70	8-1	SUNVISOR	23-56	SYSTEM, BRAKE	5-2
SPLICE LOCATIONS	8-1,8-7	SUPPLY TEST, VACUUM	8-3	SYSTEM CAPACITIES, COOLING	7-37
SPLICE LOCATIONS, 8W-95	8-1	SUPPLY—PRIMARY, FIVE VOLT SENSOR	14-29	SYSTEM, CHARGING	8-2
SPOOL VALVE	19-15	SUPPLY—SECONDARY, FIVE VOLT SENSOR	14-29	SYSTEM, CHIME WARNING	8-1
SPRING AND SHOCK DIAGNOSIS	2-13	SUPPORT BRACKET, INSTRUMENT PANEL CENTER	8-30	SYSTEM CIRCULATION, COOLING	7-2
SPRING AND STEM SEAL REPLACEMENT-IN VEHICLE, VALVE	9-59,9-94	SUPPORT BRACKET, REARVIEW MIRROR	23-56	SYSTEM COMPONENTS, COOLING	7-2
SPRING EYE BUSHINGS	2-15	SUPPORT CYLINDER, LIFTGATE	23-42	SYSTEM, COOLANT RESERVE/OVERFLOW	7-2
SPRINGS, ADJUSTMENT AT AXLE WITH LEAF	3-14	SUPPORT, OIL PUMP AND REACTION SHAFT	21-184,21-211,21-63,21-92	SYSTEM, COOLING	7-1,7-10,7-37
SPRINGS, LEAF	2-15	SUPPORT PLATE, BRAKE	5-18	SYSTEM, DEFOGGER	8-2

Description	Group-Page	Description	Group-Page	Description	Group-Page
SYSTEM, FUEL	14-49	TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINES—PCM INPUT, ENGINE		THROTTLE BODY—3.9/5.2/5.9L ENGINES	14-35, 14-43
SYSTEM, FUEL DELIVERY	14-3	COOLANT	14-29	THROTTLE CABLE	14-21
SYSTEM, FUEL INJECTION	14-23	TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINES—PCM INPUT, INTAKE MANIFOLD AIR	14-29	THROTTLE POSITION SENSOR	8-14,8-4
SYSTEM, HAZARD WARNING	8-1	TEMPERATURE SENSOR—PCM INPUT, BATTERY	14-28	THROTTLE POSITION SENSOR (TPS)—3.9/5.2/5.9L ENGINE	14-41
SYSTEM, HORN	8-1	TEMPERATURE SENSOR—PCM INPUT, TRANSMISSION	14-31	THROTTLE POSITION SENSOR (TPS)—3.9/5.2/5.9L ENGINE—PCM INPUT	14-31
SYSTEM, HOSES AND CLAMPS, COOLING	7-7	TEMPERATURE WARNING LAMP, TRANSMISSION OIL	8-11,8-24	THROTTLE POSITION SENSOR (TPS)—3.9/5.2/5.9L ENGINES	14-44
SYSTEM, HYDRAULIC CONTROL	21-122,21-7	TENSION, ACCESSORY DRIVE BELT TENSIONER (AUTO)—ACCESSORY DRIVE BELT	7-4	THROTTLE VALVE CABLE	21-124,21-9
SYSTEM, IGNITION	8-2	TENSIONER, AUTOMATIC BELT	7-34	THROTTLE VALVE CABLE ADJUSTMENT, TRANSMISSION	21-213,21-94
SYSTEM LAMP, ANTI-LOCK BRAKE	8-16,8-7	TENSIONER, PARK BRAKE CABLE	5-26	TIE ROD END	19-26
SYSTEM, LUBRICATION	9-51,9-85	TENSIONER, TIMING CHAIN	9-30	TIE ROD END, INNER	19-27
SYSTEM, METRIC	Intro-6	TERMINAL REPLACEMENT	8-13	TIMER MODULE, 8W-45 CENTRAL	8-1
SYSTEM, ON-BOARD DIAGNOSTIC TEST FOR CHARGING	8-5	TERMINAL REPLACEMENT, CONNECTOR	8-12	TIMER MODULE, CENTRAL; CHIME/BUZZER WARNING SYSTEMS	8-1,8-3
SYSTEM, ON-BOARD DIAGNOSTIC TEST FOR SPEED CONTROL	8-2	TERMINAL/CONNECTOR REPAIR-MOLEX CONNECTORS	8-11	TIMER MODULE, CENTRAL; HORN SYSTEMS	8-2
SYSTEM OPERATION, CHARGING	8-1	TERMINAL/CONNECTOR REPAIR—THOMAS AND BETTS CONNECTORS	8-11	TIMER MODULE, CENTRAL; INSTRUMENT PANEL SYSTEMS	8-34,8-4
SYSTEM, POSITIVE CRANKCASE VENTILATION (PCV)	25-15	TEST ANALYSIS, STALL	21-128,21-13	TIMER MODULE, CENTRAL; POWER LOCK SYSTEMS	8-2,8-5
SYSTEM, POWER LOCK	8-1	TEST, ANALYZING ROAD	21-10,21-124	TIMER MODULE, CENTRAL; VEHICLE THEFT/SECURITY SYSTEMS	8-2
SYSTEM, POWER LOCK SYSTEM AND REMOTE KEYLESS ENTRY	8-4	TEST, AUTOMATIC SHUTDOWN (ASD) RELAY	8-4	TIMER MODULE, CENTRAL; WIPER AND WASHER SYSTEMS	8-3
SYSTEM, POWER MIRROR	8-1	TEST, COLD CRANKING	8-3	TIMING CHAIN	9-63,9-97
SYSTEM, POWER SEAT	8-1,8-2	TEST, CONTROL CIRCUIT	8-5	TIMING CHAIN AND TENSIONER	9-30
SYSTEM, POWER STEERING	19-2	TEST, CONVERTER STALL	21-127,21-13	TIMING CHAIN COVER	9-28,9-62,9-96
SYSTEM, POWER WINDOW	8-1,8-2	TEST, CURRENT OUTPUT	8-4	TIMING CHAIN STRETCH	9-19
SYSTEM PRESSURE, FUEL	14-22	TEST, CYLINDER COMBUSTION PRESSURE LEAKAGE	9-8	TIMING CHAIN STRETCH, MEASURING	9-53, 9-87
SYSTEM PRESSURE RELEASE PROCEDURE, FUEL	14-10	TEST, CYLINDER COMPRESSION PRESSURE	9-7	TIMING, IGNITION	8-19,8-7
SYSTEM, REAR WINDOW DEFOGGER	8-1	TEST, FAILURE TO START	8-5	TIMING, VALVE	9-18,9-53,9-87
SYSTEM, REAR WIPER AND WASHER	8-2	TEST, FEED CIRCUIT	8-4	TIRE AND WHEEL BALANCE	22-9
SYSTEM, REMOTE KEYLESS ENTRY	8-1	TEST FOR CHARGING SYSTEM, ON-BOARD DIAGNOSTIC	8-5	TIRE AND WHEEL RUNOUT	22-7
SYSTEM RESISTANCE TESTS, CHARGING	8-3	TEST FOR SPEED CONTROL SYSTEM, ON-BOARD DIAGNOSTIC	8-2	TIRE INFLATION PRESSURES	22-2
SYSTEM, STARTING	8-1,8-2,8-8	TEST, FUEL INJECTOR	14-10	TIRE NOISE OR VIBRATION	22-4
SYSTEM, STEERING	19-1	TEST, FUEL PRESSURE LEAK DOWN	14-7	TIRE PRESSURE FOR HIGH SPEED OPERATION	22-3
SYSTEM SWITCHES, CHIME WARNING	8-5	TEST, FUEL PUMP AMPERAGE	14-8	TIRE WEAR PATTERNS	22-3
SYSTEM, TURN SIGNAL	8-1	TEST, FUEL PUMP CAPACITY	14-7	TIRE WINCH, SPARE	13-6
SYSTEM, VEHICLE THEFT SECURITY	8-1,8-3	TEST, HYDRAULIC PRESSURE	21-10,21-125	TIRE—TEMPORARY, SPARE	22-2
SYSTEM, WASHER	8-15,8-7	TEST, HYDROMETER	8-6	TIRES	22-1
SYSTEM, WINDSHIELD WASHER	8-1	TEST, IGNITION COIL	8-5	TIRES, CLEANING	22-6
SYSTEM, WINDSHIELD WIPER	8-1	TEST, IGNITION-OFF DRAW	8-10	TIRES, RADIAL-PLY	22-2
SYSTEM, WIPER	8-5	TEST INDICATOR, BUILT-IN	8-5	TIRES, REPLACEMENT	22-3
SYSTEM—CLEANING/REVERSE FLUSHING, COOLING	7-23	TEST, LOAD	8-8	TIRES REVOLUTIONS PER MILE	22-6
SYSTEM—DEAERATION, COOLING	7-21	TEST MODE, CIRCUIT ACTUATION	25-2	TO START TEST, FAILURE	8-5
SYSTEM—DRAINING AND FILLING, COOLING	7-22	TEST MODE, STATE DISPLAY	25-2	TOE WHEEL	5-40
SYSTEM—TESTING FOR LEAKS, COOLING	7-16	TEST, OPEN-CIRCUIT VOLTAGE	8-8	TOOL, DRB SCAN	7-9
SYSTEMS, 8W-30 FUEL/IGNITION	8-1	TEST PORT, FUEL PUMP PRESSURE	14-6	TOOLS, TROUBLESHOOTING	8-8
SYSTEMS, LAMP	8-16	TEST—ALL ENGINES WITH PRESSURE	14-6	TOOLS—HEADLAMP ALIGNMENT, SPECIAL	8-6
SYSTEMS, MONITORED	25-8	TEST, ROAD	8-2	TOP COVER, INSTRUMENT PANEL	8-38
SYSTEMS, TURN SIGNAL AND HAZARD WARNING	8-3	TEST, TRAC-LOK	3-60	TORQUE; DIFFERENTIAL AND DRIVELINE	3-14, 3-23
TABLES AND CHARTS—RE TRANSMISSION, DIAGNOSIS	21-129,21-15	TEST, VACUUM SUPPLY	8-3	TORQUE; TRANSMISSION	21-256,21-284
TACHOMETER	8-15,8-6	TEST, VOLTAGE DROP	8-11	TORQUE CHART; BRAKES	5-27,5-35,5-41
TACHOMETER—PCM OUTPUT	14-34	TESTING FOR SPARK AT COIL	8-4	TORQUE CHART; CHARGING SYSTEM	8-7
TAIL, STOP, TURN SIGNAL AND BACK-UP LAMP	8-13	TESTING, RADIATOR CAP—PRESSURE	7-21	TORQUE CHART; EMISSION CONTROL SYSTEMS	25-20
TAIL, STOP, TURN SIGNAL AND BACK-UP LAMP BULB	8-8	TESTING, ROAD	21-124,21-9	TORQUE CHART; FUEL SYSTEM	14-22,14-48
TAILPIPE	11-5	TESTING TRANSMISSION CLUTCH AND BAND OPERATION, AIR	21-128,21-14	TORQUE CHART; IGNITION SYSTEM	8-20
TAKE OUTS	8-8	TEST—3.9/5.2/5.9L ENGINE, PCV VALVE	25-16	TORQUE CHART; SPEED CONTROL SYSTEM	8-7
TAMPER ALERT	8-2	TEST—3.9/5.2/5.9L ENGINES, MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR	14-39	TORQUE CHART; STEERING	19-21,19-25,19-28, 19-9
TANK CAPACITY, FUEL	14-22	TEST—ALL ENGINES WITH PRESSURE TEST PORT, FUEL PUMP PRESSURE	14-6	TORQUE CHART; SUSPENSION	2-12,2-16
TANK, COOLANT RESERVE/OVERFLOW	7-24	TESTS, CHARGING SYSTEM RESISTANCE	8-3	TORQUE CHART; TIRES AND WHEELS	22-9
TANK FILLER TUBE CAP, FUEL	14-21,14-6	TESTS, TROUBLESHOOTING	8-9	TORQUE CONVERTER	21-146,21-28
TANK, FUEL	14-19,14-5	THEFT SECURITY SYSTEM, 8W-39 VEHICLE	8-1	TORQUE CONVERTER, ELECTRONIC LOCK-UP	21-120,21-5
TANK SKID PLATE—4WD VEHICLES, FUEL	13-6	THEFT SECURITY SYSTEM, VEHICLE	8-1,8-3	TORQUE CONVERTOR CLUTCH (TCC) SOLENOID—PCM OUTPUT	14-34
TAPE STRIPE	23-39	THERMOMETER	8-2,8-4	TORQUE REFERENCES	Intro-8
TAPPETS, HYDRAULIC	9-10,9-106,9-27,9-38, 9-61,9-72,9-95	THERMOMETER DISPLAY MODULE, TRIP COMPUTER, COMPASS	8-3,8-7	TORQUE SPECIFICATIONS; BODY	23-59
TEMPERATURE GAUGE, COOLANT	8-14,8-5	THERMOSTAT	7-29,7-4	TORQUE SPECIFICATIONS; ENGINE	9-115,9-47, 9-81
TEMPERATURE SENSOR, AMBIENT	8-8	THERMOSTAT—GAS ENGINES	7-20	TORQUE SPECIFICATIONS; EXHAUST SYSTEM AND INTAKE MANIFOLD	11-11
TEMPERATURE SENSOR, BATTERY	8-2,8-5,8-7	THREAD REPAIR, ALUMINUM	21-144,21-26	TORQUE SPECIFICATIONS; FRAME AND BUMPERS	13-12
TEMPERATURE SENSOR, ENGINE COOLANT	8-14,8-4,8-8	THREADED HOLE REPAIR	Intro-6	TORSION BAR	2-7
TEMPERATURE SENSOR, INTAKE MANIFOLD AIR	8-14,8-4,8-8	THREADS, REPAIR DAMAGED OR WORN	9-5	TOUCH-UP, PAINTED SURFACE	23-2
TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINE, ENGINE COOLANT	14-40	THREE-FOUR SHIFT SOLENOID—PCM OUTPUT	14-34		
TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINE, INTAKE MANIFOLD AIR	14-41	THROTTLE BODY MINIMUM AIR FLOW CHECK PROCEDURE	14-42		
TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINES, ENGINE COOLANT	14-47				
TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINES, INTAKE MANIFOLD AIR	14-47				

Description	Group-Page	Description	Group-Page	Description	Group-Page
TOW, 8W-54 TRAILER	8-1	TROUBLESHOOTING WIRING PROBLEMS	8-10	VEHICLE DIMENSIONS; FRAME AND BUMPERS	13-8
TOWEL BAR	23-8	TUBE CAP, FUEL TANK FILLER	14-21,14-6	VEHICLE DIMENSIONS; INTRODUCTION	Intro.-2
TOWING AND HOISTING, JUMP STARTING	0-8	TUBES, FLUSHING COOLERS	21-143,21-25	VEHICLE EMISSION CONTROL INFORMATION (VECI) LABEL	25-16
TOWING, FOUR-WHEEL-DRIVE VEHICLE	0-9	TUBES/LINES/HOSES AND CLAMPS, FUEL	14-11	VEHICLE IDENTIFICATION NUMBER (VIN) PLATE	Intro.-1
TOWING RECOMMENDATIONS (TPS)—3.9/5.2/5.9L ENGINE, THROTTLE POSITION SENSOR	14-41	TURN SIGNAL AND BACK-UP LAMP BULB, TAIL, STOP	8-8	VEHICLE INSPECTION	3-16
(TPS)—3.9/5.2/5.9L ENGINE—PCM INPUT, THROTTLE POSITION SENSOR	14-31	TURN SIGNAL AND BACK-UP LAMP, TAIL, STOP	8-13	VEHICLE SAFETY CERTIFICATION LABEL	Intro.-1
(TPS)—3.9/5.2/5.9L ENGINES, THROTTLE POSITION SENSOR	14-44	TURN SIGNAL AND HAZARD WARNING SYSTEMS	8-3	VEHICLE SERVICE, CYLINDER HEAD COMPONENTS—IN	9-24
TRACK, BUCKET SEAT	23-8	TURN SIGNAL AND SIDE MARKER LAMP, PARK	8-12	VEHICLE SPEED AND DISTANCE—PCM INPUT	14-32
TRAC-LOK	3-80	TURN SIGNAL INDICATOR LAMP; INSTRUMENT PANEL SYSTEMS	8-12,8-24	VEHICLE SPEED CONTROL, 8W-33	8-1
TRAC-LOK DIFFERENTIAL, 8 1/4	3-72	TURN SIGNAL INDICATOR LAMP; TURN SIGNAL AND HAZARD WARNING SYSTEMS	8-3	VEHICLE SPEED INPUT	8-2
TRAC-LOK DIFFERENTIAL, 9 1/4	3-76	TURN SIGNAL LAMP	8-3	VEHICLE THEFT SECURITY SYSTEM	8-1,8-3
TRAC-LOK OPERATION	3-56	TURN SIGNAL LAMP BULBS, PARK	8-8	VEHICLE THEFT SECURITY SYSTEM, 8W-39	8-1
TRAC-LOK DIFFERENTIAL NOISE	3-57	TURN SIGNAL SWITCH AND HAZARD WARNING SWITCH	8-2	VEHICLE TOWING, FOUR-WHEEL-DRIVE	0-9
TRAC-LOK TEST	3-60	TURN SIGNAL SYSTEM	8-1	VEHICLE, VALVE SPRING AND STEM SEAL REPLACEMENT-IN	9-59,9-94
TRAILER HITCH	13-7	TURN SIGNALS, 8W-52	8-1	VENTILATION (PCV) SYSTEM, POSITIVE CRANKCASE	25-15
TRAILER TOW, 8W-54	8-1	URNS, NOISE AND/OR VIBRATION IN UNBALANCE	3-16	VIBRATION	3-26,3-3,3-57
TRANSFER CASE	21-237,21-261	UNDERHOOD LAMP	8-13	VIBRATION AT HIGHWAY SPEEDS	3-16
TRANSFER CASE IDENTIFICATION	21-235, 21-259	UNDERHOOD LAMP BULB	8-9	VIBRATION DAMPER	9-28,9-61,9-95
TRANSFER CASE, NV231	21-235,21-239,21-253	UNIT, FUEL GAUGE SENDING	14-10,14-17,14-4	VIBRATION DURING ACCELERATION, SHUDDER OR	3-16
TRANSFER CASE, NV242	21-259,21-263,21-282	UNIT, HYDRAULIC CONTROL	5-37	VIBRATION IN TURNS, NOISE AND/OR	3-16
TRANSFER CASE SKID PLATE	13-6	UNIT, OVERDRIVE	21-151,21-193,21-212,21-33, 21-75,21-93	VIBRATION, TIRE NOISE OR	22-4
TRANSMISSION	21-110,21-144,21-169,21-210, 21-26,21-50,21-91	UNIVERSAL JOINT, SINGLE CARDAN UNLOCK RELAY, DRIVER	8-4,8-8	VIEW MIRROR, SIDE	23-25
TRANSMISSION, 42/44 RE	21-2	UNSCHEDULED INSPECTION	0-3	VISCOUS FAN DRIVE	7-18
TRANSMISSION, 42/44RE AUTOMATIC	21-1	UPPER BALL JOINT	2-6	VISCOUS FAN/DRIVE	7-35,7-8
TRANSMISSION, 46RE	21-117	UPPER SUSPENSION ARM	2-9	VISUAL INSPECTION—3.9/5.2/5.9L ENGINES	14-35
TRANSMISSION, 46RE AUTOMATIC	21-116	UPPER TRIM, LIFTGATE OPENING	23-47	VOLT SENSOR SUPPLY—PRIMARY, FIVE	14-29
TRANSMISSION CLUTCH AND BAND OPERATION, AIR TESTING	21-128,21-14	USAGE, FASTENER	Intro.-6	VOLT SENSOR SUPPLY—SECONDARY, FIVE	14-29
TRANSMISSION CONTROL SYSTEM, 8W-31	8-1	V-6 ENGINE, CRANKSHAFT POSITION SENSOR—3.9L	8-3	VOLTAGE DROP TEST	8-11
TRANSMISSION DIAGNOSIS, AUTOMATIC	21-123,21-8	V-6 ENGINE, ENGINE FIRING ORDER—3.9L	8-19	VOLTAGE REGULATOR, ELECTRONIC	8-2
TRANSMISSION, DIAGNOSIS TABLES AND CHARTS—RE	21-129,21-15	V-8 ENGINE, CRANKSHAFT POSITION SENSOR—5.2L/5.9L	8-3	VOLTAGE TEST, OPEN-CIRCUIT	8-8
TRANSMISSION FILL PROCEDURE	21-142,21-24	V-8 ENGINES, ENGINE FIRING ORDER—5.2L/5.9L	8-19	VOLTAGE—PCM INPUT, BATTERY	14-28
TRANSMISSION GEAR RATIOS	21-120,21-5	VACUUM RESERVOIR	8-2,8-6	VOLTMETER	8-16,8-6
TRANSMISSION GOVERNOR PRESSURE SENSOR—PCM INPUT	14-31	VACUUM SCHEMATICS	25-17	VOLUME CHECK, OIL PUMP	21-143,21-25
TRANSMISSION IDENTIFICATION	21-119,21-4	VACUUM SUPPLY TEST	8-3	WARNING LAMP, ABS	5-38
TRANSMISSION OIL COOLER, AUTOMATIC	7-5	VALUE, LOAD	25-12	WARNING LAMP, BRAKE	8-17,8-7
TRANSMISSION OIL TEMPERATURE WARNING LAMP	8-11,8-24	VALVE BODY	21-148,21-153,21-207,21-215, 21-32,21-36,21-90,21-96	WARNING LAMP, LOW FUEL	8-10,8-21
TRANSMISSION PARK/NEUTRAL SWITCH—PCM INPUT	14-31	VALVE CABLE ADJUSTMENT, TRANSMISSION THROTTLE	21-213,21-94	WARNING LAMP, LOW WASHER FLUID	8-10, 8-21
TRANSMISSION, RE	21-229,21-230	VALVE CABLE, THROTTLE	21-124,21-9	WARNING LAMP, RED BRAKE	5-2,5-7
TRANSMISSION RELAY—PCM OUTPUT	14-35	VALVE, COMBINATION	5-13,5-3,5-8	WARNING LAMP, TRANSMISSION OIL TEMPERATURE	8-11,8-24
TRANSMISSION TEMPERATURE SENSOR—PCM INPUT	14-31	VALVE, CONVERTER DRAINBACK	21-123,21-8	WARNING LAMPS, BRAKE	5-32
TRANSMISSION THROTTLE VALVE CABLE ADJUSTMENT	21-213,21-94	VALVE OPERATION, SHIFT	21-122,21-7	WARNING SWITCH, TURN SIGNAL SWITCH AND HAZARD	8-2
TRANSMISSIONS, RE	21-112	VALVE, QUICK FILL	21-123,21-8	WARNING SYSTEM, CHIME	8-1
TRANSMITTER BATTERY REPLACEMENT, REMOTE KEYLESS ENTRY	8-7	VALVE, ROLLOVER	25-13	WARNING SYSTEM, HAZARD	8-1
TRANSMITTER PROGRAMMING, REMOTE KEYLESS ENTRY	8-7	VALVE, RWAL	5-31,5-34	WARNING SYSTEM SWITCHES, CHIME	8-5
TRANSMITTER, REMOTE KEYLESS ENTRY	8-3,8-6	VALVE SERVICE	9-107,9-72	WARNING SYSTEMS, TURN SIGNAL AND HAZARD	8-3
TREAD WEAR INDICATORS	22-3	VALVE SERVICE, CONVERTER DRAINBACK CHECK	21-142,21-25	WARNINGS & CAUTIONS, SERVICE	5-2
TRIM, A-PILLAR	23-46	VALVE, SPOOL	19-15	WARNINGS, NOTES, CAUTIONS	8-7
TRIM, B-PILLAR	23-46	VALVE SPRING AND STEM SEAL REPLACEMENT-IN VEHICLE	9-59,9-94	WARNINGS, SAFETY PRECAUTIONS	23-1
TRIM COVER AND HORN SWITCH, DRIVER SIDE AIRBAG	8-7	VALVE SPRINGS, VALVES	9-15,9-50,9-61,9-95	WASHER FLUID LEVEL SENSOR	8-5
TRIM COVER, COWL	23-45	VALVE SPRINGS—CYLINDER HEAD REMOVED, VALVES	9-26	WASHER FLUID WARNING LAMP, LOW	8-10, 8-21
TRIM, C-PILLAR	23-47	VALVE TEST—3.9/5.2/5.9L ENGINE, PCV	25-16	WASHER NOZZLE AND PLUMBING	8-5
TRIM, DOOR SILL	23-46	VALVE TIMING	9-18,9-53,9-87	WASHER PUMP	8-5
TRIM, D-PILLAR	23-48	VALVE-PCM OUTPUT, DUTY CYCLE EVAP PURGE SOLENOID	14-33	WASHER RESERVOIR	8-4
TRIM, LIFTGATE OPENING UPPER	23-47	VALVES AND VALVE SPRINGS	9-15,9-50,9-61, 9-95	WASHER SWITCH, WIPER SWITCH	8-14,8-3,8-8
TRIM PANEL, FRONT DOOR	23-26	VALVES AND VALVE SPRINGS—CYLINDER HEAD REMOVED	9-26	WASHER SYSTEM	8-15,8-7
TRIM PANEL, LIFTGATE	23-42	VALVES, GUIDES AND SPRINGS	9-39	WASHER SYSTEM, REAR WIPER	8-2
TRIM PANEL, REAR DOOR	23-33	VALVE(S), ROLLOVER; EMISSION CONTROL SYSTEMS	25-18	WASHER SYSTEM, WINDSHIELD	8-1
TRIM PANELS, INTERIOR	23-16	VALVE(S), ROLLOVER; FUEL SYSTEM	14-5	WATER LEAKS	23-16
TRIM, QUARTER PANEL	23-48	VARIATION ADJUSTMENT, COMPASS	8-4	WATER PUMP	7-24,7-36,7-4,7-7
TRIP COMPUTER	8-1	VECI LABEL; FUEL SYSTEM	14-22,14-48	WATER PUMP BYPASS HOSE	7-26,7-4
TRIP COMPUTER, COMPASS, AND THERMOMETER DISPLAY MODULE	8-3,8-7	VECI LABEL; IGNITION SYSTEM	8-19	WATERDAM, FRONT DOOR	23-27
TRIP DEFINITION	25-10	VEHICLE CONTROL AND DISPLAY SYMBOLS, INTERNATIONAL	Intro.-3	WATERDAM, REAR DOOR	23-34
TRIP ODOMETER, ODOMETER	8-15,8-5			WEAR INDICATORS, TREAD	22-3
TROUBLE CODES, DIAGNOSTIC	25-2			WEAR PATTERNS, TIRE	22-3
TROUBLESHOOTING TESTS	8-9			WEATHERSTRIP AND RETAINER, ROOF RAIL	23-39
TROUBLESHOOTING TOOLS	8-8			WEATHERSTRIP, FRONT DOOR GLASS RUN	23-32
				WEATHERSTRIP, FRONT DOOR INNER BELT	23-30
				WEATHERSTRIP, FRONT DOOR OPENING	23-32

Description	Group-Page	Description	Group-Page	Description	Group-Page
WEATHERSTRIP, FRONT DOOR OUTER BELT	23-30	WHEEL MOUNTING STUDS	2-11	WINDSHIELD	23-4
WEATHERSTRIP, LIFTGATE OPENING	23-44	WHEEL OPENING MOLDING	23-40	WINDSHIELD WASHER SYSTEM	8-1
WEATHERSTRIP, REAR DOOR GLASS RUN	23-37	WHEEL RUNOUT, TIRE	22-7	WINDSHIELD WIPER SYSTEM	8-1
WEATHERSTRIP, REAR DOOR INNER BELT	23-36	WHEEL SPEED SENSOR	5-34,5-38,5-41	WIPE RELAY, INTERMITTENT	8-14,8-4,8-9
WEATHERSTRIP, REAR DOOR OPENING	23-36	WHEEL SPEED SENSOR AND EXCITER RING, REAR	5-31	WIPER AND WASHER SYSTEM, REAR	8-2
WEATHERSTRIP, REAR DOOR OUTER BELT	23-36	WHEEL SPEED SENSOR-4WD, FRONT	5-40	WIPER ARM	8-10
WHEEL	22-7	WHEEL, STEERING	8-12	WIPER ARM AND BLADE	8-2
WHEEL ALIGNMENT	2-1,2-3	WHEEL, TONE	5-40	WIPER BLADE	8-10
WHEEL ANTI-LOCK BRAKES, 8W-34 REAR	8-1	WHEELHOUSE LINER, FRONT	23-21	WIPER LINKAGE AND PIVOT	8-12,8-2
WHEEL ANTILOCK BRAKES, FOUR	5-36	WHEELS	22-7	WIPER MOTOR	8-12,8-2
WHEEL ANTILOCK BRAKES, REAR	5-28	WINCH, SPARE TIRE	13-6	WIPER SWITCH AND WASHER SWITCH	8-14,8-3,8-8
WHEEL ANTILOCK, REAR	5-28,5-33	WIND NOISE	23-17	WIPER SYSTEM	8-5
WHEEL BALANCE, TIRE	22-9	WINDOW DEFOGGER, 8W-48 REAR	8-1	WIPER SYSTEM, WINDSHIELD	8-1
WHEEL CYLINDER	5-17,5-23,5-24	WINDOW DEFOGGER SYSTEM, REAR	8-1	WIPERS, 8W-53	8-1
WHEEL HOUSE LINER, REAR	23-41	WINDOW GLASS, QUARTER	23-6	WIRING PROBLEMS, TROUBLESHOOTING	8-10
WHEEL INSPECTION	22-7	WINDOW MOTOR, POWER	8-2,8-4	WIRING REPAIR	8-10
WHEEL INSTALLATION	22-8	WINDOW REGULATOR, FRONT DOOR	23-31	WIRING/TERMINAL	8-14
		WINDOW REGULATOR, REAR DOOR	23-37	WORM SHAFT, RACK PISTON	19-17
		WINDOW SWITCH, POWER	8-1,8-3,8-4	WORN THREADS, REPAIR DAMAGED OR	9-5
		WINDOW SYSTEM, POWER	8-1,8-2	YOKE SEAL REPLACEMENT	21-146,21-29
		WINDOWS, 8W-60 POWER	8-1		