

SECTION

MA

MAINTENANCE

A

B

C

CONTENTS

E

PRECAUTIONS	2	Changing Oil Filter	17	F
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	Changing Spark Plugs (Platinum - Tipped Type) ...	18	
PREPARATION	3	Checking EVAP Vapor Lines	19	
Special Service Tool	3	CHASSIS AND BODY MAINTENANCE	20	G
Commercial Service Tool	3	Checking Exhaust System	20	
GENERAL MAINTENANCE	4	Checking Clutch Fluid Level and Leaks	20	
Explanation of General Maintenance	4	Checking M/T Oil	20	H
PERIODIC MAINTENANCE	6	Changing M/T Oil	20	
Introduction of Periodic Maintenance	6	Checking A/T Fluid	21	
Schedule 1	6	Changing A/T Fluid	22	I
EMISSION CONTROL SYSTEM MAINTENANCE	6	Balancing Wheels (Bonding Weight Type)	23	
CHASSIS AND BODY MAINTENANCE	7	REMOVAL	23	
Schedule 2	8	WHEEL BALANCE ADJUSTMENT	23	
EMISSION CONTROL SYSTEM MAINTENANCE	8	Tire Rotation	25	J
CHASSIS AND BODY MAINTENANCE	8	Checking Brake Fluid Level and Leaks	25	
RECOMMENDED FLUIDS AND LUBRICANTS	10	Checking Brake Lines and Cables	25	
Fluids and Lubricants	10	Checking Disc Brake	26	K
SAE Viscosity Number	11	ROTOR	26	
GASOLINE ENGINE OIL	11	CALIPER	26	
ANTI-FREEZE COOLANT MIXTURE RATIO	11	PAD	26	
ENGINE MAINTENANCE	12	Checking Steering Gear and Linkage	27	MA
Drive Belts	12	STEERING GEAR	27	
CHECKING DRIVE BELTS	12	STEERING LINKAGE	27	
TENSION ADJUSTMENT	12	Checking Power Steering Fluid and Lines	27	M
Changing Engine Coolant	14	Axle and Suspension Parts	28	
DRAINING ENGINE COOLANT	14	Drive Shaft	29	
REFILLING ENGINE COOLANT	14	Lubricating Locks, Hinges and Hood Latch	30	
FLUSHING COOLING SYSTEM	16	Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters	30	
Checking Fuel Lines	16	SERVICE DATA AND SPECIFICATIONS (SDS)	31	
Changing Air Cleaner Filter	16	Standard and Limit	31	
VISCOUS PAPER TYPE	16	SPARK PLUGS (PLATINUM-TIPPED TYPE) ...	31	
Changing Engine Oil	16	BELT DEFLECTION AND TENSION	31	
		Chassis and Body Maintenance	31	
		WHEEL BALANCE	31	

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

ELS000SQ

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

PREPARATION


PREPARATION

PFP:00002

Special Service Tool





ELS000SR

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name		Description
KV10115801 (J38956) Oil filter cap wrench	 <p>NT375</p>	Removing oil filter a: 64.3 mm (2.531 in)

Commercial Service Tool

ELS000SS

Tool name (Kent-Moore No.)		Description
Belt tension gauge (BT3373-F)	 <p>AMA126</p>	Checking drive belt tension
Spark plug wrench	 <p>S-NT047</p>	Removing and installing spark plugs
Coolant Refill Tool (J-45695)	 <p>LMA053</p>	For refilling engine cooling system
Power Tool	 <p>PBIC0190E</p>	Loosening bolts and nuts

GENERAL MAINTENANCE

GENERAL MAINTENANCE

PFP:00000

Explanation of General Maintenance

ELS000ST

General maintenance includes those items which should be checked during the normal day-to-day operation of the vehicle. They are essential if the vehicle is to continue operating properly. The owners can perform checks and inspections themselves or have their NISSAN dealers do them.

OUTSIDE THE VEHICLE

The maintenance items listed here should be performed from time to time, unless otherwise specified.

Item		Reference page
Tires	Check the pressure including the spare, at least once a month and always prior to a long distance trip with a gauge. Adjust to the specified pressure if necessary. Check carefully for damage, cuts or excessive wear.	WT-6
Wheel nuts	When checking the tires, make sure no nuts are missing, and check for any loose nuts. Tighten if necessary.	WT-5
Windshield	Clean the windshield on a regular basis. Check windshield at least every six months for cracks or other damage. Repair as necessary.	GW-11
Tire rotation	Tires should be rotated every 12,000 km (7,500 miles).	MA-25
Wheel alignment and balance	If the vehicle pulls to either side while driving on a straight and level road, or if you detect uneven or abnormal tire wear, there may be a need for wheel alignment. If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed.	FSU-6, "Front Wheel Alignment" and MA-23, "Balancing Wheels (Bonding Weight Type)"
Windshield wiper blades	Check for cracks or wear if they do not wipe properly. Repair as necessary.	—
Doors and engine hood	Check that all doors and the engine hood operate smoothly as well as the trunk lid and back hatch. Also make sure that all latches lock securely. Lubricate if necessary. Make sure that the secondary latch keeps the hood from opening when the primary latch is released. When driving in areas using road salt or other corrosive materials, check lubrication frequently.	MA-30
Lamps	Make sure that the headlamps, stop lamps, tail lamps, turn signal lamps, and other lamps are all operating properly and installed securely. Also check headlamp aim. Clean the headlamps on a regular basis.	LT-39 (US), LT-57 (Canada)

INSIDE THE VEHICLE

The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance, cleaning the vehicle, etc.

Item		Reference page
Warning lamps and chimes	Make sure that all warning lamps and chimes are operating properly.	—
Windshield wiper and washer	Check that the wipers and washer operate properly and that the wipers do not streak.	—
Windshield defroster	Check that the air comes out of the defroster outlets properly and in sufficient quantity when operating the heater or air conditioner.	—
Steering wheel	Check that it has the specified play. Be sure to check for changes in the steering condition, such as excessive play, hard steering or strange noises.	PS-8
Seats	Check seat position controls such as seat adjusters, seatback recliner, etc. to make sure they operate smoothly and that all latches lock securely in every position. Check that the head restraints move up and down smoothly and that the locks (if equipped) hold securely in all latched positions. Check that the latches lock securely for folding-down rear seatbacks.	—
Seat belts	Check that all parts of the seat belt system (e.g. buckles, anchors, adjusters and retractors) operate properly and smoothly, and are installed securely. Check the belt webbing for cuts, fraying, wear or damage.	MA-30
Clutch pedal	Make sure the pedal operates smoothly and check that it has proper clearance.	CL-6
Accelerator pedal	Check the pedal for smooth operation and make sure the pedal does not catch or require uneven effort. Keep the floor mats away from the pedal.	—
Brakes	Check that the brake does not pull the vehicle to one side when applied.	BR-23

GENERAL MAINTENANCE

Item		Reference page
Brake pedal and booster	Check the pedal for smooth operation and make sure it has the proper distance under it when depressed fully. Check the brake booster function. Be sure to keep the floor mats away from the pedal.	BR-6, "BRAKE PEDAL" and BR-18, "BRAKE BOOSTER"
Parking brake	Check that the lever has the proper travel and make sure that the vehicle is held securely on a fairly steep hill when only the parking brake is applied.	PB-3, "Inspection"
Automatic transaxle "Park" mechanism	Check that the lock release button on the selector lever operates properly and smoothly. On a fairly steep hill check that the vehicle is held securely with the selector lever in the "P" position without applying any brakes.	—

UNDER THE HOOD AND VEHICLE

The maintenance items listed here should be checked periodically (e.g. each time you check the engine oil or refuel).

Item		Reference page
Windshield washer fluid	Check that there is adequate fluid in the tank.	—
Engine coolant level	Check the coolant level when the engine is cold.	MA-14
Radiator and hoses	Check the front of the radiator and clean off any dirt, insects, leaves, etc., that may have accumulated. Make sure the hoses have no cracks, deformation, deterioration or loose connections.	—
Brake and clutch fluid levels	Make sure that the brake and clutch fluid levels are between the "MAX" and "MIN" lines on the reservoirs.	MA-25 (brakes), MA-20 (clutch)
Battery	Check the fluid level in each cell. It should be between the "MAX" and "MIN" lines. Vehicles operated in high temperatures or under severe conditions require frequent checks of the battery fluid level.	SC-4
Engine drive belts	Make sure that no belt is frayed, worn, cracked or oily.	MA-12
Engine oil level	Check the level on the dipstick after parking the vehicle on a level spot and turning off the engine.	MA-16
Power steering fluid level and lines	Check the level on the dipstick with the engine off. Check the lines for improper attachment, leaks, cracks, etc.	MA-27
Automatic transaxle fluid level	Check the level on the dipstick after putting the selector lever in "P" with the engine idling.	MA-21
Exhaust system	Make sure there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes, immediately locate the trouble and correct it.	MA-20
Underbody	The underbody is frequently exposed to corrosive substances such as those used on icy roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter, the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt can easily accumulate.	—
Fluid leaks	Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If you should notice any leaks or gasoline fumes are evident, check for the cause and correct it immediately.	—

PERIODIC MAINTENANCE

PERIODIC MAINTENANCE

PFP:00026

Introduction of Periodic Maintenance

ELS000SU

Two different maintenance schedules are provided, and should be used, depending upon the conditions in which the vehicle is mainly operated. After 60,000 miles (96,000 km) or 48 months, continue the periodic maintenance at the same mileage/time intervals.

Schedule 1	Follow Periodic Maintenance Schedule 1 if the driving habits frequently include one or more of the following driving conditions: <ul style="list-style-type: none"> Repeated short trips of less than 5 miles (8 km). Repeated short trips of less than 10 miles (16 km) with outside temperatures remaining below freezing. Operating in hot weather in stop-and-go "rush hour" traffic. Extensive idling and/or low speed driving for long distances, such as police, taxi or door-to-door delivery use. Driving in dusty conditions. Driving on rough, muddy, or salt spread roads. Towing a trailer, using a camper or a car-top carrier. 	Emission Control System Maintenance	MA-6
		Chassis and Body Maintenance	MA-7
Schedule 2	Follow Periodic Maintenance Schedule 2 if none of driving conditions shown in Schedule 1 apply to the driving habits.	Emission Control System Maintenance	MA-8
		Chassis and Body Maintenance	MA-8

Schedule 1

ELS000SV

EMISSION CONTROL SYSTEM MAINTENANCE

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. [: At the mileage intervals only

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	3.75 (6) 3	7.50 (12) 6	11.25 (18) 9	15 (24) 12	18.75 (30) 15	22.5 (36) 18	26.25 (42) 21	30 (48) 24	
Drive belts	NOTE (1)									MA-12
Air cleaner filter	NOTE (2)								[R]	MA-16
EVAP vapor lines									I*	MA-19
Fuel lines									I*	MA-16
Fuel filter	NOTE (3)									—
Engine coolant	NOTE (4)									MA-14
Engine oil		R	R	R	R	R	R	R	R	MA-16
Engine oil filter (Use part No. 15208 65F01 or equivalent.)		R	R	R	R	R	R	R	R	MA-17
Spark plugs (PLATINUM-TIPPED type)		Replace every 105,000 miles (169,000 km).								MA-18
Intake & exhaust valve clearance*	NOTE (5)									EM-89

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	33.75 (54) 27	37.5 (60) 30	41.25 (66) 33	45 (72) 36	48.75 (78) 39	52.5 (84) 42	56.25 (90) 45	60 (96) 48	
Drive belts	NOTE (1)								I*	MA-12
Air cleaner filter	NOTE (2)								[R]	MA-16
EVAP vapor lines									I*	MA-19
Fuel lines									I*	MA-16
Fuel filter	NOTE (3)									-
Engine coolant	NOTE (4)								R*	MA-14

PERIODIC MAINTENANCE

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	33.75 (54) 27	37.5 (60) 30	41.25 (66) 33	45 (72) 36	48.75 (78) 39	52.5 (84) 42	56.25 (90) 45	60 (96) 48	
Engine oil		R	R	R	R	R	R	R	R	MA-16
Engine oil filter 15208 65F01 or equivalent.		R	R	R	R	R	R	R	R	MA-17
Spark plugs (PLATINUM-TIPPED type)		Replace every 105,000 miles (169,000 km).								MA-18
Intake & exhaust valve clearance*	NOTE (5)									EM-89

NOTE:

- (1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months. Replace the drive belts if found damaged.
- (2) If operating mainly in dusty conditions, more frequent maintenance may be required.
- (3) Maintenance-free item. For service procedures, go to the FL section.
- (4) After 60,000 miles (96,000 km) or 48 months, replace every 30,000 miles (48,000 km) or 24 months.
- (5) If valve noise increases, inspect valve clearance.

* Maintenance items and intervals with “*” are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

CHASSIS AND BODY MAINTENANCE

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary.

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	3.75 (6) 3	7.50 (12) 6	11.25 (18) 9	15 (24) 12	18.75 (30) 15	22.5 (36) 18	26.25 (42) 21	30 (48) 24	
Brake lines & cables					I				I	MA-25
Brake pads & rotors			I		I		I		I	MA-26
Automatic transaxle fluid & manual transaxle gear oil	NOTE (1)				I				I	MA-22 (A/T) or MA-20 (M/T)
Steering gear & linkage, axle & suspension parts			I		I		I		I	MA-27 , MA-28
Tire rotation	NOTE (2)									MA-25
Exhaust system			I		I		I		I	MA-20
Front drive shaft boot			I		I		I		I	MA-29
In-cabin microfilter					R				R	ATC-108

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	33.75 (54) 27	37.5 (60) 30	41.25 (66) 33	45 (72) 36	48.75 (78) 39	52.5 (84) 42	56.25 (90) 45	60 (96) 48	
Brake lines & cables					I				I	MA-25
Brake pads & rotors			I		I		I		I	MA-26
Automatic transaxle fluid & manual transaxle gear oil	NOTE (1)				I				I	MA-22 (A/T) or MA-20 (M/T)
Steering gear & linkage, axle & suspension parts			I		I		I		I	MA-27 , MA-28
Tire rotation	NOTE (2)									MA-25

PERIODIC MAINTENANCE

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	33.75 (54) 27	37.5 (60) 30	41.25 (66) 33	45 (72) 36	48.75 (78) 39	52.5 (84) 42	56.25 (90) 45	60 (96) 48	
Exhaust system			I		I		I		I	MA-20
Front drive shaft boots			I		I		I		I	MA-29
In-cabin microfilter					R				R	ATC-108

NOTE:

(1) If towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads, change (not just inspect) oil at every 30,000 miles (48,000 km) or 24 months. Using automatic transmission fluid other than Genuine Nissan Matic Fluid K ATF will cause deterioration in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the NISSAN new vehicle limited warranty.

(2) Refer to [MA-4, "GENERAL MAINTENANCE"](#) .

Schedule 2 EMISSION CONTROL SYSTEM MAINTENANCE

ELS000SW

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. []: At the mileage intervals only

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	7.5 (12) 6	15 (24) 12	22.5 (36) 18	30 (48) 24	37.5 (60) 30	45 (72) 36	52.5 (84) 42	60 (96) 48	
Drive belts	NOTE (1)								I*	MA-12
Air cleaner filter					[R]				[R]	MA-16
EVAP vapor lines					I*				I*	MA-19
Fuel lines					I*				I*	MA-16
Fuel filter	NOTE (2)									-
Engine coolant	NOTE (3)								R*	MA-14
Engine oil		R	R	R	R	R	R	R	R	MA-16
Engine oil filter (Use part No. 15208 65F01 or equivalent.		R	R	R	R	R	R	R	R	MA-17
Spark plugs (PLATINUM-TIPPED type)		Replace every 105,000 miles (169,000 km).								MA-18
Intake & exhaust valve clearance*	NOTE (4)									EM-89

NOTE:

(1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months. Replace the drive belts if found damaged.

(2) Maintenance-free item. For service procedures, go to FL section.

(3) After 60,000 miles (96,000 km) or 48 months, replace every 30,000 miles (48,000 km) or 24 months.

(4) If valve noise increases, inspect valve clearance.

* Maintenance items and intervals with "*" are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

CHASSIS AND BODY MAINTENANCE

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary.

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	7.5 (12) 6	15 (24) 12	22.5 (36) 18	30 (48) 24	37.5 (60) 30	45 (72) 36	52.5 (84) 42	60 (96) 48	
Brake lines & cables			I		I		I		I	MA-25
Brake pads & rotors			I		I		I		I	MA-26

PERIODIC MAINTENANCE

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	7.5 (12) 6	15 (24) 12	22.5 (36) 18	30 (48) 24	37.5 (60) 30	45 (72) 36	52.5 (84) 42	60 (96) 48	
Automatic transaxle fluid & manual transaxle gear oil	NOTE (1)		I		I		I		I	MA-21 (A/T) or MA-20 (M/T)
Steering gear & linkage, axle & suspension parts					I				I	MA-27 , MA-28
Tire rotation	NOTE (2)									MA-25
Exhaust system					I				I	MA-20
Front drive shaft boots			I		I		I		I	MA-29
In-cabin microfilter			R		R		R		R	ATC-108

NOTE:

(1) Using automatic transmission fluid other than Genuine Nissan Matic Fluid K ATF will cause deterioration in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the NISSAN new vehicle limited warranty.

(2) Refer to [MA-4, "GENERAL MAINTENANCE"](#)

A

B

C

D

E

F

G

H

I

J

K

MA

M

RECOMMENDED FLUIDS AND LUBRICANTS

RECOMMENDED FLUIDS AND LUBRICANTS

PFP:00000

Fluids and Lubricants

ELS000SX

Description		Capacity (approximate)			Recommended Fluids and Lubricants
		US measure	Liter	Imp measure	
Engine oil Drain and refill	With oil filter change	4 1/4 qt	4.0	3 1/2 qt	<ul style="list-style-type: none"> ● API Certification Mark*1 ● API grade SL, Energy Conserving*1 ● ILSAC grade GF-III*1
	Without oil filter change	3 7/8 qt	3.7	3 1/4 qt	
Dry engine (engine overhaul)		5 1/4 qt	5.0	4 3/8 qt	
Cooling system	Without reservoir	7 7/8 qt	7.5	6 5/8 qt	Genuine NISSAN Long Life Anti-freeze Coolant or equivalent
	Reservoir	3/4 qt	0.7	5/8 qt	
Manual transaxle fluid (MTF)		2 3/8 qt	2.3	2 qt	Genuine NISSAN Manual Transmission Fluid (MTF) HQ Multi 75W-85
Automatic transaxle fluid (ATF)	4 A/T	9 3/4 qt	9.2	8 1/8 qt	Genuine NISSAN Matic "D" ATF (Continental US and Alaska) or Canada NISSAN Automatic Transmission Fluid *2
	5 A/T	7 3/4 qt	7.3	6 3/8 qt	Genuine NISSAN Matic "K" ATF*3
Power steering fluid (PSF)		2 1/8 pt	1.0	1 3/4 pt	Genuine NISSAN PSF or equivalent*4
Brake and clutch fluids		—	—	—	Genuine NISSAN Super Heavy Duty Brake Fluid *5 or equivalent DOT 3 (US FMVSS No. 116)
Multi-purpose grease		—	—	—	NLGI No. 2 (Lithium soap base)
Windshield washer fluid		—	—	—	Genuine NISSAN Windshield Washer Concentrate Cleaner & Anti-freeze or equivalent
Air conditioning system refrigerant		—	—	—	HFC-134a (R-134a)*6
Air conditioning system lubricant		—	—	—	Genuine NISSAN A/C System Lubricant Type DH-PS or equivalent*6

*1: For further details, see "SAE Viscosity Number".

*2: DEXRON™ III / MERCON™ or equivalent may also be used. Outside the continental United States and Alaska contact a NISSAN dealership for more information regarding suitable fluids, including recommended brand(s) of DEXRON™ III / MERCON™ Automatic Transmission Fluid.

*3: Using automatic transmission fluid other than Genuine NISSAN Matic "K" ATF will cause deterioration in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the NISSAN new vehicle limited warranty.

*4: For Canada, NISSAN Automatic Transmission Fluid (ATF), DEXRON™ III / MERCON™ or equivalent ATF may also be used.

*5: Available in mainland U.S.A. through your NISSAN dealer.


*6: For further details, see "Air conditioner specification label".

RECOMMENDED FLUIDS AND LUBRICANTS

ELS000SY

SAE Viscosity Number GASOLINE ENGINE OIL

- SAE 5W-30 viscosity oil is preferred for all temperatures. SAE 10W-30 and 10W-40 viscosity oil may be used if the ambient temperature is above -18°C (0°F).
- Use of 5W-30 viscosity oil will increase fuel economy.



ANTI-FREEZE COOLANT MIXTURE RATIO

The engine cooling system is filled at the factory with a high-quality, long life, year-round, anti-freeze coolant solution. The anti-freeze solution contains rust and corrosion inhibitors. Therefore, additional cooling system additives are not necessary.

Protection for outside temperatures down to		Genuine NISSAN Long life Anti-freeze Coolant	Demineralized water or dis- tilled water
°C	°F		
- 35	- 30	50%	50%

CAUTION:

- When adding or replacing coolant, be sure to use only Genuine NISSAN anti-freeze coolant or equivalent with the proper mixture ratio of 50% anti-freeze and 50% demineralized water or distilled water.
- Other types of coolant solutions may damage your cooling system.

ENGINE MAINTENANCE

ENGINE MAINTENANCE

PFP:00000

Drive Belts

CHECKING DRIVE BELTS

ELS000UG

WARNING:

Be sure to perform when the engine is not running.

1. Inspect belt for cracks, fraying, wear or oil adhesion. If necessary, replace with a new one.
2. Inspect drive belt deflections by applying 98N (10kg, 22lb) on the belt midway between pulleys as shown.
3. Measure the belt tension using Tool at the locations shown.



Tool number : BT3373-F

NOTE:

- Inspect drive belt deflection or tension when engine is cold.
- Adjust if belt deflections exceed the limit or if belt tension is not within specifications.

CAUTION:

- When checking belt deflection or tension immediately after installation, first adjust it to the specification value. Then, after turning the crankshaft two turns or more, readjust to the specified value to avoid variation in deflection between pulleys.
- Tighten idler pulley lock nut by hand and measure deflection or tension without looseness.



Belt Deflection and Tension

	Deflection adjustment		Unit: mm (in)	Tension adjustment*		Unit: N (kg-f, lb-f)
	Used belt		New belt	Used belt		New belt
	Limit	After adjustment		Limit	After adjustment	
Generator and air conditioning compressor	7 (0.28)	4.2 - 4.6 (0.17 - 0.18)	3.7 - 4.1 (0.15 - 0.16)	294 (30, 66)	730 - 818 (74.5 - 83.5, 164 - 184)	838 - 926 (85.5 - 94.5, 188 - 208)
Power steering pump	11 (0.43)	7.3 - 8.0 (0.29 - 0.30)	6.5 - 7.2 (0.26 - 0.28)	196 (20, 44)	495 - 583 (50.5 - 59.5, 111 - 131)	603 - 691 (61.5 - 70.5, 135.6 - 155.4)
Applied pushing force	98 N (10 kg-f, 22 lb-f)			—		

*: If belt tension gauge cannot be installed at check points shown, check drive belt tension at different location on the belt.

TENSION ADJUSTMENT

Portion	Belt tightening method for adjustment
Power steering oil pump belt	Adjusting bolt on idler pulley
Generator and air conditioner compressor belt	Adjusting bolt on idler pulley

CAUTION:

- When belt is replace with a new one, adjust it to value for “New belt” to accommodate for insufficient adaptability with pulley grooves.

ENGINE MAINTENANCE

- When deflection or tension of belt being used exceeds "Used belt limit" adjust it to value for "Used belt".
- When checking belt deflection or tension immediately after installation, first adjust it to the specification value. Then, after turning the crankshaft two turns or more, readjust to the specified value to avoid variation in deflection between pulleys.
- When installing belt, make sure that it is correctly engaged with pulley groove.
- Keep oil and water away from belt.
- Do not twist or bend belt excessively.


Generator and air conditioner compressor belt

1. Remove engine undercover.
2. Loosen idler pulley lock nut "A" and adjust by turning adjusting bolt "B".
 - For specified belt tension, refer to [MA-12, "Drive Belts"](#) .
3. Tighten lock nut "A".

**Lock nut "A" : 25.5 - 32.4 N·m (2.6 - 3.3 kg-m,
19 - 23 ft-lb)**

4. Tighten adjusting bolt "B".

**Adjusting bolt "B" : 3.9 - 6.9 N·m (0.4 - 0.7 kg-m,
35 - 61 in-lb)**



A
B
C
D
E
F
G
H
I
J
K
MA
M

ENGINE MAINTENANCE

Power steering oil pump belt

1. Remove engine undercover.
2. Loosen adjusting bolt "C".
3. Loosen power steering oil pump bolt "D".

NOTE:


Bolt head "D" is at the engine rear side.

4. Adjust by turning the adjusting bolt "E".
 - For specified belt tension, refer to [MA-12, "Drive Belts"](#).
- NOTE:
Adjusting bolt "E" is loosened with counterclockwise rotation.
5. Tighten adjusting bolt "C".

Adjusting bolt "C" : 15.5 - 18.6 N·m (1.6 - 1.8 kg-m,
12 - 13 ft-lb)

6. Tighten power steering oil pump bolt "D".

Power steering oil pump bolt "D" : 36.3 - 50.0 N·m (3.7 - 5.1 kg-m,
27 - 36 ft-lb)



ELS000U4


Changing Engine Coolant

WARNING:

- To avoid being scalded, never change the coolant when the engine is hot.
- Wrap a thick cloth around cap and carefully remove the cap. First, turn the cap a quarter of a turn to release built-up pressure. Then turn the cap all the way.

DRAINING ENGINE COOLANT

1. Remove engine undercover.
2. Open radiator drain plug at the bottom of radiator and remove the radiator filler cap. This is the only step required for a partial cooling system drain.
3. For a complete cooling system drain, remove the reservoir tank and drain the coolant, and then clean the reservoir tank before installation.
 - Do not allow coolant to spill on the drive belts.
4. When performing a complete cooling system drain (to remove the engine or for engine repair), remove the cylinder block front drain plug and the cylinder block RH drain plug.
5. Check the drained coolant for contaminants such as rust, corrosion or discoloration.



- If contaminated, flush the engine cooling system. Refer to [MA-16, "FLUSHING COOLING SYSTEM"](#).

REFILLING ENGINE COOLANT

1. Install the radiator drain plug. If the cooling system was drained completely, install the reservoir tank and the cylinder block drain plugs.
 - The radiator must be completely empty of coolant and water.
 - Apply sealant to the threads of the cylinder block drain plugs. Use Genuine High Performance Thread Sealant or equivalent. Refer to [GI-43, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).

Radiator drain plug : 7.8 - 11.8 N·m (0.8 - 1.2 kg-m , 69 - 104 in-lb)

ENGINE MAINTENANCE

Cylinder block front drain plug : 8 - 11 N·m (0.8 - 1.2 kg-m, 70 - 104 in-lb)

Cylinder block RH drain plug : 24.5 - 29.4 N·m (2.5 - 2.9 kg-m, 18 - 21 ft-lb)

2. If disconnected, reattach the upper radiator hose at the engine side.
3. Set the vehicle heater controls to the full HOT and heater ON position. Turn the vehicle ignition ON with the engine OFF as necessary to activate the heater mode.
4. Install the Tool by installing the radiator cap adapter onto the radiator neck opening. Then attach the gauge body assembly with the refill tube and the venturi assembly to the radiator cap adapter.
5. Insert the refill hose into the coolant mixture container that is placed at floor level. Make sure the ball valve is in the closed position.

- Use Genuine NISSAN Long Life Anti-Freeze Coolant or equivalent, mixed 50/50 with distilled water or demineralized water.


Refer to [MA-11, "ANTI-FREEZE COOLANT MIXTURE RATIO"](#).

Engine coolant capacity : 7.5 ℓ (7 7/8 US qt, 6 5/8 Imp qt)
(without reservoir tank)

Reservoir tank : 0.7 ℓ (3/4 US qt, 5/8 Imp qt)

6. Install an air hose to the venturi assembly, the air pressure must be within specification.

Compressed air supply pressure : 5.7 - 8.5 kPa (5.6 - 8.4 kg/cm², 80 - 120 psi)




CAUTION:

The compressed air supply must be equipped with an air dryer.

7. The vacuum gauge will begin to rise and there will be an audible hissing noise. During this process open the ball valve on the refill hose slightly. Coolant will be visible rising in the refill hose. Once the refill hose is full of coolant, close the ball valve. This will purge any air trapped in the refill hose.
8. Continue to draw the vacuum until the gauge reaches 28 inches of vacuum. The gauge may not reach 28 inches in high altitude locations, refer to the vacuum specifications based on the altitude above sea level.

Altitude above sea level	Vacuum gauge reading
0 - 100 m (328 ft)	: 28 inches of vacuum
300 m (984 ft)	: 27 inches of vacuum
500 m (1,641 ft)	: 26 inches of vacuum
1,000 m (3,281 ft)	: 24 - 25 inches of vacuum



9. When the vacuum gauge has reached the specified amount, disconnect the air hose and wait 20 seconds to see if the system loses any vacuum. If the vacuum level drops, perform any necessary repairs to the system and repeat steps 6 - 8 to bring the vacuum to the specified amount. Recheck for any leaks.
10. Place the coolant container (with the refill hose inserted) at the same level as the top of the radiator. Then open the ball valve on the refill hose so the coolant will be drawn up to fill the cooling system. The cooling system is full when the vacuum gauge reads zero.

CAUTION:

Do not allow the coolant container to get too low when filling, to avoid air from being drawn into the cooling system.

11. Remove the Tool from the radiator neck opening.

ENGINE MAINTENANCE


12. Fill the cooling system to the specified level and install the radiator cap. Run the engine to warm up the cooling system and top up the system as necessary.

FLUSHING COOLING SYSTEM

1. Fill the radiator from the filler neck above the radiator upper hose and reservoir tank with clean water and reinstall radiator filler cap.
2. Run the engine and warm it up to normal operating temperature.
3. Rev the engine two or three times under no-load.
4. Stop the engine and wait until it cools down.
5. Drain the water from the system. Refer to [MA-14, "DRAINING ENGINE COOLANT"](#).
6. Repeat steps 1 through 5 until clear water begins to drain from the radiator.

Checking Fuel Lines

Inspect the fuel lines and fuel tank for improper hose attachment, leaks, cracks, damage, loose connections, chafing, or deterioration. If necessary, repair or replace faulty parts.




Changing Air Cleaner Filter VISCIOUS PAPER TYPE

NOTE:

The viscous paper type filter does not need cleaning between replacement intervals. Refer to [MA-6, "PERIODIC MAINTENANCE"](#).

1. Loosen the clamp between the mass air flow sensor and the air cleaner to electric throttle control actuator tube.
2. Release the air cleaner case (upper) clamps.
3. Remove the air cleaner case (upper).
4. Remove the air cleaner filter.
5. Install a new air cleaner filter.
6. Installation of remaining components is in the reverse order of removal.



Changing Engine Oil

WARNING:

- Be careful not to burn yourself, as the engine oil is hot.
 - Prolonged and repeated contact with used engine oil may cause skin cancer; try to avoid direct skin contact with used oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.
1. Position the vehicle so it is level on the hoist.
 2. Warm up the engine, and check for oil leaks from the engine.
 3. Stop the engine and wait at least 10 minutes.

ENGINE MAINTENANCE

- Remove the oil drain plug and oil filler cap.
- Drain the engine oil.
- Install the oil drain plug.

CAUTION:

- Clean the drain plug and use a new washer for installation.

Oil pan drain plug : 29 - 39 N·m (3.0 - 4.0 kg-m, 22 - 29 ft-lb)

- Refill the engine with new engine oil. Refer to [MA-10, "RECOMMENDED FLUIDS AND LUBRICANTS"](#).

CAUTION:



- The refill oil capacity depends on the oil temperature and drain time. Use these specifications for reference only.
- Always use the dipstick to determine when the proper amount of oil is in the engine.

Oil Capacity (Approximate):

Unit: ℓ (US qt, Imp qt)

Drain and refill	With oil filter change	4.0 (4 1/4, 3 1/2)
	Without oil filter change	3.7 (3 7/8, 3 1/4)
Dry engine (engine overhaul)		5.0 (5 1/4, 4 3/8)

- Start the engine and run it at idle to warm up, then check the oil drain plug and oil filter for oil leaks.
- Stop the engine and wait at least 10 minutes.
- Check the engine oil level using the dipstick as shown. Refer to [LU-6, "OIL LEVEL"](#).




Changing Oil Filter

- Remove the RH splash shield.
- Remove the oil filter using Tool.

Tool number: KV10115801 (J38956)


CAUTION:

- The oil filter is provided with a relief valve. Use a Genuine NISSAN oil filter.
- Be careful not to get burned when the engine and engine oil are hot.
- When draining the oil, use a shop cloth to absorb any oil leaks and spills.
- Do not allow engine oil to contaminate the drive belts.
- Wipe off any oil that spills on the engine and vehicle.




ENGINE MAINTENANCE

3. Clean the oil filter mounting surface on the cylinder block.
 - Coat the rubber seal of new oil filter with engine oil as shown.




4. Screw the oil filter manually until it touches the engine block sealing surface, then tighten the oil filter by turning it another 2/3 turn, or tighten to specification.

Oil filter : 14.7 - 20.5 N·m (1.5 - 2.1 kg-m, 11 - 15 ft-lb)



5. Check the engine oil level using the dipstick as shown.
6. After running the engine at idle until it warms up, check for engine oil leaks and correct as necessary.



Changing Spark Plugs (Platinum - Tipped Type)

ELS000U9

1. Remove the engine cover using power tool.
2. Remove the intake manifold collector. Refer to [EM-24, "REMOVAL"](#).
3. Remove the ignition coils. Refer to [EM-36, "Removal and Installation"](#).
4. Remove the spark plugs.
5. Install the new spark plugs. Check the gap before installing the new spark, the gap is not adjustable, replace the spark plug as necessary.

Spark plug : 20 - 29 N·m (2.0 - 3.0 kg-m, 14 - 22 ft-lb)

Gap (Nominal) : 1.1 mm (0.043 in)

Spark Plug Types

Make	NGK
Standard type	PLFR5A-11
Hot type	PLFR4A-11
Cold type	PLFR6A-11

- Use the standard type spark plugs for normal driving conditions.
- The hot type spark plug is suitable when fouling occurs with the standard type spark plug under conditions such as:
 - frequent engine starts
 - low ambient temperatures

ENGINE MAINTENANCE


- The cold type spark plug is suitable when spark knock occurs with the standard type spark plug under conditions such as:
 - extended highway driving
 - frequent high engine revolution
- If the spark plug tip is covered with carbon, a spark plug cleaner may be used.

Cleaner air pressure : Less than 588 kPa (6 kg/cm², 85 psi)


Cleaning time : Less than 20 seconds

CAUTION:

Do not use a wire brush for cleaning the spark plug tip.



- Checking and adjusting the spark plug gap is not required between change intervals, replace the spark plugs as necessary.



6. Install the ignition coils. Refer to [EM-36. "Removal and Installation"](#).

Ignition coil bolt : 6.37 - 7.54 N·m (0.65 - 0.77 kg-m, 56 - 67 in-lb)

Checking EVAP Vapor Lines

ELS000UA

1. Visually inspect the EVAP vapor lines for cracks, damage, loose connections, chafing, and deterioration. Replace the lines as necessary.
2. Inspect the fuel tank filler cap vacuum relief valve for clogging and sticking. Fix or replace as necessary.

A

B

C

D

E

F

G

H

I

J

K

MA

M


CHASSIS AND BODY MAINTENANCE

PFP:00100

Checking Exhaust System

ELS000TF


Check the exhaust pipes, muffler, and exhaust mounts for improper attachment, leaks, cracks, damage, chafing, or deterioration.



Checking Clutch Fluid Level and Leaks

ELS000TG

If the clutch fluid level is extremely low or below the "MIN" level in the reservoir, check the clutch system for leaks.




Checking M/T Oil

ELS000TH

Check for oil leaks. Check that the oil level is at the correct level through the filler plug hole as shown.

- **Never start the engine while checking the oil level.**

Filler plug : 30 - 39 N·m (3.1 - 4.0 kg·m, 23 - 28 ft·lb)



Changing M/T Oil

ELS000TI

1. Drain the MTF by removing the drain plug.
2. Install the drain plug using a new washer.

Drain plug : 30 - 39 N·m (3.1 - 4.0 kg·m, 23 - 28 ft·lb)


3. Remove the filler plug and fill the transaxle with new MTF through the filler plug hole. Check the MTF level as shown.

Manual Transmission Fluid specification : Refer to [MA-10, "Fluids and Lubricants"](#) .

Capacity (RS6F51A & RS6F51A) : 2.3 ℓ (2 3/8 US qt, 2 Imp qt)

4. Install the filler plug using a new washer.

Filler plug : 30 - 39 N·m (3.1 - 4.0 kg·m, 23 - 28 ft·lb)



CHASSIS AND BODY MAINTENANCE


Checking A/T Fluid

ELS0007J


1. Warm up the engine.
2. Check for any transaxle fluid leaks.
3. Before driving, the fluid level can be checked at fluid temperatures of 30° - 50°C (86° - 122°F) using the "COLD" range on the A/T fluid level gauge.

4 A/T

Front side
HOT
[122 to 176°F
(50 to 80°C)]



Reverse side
COLD
[86 to 122°F
(30 to 50°C)]



LLIA0063E


5 A/T



LLIA0064E


- a. Park the vehicle on a level surface and set parking brake.
- b. Start the engine and move the transaxle selector lever through each gear position. Leave the selector lever in the "P" park position.
- c. Check the fluid level with the engine idling.

4 A/T



WLIA0008E

5 A/T



LLIA0065E

- d. Remove the A/T fluid level gauge and wipe it clean with a lint-free paper.
- e. Re-insert the A/T fluid level gauge into the charging pipe as far as it will go.
- f. Remove the A/T fluid level gauge and note the reading. If the reading is at or below the low side of the range, add the necessary specified A/T fluid through the A/T fluid charging pipe.

CHASSIS AND BODY MAINTENANCE

CAUTION:


Do not overfill the transaxle.

4. Drive the vehicle for approximately 5 minutes at moderate speeds.
5. Re-check the fluid level at fluid temperatures of 50° - 80°C (122° - 176°F) using the "HOT" range on the A/T fluid level gauge.

CAUTION:

Firmly fix the A/T fluid level gauge into the A/T fluid charging pipe using the attached stopper, this will provide an accurate reading on the gauge, and will keep the gauge in position while driving.

6. Check the fluid for the following conditions:
 - If the fluid is very dark or smells burned, refer to the AT section for checking the operation of the transaxle. Flush the AT fluid cooling system after repairing the transaxle.
 - On 4 A/T equipped vehicles, if the fluid contains frictional material (from the clutches or bands), remove the radiator and flush the cooler lines using a cleaning solvent and compressed air after completing repairs to the transaxle. Refer to [CO-10, "RADIATOR"](#).



Changing A/T Fluid



ELS000TK

1. Run the engine to warm up the transaxle until the fluid is at full operating temperature of 50° - 80°C (122° - 176°F).
2. Stop the engine.
3. Drain the A/T fluid by removing the drain plug. Reinstall the drain plug to the specified tightness using a new drain washer.

Drain plug

4 A/T : 29 - 39 N·m (3.0 - 4.0 kg·m, 22 - 29 ft·lb)

5 A/T : 23.5 - 54.9 N·m (2.4 - 5.5 kg·m, 18 - 40 ft·lb)



4. Refill the transaxle with new specified A/T fluid through the A/T fluid charging pipe. Always refill the transaxle with the same volume amount that was drained out.

CAUTION:

Do not overfill the transaxle.

Fluid grade

4 A/T : Genuine NISSAN Matic "D" ATF (Continental U.S. and Alaska) or Canada NISSAN Automatic Transmission Fluid. Refer to [MA-10, "RECOMMENDED FLUIDS AND LUBRICANTS"](#).

CHASSIS AND BODY MAINTENANCE

5 A/T : Genuine NISSAN Matic "K" ATF. Refer to [MA-10, "RECOMMENDED FLUIDS AND LUBRICANTS"](#) .

Fluid capacity (with torque converter)

4 A/T : 9.2 ℓ (9 3/4 US qt, 8 1/8 Imp qt)

5 A/T : 7.3 ℓ (7 3/4 US qt, 6 3/8 Imp qt)

- Run the engine at idle speed for five minutes.
- Check fluid level and condition. Refer to [MA-21, "Checking A/T Fluid"](#) . If the fluid is still contaminated, repeat step 2 through 5.

Balancing Wheels (Bonding Weight Type) REMOVAL

ELS0007L

- Remove the inner and outer balance weights from the road wheel.

CAUTION:

Be careful not to scratch the road wheel during removal.

- Use a releasing agent to remove the double-faced adhesive tape from the road wheel.

CAUTION:

- Be careful not to scratch the road wheel during removal.**
- After removing the double-faced adhesive tape, wipe off any traces of the releasing agent from the road wheel.**

WHEEL BALANCE ADJUSTMENT

NOTE:

If a tire balance machine has an adhesion balance weight mode setting and drive-in weight mode setting, select and adjust in the drive-in weight mode suitable for the road wheels.

- Set the road wheel on the wheel balancer using the center hole as a guide. Start the tire balance machine.
- When the inner and outer unbalance values are shown on the wheel balancer indicator, multiply outer unbalance value by 1.6 to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value, then install it at the designated outer position of, or at the designated angle position on the road wheel.

Outer balance weight calculation:

Indicated unbalance value $\times 1.6$ = outer balance weight

Calculation example:

23 g (0.81 oz) $\times 1.6$ = 38.33 g (1.35 oz) = 40 g (1.41 oz) outer balance weight (closer to calculated balance weight value)

NOTE:

The selected balance weight value must be the closest balance weight available to the calculated balance weight value.


Example:

37.4 = 35 g (1.23 oz)

37.5 = 40 g (1.41 oz)

CAUTION:

- Do not install the inner balance weight before installing the outer balance weight.**
- Before installing the balance weight, be sure to clean the mating surface of the road wheel.**




CHASSIS AND BODY MAINTENANCE

- a. Install the balance weight in the position as shown.
- b. When installing the balance weight to the road wheels, set it into the grooved area on the inner wall of the road wheel as shown, so that the balance weight center is aligned with the wheel balancer indication position (angle).

CAUTION:


- Always use genuine NISSAN adhesion balance weights.
- Balance weights are not reusable; always replace with new ones.
- Do not install more than three sheets of balance weight.



- c. If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other.

CAUTION:

Do not install one balance weight sheet on top of another.



3. Start the wheel balancer.
4. Install the drive-in balance weight on the inner side of the road wheel in the wheel balancer indication position (angle).

CAUTION:

Do not install more than two balance weights in one position (angle).

5. Start the wheel balancer. Make sure that the inner and outer residual unbalance values are 10 g (0.35 oz) each or less.
 - If either residual unbalance value exceeds 10 g (0.35 oz), repeat the installation procedures.

CHASSIS AND BODY MAINTENANCE

Wheel balance (maximum allowable unbalance):


Maximum allowable unbalance	Dynamic (at rim flange)	10 g (0.35 oz) (one side)
	Static	20 g (0.71 oz)

Tire Rotation

ELS000TM

- After rotating the tires as shown, adjust the tire pressure to specification.
- Retighten the wheel nuts after the vehicle has been driven the first 1,000 km (600 miles). Also retighten the wheel nuts after a flat tire repair, or any type of service where the wheels have been removed and installed.


Wheel nuts : 98 - 117 N·m (10 - 12 kg-m, 73 - 86 ft-lb)



Checking Brake Fluid Level and Leaks

ELS000TN


- Check the brake fluid level in the reservoir tank. It should be between the "MAX" and "MIN" lines on the reservoir tank.
- If the brake fluid level is extremely low or below the "MIN" level, check the brake system for leaks.
- Release the parking brake lever and check that the brake warning lamp goes off. If not, check the brake system for leaks.



Checking Brake Lines and Cables

ELS000TO

Check the brake fluid lines and parking brake cables for improper attachment, leaks, chafing, abrasions, deterioration, and damage. Repair or replace parts as necessary.




CHASSIS AND BODY MAINTENANCE

Checking Disc Brake ROTOR

ELS000TP

Check the rotor condition and thickness. Resurface or replace the rotor as necessary.




Brake Rotor Specifications

Unit: mm (in)

	Front	Rear
Brake model	CLZ25VD	AD9V
Standard thickness	28.0 (1.10)	9 (0.35)
Maximum runout	0.07 (0.0028)	0.07 (0.0028)
Minimum thickness (Wear limit)	26.0 (1.02)	8.0 (0.315)


CALIPER

Check the caliper for leakage.



PAD

Check the brake pads for wear or damage.



Brake Pad Specifications

Unit: mm (in)


	Front brake pad	Rear brake pad
Brake model	CLZ25VD	AD9V
Standard thickness	11 (0.43)	10 (0.39)
Minimum thickness (wear limit)	2.0 (0.079)	1.5 (0.059)

CHASSIS AND BODY MAINTENANCE

Checking Steering Gear and Linkage

ELS0007Q

- Check the gear housing and boots for looseness, damage and power steering fluid leaks.



- Check the power steering hose connections for leaks.
- Check the steering column for looseness.

STEERING LINKAGE

Check the ball joint, dust cover and other component parts for looseness, wear, damage and grease leakage.

Checking Power Steering Fluid and Lines


ELS000TR

Check the power steering fluid level in the reservoir tank with the engine off.

Use the "HOT" range at fluid temperatures of 50° - 80°C (122° - 176°F) or the "COLD" range at fluid temperatures of 0° - 30°C (32° - 86°F).


CAUTION:

- Do not overfill the power steering reservoir tank.
- Use the recommended power steering fluid, Genuine NISSAN PSF or equivalent.
Refer to [MA-10, "RECOMMENDED FLUIDS AND LUBRICANTS"](#).



CHASSIS AND BODY MAINTENANCE

- Check the power steering hoses for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.




- Check the steering rack boots for accumulation of power steering fluid indicating an internal leak.

Axle and Suspension Parts


ELS000TS

Check the front and rear axle and suspension parts for excessive play, cracks, wear, or other damage.

- Shake each wheel as shown to check for excessive play.
- Rotate each wheel to check for abnormal noise.




- Check the strut mount nuts for looseness.




CHASSIS AND BODY MAINTENANCE

- Check the axle and suspension nuts and bolts for looseness.




- Check the struts for oil leakage or other damage.
- Check suspension ball joint for grease leakage and ball joint dust cover for cracks or other damage.



Drive Shaft

- Check the boot and drive shaft for cracks, wear, damage and grease leakage as shown.




A
B
C
D
E
F
G
H
I
J
K
MA
M

CHASSIS AND BODY MAINTENANCE

Lubricating Locks, Hinges and Hood Latch

ELS000TU



WLIA0010E

Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters

ELS000TV

CAUTION:

- After any collision, inspect all seat belt assemblies, including retractors and other attached hardware (i.e. anchor bolt, guide rail set). Nissan recommends to replace all seat belt assemblies in use during a collision, unless not damaged and properly operating after minor collision. Also inspect seat belt assemblies not in use during a collision, and replace if damaged or improperly operating. Seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision where the driver and passenger air bags are deployed.
- If any component of seat belt assembly is questionable, do not repair. Replace as seat belt assembly.
- If webbing is cut, frayed, or damaged, replace belt assembly.
- Never oil tongue and buckle.
- Use a genuine NISSAN seat belt assembly.


For details, refer to "Seat Belt Inspection" in SB section.

Anchor bolt

43.1 – 54.9 (4.4 – 5.5, 32 – 40)

N·m (kg·m, ft·lb)

4 Passenger




Check anchors for loose mounting


43.1 – 54.9 (4.4 – 5.5, 32 – 40)

Check belts for damage

5 Passenger



Check function of buckles and tongues when buckled and released



Check retractor for smooth operation

WLIA0011E

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Standard and Limit

ELS000TX

SPARK PLUGS (PLATINUM-TIPPED TYPE)

Type	Standard	PLFR5A-11
	Hot	PLFR4A-11
	Cold	PLFR6A-11
Plug gap		Nominal: 1.1 mm (0.043 in)

BELT DEFLECTION AND TENSION

	Deflection adjustment		Unit: mm (in)	Tension adjustment		Unit: N (kg, lb)
	Used belt		New belt	Used belt		New belt
	Limit	After adjustment		Limit	After adjustment	
Alternator, Air conditioner compressor	7.0 (0.28)	4.2 - 4.6 (0.17 - 0.18)	3.7 - 4.1 (0.15 - 0.16)	294 (30, 66)	730 - 818 (74.5 - 83.5, 164 - 184)	838 - 926 (85.5 - 94.5, 188 - 208)
Power steering oil pump	11.0 (0.43)	7.3 - 8.0 (0.29 - 0.32)	6.5 - 7.2 (0.26 - 0.28)	196 (20, 44)	495 - 583 (50.5 - 59.5, 111.3 - 131.1)	603 - 691 (61.5 - 70.5, 135.6 - 155.4)

Chassis and Body Maintenance

ELS000TY

WHEEL BALANCE

Maximum allowable unbalance	Dynamic (at rim flange) g (oz)	10 (0.35) (one side)
	Static g (oz)	20 (0.71)

SERVICE DATA AND SPECIFICATIONS (SDS)
