

A

B

C

D

E

F

PS

H

I

J

K

L

M

SECTION

PS

POWER STEERING SYSTEM

CONTENTS

PRECAUTIONS	2	Disassembly and Assembly	15	F
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	Inspection	15	
Precautions for Steering System	2	POWER STEERING GEAR AND LINKAGE	16	PS
PREPARATION	3	On-Vehicle Service	16	
Special Service Tools	3	CHECKING STEERING GEAR	16	
Commercial Service Tool	4	CHECKING STEERING LINKAGE	16	
NOISE, VIBRATION, AND HARSHNESS (NVH)		CHECKING GEAR HOUSING MOVEMENT	16	H
TROUBLESHOOTING	5	CHECKING RACK SLIDING FORCE	16	
NVH Troubleshooting Chart	5	Removal and Installation	17	
POWER STEERING FLUID	6	REMOVAL	17	
Checking Fluid Level	6	Disassembly and Assembly	20	I
Checking Fluid Leakage	6	DISASSEMBLY	20	
Bleeding Hydraulic System	7	INSPECTION AFTER DISASSEMBLY	20	
STEERING WHEEL	8	ASSEMBLY	21	J
On-Vehicle service	8	Adjustment for Rack Sliding Force	22	
CHECKING STEERING WHEEL PLAY	8	DECREASE	22	
CHECKING NEUTRAL POSITION ON STEERING WHEEL	8	INCREASE	22	K
CHECKING STEERING WHEEL TURNING FORCE	8	POWER STEERING OIL PUMP	24	
FRONT WHEEL TURNING ANGLE	9	On-Vehicle Service	24	
Removal and Installation	9	CHECKING HYDRAULIC SYSTEM	24	
REMOVAL	9	Removal and Installation	24	L
INSTALLATION	9	REMOVAL	24	
HEATED STEERING WHEEL	10	INSTALLATION	24	
Wiring Diagram — PS-H/STRG —	10	Disassembly and Assembly	25	M
TILT & TELESCOPIC SYSTEM	11	PRE-DISASSEMBLY INSPECTION	25	
Removal and Installation	11	DISASSEMBLY	26	
TILT MOTOR AND TILT SENSOR	11	ASSEMBLY	26	
TELESCOPIC MOTOR AND TELESCOPIC SENSOR	12	Inspection After Disassembly	28	
STEERING COLUMN	13	HYDRAULIC LINE	29	
Removal and installation	13	Removal and Installation	29	
REMOVAL	14	REMOVAL	29	
INSTALLATION	14	SERVICE DATA AND SPECIFICATIONS (SDS)	30	
		General Specifications	30	
		Steering Wheel	30	
		Steering Column	30	
		Steering Gear and Linkage	30	
		Power Steering	31	

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EGS000HS

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Steering System

EGS000HT

- Before disassembly, thoroughly clean the outside of the unit.
- Disassembly should be done in a clean work area. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- For easier and proper assembly, place disassembled parts in order on a parts rack.
- Use nylon cloths or paper towels to clean the parts; common shop rags can leave lint that might interfere with their operation.
- Before inspection or reassembly, carefully clean all parts with a general purpose, non-flammable solvent.
- Before assembly, apply a coat of recommended Genuine NISSAN PSF or equivalent to hydraulic parts. Petroleum jelly may be applied to O-rings and seals. Do not use any grease.
- Replace all gaskets, seals and O-rings. Avoid damaging O-rings, seals and gaskets during installation. Perform functional tests whenever designated.

PREPARATION







PREPARATION

PFP:00002




Special Service Tools

EGS000HU

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number (Kent-Moore No.) Tool name		Description
KV48100700 (J26364) Torque adapter		Measuring pinion rotating torque
	NT169	
KV48102500 (J33914) Pressure gauge adapter		Measuring oil pressure
	S-NT542	
ST27180001 (J25726-A) Steering wheel puller		Removing steering wheel
	S-NT544	
HT72520000 (J25730-B) Ball joint remover		Removing ball joint a: 33 mm (1.30 in) b: 50 mm (1.97 in) r: R11.5 mm (0.453 in)
	S-NT546	
KV48103500 (J26357 and J26357-10) Pressure gauge		Measuring oil pressure
	S-NT547	
KV48104400 () Rack seal ring reformer		Reforming teflon ring a: 50 mm (1.97 in) dia. b: 36 mm (1.42 in) dia. c: 100 mm (3.94 in)
	S-NT550	

PREPARATION

Tool number (Kent-Moore No.) Tool name	Description
ST3127S000 1 GG91030000 (See J25765-A) Torque wrench 2 HT62940000 (—) Socket adapter 3 HT62900000 (—) Socket adapter	Measuring turning torque 
(J-44372) Spring gauge	Measuring steering wheel turning force 
(J-44183-A) Spring gauge	Measuring rack sliding force 

Commercial Service Tool

EGS000HV

Tool number	Description
Oil pump attachment	Disassembling and assembling oil pump Unit: mm (in) 

POWER STEERING FLUID

POWER STEERING FLUID

PFP:KLF20

Checking Fluid Level

EGS000HX


Check fluid level, referring to the scale on reservoir tank.

Use HOT range for fluid temperatures of 50° to 80°C (122° to 176°F).

Use COLD range for fluid temperatures of 0° to 30°C (32° to 86° F).

CAUTION:


- Do not overfill.
- Recommended fluid is Genuine NISSAN PSF II or equivalent refer to [MA-10, "RECOMMENDED FLUIDS AND LUBRICANTS"](#).



Checking Fluid Leakage

EGS000HY

Check the lines for improper attachment and for leaks, cracks, damage, loose connections, chafing and deterioration.



WGIA0039E

1. Run engine between idle speed and 1,000 rpm.
Make sure temperature of fluid in oil tank rises to 60° to 80°C (140° to 176°F).
2. Turn steering wheel right-to-left several times.
3. Hold steering wheel at each lock position for five seconds and carefully check for fluid leakage.

CAUTION:

Do not hold the steering wheel in a locked position for more than 15 seconds.


4. If fluid leakage at connectors is noticed, loosen flare nut and then retighten.
Do not overtighten connector as this can damage O-ring, washer and connector.
5. If fluid leakage from power steering oil pump is noticed, check the power steering oil pump. Refer to [PS-28, "Inspection After Disassembly"](#).
6. Check steering gear boots for accumulation of power steering fluid indicating a steering gear leak.

POWER STEERING FLUID

Bleeding Hydraulic System

EGS000HZ

1. Raise the front end of vehicle until the wheels are clear of the ground.
2. Add Genuine NISSAN PSF or equivalent, refer to [MA-10, "RECOMMENDED FLUIDS AND LUBRICANTS"](#) into the steering fluid reservoir tank to the specified level. Then quickly turn the steering wheel fully to right and left and lightly touch steering stoppers. Repeat steering wheel operation until the fluid level no longer decreases.



3. Start the engine then repeat step 2 above. Incomplete air bleeding will cause the following symptoms:
 - Air bubbles in reservoir tank
 - Clicking noise in oil pump
 - Excessive buzzing in oil pump

If this happens, bleed out the air repeating step 2 above. Fluid noise may occur in the valve or oil pump. This is common when the vehicle is stationary or while turning the steering wheel slowly. This does not affect the performance or durability of the system.

STEERING WHEEL

STEERING WHEEL

PFP:48430

EGS00010


On-Vehicle service

CHECKING STEERING WHEEL PLAY

- With wheels in a straight-ahead position, check steering wheel play.

Steering wheel play : 35 mm (1.38 in) or less

- If it is not within specification, check the following for looseness or worn components.
 - Steering gear assembly
 - Steering column
 - Front suspension and axleCheck steering system for looseness while moving the steering wheel in all directions.



Axial end play : 0 mm (0 in)


CHECKING NEUTRAL POSITION ON STEERING WHEEL

Pre-checking

- Make sure that wheel alignment is correct. Refer to [FSU-18, "Front Wheel Alignment \(Unladen*1\)"](#).
- Verify that the steering gear is centered before removing the steering wheel.

Checking

- Check that the steering wheel is in neutral position when driving straight ahead.
- If it is not in neutral position, remove the steering wheel and reinstall it correctly.
- If the neutral position is between two teeth, loosen tie-rod lock nuts. Turn the tie-rods by the same amount in opposite directions on both left and right sides.




CHECKING STEERING WHEEL TURNING FORCE

- Park vehicle on a level, dry surface and set parking brake.
- Start engine.
- Bring power steering fluid up to adequate operating temperature. Make sure the fluid temperature is approximately 60° to 80°C (140° to 176°F).
Tires need to be inflated to normal pressure.
- Check steering wheel turning force using Tool when steering wheel has been turned 360° from the neutral position.

Tool number: J-44372

Steering wheel turning : 39 N (4 kg-f, 9 lb-f) or less force


- If steering wheel turning force is out of specification, check rack sliding force. Refer to [PS-16, "CHECKING RACK SLIDING FORCE"](#).
- If rack sliding force is not within specifications, adjust rack sliding force. Refer to [PS-22, "Adjustment for Rack Sliding Force"](#).
- If rack sliding force is OK, inspect steering column. Refer to [PS-15, "Inspection"](#).



STEERING WHEEL

FRONT WHEEL TURNING ANGLE

1. Rotate steering wheel all the way right and left; measure turning angle. Refer to [FSU-18, "General Specifications \(Front\)"](#) .
2. If it is not within specifications, check rack stroke. Refer to [PS-30, "Steering Gear and Linkage"](#) .



EGS00011


Removal and Installation

REMOVAL

1. Set the front wheels in the straight-ahead position.
2. Remove the driver air bag module. Refer to [SRS-40, "Removal and Installation"](#) .
3. Remove the steering wheel center nut.
4. Remove the steering wheel using Tool.


Tool number: **ST27180001 (J25726-A)**

5. Place a piece of tape across the spiral cable so it will not be rotated out of position.



INSTALLATION

1. Installation is in the reverse order of removal.
- Align spiral cable correctly when installing steering wheel. Make sure that the spiral cable is in the neutral position. The neutral position is detected by turning left 2.5 revolutions from the right end position and ending with the knob at the top.



CAUTION:

The spiral cable may snap due to steering operation if the cable is installed in an improper position. Also, with the steering linkage disconnected, the cable may snap by turning the steering wheel beyond the limited number of turns. (The spiral cable can be turned up to 2.5 turns from the neutral position to both the right and left.)

Steering wheel center nut : 29 - 39 N·m (3.0 - 4.0 kg-m, 22 - 29 ft-lb)

HEATED STEERING WHEEL



PFP:48430

EGS0001R

HEATED STEERING WHEEL

Wiring Diagram — PS-H/STRG —


PS-H/STRG-01



TILT & TELESCOPIC SYSTEM

Removal and Installation TILT MOTOR AND TILT SENSOR

Removal



1. Tilt sensor

2. Tilt motor

1. Remove the instrument column cover and lower driver instrument panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove LH lower knee protector.
3. Disconnect the tilt sensor electrical connector.
4. Remove the two tilt sensor screws and the tilt sensor.
5. Disconnect the tilt motor electrical connector.
6. Remove the tilt motor bolt and the tilt motor.

Installation

Installation is in reverse order of removal.


NOTE:

Make sure the tab in the tilt sensor is engaged with the bracket on the tilt motor.

TILT & TELESCOPIC SYSTEM

TELESCOPIC MOTOR AND TELESCOPIC SENSOR

Removal



1. Remove the instrument column cover and lower driver instrument panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove LH lower knee protector.
3. Disconnect the telescopic sensor electrical connector.
4. Remove the two telescopic sensor screws and the telescopic sensor.
5. Disconnect the telescopic motor electrical connector.
6. Remove the two telescopic motor bushing bracket screws.
7. Remove the telescopic motor bolt and the telescopic motor.

Installation

Installation is in reverse order of removal.

NOTE:

Make sure the tab in the telescopic sensor is engaged with the telescopic motor bushing bracket.

STEERING COLUMN


PFP:48810

EGS00012

STEERING COLUMN

Removal and installation

SEC. 484 • 487 • 488



- | | | |
|--|------------------------------------|---------------------|
| 1. Driver air bag module | 2. Steering wheel | 3. Spiral cable |
| 4. Steering wheel side cover | 5. Wiper/washer switch | 6. Head lamp switch |
| 7. Upper and lower column covers | 8. Ignition switch | 9. Upper joint |
| 10. Steering column (manual tilt/telescope type) | 11. Lower joint and shaft assembly | 12. Cowl panel |

STEERING COLUMN

- | | | |
|-------------------------|---|-----------------------------|
| 13. Hole cover | 14. Shaft lower cover | 15. LH lower knee protector |
| 16. ADP steering switch | 17. Steering column (electric tilt/telescopic type) | |

REMOVAL

CAUTION:

- The rotation of the spiral cable (SRS air bag component part) is limited. If the steering gear must be removed, set the front wheels in the straight-ahead direction. Do not rotate the steering column while the steering gear is removed.
 - Remove the steering wheel before disconnecting the coupling joint to avoid damaging the spiral cable.
1. Disconnect battery negative terminal.
 2. If necessary, remove the steering wheel. Refer to [PS-9, "Removal and Installation"](#).
 3. Remove the instrument column cover and lower driver instrument panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
 4. Remove the combination meter. Refer to [DI-31, "Removal and Installation of Combination Meter"](#).
 5. Remove the cluster lid and center console assembly. Refer to [IP-10, "Removal and Installation"](#).
 6. Remove the instrument panel screws from the LH side of the instrument panel to allow the ignition switch to clear the instrument panel during removal.
 7. Remove LH lower knee protector.
 8. Disconnect the following:
 - Telescopic motor, if equipped
 - Telescopic sensor, if equipped
 - Tilt motor, if equipped
 - Tilt sensor, if equipped
 - Headlamp switch
 - Wiper switch
 - Spiral cable
 - Key in reminder
 - Immobilizer
 - Illumination lamp
 - Ignition switch
 - Column harness clips, position aside
 9. Remove the shaft lower cover.
 10. Remove the pinch bolt.
 11. Remove the steering column nuts and steering column.

INSTALLATION

Installation is in the reverse order of removal.


CAUTION:

When installing the steering column, finger-tighten all of the lower bracket and joint retaining bolts; then tighten them to specification. Do not apply undue stress to the steering column.

NOTE:

Align slit of the coupling joint with projection on dust cover. Insert the joint until surface A contacts surface B.

- After installation, turn steering wheel to make sure it moves smoothly. Ensure the number of turns are the same from the straight-forward position to left and right locks. Be sure that the steering wheel is in a neutral position when driving straight ahead.




STEERING COLUMN

Disassembly and Assembly

EGS00013

- Remove the tamper resistant self-shear type screws with a drill or other appropriate tool.
- Disconnect key interlock cable.
- Install new tamper resistant self-shear type screws.



Inspection

EGS00014

- When the steering wheel does not turn smoothly, check the steering column as follows:
 1. Check the column bearings for damage or unevenness. Lubricate with recommended multi-purpose grease. Replace the steering column as an assembly, if necessary.
 2. Check the column tube for deformation or breakage. Replace the steering column as an assembly, if necessary.
- If the vehicle has been involved in a collision, or if noise and rattles are heard during a turn, check the length (L) of the column. If out of specification, replace the steering column as an assembly.



Steering column length (L) : 493 mm (19.4 in)

- Check for proper lubrication, apply grease as necessary.
 - Check for wear around the seal edges, replace as necessary.
 - Check for corrosion or pitting around the seal sliding area.
 - Replace the seal and shaft in case of seal edge wear or damage.
- After installing the steering column, check the tilt mechanism for proper operation.

Tilt mechanism range : 3° per notch at 7 steps (Manual tilt)

CAUTION:

- Do not exert any load or impact in the axial direction immediately before or after column removal.
- After installation check for smooth steering wheel rotation, without any catches or noise.
- Replace the column if it is depleted of grease, worn, damaged, or if any scratches or coating separation is present on the shaft seal area.
- The nut on the upper joint may not be reused.
- During lower joint detachment, insert a tool into the yoke groove to prevent gouging damage.
- A washer must be used on all fastener bolts.



POWER STEERING GEAR AND LINKAGE

PFP:49001

EGS00015

On-Vehicle Service

CHECKING STEERING GEAR

- Check gear housing and boots for looseness and damage, and fluid leakage.
- Check gear housing and boots for fluid leakage. Refer to [PS-6, "Checking Fluid Leakage"](#).
- Check connection with steering column for looseness.
- Prior to removing the steering gear from the vehicle, check rack sliding force. Refer to [PS-16, "CHECKING RACK SLIDING FORCE"](#).
- If rack sliding force is not within specification, adjust rack sliding force. Refer to [PS-22, "Adjustment for Rack Sliding Force"](#).

CHECKING STEERING LINKAGE

- Check ball joint, and other component parts for looseness, wear, and damage.

CHECKING GEAR HOUSING MOVEMENT

1. Check the movement of steering gear housing during stationary steering on a dry paved surface.
 - Apply a force of 49 N (5 kg, 11 lb) to steering wheel to check the gear housing movement.Turn off ignition key while checking.

Movement of gear housing : ± 2 mm (± 0.08 in) or less

2. If movement exceeds the limit, replace or repair as necessary.

CHECKING RACK SLIDING FORCE

1. Disconnect steering column lower joint and knuckle arms from the gear.
2. Start and run engine at idle to make sure steering fluid has reached normal operating temperature.
3. Pull tie-rod slowly, using Tool, to move it from neutral position to ± 11.5 mm (± 0.453 in) at speed of 3.5 mm (0.138 in)/s. Check that rack sliding force is within specification.

Tool number : J-44183-A

Average rack sliding force : 210.7 - 298.9 N (21.49 - 30.49 kg-f, 47.37 - 67.19 lb-f)


Maximum force deviation : 98 N (10 kg-f, 22 lb-f)

4. Check sliding force outside the above range at rack speed 40 mm (1.57 in)/s.

Rack sliding force

Maximum : Not more than 294 N (30 kg-f, 66 lb-f)

Maximum deviation : 147 N (15 kg-f, 33 lb-f)




SST090B

POWER STEERING GEAR AND LINKAGE

Removal and Installation

EGS00016



- | | | |
|---|-------------------------------|------------------------------|
| 1. Cotter pin | 2. Castellated nut | 3. Outer tie rod end |
| 4. Gear housing bracket nut | 5. Gear housing mounting bolt | 6. Gear housing bracket bolt |
| 7. Power steering gear and linkage assembly | 8. Gear housing mounting bolt | |

REMOVAL


CAUTION:

- The rotation of the driver air bag spiral cable is limited. If the steering gear must be removed, set the front wheels in the straight-ahead direction. Do not rotate the steering column while the steering gear is removed.
- Remove the steering wheel and spiral cable before removing the steering lower joint to avoid damaging the SRS spiral cable.

1. Remove the two front tires with power tool.
2. Disconnect the outer tie-rod ends using Tool.


Tool number : HT72520000 (J25730-B)

3. Disconnect the outer swaybar ends with power tool.




POWER STEERING GEAR AND LINKAGE


4. Remove the swaybar bracket rear bolts and loosen the front bolts with power tool.



5. Remove the lower joint pinch bolt.




6. Disconnect the power steering high and low pressure lines from the steering gear.
7. Reposition the swaybar up and out of the way.
8. Remove the two gear housing mounting bolts.
 - Do not remove the gear housing mounting bracket from the gear housing.
9. Remove the power steering gear and linkage assembly.



10. Installation is in the reverse order of removal.

- Install pipe connector.
- Use the specified tightening torque when installing the high-pressure and low-pressure pipe connections. Excessive tightening will damage threads of connection or O-ring.



- The O-ring in low-pressure pipe connector is larger than that in high-pressure connector. Take care to install the proper O-ring.


POWER STEERING GEAR AND LINKAGE

- Initially, tighten nut on tie-rod outer socket and knuckle arm to specification. Then tighten further to align nut groove with first pin hole so that the cotter pin can be installed.

**Outer tie rod grooved nut : 29 - 39 N·m (3 - 4 kg-m,
22 - 29 ft-lb)**

CAUTION:

Tightening torque must not exceed 49 N·m (5 kg-m, 36 ft-lb).



A

B

C

D

E

F

PS

H

I

J

K

L


M

POWER STEERING GEAR AND LINKAGE

EGS00017

Disassembly and Assembly

SEC. 492



WGIA0029E

- | | | |
|------------------|----------------------------|-------------------------|
| 1. Steering gear | 2. Gear housing fluid tube | 3. Boot clamp |
| 4. Dust boot | 5. Boot band | 6. Tie-rod inner socket |
| 7. Inner tie-rod | 8. Outer tie-rod | 9. Cotter pin |

DISASSEMBLY

CAUTION:

Use soft jaws when holding steering gear housing. Handle gear housing carefully, as it is made of aluminum. Do not grip cylinder in a vise.

1. Remove the outer tie-rod sockets.
2. Remove the inner tie-rod sockets and boots.

INSPECTION AFTER DISASSEMBLY

Thoroughly clean all parts in cleaning solvent or Genuine NISSAN PSF II or equivalent. Blow dry with compressed air.

POWER STEERING GEAR AND LINKAGE

Boot


- Check condition of boot. If cracked, replace it.
- Check boots for accumulation of power steering fluid indicating steering gear leak, replace the gear.

Gear

- Thoroughly examine steering gear. If damaged, cracked, leaking, or worn, replace it.

Inner and outer tie-rods


- Check ball joints for swinging force:
Tie-rod outer and inner ball joints swinging force A. Refer to [PS-30, "Steering Gear and Linkage"](#).
- Check ball joint for rotating torque:
Tie-rod outer ball joint rotating torque B. Refer to [PS-30, "Steering Gear and Linkage"](#).
- Check ball joints for axial end play:
Tie-rod outer and inner ball joints axial end play C. Refer to [PS-30, "Steering Gear and Linkage"](#).
- Check condition of dust cover. If cracked, replace outer tie-rod.




ASSEMBLY

1. Install the inner tie-rods.
2. Install the outer tie-rods to the specified length and tighten the outer socket lock nut. Refer to [PS-30, "Steering Gear and Linkage"](#).
Use Genuine High Temperature, High Strength Thread Locking Sealant (Red) or equivalent. Refer to [GI-43, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).


Outer socket lock nut : 37 - 46 N·m (3.8 - 4.7 kg-m, 27 - 34 ft-lb)



3. Measure rack stroke. Refer to [PS-30, "Steering Gear and Linkage"](#).




4. Before installing boot, coat the contact surfaces between boot and tie-rod with grease.



POWER STEERING GEAR AND LINKAGE

5. Install the boot clamps and crimp securely.



EGS00018

Adjustment for Rack Sliding Force DECREASE

Decrease rack sliding force as follows:

1. Loosen adjusting screw two rotations counterclockwise.

CAUTION:


- Do not remove adjusting screw.
- Steering gear must be replaced if adjusting screw is removed or loosened more than two rotations.

2. Tighten adjusting screw in 40° - 60° increments until rack sliding force is within specification.

Average rack sliding force : 210.7 - 298.9 N (21.49 - 30.49 kg-f, 47.37 - 67.19 lb-f)
Maximum force deviation : 98 N (10 kg-f, 22 lb-f)

NOTE:

Steering gear must be replaced if adjusting screw rotation torque is less than 5.0 N·m (0.9 kg-m, 44 in-lb).



3. Verify rack sliding force. Refer to [PS-16. "CHECKING RACK SLIDING FORCE"](#).
4. If rack sliding force is out of specification adjust rack sliding force again.
5. If rack sliding force can not be adjusted within specification replace steering gear.

INCREASE


Increase rack sliding force as follows:

POWER STEERING GEAR AND LINKAGE

1. Tighten adjusting screw until it is flush with housing surface.

CAUTION:

- Do not remove adjusting screw.
- Steering gear must be replaced if adjusting screw is removed or loosened more than two rotations.




2. Loosen adjusting screw in 40° - 60° increments until rack sliding force is within specification.

Average rack sliding force : 210.7 - 298.9 N (21.49 - 30.49 kg-f, 47.37 - 67.19 lb-f)

Maximum force deviation : 98 N (10 kg-f, 22 lb-f)

NOTE:

Steering gear must be replaced if adjusting screw rotation torque is less than 5.0 N·m (0.9 kg-m, 44 in-lb).



3. Verify rack sliding force. Refer to [PS-16, "CHECKING RACK SLIDING FORCE"](#).
4. If rack sliding force is out of specification adjust rack sliding force again.
5. If rack sliding force cannot be adjusted within specification replace steering gear.

POWER STEERING OIL PUMP

PFP:49110

On-Vehicle Service

EGS00019

CHECKING HYDRAULIC SYSTEM

Before starting, check belt tension, driving pulley and tire pressure.

1. Set Tool. Open shut-off valve. Then bleed air. Refer to [PS-7, "Bleeding Hydraulic System"](#).

Tool numbers : KV48103500 (J26357 and J26357-10),
KV48102500 (J33914)

2. Run engine at idle speed or 1,000 rpm.
Make sure temperature of fluid in tank rises to 60 - 80°C (140 - 176°F).

WARNING:

Warm up engine with shut-off valve fully opened. If engine is started with shut-off valve closed, fluid pressure in oil pump increases to maximum. This will raise oil temperature abnormally.

3. Check pressure with steering wheel fully turned to left and right positions with engine idling at 1,000 rpm.

CAUTION:

Do not hold the steering wheel in a locked position for more than 15 seconds.


Oil pump maximum standard pressure : 8,000 - 8,800 kPa (82 - 90 kg/cm, 1,160 - 1,276 psi)

- If pressure reaches maximum operating pressure, system is OK.
 - If pressure increases above maximum operating pressure, check power steering pump flow control valve. Refer to [PS-31, "Power Steering"](#).
4. If power steering pressure is below the maximum operating pressure, slowly close shut-off valve and check pressure again.

CAUTION:

Do not close shut-off valve for more than 15 seconds.

- If pressure increases to maximum operating pressure, gear is damaged. Refer to [PS-17, "Removal and Installation"](#).
 - If pressure remains below maximum operating pressure, pump is damaged. Refer to [PS-24, "Removal and Installation"](#).
5. After checking hydraulic system, remove Tool and add fluid as necessary. Then completely bleed air out of system. Refer to [PS-7, "Bleeding Hydraulic System"](#).



Removal and Installation

EGS0001A

REMOVAL

1. Loosen adjust screw and oil pump fixing bolt, then remove belt.
2. Remove oil pump union bolts and hose.
3. Remove oil pump bracket fixing bolts.
4. Remove oil pump.

INSTALLATION


Installation is in the reverse order of removal.

- Adjust belt tension. Refer to [MA-12, "CHECKING DRIVE BELTS"](#).
- Bleed air after installation. Refer to [PS-7, "Bleeding Hydraulic System"](#).

POWER STEERING OIL PUMP

Disassembly and Assembly

EGS0001B




- | | | |
|---------------------------------|-----------------------|----------------------|
| 1. Pulley | 2. Snap ring | 3. Drive shaft |
| 4. Oil seal | 5. Suction pipe | 6. O-ring |
| 7. Spring | 8. Flow control valve | 9. O-ring |
| 10. Connector | 11. Washer | 12. Joint |
| 13. Connector bolt | 14. Pump case | 15. O-ring |
| 16. O-ring | 17. Front side plate | 18. Vane |
| 19. Rotor | 20. Pin | 21. Cam ring |
| 22. Gasket | 23. Rear cover | 24. Mounting bracket |
| 25. Power steering pump bracket | | |

PRE-DISASSEMBLY INSPECTION

Disassemble the power steering oil pump only if the following items are found.

- Oil leak from any point shown in the figure
- Deformed or damaged pulley
- Poor performance




POWER STEERING OIL PUMP

DISASSEMBLY

CAUTION:

- Parts which can be disassembled are strictly limited. Never disassemble parts other than those specified.
- Disassemble in as clean a place as possible.
- Clean your hands before disassembly.
- Do not use rags; use nylon cloths or paper towels.
- Follow the procedures and cautions in the Service Manual.
- When disassembling and reassembling, do not let foreign matter enter or contact the parts.


1. Remove snap ring, then draw drive shaft out.
 - Be careful not to drop drive shaft.



2. Remove oil seal.

CAUTION:

Be careful not to damage front housing.




3. Remove connector and flow control valve with spring.

CAUTION:

Be careful not to drop flow control valve.

4. Inspect all of the power steering oil pump components, and repair or replace as necessary. Refer to [PS-28, "Inspection After Disassembly"](#).




ASSEMBLY

Assembly is in the reverse order of disassembly, noting the following instructions.


- Make sure O-rings and oil seal are properly installed.
- Always install new O-rings and oil seal.

POWER STEERING OIL PUMP


- Be careful of oil seal direction.
- Cam ring, rotor and vanes must be replaced as a set if necessary.
- Coat each part with Genuine NISSAN PSF, refer to [GI-43, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#) when assembling.



- Pay attention to the direction of rotor.




- When assembling vanes to rotor, rounded surfaces of vanes must face cam ring side.



POWER STEERING OIL PUMP

- Insert pin 2 into pin groove 1 of front housing and front side plate. Then install cam ring 3 as shown.

Cam ring : D_1 is less than D_2



Inspection After Disassembly

- If pulley is cracked or deformed, replace it.
- If an oil leak is found around pulley shaft oil seal, replace the seal.
- If the pulley or pulley shaft is deformed or worn, replace it.


HYDRAULIC LINE

HYDRAULIC LINE

PFP:49721

Removal and Installation

EGS0001D



REMOVAL

Refer to illustration for hydraulic line routing. Remove any components to access lines.

CAUTION:

Be careful to not kink or bend lines.

A

B

C

D

E

F

PS

H

I

J

K

L

M

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00100

General Specifications

EGS000IE

Steering model		Power steering	
		17 inch tire	18 inch tire
Steering gear type		PR26AD	
Steering overall gear ratio		16.1	
Turns of steering wheel (Lock to lock)		2.6	
Steering column type	Standard	Collapsible, tilt, non-motorized telescoping	
	Optional	Collapsible, tilt, motorized telescoping	

Steering Wheel


EGS000IF

Steering wheel axial play mm (in)	0 (0)
Steering wheel play mm (in)	35 (1.38) or less
Movement of gear housing mm (in)	±2 (±0.08) or less

Steering Column

EGS000IG

Applied model	All
Steering column length "L" mm (in)	493 (19.4)




LGIA0020E

Steering Gear and Linkage

EGS000IH

Applied model		All
Steering gear type		PR26AD
Tie-rod outer ball joint	Swinging force at cotter pin hole: "A" N (kg-f, lb-f)	6.47 - 64.63 (0.66 - 6.59, 1.46 - 14.53)
	Rotating torque: "B" N-m (kg-cm, in-lb)	0.29 - 2.94 (3.0 - 30.0, 2.6 - 26.0)
	Axial end play: "C" mm (in)	0.4 (0.016) or less
Tie-rod inner ball joint	Swinging force*: "A" N (kg-f, lb-f)	5.69 - 45.60 (0.58 - 4.65, 1.28 - 10.25)
	Axial end play: "C" mm (in)	0.2 (0.008) or less
Tie-rod standard length "L" mm (in)		213.8 (8.417)


*: Measuring point [I: 172 mm (6.77 in)]



SGIA0167E

SERVICE DATA AND SPECIFICATIONS (SDS)

Rack sliding force N (kg-f, lb-f) Under normal operating oil pressure	Range within ±11.5 mm (±0.453 in) from the neutral position at rack speed of 3.5 mm (0.138 in)/s	Average force	210.7 - 298.9 (21.49 - 30.49, 47.37 - 67.19)
		Maximum force devi- ation	98 (10, 22)
	Except for the above range	Maximum sliding force	294 (30, 66)
		Maximum force devi- ation	147 (15, 33)
Rack stroke “S” mm (in)		65 (2.6)	



SST086BA

Power Steering

EGS000II

Applied model	All
Steering gear type	PR26AD
Pump type	F40
Steering wheel turning force (Measured at one full turn from the neutral position) N (kg-f, lb-f)	39 (4, 9) or less
Fluid capacity (Approximate) ℓ (US pt, Imp pt)	1.0 (2-1/8, 1-3/4)
Oil pump maximum pressure kPa (kg/cm ² , psi)	8,000 - 8,800 (82 - 90, 1,160 - 1,276)

SERVICE DATA AND SPECIFICATIONS (SDS)
