

A

B

C

D

E

F

G

H

I

J

L

M

BCS

SECTION

BCS

BODY CONTROL SYSTEM

CONTENTS

<b>PRECAUTIONS</b> .....	2	CAN Communication System Description .....	8	F
Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER” .....	2	Schematic .....	9	
<b>BCM (BODY CONTROL MODULE)</b> .....	3	CONSULT-II .....	11	G
System Description .....	3	CONSULT–II INSPECTION PROCEDURE .....	11	
BCM FUNCTION .....	3	ITEMS OF EACH PART .....	12	
COMBINATION SWITCH READING FUNCTION .....	3	WORK SUPPORT .....	12	
CAN COMMUNICATION CONTROL .....	6	CAN Communication Inspection Using CONSULT-II (Self-Diagnosis) .....	13	H
BCM STATUS CONTROL .....	6	Configuration .....	14	
SYSTEMS CONTROLLED BY BCM DIRECTLY .....	7	DESCRIPTION .....	14	
SYSTEMS CONTROLLED BY BCM AND IPDM E/R .....	7	READ CONFIGURATION PROCEDURE .....	14	I
MAJOR COMPONENTS AND CONTROL SYSTEM .....	7	WRITE CONFIGURATION PROCEDURE .....	16	
		Removal and Installation of BCM .....	19	
		REMOVAL .....	19	J
		INSTALLATION .....	20	

# PRECAUTIONS

## PRECAUTIONS

PFP:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS004AJ

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

BCM (BODY CONTROL MODULE)

PFP:284B2

System Description

EKS003V1


- BCM (Body Control Module) controls the operation of various electrical units installed on the vehicle.

BCM FUNCTION

BCM has a combination switch reading function for reading the operation of combination switches (light, wiper washer, turn signal) in addition to the function for controlling the operation of various electrical components. Also, it functions as an interface that receives signals from the A/C control unit (with manual A/C), A/C auto amplifier (with auto A/C), and sends signals to ECM using CAN communication.

COMBINATION SWITCH READING FUNCTION

1. Description
  - BCM reads combination switch (light, wiper) status, and controls various electrical components according to the results.
  - BCM reads information of a maximum of 20 switches by combining five output terminals (OUTPUT 1 - 5) and five input terminals (INPUT 1 - 5).
2. Operation description
  - BCM activates transistors of output terminals (OUTPUT 1-5) periodically and allows current to flow in turn.
  - If any (1 or more) of the switches are turned ON, circuit of output terminals (OUTPUT 1-5) and input terminals (INPUT 1-5) becomes active.
  - At this time, transistors of output terminals (OUTPUT 1 - 5) are activated to allow current to flow. When voltage of input terminals (INPUT 1-5) corresponding to that switch changes, interface in BCM detects voltage change and BCM determines that switch is ON.



3. BCM - Operation table of combination switch
  - BCM reads operation status of combination switch by the combination shown in the following table.

## BCM (BODY CONTROL MODULE)

	COMB SW OUTPUT 1		COMB SW OUTPUT 2		COMB SW OUTPUT 3		COMB SW OUTPUT 4		COMB SW OUTPUT 5	
	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
COMB SW INPUT 1	—	—	FR WIPER HI ON	FR WIPER HI OFF	INT VOLUME 1 ON	INT VOLUME 1 OFF	RR WIPER INT ON	RR WIPER INT OFF	INT VOLUME 2 ON	INT VOLUME 2 OFF
COMB SW INPUT 2	FR WASHER ON	FR WASHER OFF	—	—	RR WASHER ON	RR WASHER OFF	INT VOLUME 3 ON	INT VOLUME 3 OFF	RR WIPER ON	RR WIPER OFF
COMB SW INPUT 3	FR WIPER LOW ON	FR WIPER LOW OFF	FR WIPER INT ON	FR WIPER INT OFF	—	—	AUTO LIGHT ON	AUTO LIGHT OFF	—	—
COMB SW INPUT 4	TURN LH ON	TURN LH OFF	PASSING ON	PASSING OFF	HEAD- LAMP 2 ON	HEAD- LAMP 2 OFF	—	—	FR FOG ON	FR FOG OFF
COMB SW INPUT 5	TURN RH ON	TURN RH OFF	HEAD- LAMP 1 ON	HEAD- LAMP 1 OFF	HI BEAM ON	HI BEAM OFF	LIGHTING SW (1st) ON	LIGHTING SW (1st) OFF	—	—


SKIA4959E

**NOTE:**

Headlamp has a dual system switch.

4. Example operation: (When lighting switch 1st position turned ON)
  - When lighting switch 1st position is turned ON, contact in combination switch turns ON. At this time if OUTPUT 4 transistor is activated, BCM detects that voltage changes in INPUT 5.
  - When OUTPUT 4 transistor is ON, BCM detects that voltage changes in INPUT 5, and judges lighting switch 1st position is ON. Then BCM sends tail lamp ON signal to IPDM E/R using CAN communication.
  - When OUTPUT 4 transistor is activated again, BCM detects that voltage changes in INPUT 5 and recognizes that lighting switch 1st position is continuously ON.

## BCM (BODY CONTROL MODULE)



### NOTE:

Each OUTPUT terminal transistor is activated at 10 ms intervals. Therefore, after a switch is turned ON, electrical loads are activated with a time delay. But this time delay is so short that it cannot be noticed.

### 5. Operation mode

- Combination switch reading function has operation modes as follows:


Normal status

- When BCM is not in sleep status, OUTPUT terminals (1 - 5) each turn ON-OFF every 10 ms.

Sleep status

## BCM (BODY CONTROL MODULE)

- When BCM is in sleep mode, transistors of OUTPUT 1 and 5 stop the output, and BCM enters low-current-consumption mode. OUTPUTS (2, 3, and 4) turn ON-OFF at 10 ms intervals, and receives lighting switch input only.



### CAN COMMUNICATION CONTROL

CAN communication allows a high rate of information through the two communication lines (CAN L-line, CAN H-line) connecting the various control units in the system. Each control unit transmits/receives data, but selectively reads required data only.

### BCM STATUS CONTROL

BCM changes its status depending on the operation status in order to save power consumption.

- CAN communication status
  - With ignition switch ON, CAN communicates with other control units normally.
  - Control by BCM is being operated properly.
  - When ignition switch is OFF, switching to sleep mode is possible.
  - Even when ignition switch is OFF, if CAN communication with IPDM E/R and combination meter is active, CAN communication status is active.
- Sleep transient status
  - This status shuts down CAN communication when ignition switch is turned OFF.
  - It transmits sleep request signal to IPDM E/R and combination meter.
  - Two seconds after CAN communication of all control units stops, CAN communication switches to inactive status.
- CAN communication inactive status
  - With ignition switch OFF, CAN communication is not active.
  - With ignition switch OFF, control performed only by BCM is active.
  - Three seconds after CAN communication of all control units stops, CAN communication switches to inactive status.
- Sleep status

## BCM (BODY CONTROL MODULE)

- BCM is activated with low current consumption mode.
- CAN communication is not active.
- When CAN communication operation is detected, it switches to CAN communication status.
- When a state of the following switches changes, it switches to CAN communication state:
  - Key switch
  - Hazard switch
  - Door lock/unlock switch
  - Front door switch (LH, RH)
  - Rear door switch (LH, RH)
  - Trunk switch
  - Combination switch (passing, lighting switch 1st position, front fog lamp)
  - Key fob (lock/unlock signal)
  - Key cylinder switch
- When control performed only by BCM is required by switch, it shifts to CAN communication inactive mode.
- Status of combination switch reading function is changed.

### SYSTEMS CONTROLLED BY BCM DIRECTLY

- Power door lock system. Refer to [BL-17, "POWER DOOR LOCK SYSTEM"](#).
- Remote keyless entry system. Refer to [BL-37, "REMOTE KEYLESS ENTRY SYSTEM"](#).
- Power window system. Refer to [GW-19, "POWER WINDOW SYSTEM"](#). NOTE
- Sunroof system. Refer to [RF-10, "SUNROOF"](#). NOTE
- Room lamp timer. Refer to [LT-149, "INTERIOR ROOM LAMP"](#).
- Warning chime system. Refer to [DI-59, "WARNING CHIME"](#).
- Turn signal and hazard warning lamps system. Refer to [LT-90, "TURN SIGNAL AND HAZARD WARNING LAMPS"](#).
- Front wiper and washer system. Refer to [WW-4, "FRONT WIPER AND WASHER SYSTEM"](#).

#### NOTE:

Power supply only. No system control.

### SYSTEMS CONTROLLED BY BCM AND IPDM E/R

- Panic system. Refer to [BL-37, "REMOTE KEYLESS ENTRY SYSTEM"](#).
- Vehicle security system. Refer to [BL-79, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#).
- NVIS (NATS) system. Refer to [BL-99, "NVIS\(NISSAN Vehicle Immobilizer System-NATS\)"](#).
- Headlamp, tail lamp, auto light and battery saver control systems. Refer to [LT-6, "HEADLAMP \(FOR USA\)"](#) or [LT-43, "HEADLAMP \(FOR CANADA\) - DAYTIME LIGHT SYSTEM -"](#).
- Front wiper and washer system. Refer to [WW-4, "FRONT WIPER AND WASHER SYSTEM"](#).
- Rear window defogger system. Refer to [GW-94, "REAR WINDOW DEFOGGER"](#).

### MAJOR COMPONENTS AND CONTROL SYSTEM

System	Input	Output
Remote keyless entry system	Key fob	<ul style="list-style-type: none"> <li>● All-door locking actuator</li> <li>● Trunk lid opener actuator</li> <li>● Turn signal lamp (LH, RH)</li> </ul>
Power door lock system	Front power door lock/unlock switch (LH, RH)	All-door locking actuator
Power supply (IGN) to power window, sunroof	Ignition power supply	Power supply to power window and sunroof system
Power supply (BAT) to power window, sunroof and power seat	Battery power supply	Power supply to power window, sunroof system and power seat
Panic alarm	<ul style="list-style-type: none"> <li>● Key switch</li> <li>● Key fob</li> </ul>	IPDM E/R

## BCM (BODY CONTROL MODULE)

System	Input	Output
Vehicle security system	<ul style="list-style-type: none"> <li>● All-door switch</li> <li>● Hood switch</li> <li>● Key fob</li> <li>● Front door lock/unlock switch (LH)</li> <li>● Trunk room lamp switch</li> <li>● Trunk lid opener actuator</li> </ul>	<ul style="list-style-type: none"> <li>● IPDM E/R</li> <li>● Security indicator lamp</li> </ul>
Auto light system	<ul style="list-style-type: none"> <li>● Auto light sensor</li> <li>● Combination switch</li> </ul>	IPDM E/R
Battery saver control	<ul style="list-style-type: none"> <li>● Ignition switch</li> <li>● Combination switch</li> </ul>	IPDM E/R
Headlamp	Combination switch	IPDM E/R
Tail lamp	Combination switch	IPDM E/R
Fog lamp	Combination switch	IPDM E/R
Turn signal lamp	Combination switch	<ul style="list-style-type: none"> <li>● Turn signal lamp</li> <li>● Combination meter</li> </ul>
Hazard lamp	Hazard switch	<ul style="list-style-type: none"> <li>● Turn signal lamp</li> <li>● Combination meter</li> </ul>
Room lamp timer	<ul style="list-style-type: none"> <li>● Key switch</li> <li>● Key fob</li> <li>● Front door lock/unlock switch (LH)</li> <li>● Front door switch LH</li> <li>● All-door switch</li> </ul>	Interior room lamp
Key warning chime	<ul style="list-style-type: none"> <li>● Key switch</li> <li>● Front door switch LH</li> </ul>	Combination meter (warning buzzer)
Light warning chime	<ul style="list-style-type: none"> <li>● Combination switch</li> <li>● Key switch</li> <li>● Front door switch LH</li> </ul>	Combination meter (warning buzzer)
Seat belt warning chime	Combination meter (Seat belt buckle switch LH)	Combination meter (warning buzzer)
Vehicle-speed-sensing intermittent wiper	<ul style="list-style-type: none"> <li>● Combination switch</li> <li>● Combination meter</li> </ul>	IPDM E/R
Rear window defogger	Rear window defogger switch	IPDM E/R
Air conditioner switch signal	Unified meter and A/C amp.	ECM
Blower fan switch signal	Unified meter and A/C amp.	ECM

### CAN Communication System Description

EKS003V2


Refer to [LAN-8, "CAN COMMUNICATION"](#) .



BCM (BODY CONTROL MODULE)


Schematic

EKS003V3



LKWA0153E

# BCM (BODY CONTROL MODULE)



LKWA0154E

# BCM (BODY CONTROL MODULE)

## CONSULT-II

EKS003V4

CONSULT-II can display each diagnostic item using the following diagnostic test modes: work support, self-diagnosis results, data monitor and active test through data reception and command transmission via the BCM CAN communication lines.


BCM diagnostic test item	Check item, diagnostic test mode	Content
Inspection by part	Work support	Changes setting of each function.
	Self-diagnosis results	BCM performs self-diagnosis of CAN communication.
	Data monitor	Displays the input data of BCM in real time.
	Active test	Gives a drive signal to a load to check the operation.
	Configuration	Function to write vehicle configuration on BCM.

## CONSULT-II INSPECTION PROCEDURE


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector and turn ignition switch ON.



2. Touch "START(NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.



## BCM (BODY CONTROL MODULE)

4. Select item to be diagnosed on "SELECT TEST ITEM" screen.



### ITEMS OF EACH PART

#### NOTE:


CONSULT-II will only display systems the vehicle possesses.

System and item	CONSULT-II display	Diagnostic test mode (Inspection by part)					
		WORK SUPPORT	SELF-DIAG RESULTS	DATA MONITOR	ECU PART NUMBER	ACTIVE TEST	CONFIGURATION
Power door lock system	DOOR LOCK	×		×		×	
Rear defogger	REAR DEFOGGER			×		×	
Warning chime	BUZZER			×		×	
Room lamp timer	INT LAMP	×		×		×	
Remote keyless entry system	MULTI REMOTE ENT	×		×		×	
Headlamp	HEAD LAMP	×		×		×	
Wiper	WIPER			×		×	
Turn signal lamp Hazard lamp	FLASHER			×		×	
Blower fan switch signal Air conditioner switch signal	AIR CONDITIONER			×			
Combination switch	COMB SW			×			
BCM	BCM		×	×	×		×
NVIS (NATS)	IMMU			×		×	
Interior lamp battery saver	BATTERY SAVER	×		×		×	
Trunk lid	TRUNK			×		×	
Vehicle security system	THEFT ALARM	×		×		×	
Retained power control	RETAINED PWR	×		×		×	
Oil pressure switch	SIGNAL BUFFER			×		×	

### WORK SUPPORT


#### Operation Procedure

1. Touch "BCM" on "SELECT TEST ITEM" screen.



## BCM (BODY CONTROL MODULE)

2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch item on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "RESETTING COMPLETED" will be displayed.
7. Touch "END".



### Display Item List

Item	Description
RESET SETTING VALUE	Return a value set with WORK SUPPORT of each system to a default value in factory shipment.

## CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)

EKS003V5

### 1. SELF-DIAGNOSTIC RESULT CHECK

#### NOTE:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. Connect to CONSULT-II, and select "BCM" on "SELECT SYSTEM" screen.
2. Select "BCM control unit" on "SELECT WORK ITEM" screen, and select "SELF-DIAG RESULTS".
3. Check display content in self-diagnostic results.

CONSULT-II display code	Diagnosis item
U1000	CAN COMM
	CAN CIRC 1
	CAN CIRC 2
	CAN CIRC 3
	CAN CIRC 4
	CAN CIRC 5

#### Contents displayed

No malfunction>>Inspection End  
Malfunction in CAN communication system>>GO TO 2.

### 2. SYMPTOM CHECK

1. Select "CAN diagnosis support monitor" in data monitor.
2. Select "START" and check display content.

Diagnosis item	Self-diagnostic result content	
	Normal	Not normal (Example)
CAN COMM	OK	NG
CAN CIRC 1	OK	UNKWN
CAN CIRC 2	OK	UNKWN
CAN CIRC 3	OK	UNKWN
CAN CIRC 4	OK	UNKWN
CAN CIRC 5	OK	UNKWN

>> After printing the monitor items, go to "CAN System". Refer to [LAN-8, "CAN COMMUNICATION"](#).

# BCM (BODY CONTROL MODULE)

EKS004T2

## Configuration DESCRIPTION

CONFIGURATION has two functions as follows:

- READ CONFIGURATION is the function to confirm vehicle configuration of current BCM.
- WRITE CONFIGURATION is the function to write vehicle configuration on BCM.

### CAUTION:


- When replacing BCM, you must perform WRITE CONFIGURATION with CONSULT-II.
- Complete the procedure of WRITE CONFIGURATION in order.
- If you set incorrect WRITE CONFIGURATION, incidents will occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.

## READ CONFIGURATION PROCEDURE


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector and turn ignition switch ON.



2. Touch "START(NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT ITEM" screen. If "BCM" is not indicated, go to LAN Section to check data link connector (DLC) circuit.



BCM (BODY CONTROL MODULE)

4. Touch “BCM” on “SELECT TEST ITEM” screen.




A

B

C

D

5. Touch “CONFIGURATION” on “SELECT DIAG MODE” screen.



E


F

G

6. Touch “A34” and "OK" on “VEHICLE SELECT” screen. For canceling, touch "CANCEL" on "VEHICLE SELECT" screen.

**NOTE:**

Confirm vehicle model on IDENTIFICATION PLATE. Refer to [GI-44, "Model Variation"](#) in GI section.




H

I

J

BCS

7. Touch “READ CONFIGURATION” on “CONFIGURATION” screen.



L

M

## BCM (BODY CONTROL MODULE)

8. Configuration of current BCM is printed out automatically. Configuration of brand-new BCM before executing "WRITE CONFIGURATION" is as follows:

MANUAL SETTING ITEM	
Items	Setting Value
DTRL	WITHOUT
AUTO SETTING ITEM	
NON ITEM	

NISSAN  
CONSULT-II  
READ CONFIGURATION

SYSTEMXXXXXXXXX  
DATEMM/DD/YYYY HH:MM:SS  
P#P#  
VEHICLEXX

MANUAL SETTING ITEM

Items	Setting Value
DTRL	WITHOUT

AUTO SETTING ITEM

NON ITEM

LKIA0173E

9. Touch "BACK" on "READ CONFIGURATION" screen.

READ CONFIGURATION

DTRL	WITHOUT


LKIA0174E

### WRITE CONFIGURATION PROCEDURE

#### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector and turn ignition switch ON.






# BCM (BODY CONTROL MODULE)


- Touch "START(NISSAN BASED VHCL)".




- Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, go to LAN Section to check data link connector (DLC) circuit.



- Touch "BCM" on "SELECT TEST ITEM" screen.




- Touch "CONFIGURATION" on "SELECT DIAG MODE" screen.



- Touch "A34" and "OK" on "VEHICLE SELECT" screen. For canceling, touch "CANCEL" on "VEHICLE SELECT" screen.

**NOTE:**

Confirm vehicle model on IDENTIFICATION PLATE. Refer to [GI-44, "Model Variation"](#) in GI section.



A

B

C

D

E

F

G

H

I

J


BCS

L


M

## BCM (BODY CONTROL MODULE)

7. Touch "WRITE CONFIGURATION" on "CONFIGURATION" screen.



8. Touch "OK".  
For canceling, touch "CANCEL".




9. Touch "CAN DTRL" or "WITHOUT" on "WRITE CONFIGURATION" screen based on the following ITEM LIST.

ITEM	SET VAL	NOTE
DTRL (Daytime running light)	CAN DTRL	Canadian specification vehicle
	WITHOUT	United States specification vehicle

**NOTE:**

Confirm vehicle model on IDENTIFICATION PLATE. Refer to [GI-44, "Model Variation"](#) in GI section.




10. Touch "CHNG SETTING" on "WRITE CONFIGURATION" screen.

**CAUTION:**

**Make sure to touch "CHNG SETTING" even if the indicated configuration of brand-new BCM is same as the desirable configuration.**


**If not, configuration which is set automatically by selecting vehicle model cannot be memorized.**

11. Touch "OK" on "WRITE CONFIGURATION" screen.  
If "CANCEL" is touched, it will return to previous screen.




# BCM (BODY CONTROL MODULE)


12. Wait until the next screen during setting.



13. WRITE CONFIGURATION results are printed out automatically. Check "WRITE CONFIGURATION" is correctly executed by comparing sheet automatically printed out with desirable configuration.



14. Touch "OK" on "WRITE CONFIGURATION" screen. WRITE CONFIGURATION is completed.



## Removal and Installation of BCM REMOVAL


### NOTE:

If possible, before removing BCM, retrieve current BCM configuration to use for reference when configuring brand-new BCM after installation. Refer to [BCS-14, "Configuration"](#) .

1. Disconnect negative battery cable.
2. Remove driver lower instrument panel. Refer to [IP-14, "Lower Driver Instrument Panel"](#) .

## BCM (BODY CONTROL MODULE)

3. Remove screws (2) and release BCM from steering member.
4. Disconnect connectors and then remove BCM.



### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

- When replacing BCM, it must be configured. Refer to [BCS-14, "Configuration"](#) .
- When replacing BCM, perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-99, "NVIS\(NISSAN Vehicle Immobilizer System-NATS\)"](#) .