

SECTION **IDX**
ALPHABETI CAL I NDEX

A
B
C
D
E
F
G
H
I
J
K
L

IDX

ALPHABETICAL INDEX

A

A/C air flow	ATC-27	A/T Wiring diagram AT - TCCSIG	AT-155 , AT-512
A/C compressor clutch removal and installation ..	ATC-120	A/T Wiring diagram AT - TCV	AT-150
A/C compressor mounting	ATC-119	A/T Wiring diagram AT - TPS	AT-180
A/C compressor precaution	ATC-9	A/T Wiring diagram AT - VSS A/T	AT-119
A/C compressor special service tool	ATC-12	A/T Wiring diagram AT - VSSMTR	AT-199 , AT-204
A/C control operation (auto A/C)	ATC-24	A/T Wiring diagram AT ? PC/A	AT-515
A/C diagnostic work flow (auto A/C)	ATC-87	A/T Wiring diagram AT ? PC/B	AT-546
A/C evaporator	ATC-124	A/T Wiring diagram AT ? PC/C	AT-553
A/C HFC134a (R134a) system identification	ATC-6	A/T Wiring diagram AT ? PC/CS	AT-557
A/C HFC134a (R134a) system precaution	ATC-4	A/T Wiring diagram AT ? PWR/IN	AT-567
A/C HFC134a (R134a) system service procedure	ATC-116	A/T Wiring diagram AT ? SFTFNC	AT-550
A/C HFC134a (R134a) system service tools ...	ATC-12	A/T Wiring diagram AT ? TRSC	AT-482
A/C HFC134a system service equipment precaution ...	ATC-9	A/T Wiring diagram AT ? VSSATC	AT-486
A/C lubricant (R134a)	ATC-18	Accelerator control system	ACC-2
A/C lubrication oil	ATC-18	Accelerator pedal position (APP) sensor	EC-598 , EC-604 , EC-616
A/C operational check	ATC-50	Accelerator pedal released position learning	EC-47
A/C self-diagnoses (auto A/C)	ATC-42 , ATC-87	Active damper suspension system - Wiring diagram	FSU-4
A/C service data specification	ATC-130	AF1B1-Wiring diagram	EC-478 , EC-485 , EC-492 , EC-501 , EC-511 , EC-518 , EC-529
A/C system description (auto A/C)	ATC-21	AF1B2-Wiring diagram	EC-480 , EC-487 , EC-494 , EC-503 , EC-513 , EC-520 , EC-531
A/C trouble diagnoses (auto A/C)	ATC-30	AF1HB1-Wiring diagram	EC-395
A/C, A - Wiring diagram	ATC-36	AF1HB2-Wiring diagram	EC-397
A/T - Wiring diagram	AT-18	Aiming adjustment	LT-39
A/T fluid checking	AT-393 , AT-432	Air bag	SRS-3
A/T fluid replacement	AT-393	Air bag disposal	SRS-52
A/T fluid temperature sensor	AT-111 , AT-471 , AT-476	Air bag precautions	GI-3
A/T IND - Wiring diagram	DI-54	Air bleeding (hydraulic clutch)Air bleeding (hydraulic clutch)	CL-7
A/T indicator	DI-54	Air bleeding for brake systemAir bleeding for brake system	BR-8
A/T self-diagnoses	AT-43 , AT-53 , AT-54 , AT-452 , AT-457	Air cleaner and air duct	EM-15
A/T shift lock system	AT-260 , AT-592	Air cleaner filter replacement	MA-16
A/T shift lock system - Wiring diagram	AT-261 , AT-593	Air conditioner cut control	EC-32
A/T trouble diagnoses	AT-422	Air flow meter - See Mass air flow sensor	EC-162 , EC-170
A/T Wiring diagram AT - 1ST	AT-128 , AT-492	Air fuel ratio sensor 1 ..	EC-476 , EC-483 , EC-490 , EC-499 , EC-508 , EC-516 , EC-527
A/T Wiring diagram AT - 2ND	AT-133 , AT-496	Air fuel ratio sensor 1 heater	EC-393
A/T Wiring diagram AT - 3RD	AT-138 , AT-501	Air mix. door motor	ATC-61
A/T Wiring diagram AT - 4TH	AT-143 , AT-505	Ambient sensor	ATC-89 , ATC-101
A/T Wiring diagram AT - 5TH	AT-509	Angular tightening application	EM-4
A/T Wiring diagram AT - BA/FTS	AT-193	APPS1 - Wiring diagram	EC-600
A/T Wiring diagram AT - CAN	AT-189 , AT-460	APPS2 - Wiring diagram	EC-606
A/T Wiring diagram AT - ENG SS	AT-123	APPS3 - Wiring diagram	EC-618
A/T Wiring diagram AT - FTS	AT-113 , AT-472	ASC/BS - Wiring diagram	EC-569
A/T Wiring diagram AT - FTSP	AT-477	ASC/SW - Wiring diagram	EC-562
A/T Wiring diagram AT - LPSV	AT-163	ASCSOF - Wiring diagram	EC-666
A/T Wiring diagram AT - MAIN	AT-102	ASCD	EC-695
A/T Wiring diagram AT - MMSW	AT-561	ASCD brake switch	EC-567 , EC-665
A/T Wiring diagram AT - NONDTC	AT-211	ASCD clutch switch	EC-567 , EC-665
A/T Wiring diagram AT - OVRCSV	AT-185	ASCD indicator lamp	EC-675
A/T Wiring diagram AT - PNP/SW	AT-107 , AT-467	ASCD steering switch	EC-560
A/T Wiring diagram AT - SSV/A	AT-169 , AT-519	ASCIND - Wiring diagram	EC-676
A/T Wiring diagram AT - SSV/B	AT-174 , AT-523	AUDIO - Wiring diagram	AV-12
A/T Wiring diagram AT - SSV/C	AT-527	AUT/DP - Wiring diagram	SE-19
A/T Wiring diagram AT - SSV/CS	AT-532	Auto air conditioner - Wiring diagram	ATC-36
A/T Wiring diagram AT - SSV/D	AT-537		
A/T Wiring diagram AT - SSV/E	AT-542		

ALPHABETICAL INDEX

Auto anti-dazzling inside mirror [GW-92](#), [GW-93](#)
Automatic amplifier [ATC-40](#), [ATC-52](#)
Automatic transaxle number [GI-44](#)
Automatic transmission fluid replacement [MA-22](#)
AV and NAVI control unit [AV-98](#)
AV communication line [AV-78](#), [AV-121](#)

B

Back door trim [EI-30](#)
BACK/L - Wiring diagram [LT-132](#)
Back-up lamp [LT-132](#)
Back-up lamp switch (M/T)Back-up lamp switch [MT-12](#)
Basic inspection [EC-84](#)
Battery [SC-4](#)
Battery/Starting/Charging System Tester [SC-6](#), [SC-14](#),
[SC-26](#)
Baulk ring (M/T) [MT-20](#)
BCM (Body control module) [BCS-3](#)
Block heater [EM-121](#)
Blower motor [ATC-67](#), [ATC-106](#)
Blower unit [ATC-105](#)
Board computer [AV-68](#)
Board-on lift [GI-38](#)
Body alignment [BL-133](#)
Body component parts [BL-122](#)
Body construction [BL-132](#)
Body exterior paint color [BL-121](#)
Body repair [BL-121](#)
Body sealing [BL-129](#)
Bose speaker amp. [AV-7](#)
Brake boosterBrake booster [BR-18](#)
Brake control valve (Proportioning valve)Brake control
valve (Proportioning valve) [BR-36](#)
Brake fluid changeBrake fluid change [BR-8](#)
Brake fluid level [MA-25](#)
Brake fluid level and line checkBrake fluid level and line
check [BR-8](#)
Brake hydraulic lineBake hydraulic line [BR-9](#)
Brake inspection [MA-26](#)
Brake lines and cables inspection [MA-25](#)
Brake master cylinderBrake master cylinder [BR-12](#)
Brake pedalBrake pedal [BR-6](#)
Brake switch [EC-567](#), [EC-593](#), [EC-665](#)
BRK/SW - Wiring diagram [EC-594](#)
Bulb specifications [LT-187](#)
Bumper, front [EI-14](#)
Bumper, rear [EI-16](#)

C

Camshaft [EM-80](#)
Camshaft inspection [EM-86](#)
Camshaft position sensor (PHASE) [EC-279](#)
CAN - Wiring diagram [EC-148](#), [LAN-23](#), [LAN-41](#), [LAN-60](#),
[LAN-79](#), [LAN-99](#), [LAN-121](#), [LAN-143](#), [LAN-167](#),
[LAN-191](#), [LAN-211](#), [LAN-233](#), [LAN-255](#), [LAN-279](#), [LAN-303](#),
[LAN-323](#), [LAN-345](#)
CAN (Controller Area Network) [BRC-11](#), [BRC-52](#),

[BRC-96](#), [LAN-8](#), [LAN-21](#), [LAN-39](#), [LAN-58](#), [LAN-77](#),
[LAN-97](#), [LAN-119](#), [LAN-141](#), [LAN-165](#), [LAN-189](#), [LAN-209](#),
[LAN-231](#), [LAN-253](#), [LAN-277](#), [LAN-301](#), [LAN-321](#),
[LAN-343](#)
CAN communication . [EC-33](#), [EC-147](#), [AT-31](#), [AT-188](#),
[AT-413](#), [AT-459](#), [BRC-11](#), [BRC-52](#), [BRC-96](#), [LAN-8](#),
[LAN-21](#), [LAN-39](#), [LAN-58](#), [LAN-77](#), [LAN-97](#), [LAN-119](#),
[LAN-141](#), [LAN-165](#), [LAN-189](#), [LAN-209](#), [LAN-231](#), [LAN-253](#),
[LAN-277](#), [LAN-301](#), [LAN-321](#), [LAN-343](#)
Canister-See EVAP canister [EC-683](#)
CHARGE - Wiring diagram [SC-25](#)
Charging system [SC-24](#)
Chassis and body maintenance [MA-20](#)
Chassis and body maintenanceSchedule 1 [MA-7](#)
Chassis and body maintenanceSchedule 2 [MA-8](#)
CHIME - Wiring diagram [DI-61](#)
CIGAR - Wiring diagram [WW-33](#)
Cigarette lighter [WW-33](#)
Circuit breaker [PG-60](#)
Closed loop control [EC-30](#)
Closed loop control (Bank 1) [EC-454](#)
Closed loop control (Bank 2) [EC-454](#)
Clutch coverClutch cover [CL-15](#)
Clutch discClutch disc [CL-15](#)
Clutch fluid level [MA-20](#)
Clutch master cylinderClutch master cylinder [CL-8](#)
Clutch operating cylinderClutch operating cylinder [CL-10](#)
Clutch pedalClutch pedal [CL-5](#)
Clutch release mechanismClutch release mechanism .
[CL-13](#)
Coil spring (front) [FSU-9](#)
Coil spring (rear)Coil spring [RSU-9](#)
Collision diagnosis [SRS-59](#)
Combination lamp, front, removal and installation .. [LT-41](#)
Combination lamp, rear, removal and installation .. [LT-148](#)
Combination meter [DI-5](#)
Combination switch [LT-123](#)
COMM - Wiring diagram [AV-78](#), [AV-121](#)
COMPAS - Wiring diagram [DI-42](#)
Component Location (auto A/C) [ATC-33](#)
Compressor clutch removal and installation .. [ATC-120](#)
Compressor mounting [ATC-119](#)
Compressor precaution [ATC-9](#)
Compressor special service tool [ATC-12](#)
Condenser [ATC-123](#)
Connector inspection [GI-22](#)
Console box - See Instrument panel [IP-10](#)
CONSULT for VDC [BRC-24](#), [BRC-65](#), [BRC-112](#)
CONSULT general information [GI-35](#)
CONSULT-áU for engine [EC-112](#)
Control unit [ATC-100](#)
Control units (terminal arrangement) [PG-64](#)
Controller Area Network (CAN) [BRC-11](#), [BRC-52](#),
[BRC-96](#), [LAN-8](#), [LAN-21](#), [LAN-39](#), [LAN-58](#), [LAN-77](#),
[LAN-97](#), [LAN-119](#), [LAN-141](#), [LAN-165](#), [LAN-189](#), [LAN-209](#),
[LAN-231](#), [LAN-253](#), [LAN-277](#), [LAN-301](#), [LAN-321](#),

A
B
C
D
E
F
G
H
I
J
K
L

I DX

ALPHABETICAL INDEX

LAN-343

Converter housing installation	AT-370
COOL/F - Wiring diagram	EC-460
Coolant mixture ratio	MA-11
Coolant replacementVQ35DE	MA-14
Cooling fan control	EC-457
Cooling fan motor	EC-457
Cooling unit (A/C evaporator)	ATC-109 , ATC-124
Cornering lamp	LT-108
Corrosion protection	BL-126
Coupling sleeve (M/T)	MT-20
Crankcase ventilation system - See Positive crankcase ventilation	EC-693
Crankshaft position sensor (POS)	EC-273
Crash zone sensor	SRS-48
Cylinder block	EM-121
Cylinder head	EM-99

D

Data link connector for Consult	EC-114 , EC-126
Daytime light system	LT-43
Daytime running light - See Daytime light system ..	LT-43
Diagnosis sensor unit	SRS-51
Diagnostic trouble code (DTC) for OBD system .	EC-9 , EC-57
Diagnostic trouble code (DTC) inspection priority chart	EC-81
Differential gear (FF M/T)	MT-24
Dimensions	GI-44
Display and amp.assembly	ATC-40 , ATC-52
Display Control Unit	AV-191
Display Unit	AV-95 , AV-191
Door glass	GW-87 , GW-90
Door glass Fitting Adjustment(Front)	GW-88
Door glass Fitting Adjustment(Rear)	GW-91
Door lock	BL-68
Door trim	EI-30
Door, front	BL-65 , GW-87
Door, rear	BL-65 , GW-90
Drive shaft (front)	FAX-11
Driver air bag	SRS-40
Dropping resistor (A/T)	AT-161
DTC work support	EC-124
DTRL - Wiring diagram	LT-46
Duct and grilles	ATC-114

E

ECM input/output signal	EC-103 , EC-129
ECM power supply	EC-140 , EC-401
ECM/PW - Wiring diagram	EC-402
ECTS - Wiring diagram	EC-183
EGR function	EC-287 , EC-538
EGR temperature sensor	EC-302
EGR volume control valve	EC-295
EGR/TS - Wiring diagram	EC-305
EGRC1 - Wiring diagram	EC-291 , EC-542

EGVC/V - Wiring diagram	EC-297
Electric sunroof	RF-10
Electric throttle control actuator	EC-412 , EC-414
Electrical diagnoses	GI-22
Electrical load signal circuit	EC-664
Electronic ignition (EI) system	EC-31
EMNT - Wiring diagram	EC-655
Engine control circuit diagram	EC-101
Engine control component parts location	EC-93
Engine control module (ECM)	EC-390
Engine control system diagram and chart	EC-26
Engine coolant temperature sensor (ECTS) ..	EC-181 , EC-199
Engine mounting control (Front)	EC-654
Engine oil	LU-6
Engine oil filter replacementQR25DE	MA-17
Engine oil precautions	GI-3 , GI-6
Engine oil replacementQR25DE	MA-16
Engine removal	EM-116
Engine serial number	GI-44
ETC1 - Wiring diagram	EC-415
ETC2 - Wiring diagram	EC-422
ETC3 - Wiring diagram	EC-426
EVAP canister	EC-683
EVAP canister purge volume control solenoid valve	EC-327 , EC-545
EVAP canister vent control valve	EC-334 , EC-553
EVAP control system (small leak) diagnosis ..	EC-317 , EC-355 , EC-363
EVAP control system pressure sensor	EC-341 , EC-347
EVAP control system purge flow monitoring diagnosis .	EC-312
EVAP vapor lines inspection	MA-19
Evaporative emission (EVAP) system	EC-680
Evaporator	ATC-124
Exhaust manifold	EM-26
Exhaust system inspection	EX-3 , MA-20
Expansion valve	ATC-125

F

F/FOG - Wiring diagram	LT-79
F/PUMP - Wiring diagram	EC-649
Fan control amp.	ATC-113
Final drive (FF M/T)	MT-24
Flow charts	GI-25
Fluid temperature sensor (A/T) ..	AT-111 , AT-471 , AT-476
Fluids	MA-10
Fluorescent leak detector	ATC-126
Flywheel (clutch)Flywheel (clutch)	CL-15
Fog lamp, front	LT-77
Foot lamp	LT-150
Fork rod (M/T)	MT-22
Freeze frame data	EC-58 , EC-116
Front bumper	EI-14
Front combination lamp removal and installation	LT-41
Front disc brakeFront disc brake	BR-23
Front door	BL-65 , BL-68 , GW-87

ALPHABETICAL INDEX

Front Door Trim [EI-30](#)
 Front fog lamp [LT-77](#)
 Front passenger air bag [SRS-44](#)
 Front seat [SE-104](#)
 Front seat belt [SB-4](#)
 Front seat belt pre-tensioner [SB-2](#), [SRS-3](#), [SRS-50](#)
 Front side air bag [SRS-45](#)
 FTTS - Wiring diagram [EC-248](#), [EC-252](#)
 Fuel cut control (at no load high engine speed) [EC-32](#)
 Fuel gauge [DI-5](#)
 Fuel injection system (Bank 1) [EC-229](#), [EC-238](#)
 Fuel injection system (Bank 2) [EC-229](#), [EC-238](#)
 Fuel injector and fuel tube [EM-39](#)
 Fuel level sensor [EC-373](#), [EC-375](#), [EC-377](#)
 Fuel line inspection [FL-3](#), [MA-16](#)
 Fuel precautions [GI-3](#), [GI-5](#)
 Fuel pressure check [EC-50](#)
 Fuel pressure release [EC-50](#)
 Fuel pump [EC-648](#)
 Fuel system [FL-3](#)
 Fuel systemCommercial Service Tools [FL-2](#)
 Fuel systemPREPARATION [FL-2](#)
 Fuel tank temperature sensor [EC-246](#), [EC-251](#)
 Fuel tank vacuum relief valve [EC-683](#)
 FUELB1 - Wiring diagram [EC-231](#), [EC-240](#)
 FUELB2 - Wiring diagram [EC-232](#), [EC-241](#)
 Fuse [PG-60](#), [PG-68](#)
 Fuse block [PG-67](#)
 Fusible link [PG-60](#), [PG-68](#)

G

Garage jack and safety stand [GI-38](#)
 Gauges [DI-5](#)
 Gear components (M/T) [MT-20](#)
 Generic scan tool (GST) [EC-126](#)
 Glass [GW-11](#), [GW-14](#), [GW-87](#), [GW-90](#)
 Glove box lamp [LT-175](#)
 GPS antenna [AV-97](#)
 Grease [MA-10](#)
 Ground distribution [PG-27](#)

H

H/LAMP - Wiring diagram [LT-11](#)
 Handling precautions for plastics [BL-144](#)
 Harness connector [PG-61](#)
 Harness connector inspection [GI-22](#)
 Harness layout [PG-36](#)
 Hazard warning lamp [LT-90](#), [LT-108](#)
 Headlamp [LT-6](#)
 Headlamp removal and installation [LT-41](#)
 Heated oxygen sensor 2 (bank 1) [EC-207](#), [EC-217](#),
[EC-430](#), [EC-442](#)
 Heated oxygen sensor 2 (bank 2) [EC-207](#), [EC-217](#),
[EC-430](#), [EC-442](#)
 Heated oxygen sensor 2 heater (bank 1) [EC-153](#)
 Heated oxygen sensor 2 heater (bank 2) [EC-153](#)
 Heated seat [SE-93](#)

Heater and cooling unit (Heater core) [ATC-109](#), [ATC-110](#)
 Heater unit (heater core) [ATC-109](#), [ATC-110](#)
 Height (Dimensions) [GI-44](#)
 HFC134a (R134a) system identification [ATC-6](#)
 HFC134a (R134a) system precaution [ATC-4](#)
 HFC134a (R134a) system service procedure [ATC-116](#)
 HFC134a (R134a) system service tools [ATC-12](#)
 HFC134a system service equipment precaution [ATC-9](#)
 Horn [WW-37](#)
 HORN - Wiring diagram [WW-37](#)
 How to erase DTC for OBD system [EC-67](#)
 HSEAT - Wiring diagram [SE-94](#), [SE-96](#)

I

IATS - Wiring diagram [EC-178](#)
 Identification plate [GI-44](#)
 Idle air volume learning [EC-48](#)
 Idle mixture ratio [EC-36](#)
 Idle speed [EC-36](#), [EC-84](#)
 Idle speed control (ISC) [EC-381](#), [EC-383](#)
 Ignition coil [EM-36](#), [EC-622](#)
 Ignition control system [EC-622](#)
 Ignition timing [EC-36](#), [EC-84](#)
 IGNSYS - Wiring diagram [EC-623](#)
 Illumination control [LT-186](#)
 In vehicle sensor [ATC-92](#), [ATC-102](#)
 INF/D - Wring diagram [AV-73](#)
 INJECT - Wiring diagram [EC-643](#)
 Injector [EC-642](#)
 Input shaft (FF M/T) [MT-20](#)
 Instrument panel [IP-10](#)
 Intake air temperature sensor [EC-177](#), [EC-202](#)
 Intake door control linkage adjustment [ATC-66](#)
 Intake door motor [ATC-64](#), [ATC-107](#)
 Intake manifold [EM-24](#)
 Intake sensor [ATC-98](#), [ATC-104](#)
 Intake valve timing control (Bank 1) [EC-150](#)
 Intake valve timing control (Bank 2) [EC-150](#)
 Intake valve timing control solenoid valve (Bank 1) [EC-405](#)
 Intake valve timing control solenoid valve (Bank 2) [EC-405](#)
 Interior [EI-32](#)
 Interior lamp [LT-149](#)
 Interior lamp on-off control [LT-150](#)
 IPDM (Intelligent power distribution module engine room) [PG-14](#)
 IVCB1 - Wiring diagram [EC-406](#)
 IVCB2 - Wiring diagram [EC-408](#)

J

Jacking points [GI-38](#)
 Junction box (J/B) [PG-67](#)

A
B
C
D
E
F
G
H
I
J
K
L
I DX

ALPHABETICAL INDEX

K

Key illumination	LT-150
Keyless entry system - See Multi-remote control system	
BL-37	
Knock sensor (KS)	EC-268
KS - Wiring diagram	EC-269

L

LAN system circuit	ATC-55
Length (Dimensions)	GI-44
Lifting points	GI-38
Line pressure solenoid valve	AT-161
Line pressure test (A/T)	AT-71 , AT-434
Liquid gasket application	EM-4
Location of electrical units	PG-57
Lubricant (R134a) A/C	ATC-18
Lubricants	MA-10
Lubrication circuit (engine)	LU-4
Lubrication oil A/C	ATC-18
Lubrication-locks, hinges and hood latches	MA-30
Luggage compartment trim	EI-42

M

M/T major overhaul	MT-24
M/T oil replacementM/T oil replacement	MT-10
MAFS - Wiring diagram	EC-165 , EC-172
Magnet clutch	ATC-72 , ATC-120
MAIN - Wiring diagram	EC-140
Mainshaft (M/T)	MT-20
Maintenance	MA-4
Malfunction indicator lamp (MIL)	EC-69
Manual transaxle number	GI-44
Manual transmission oil replacement	MA-20
Map lamp	LT-150
Mass air flow sensor (MAFS)	EC-162 , EC-170
Master cylinder (brake)Master cylinder (brake) ..	BR-12
Master cylinder (clutch)Master cylinder (clutch) ..	CL-8
Meter	DI-5
METER - Wiring diagram	DI-11
MIL data link connectors circuit	EC-678
MIL/DL - Wiring diagram	EC-678
Misfire	EC-261
Mode door control linkage adjustment	ATC-60
Mode door motor	ATC-58 , ATC-111
Model variation	GI-44
Multiport fuel injection (MFI) system	EC-29
Multiport fuel injection precautions	GI-3 , GI-5
Multi-remote control system	BL-37

N

NATS - Wiring diagram	BL-102
NAVI - Wiring diagram	AV-113
NAVI Control Unit	AV-191
Navigation system	AV-96
NVH troubleshooting (BR)NVH troubleshooting (BR) ...	

BR-5

NVH troubleshooting (CL)NVH troubleshooting (CL)	
CL-4	
NVH troubleshooting (EM)	EM-10
NVH troubleshooting (FA)	FAX-4
NVH troubleshooting (RA)	RAX-4
NVH troubleshooting (RSU)NVH Troubleshooting (RSU)	
RSU-4	
NVH troubleshooting (ST)	PS-5
NVH troubleshooting (WT)NVH troubleshooting (WT) ..	
WT-2	

O

O2H2B1 - Wiring diagram	EC-155
O2H2B2 - Wiring diagram	EC-157
O2S2B1 - Wiring diagram ..	EC-209 , EC-220 , EC-433 , EC-445
O2S2B2 - Wiring diagram ..	EC-211 , EC-222 , EC-435 , EC-447
Oil filter	LU-8
Oil pump (engine)	LU-9
Oil seal replacement (engine)	EM-93
On board diagnostic system	EC-52
Operating cylinder (clutch)Operating cylinder (clutch) ..	
CL-10	
ORVR (On-board Refueling Vapor Recovery)	EC-687
Overdrive control switch	AT-255
Overheat	EC-457
Overrun clutch solenoid valve	AT-183

P

Park/Neutral position switch	EC-580
Park/neutral position switch (A/T)	AT-105 , AT-466
Park/neutral position switch (M/T)Park/neutral position switch (M/T)	MT-12
Parking brake controlParking brake control	PB-2
Parking drum brakeParking drum brake	PB-5
PCV (positive crankcase ventilation)	EC-693
Periodic maintenance	MA-6
Personal lamp	LT-150
PGC/V - Wiring diagram	EC-329 , EC-547
PHSB1 - Wiring diagram	EC-280
PHSB2 - Wiring diagram	EC-282
Piston ring inspection	EM-139
PNP/SW - Wiring diagram	EC-582
POS - Wiring diagram	EC-274
POWER - Wiring diagram	PG-5
Power seat	SE-89
Power steering fluid level	MA-27
Power steering pressure (PSP) sensor	EC-385
Power supply routing	PG-3
Power transistor	EC-622
Power window	GW-19
PRE/SE - Wiring diagram	EC-343 , EC-349
Precautions (General)	GI-3
Precautions in repairing high strength steel	BL-147
Pressure control solenoid valve A	AT-514

ALPHABETICAL INDEX

Pressure control solenoid valve B [AT-545](#)
 Pressure control solenoid valve C [AT-552](#)
 Pressure test (A/T) [AT-71](#), [AT-434](#)
 PS/SEN - Wiring diagram [EC-386](#)

R

Rear bumper [EI-16](#)
 Rear combination lamp removal and installation ... [LT-148](#)
 Rear disc brakeRear disc brake [BR-29](#)
 Rear door [BL-65](#), [GW-90](#)
 Rear seat [SE-110](#)
 Rear seat belt [SB-5](#)
 Rear suspensionRear suspension [RSU-5](#)
 Rear window [GW-14](#)
 Rear window defogger [GW-94](#)
 Refrigerant connection precaution [ATC-6](#)
 Refrigerant discharging evacuating charging [ATC-116](#)
 Refrigerant general precaution [ATC-5](#)
 Refrigerant lines [ATC-116](#)
 Refrigerant pressure sensor ... [EC-659](#), [ATC-77](#), [ATC-123](#)
 Remote keyless entry system [BL-37](#)
 Removal and installation (A/T) [AT-274](#), [AT-602](#)
 Reverse idler shaft (M/T) [MT-20](#)
 Reverse main gear (M/T) [MT-20](#)
 Revolution sensor (A/T) [AT-117](#), [AT-485](#)
 Road wheel size [GI-44](#)
 Rocker cover [EM-42](#)
 Room lamp - See Interior lamp [LT-149](#)
 ROOM/L - Wiring diagram [LT-154](#)
 RP/SEN - Wiring diagram [EC-660](#)

S

SAE J1930 terminology list [GI-48](#)
 SEAT - Wiring diagram [SE-89](#), [SE-90](#)
 Seat belt inspection [SB-6](#), [MA-30](#)
 Seat belt pre-tensioner disposal [SRS-52](#)
 Seat belt, front [SB-4](#)
 Seat belt, rear [SB-5](#)
 Seat, front [SE-104](#)
 Seat, rear [SE-110](#)
 SEN/PW - Wiring diagram [EC-473](#)
 SHIFT - Wiring diagram [AT-261](#), [AT-593](#)
 Shift control components (M/T) [MT-22](#)
 Shift control components (M/T)Shift control components (M/T) [MT-13](#)
 Shift fork (M/T) [MT-22](#)
 Shift lock system [AT-260](#), [AT-592](#)
 Shift schedule [AT-377](#), [AT-441](#)
 Shift solenoid valve A (A/T) [AT-167](#), [AT-518](#)
 Shift solenoid valve B (A/T) [AT-172](#), [AT-522](#)
 Shift solenoid valve C (A/T) [AT-526](#)
 Shift solenoid valve D (A/T) [AT-536](#)
 Shift solenoid valve E (A/T) [AT-541](#)
 Shock absorber (front) [FSU-10](#)
 Shock absorber (rear)Shock absorber (rear) [RSU-9](#)

Side air bag (satellite) sensor [SRS-49](#)
 Side curtain air bag [SRS-46](#)
 Side trim [EI-32](#)
 Spare tire size [GI-44](#)
 Spark plug [EM-37](#)
 Spark plug replacementQR25DE [MA-18](#)
 Specification value [EC-135](#)
 Speedometer [DI-5](#)
 Spiral cable [SRS-42](#)
 SROOF - Wiring diagram [RF-12](#)
 SRS - See Supplemental Restraint System [SRS-6](#)
 SRS - Wiring diagram [SRS-13](#)
 SRS Trouble diagnoses [SRS-9](#)
 Stabilizer bar (front) [FSU-11](#)
 Stall test (A/T) [AT-68](#), [AT-432](#)
 Standardized relay [PG-65](#)
 START - Wiring diagram [SC-11](#)
 Starting system [SC-10](#)
 Steering gear and linkage inspection [MA-27](#)
 Steering knuckle [FAX-6](#)
 Step lamp [LT-150](#)
 Stop lamp [LT-129](#)
 Stop lamp switch [EC-567](#), [EC-593](#), [EC-665](#)
 STOP/L - Wiring diagram [LT-130](#)
 Strut (front) [FSU-9](#)
 Sun roof, electric [RF-10](#)
 Sunload sensor [ATC-95](#), [ATC-103](#)
 Sunroof [RF-21](#)
 Supplemental Restraint System [SRS-6](#)
 Supplemental restraint system - Wiring diagram . [SRS-13](#)
 Symbols and abbreviations [GI-8](#), [GI-9](#), [GI-20](#)
 Symptom matrix chart [EC-89](#)
 Synchronizer (M/T) [MT-20](#)
 System readiness test (SRT) code [EC-59](#)

T

Tachometer [DI-5](#)
 TCM circuit diagram [AT-18](#), [AT-431](#)
 TCM inspection table [AT-99](#), [AT-448](#)
 TCS - Wiring diagram [BRC-16](#), [BRC-57](#), [BRC-101](#)
 TCS component parts and connector location [BRC-15](#), [BRC-56](#), [BRC-100](#)
 TCS wheel sensors [BRC-15](#), [BRC-56](#), [BRC-100](#)
 Three way catalyst [EM-26](#)
 Three way catalyst function (Bank 1) [EC-308](#)
 Three way catalyst function (Bank 2) [EC-308](#)
 Three way catalyst precautions [GI-3](#), [GI-5](#)
 Throttle control motor [EC-425](#)
 Throttle control motor relay [EC-420](#)
 Throttle position sensor (TPS) ... [EC-186](#), [EC-193](#), [EC-255](#), [EC-468](#), [EC-470](#), [EC-610](#)
 Throttle position switch [AT-255](#)
 Throttle valve closed position learning [EC-47](#)
 Tightening torque of standard bolts [GI-42](#)
 Time lag test [AT-433](#)
 Timing chain [EM-56](#)
 Tire rotation [MA-25](#)

ALPHABETICAL INDEX

Tire size	GI-44	Wheel hub (front)	FAX-5 , FAX-6
Torque converter installation	AT-275 , AT-370 , AT-602	Wheel hub (rear)	RAX-5
Torque convertor clutch solenoid valve ...	AT-148 , AT-511	Wheel size	GI-44
Tow truck towing	GI-41	Wheelarch heightWheelarch height	RSU-13
Towing point	GI-41	Wheelbase (Dimensions)	GI-44
TPS1 - Wiring diagram	EC-257	Width (Dimensions)	GI-44
TPS2 - Wiring diagram	EC-195	WINDOW - Wiring diagram	GW-28
TPS3 - Wiring diagram	EC-188 , EC-612	Window, door	GW-87 , GW-90
Traction control system - Wiring diagram	BRC-16 , BRC-57 , BRC-101	Window, rear	GW-14
Transaxle serial number	GI-44	Windshield	GW-11
Transmission case (M/T)	MT-19	Wiper and washer	WW-4
TRANSMT - Wiring diagram	BL-118	Wiring Diagram (Cell code) list	PG-54
Tread-FR&RR (Dimensions)	GI-44	Wiring diagrams	GI-8 , GI-12
Trim	EI-32		
Trouble diagnoses	GI-9		
Trunk lid trim	EI-42		
Trunk room trim	EI-42		
Turbine revolution sensor	AT-481		
TURN - Wiring diagram	LT-94 , LT-111		
Turn signal lamp	LT-90 , LT-108		
Two trip detection logic	EC-52		
Two-pole lift	GI-38		

U

Unified meter and A/C amp.	DI-32
---------------------------------	-----------------------

V

Vacuum hose (brake system)Vacuum hose (brake system)	BR-21
Vacuum hose drawing (Engine control)	EC-27
Valve clearance	EM-89
Valve guide	EM-111 , EM-112
Valve seat	EM-113
Valve spring	EM-114
Variable induction air control system (VIAS) ..	EC-588 , EC-634
Vehicle identification number	GI-44
Vehicle recovery (freeing a stuck vehicle)	GI-41
Vehicle speed sensor (VSS)	EC-379
VENT/V - Wiring diagram	EC-336 , EC-555
VIAS - Wiring diagram	EC-636
VIAS/V - Wiring diagram	EC-589
Viscosity number (SAE)	MA-11

W

W/ANT - Wiring diagram	AV-64
WARN - Wiring diagram	DI-46
Warning chime	DI-59
Warning lamps	DI-45
Water temperature gauge	DI-5
Wheel alignment (rear)Wheel alignment (rear) .	RSU-6
Wheel balance	MA-23
Wheel bearing (front axle)	FAX-5
Wheel bearing (rear)	RAX-5